



## Service Manual

### FB6000 Series Instrumentation

**FB6001** In/Out/ GTN Analog Desktop Instrument

**FB6002** In/Out/ GTN Analog NEMA 4X Wall Mount Instrument

**FB6003** In/Out/GTN Analog Panel Mount Instrument

**Generation 1 & 2**



*For complete wiring information, see*

**Load Cell-to-Instrument Interfaces Installation Manual,**  
**51326**

**51292**



## **Disclaimer**

Every effort has been made to provide complete and accurate information in this manual. However, although this manual may include a specifically identified warranty notice for the product, Fairbanks Scale makes no representations or warranties with respect to the contents of this manual, and reserves the right to make changes to this manual without notice when and as improvements are made.

Fairbanks Scale shall not be liable for any loss, damage, cost of repairs, incidental or consequential damages of any kind, whether or not based on express or implied warranty, contract, negligence, or strict liability arising in connection with the design, development, installation, or use of the scale.

## **© Copyright 2012-2017**

This document contains proprietary information protected by copyright. All rights are reserved; no part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without prior written permission of the manufacturer.

# Public License Statement

Copyright © 2017, Fairbanks Scales, Inc.  
All Rights Reserved

THE FAIRBANKS SCALES COMPANY DEVELOPED SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The software included in this [Fairbanks Scales, Inc.](#) product includes one or more open source software components. This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org>). This product also includes software licensed under the Apache License and you may not use any of these files except in compliance with the Apache License. A copy of the Apache License may be obtained at <http://www.apache.org/licenses>. This product may also include the applications governed by the Zlib license, LibPNG license, and the MIT license. For a listing of the open source software applications included in the product that are governed by any one of the above identified licenses, please contact Fairbanks Scales, Inc. at the address provided below.

To the extent applicable, Fairbanks Scales, Inc. will comply with the required disclosure conditions set forth in each of the open source software licenses identified below.

## GNU PUBLIC LICENSE:

This Fairbanks Scales, Inc. product includes open source software components governed by the GNU Public License. To the extent applicable, the person in possession of this product may request a copy of the source code of the software included in the product that is covered by the GNU Public License. The possessor of this product may request such a copy by contacting [Fairbanks Scales, Inc.](#) at the address set forth below. A copy of the GNU Public License may be found at <http://www.gnu.org/licenses/gpl.html>.

## GNU LESSER GENERAL PUBLIC LICENSE (LGPL):

This Fairbanks Scales, Inc. product includes open source software libraries governed by the LGPL. The use of the open source libraries is governed by the LGPL and copies of the source code of these libraries may be obtained by contacting [Fairbanks Scales, Inc.](#) at the address set forth below. A copy of the LGPL license may be found at <http://www.gnu.org/copyleft/lesser.html> and a copy of the GNU Public License incorporated into the LGPL is found at the link provided above.

## BSD LICENSE:

This Fairbanks Scales, Inc. product includes open source software governed by the BSD open source license. Your own redistribution and use in source and binary forms of these Applications, with or without modification, are permitted provided that the following conditions set forth in the BSD license are met, including:

Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

A copy of the BSD license may be found at <http://opensource.org/licenses/BSD-2-Clause> or <http://opensource.org/licenses/BSD-3-Clause>.

## ARTISTIC LICENSE:

This Fairbanks Scales, Inc. product includes open source software governed by the Artistic License. To the extent applicable, the person in possession of this product may request a copy of the source code of the portions of the product software that are covered by the Artistic License or you may find copies of these open source code applications at [\[www.cpan.org\]](http://www.cpan.org) [\[Fairbanks to verify location at which user can download source code\]](#). To request a list of the applications and copy of the source code by contacting Fairbanks Scales, Inc. at the address set forth below. A copy of the Artistic License can be found at <http://opensource.org/licenses/artistic-license-2.0>.

Any Open Source Software inquiries to Fairbanks Scales, Inc. shall be sent to: [\[Fairbanks to provide contact \(either person or the title\) and the mailing address.\]](#) Any request for copies of the source code will only be provided as required by the license under which the open source component was used. For any copies of source code provided, a small processing fee of **\$15.00** may apply to cover the cost of the storage medium and the time required for reproduction.

---

# AMENDMENT RECORD

---

## FB6000 Series Instrumentation

**FB6001** IN/OUT/ GTN Analog Desktop Instrument (**31675**)

**FB6002** IN/OUT/ GTN Analog NEMA 4X Wall Mount Instrument (**32575**)

**FB6003** IN/OUT/GTN Analog Panel Mount Instrument (**32675**)

## Service Manual Document 51292

Manufactured by

**Fairbanks Scales**

821 Locust

Kansas City, MO 64106

Created	08/12	
Revision 1	12/12	New product documentation release
Revision 2	01/13	Corrected 20mA wiring. Added Factory Default Service Password. Added 32765 Labels to parts list
Revision 3	01/13	Corrected specification typographical error
Revision 4	08/14	Updated manual due to software updates and hardware changes
Revision 5	03/15	Corrected Remote switch wiring
Revision 6	07/15	Added part #34327 to parts lists and Web Interface section
Revision 7	09/15	Removed references to Intalogix. These were added incorrectly.
Revision 8	11/15	Updated Basic Troubleshooting in Service & Maintenance chapter
Revision 9	01/16	Appendix 1: Data String Output, Updated multiple broken cross-reference links
Revision 10	03/17	Added active 4-20 mA
Revision 11	06/17	Added TM-U220 printer and part # 34291C (LED Display assembly), analog scale card update
Revision 12	10/17	Updated Section 4: Web Interface
Revision 13	10/17	Updated Section 4: Web Interface > Configuration

---

# TABLE OF CONTENTS

---

<b>SECTION 1: GENERAL INFORMATION, GENERATION 2.....</b>	<b>10</b>
<b>1.1. Generation 1 &amp; 2 Differences .....</b>	<b>10</b>
1.1.1 Component Differences .....	10
1.1.2 GENERATION 1 Instrument Components.....	11
1.1.3 GENERATION 2 Instrument Components.....	12
1.1.4 GENERATION 1 & 2 Programming Differences .....	13
<b>1.2. Instrument Description .....</b>	<b>14</b>
1.2.1 Standard Features .....	14
1.2.2 Accessories .....	14
<b>1.3. Instrument Components .....</b>	<b>15</b>
1.3.1 Front Panel Assembly and LED Display Assembly (31672 & 34291C).....	16
1.3.2 Base Board PCB Assembly (33143) .....	17
1.3.3 Analog Scale Card (30997).....	17
1.3.4 Expansion Modules (30919, 30920).....	19
1.3.5 Power Supply PCB Assembly (31873) .....	19
<b>1.4. Technical Specifications.....</b>	<b>20</b>
<b>1.5. Users' Responsibility.....</b>	<b>21</b>
<b>SECTION 2: STANDARD INSTALLATION.....</b>	<b>22</b>
<b>2.1. Introduction .....</b>	<b>22</b>
<b>2.2. General Service Policy.....</b>	<b>23</b>
<b>2.3. Pre-Installation Guidelines .....</b>	<b>24</b>
<b>2.4. Overview of Installation steps.....</b>	<b>25</b>
<b>2.5. Base Board PCB Wiring, Switches &amp; Jumpers .....</b>	<b>26</b>
2.5.1 Base Board JP2 and JP3 Jumpers.....	26
2.5.2 Remote Switch Wiring.....	26
2.5.3 Remote Display 20mA Wiring (J4) .....	27
2.5.4 Analog Interface Card (30997) .....	28
<b>SECTION 3: SECURITY .....</b>	<b>29</b>
<b>3.1. Levels of Security .....</b>	<b>29</b>
<b>3.2. Factory Default Service Password.....</b>	<b>30</b>
<b>3.3. Different Programming Options.....</b>	<b>30</b>
<b>SECTION 4: WEB INTERFACE .....</b>	<b>31</b>
<b>4.1. How to Connect Remotely to the FB60XX Series: .....</b>	<b>31</b>
4.1.1 To obtain the current IP address of the FB60XX: .....	31
<b>4.2. Logging In to the Web Interface .....</b>	<b>32</b>
<b>4.3. Navigating the Web Interface .....</b>	<b>33</b>
4.3.1 Audit Trail.....	33
4.3.2 Operator Menu.....	34
4.3.3 Configuration Menu.....	35
4.3.4 Service Menu.....	37
4.3.5 Expansion Cards.....	38
4.3.6 Scale Diagnostics .....	38
<b>SECTION 5: STANDARD PROGRAMMING .....</b>	<b>43</b>
<b>5.1. Programming the Instrument.....</b>	<b>43</b>

5.1.1 Login.....	44
5.1.2 Defining the Programming Menus.....	45
<b>5.2. Audit Trail .....</b>	<b>45</b>
5.2.1 Display.....	45
5.2.2 Print.....	46
5.2.3 NJ Jumper State .....	46
5.2.4 SW Revision .....	46
<b>SECTION 6: CONFIGURATION MENU .....</b>	<b>48</b>
6.1. Change Customer PW.....	48
6.2. Prompts – Programmable.....	48
6.3. Legends – Programmable.....	49
6.4. Ticket Formats.....	49
6.5. Remote Display .....	49
6.6. COM Ports .....	49
6.7. Threshold Weights .....	50
6.8. Traffic Light Control.....	50
6.9. Reports .....	51
6.10. Network.....	52
6.11. Transaction Files.....	53
<b>SECTION 7: SERVICE MENU .....</b>	<b>54</b>
7.1. Change Service PW.....	54
7.2. Options (Service) .....	55
7.2.1 Operating Modes .....	55
7.2.2 Dual Units .....	58
7.2.3 Display Rate .....	59
7.2.4 Zero Mode .....	60
7.2.5 Tare Options .....	62
7.2.6 NJ Jumper Required.....	63
7.3. Scales (Service).....	65
7.3.1 Cell Outputs.....	65
7.3.2 Calibration.....	66
7.3.3 Options (Scale), On Scale Alarm .....	66
7.3.4 Options (Scale), Reset Cell Errors .....	66
7.4. Special Functions .....	67
7.4.1 System Settings.....	67
7.4.2 COM Port Test.....	67
7.5. Database Maintenance.....	68
7.5.1 Defaults Set .....	68
7.5.2 Backup.....	69
7.5.3 Restore .....	70
7.5.4 Ticket Format Restore.....	71
7.6. Upgrade .....	71
<b>SECTION 8: CALIBRATION .....</b>	<b>72</b>
8.1. Calibration .....	72
8.1.1 Data (Calibration).....	72
8.2. Cell Sensitivity.....	73
8.2.1 Pre-calibrate All Cells Together.....	73
8.3. Trim (Cell/Section/Scale) .....	74

<b>SECTION 9: SERIAL INPUT / OUTPUT.....</b>	<b>77</b>
<b>9.1. Printers .....</b>	<b>77</b>
9.1.1 Printer Switch Settings.....	77
9.1.2 Printer Cabling.....	77
9.1.3 iDP3550 Tape Printer Settings.....	78
9.1.4 TM-U590 Ticket Printer Settings.....	78
9.1.5 TM-U220 Tape Printer.....	79
9.1.6 TM-U295 Ticket Printer Settings.....	81
9.1.7 SP298 Printer Settings.....	81
9.1.8 SP700 Printer Settings.....	83
9.1.9 SP2000 Printer Settings.....	85
9.1.10 SP2200 Printer Settings.....	85
9.1.11 TM-U230 Printer Settings.....	86
<b>9.2. COM Ports .....</b>	<b>87</b>
9.2.1 Programming COM PORTS.....	88
9.2.2 Configuring the Remote Display Output.....	88
9.2.3 Selecting the Printer.....	90
9.2.4 Selecting the PC Data String Output.....	91
9.2.5 DemandPC.....	92
<b>9.3. Formatting Tickets .....</b>	<b>93</b>
9.3.1 Standard Ticket Formatting Steps.....	93
9.3.2 Programming Tips.....	95
9.3.3 Programming Tips.....	96
9.3.4 Ticket Format Commands.....	97
9.3.5 Ticket Formats.....	98
9.3.6 G/T/N Ticket Formatting.....	100
9.3.7 Inbound Ticket Formatting.....	101
9.3.8 Outbound Ticket Formatting.....	102
9.3.9 Completed Transaction Ticket Example.....	103
9.3.10 BasicIn and BasicOut Ticket Formatting.....	104
9.3.11 Deleting a Ticket Format.....	105
<b>9.4. Formatting Web Interface Tickets .....</b>	<b>105</b>
9.4.1 Logging In to the Web Interface.....	105
9.4.2 Ticket Format.....	106
9.4.3 Standard Default Formats.....	108
9.4.4 Exiting Without Saving.....	109
<b>9.5. 4-20mA Analog Card .....</b>	<b>109</b>
9.5.1 Active 4-20mA Kit Installation (33258).....	110
9.5.2 Passive 4-20mA Kit Installation (30919).....	111
<b>SECTION 10: ACCESSORIES .....</b>	<b>113</b>
<b>10.1. Installing Accessories .....</b>	<b>113</b>
<b>10.2. Expansion Modules (30919, 30920).....</b>	<b>114</b>
10.2.1 Analog Scale Card Programming.....	114
10.2.2 Relay PCB Assembly (30920).....	115
10.2.3 ACC 777 LED Traffic Light (29001).....	116
10.2.4 ACC 2018 Traffic Light Relay Box (16163).....	116
10.2.5 ACC 703 Relay Box (13170).....	118
10.2.6 Relay Module [Expansion Card].....	120
10.2.7 D/A Module [Expansion Card].....	120
<b>10.3. Traffic Light Control.....</b>	<b>121</b>
10.3.1 Control (Traffic Light).....	121
10.3.2 Event to Signal.....	122

<b>10.4. Programming the Remote Display .....</b>	<b>122</b>
10.4.1 <i>Display Mode</i> .....	122
10.4.2 <i>Type (Output)</i> .....	123
10.4.3 <i>Enable 1605T</i> .....	124
<b>SECTION 11: USER OPERATIONS.....</b>	<b>125</b>
<b>11.1. Front Panel Key Functions .....</b>	<b>125</b>
<b>11.2. Operational Procedures.....</b>	<b>126</b>
11.2.1 <i>Gross Weighing</i> .....	126
11.2.2 <i>Basic Weighing</i> .....	126
11.2.3 <i>Gross-Tare-Net Weighing</i> .....	127
11.2.4 <i>Inbound/Outbound Weighing</i> .....	128
<b>11.3. Programming the Operator Menu .....</b>	<b>130</b>
11.3.1 <i>Format Time &amp; Date</i> .....	130
11.3.2 <i>Set Time &amp; Date</i> .....	131
11.3.3 <i>Ticket Number</i> .....	131
11.3.4 <i>Load Cell Diagnostics</i> .....	132
11.3.5 <i>New Tare</i> .....	133
11.3.6 <i>New Keyboard Tare</i> .....	134
11.3.7 <i>Tare Delete</i> .....	135
11.3.8 <i>Tare Report</i> .....	135
11.3.9 <i>Utility – Set Display Intensity</i> .....	136
11.3.10 <i>Utility – Key Pad Beep, Set Volume, Mute</i> .....	136
11.3.11 <i>Options (Operator)</i> .....	137
<b>SECTION 12: SERVICE &amp; MAINTENANCE .....</b>	<b>138</b>
<b>12.1. Basic Troubleshooting .....</b>	<b>138</b>
<b>12.2. Replacing the Analog Interface PCB Assembly (30997).....</b>	<b>139</b>
<b>12.3. Replacing the Keypad (32060) and Display Assembly (34291C).....</b>	<b>140</b>
<b>12.4. Base Board PCB Assembly (33143) Replacement .....</b>	<b>141</b>
<b>12.5. Replacing the Power Supply PCB Assembly (31873) .....</b>	<b>142</b>
<b>SECTION 13: GENERATION 2 PARTS .....</b>	<b>143</b>
<b>13.1. FB6001 Desktop Model (31675).....</b>	<b>143</b>
13.1.1 <i>Parts List</i> .....	143
13.1.2 <i>Parts Diagram</i> .....	145
<b>13.2. FB6002 NEMA 4X Hostile Model (32575) .....</b>	<b>146</b>
13.2.1 <i>Parts List</i> .....	146
13.2.2 <i>Parts Diagram</i> .....	148
<b>13.3. FB6003 Panel Mount (32675).....</b>	<b>149</b>
13.3.1 <i>Parts List</i> .....	149
13.3.2 <i>Parts Diagram</i> .....	151
<b>13.4. Optional Accessories.....</b>	<b>152</b>
<b>APPENDIX I: DATA STRING OUTPUTS .....</b>	<b>153</b>
<b>A. Remote Display Output .....</b>	<b>153</b>
<b>B. Configure Output .....</b>	<b>153</b>
<b>APPENDIX II: REMOTE DISPLAY CODES FOR 20MA OUTPUT.....</b>	<b>157</b>
<b>APPENDIX III: REMOTE SERIAL COMMANDS .....</b>	<b>158</b>
<b>APPENDIX IV: FB6001/02/03, GENERATION 1 PARTS.....</b>	<b>159</b>
<b>A. Desktop Model (31675).....</b>	<b>159</b>





**B. FB6002 NEMA 4X Hostile Model (32575)..... 162**  
    *Parts List..... 162*  
    *Parts Diagram..... 164*

**C. FB6003 Panel Mount (32675) ..... 165**  
    *Parts List..... 165*  
    *Parts Diagram..... 166*

**SECTION 14: APPENDIX V: CONNECTING TO THE FB60XX VIA ETHERNET . 167**

---

# SECTION 1: GENERAL INFORMATION,

## GENERATION 2

---

This manual details the **FB6001/02/03 Instrument, GENERATION 2**.

- Identifying the difference between **GENERATION 1** and **GENERATION 2** is necessary for all maintenance upgrades, installations, and programming updates.

---

**NOTE:** For complete details regarding **GENERATION 1**, see [Appendix IV](#).

---

## 1.1. Generation 1 & 2 Differences

### 1.1.1 Component Differences

*The following outlines the two (2) main physical, visual differences between the FB6001 Instrument **Generation ONE** and **TWO**.*

#### DIFFERENT BASE BOARD PROCESSORS

**GENERATION 1** uses the **BASE BOARD PCB ASSY (31751)**.


- **GENERATION 2** uses the **BASE BOARD PCB ASSY (33143)**.
  - **GENERATION 2** is labeled on one side of the PCB with “**VARISCITE**”.
  - The component configurations are different between the two board types.
  - This PCB is interchangeable with the **GEN 1**, but not visa-versa, as it is obsolete.

#### DIFFERENT POWER SUPPLY PCB

- **GENERATION 1** uses the **POWER SUPPLY PCB ASSY (31873)**.

### 1.1.2 GENERATION 1 Instrument Components

The image below displays the **Generation 1 FB6001**, noting the differences in this Instrument from **Generation 2**.



1. **Less populated** Power Supply PCB Assy.
  - Very few capacitors and terminator blocks attached.
2. **Relocated J4** and **J17 Terminal Blocks** on the Base Board.
3. **Relocated** Battery Terminal 1 (**BT1**) on the Base Board.
4. **Different** Main Processor on Base Board.
  - **GENERATION 1** has no specific manufacture labeling on the Main Processor.

### 1.1.3 GENERATION 2 Instrument Components



The image above displays the **Generation 2 FB6001**, noting the differences in this Instrument from **Generation 1**.

1. Relocated Jumpers 4, 17 (J4, J17) on the Base Board assembly.
2. Relocated Battery Terminal 1 (**BT1**) on the Base Board assembly.
3. Different Main Processor on Base Board assembly.
4. GENERATION 2 labels the main processor as "**Variscite**".

### 1.1.4 GENERATION 1 & 2 Programming Differences

There are numerous programming differences between the FB6001 Instrument **GENERATION 1** and **2** versions.

*Some of the primary programming differences are noted below.*

#### OPERATOR MENU

- The **SET VOLUME** and **MUTE** functions were added to **GEN 2**.
  - For complete procedures, see **SECTION 11.3.10. UTILITY – KEY PAD BEEP, SET VOLUME, MUTE.**
- The **OPTIONS <OPERATOR>** menu was added to **GEN 2**.
  - For complete procedures, see **SECTION 11.3.11. OPTIONS (OPERATOR).**

#### CONFIGURATION MENU

- Many of the processing steps are different for creating each of the five (5) **TICKET FORMAT** types.
  - For complete procedures, see **SECTION 9.3. FORMATTING TICKETS.**
- The **NETWORK** and **TRANSACTION** functions were added to **GEN 2**.
  - For complete procedures, see **SECTION 6.11. NETWORK** and **6.12. TRANSACTION FILES.**

#### SERVICE MENU

- Some of the **CALIBRATION** functions are performed differently in **GEN 2**.
  - This is especially true with the **TRIM (Cell, Section, Scale).**
  - For complete procedures, see **SECTION 8: CALIBRATION.**

---

**NOTE:** For complete details regarding **GENERATION 1**, see [Appendix IV.](#)

---



## 1.2. Instrument Description

The **FB6001/6002/6003 Instrument** is a Basic, Inbound, Outbound, and GTN instrument.

- The Instrument may be enhanced by adding either a 4-20mA or a Relay Module to the unit.
- Only one (1) module may be added to provide either a 4-20mA output or a Relay Module interface to control traffic lights.

The **FB6001/6002/6003 Instrument** is designed for a wide variety of truck, floor, hopper, and tank scale applications.

- The load cells interface with the Instrument through the **Analog Interface Card**.
- An RS-232 interface allows for the transfer of data from the Instrument to a computer and vice versa.
- The three FB6000 Series instrument models are the **Desktop (FB6001)**, **NEMA 4X Wall Mount (FB6002)** and the **Panel Mount (FB6003)**.

### 1.2.1 Standard Features

- 1.8" LED alphanumeric display
- One (1) Ethernet Port
- Three (3) USB Ports
- Choice of either One (1) 4-20mA port or one (1) Analog Relay Board.
- External Display COM Port 4
- Three (3) RS232 serial ports
- Capable of formatting tickets
- Keypad Buttons, including the following:
  - 0-9 keys, Enter, Red (stop), Green (go), Tare, In, Out, Units, B/G/Net, Zero and Print.

### 1.2.2 Accessories


PART NO.	DESCRIPTION
<b>30919</b>	4-20mA Analog Kit * (passive)
<b>33258</b>	4-20mA Analog Kit * (active)
<b>30920</b>	Relay PCB Assy Kit *
<b>25498</b>	Mini USB Keyboard (87 key)
<b>31036</b>	Standard USB Keyboard (104 key)
<b>15892</b>	SVP/ Uninterruptable Power Supply

\* Only one or the other of these accessories may be used in the FB6001/02/03 series instrument.

## 1.3. Instrument Components

Each FB6001/02/03 Instrument consists of the components listed below.

1	Front Panel Assembly ( <b>31672</b> )	6	Power Cable Outlet
2	Base Board BCB Assy ( <b>33143</b> )	7	Load Cell Cable Gland
3	Power Supply PCB Assembly ( <b>31873</b> )	8	RJ45 Network Cable Port
4	Analog PCB Assembly – <b>J6</b> ( <b>30997</b> )	9	Three (3) USB Jacks
5	Open Expansion Card Slots – <b>J8</b>	10	RS232 Port ( <b>Console</b> ) for external programming and configuration
— Relay Assy ( <b>30757</b> ) — 4-20mA PCB ( <b>30738</b> )		11	Three (3) RS232 9-pin Serial I/O COM




J3	SD Card Socket
J4	Remote Display Connection
J6	Analog Module Sockets (2)
J8	Expansion Module Sockets (2)
J14	Front Keypad & Display USB Port
J17	Remote Switch wiring

JP1 on Base Board PCB	Calibration (NJ Jumper)
BT1	Battery Terminal
JP2	Console Communications
SW2	Configuration Switch

### 1.3.1 Front Panel Assembly and LED Display Assembly (31672 & 34291C)

The **Front Panel Assembly** provides power to the Keypad.

- The USB Cable connects to **Terminal J14** on the **Base Board Assembly (33143)** from the **LED Display Assembly (31692C)**.




Back-side, component view of the LED Display PCB Assy.



### 1.3.2 Base Board PCB Assembly (33143)

The **Base Board PCB Assembly** is the main instrument interface controller. The weighing application resides on this assembly.



- Communication between the Base Board and the expansion modules are routed through the Expansion Module.
- Communications from the Base Board to the Expansion Module is RS232.



### 1.3.3 Analog Scale Card (30997)

The **Analog Scale Card** provides the communications interface to Fairbanks' Analog Technology.

- This card connects into **J6** of the Base Board PCB Assembly.
- Only one (1) card per scale can be configured per Instrument.





### **1.3.3. Analog Scale Card (30997), Continued**

When configuring a **levertronic scale**, cell capacity must be set as “lever system multiple X actual load cell capacity.”

**Example:** 8 ea. 50,000 lb. load cells.  $8 \times 50,000 = 400,000$ . Cell capacity = 400,000 lb.

**Example:** Fairbanks Type “S” lever scale with short transverse and 3,000 lb. load cell:  
Scale multiple is 60:1.  $60 \times 3000 = 180,000$  lb. Cell capacity = 180,000 lb.

#### **Wiring:**

TB1-1:- Excitation

TB1-2:- Sense

TB1-3:+ Excitation

TB1-4:+ Sense

TB1-6: Shield

TB1-7:+ Signal

TB1-8:- Signal

---

#### **NOTE:**



*To enable the sense lead circuit, remove the 2 jumpers from the board.  
Sense leads are required when cable length exceeds 25 feet.*

---

### 1.3.4 Expansion Modules (30919, 30920)

**Expansion Modules** provide the physical connectivity between the FB6001/2/3 and all scale and peripheral Input/Output (I/O) devices.

- Each Expansion Module is an intelligent device, consisting of the following components:
  - A Processor
  - Non-volatile Memory
  - An RS-232 Communication Node
- Insert one of the two (2) **Expansion Modules** into the two (2) dedicated **Base Board** sockets, **J8**.
  - 4-20mA Analog Kit (30919)
  - Relay PCB Assembly Kit (30920)



Expansion Cards are installed into Port J8.

### 1.3.5 Power Supply PCB Assembly (31873)

The **Power Supply PCB Assembly** provides power to the Instrument.

- Power Supply PCB **provides power to all the** external scale components.
- Communications to this board use the **Analog Interface Card**, plugged into the load cell homerun cable.



## 1.4. Technical Specifications

PARAMETER	SPECIFICATION
<b>Model</b>	Desktop FB6001; NEMA 4X Wall Mount FB6012; Panel Mount FB6013
<b>Load Cell Interface</b>	Up to 16 ~ 1000Ω load cells max, Or up to 8 ~ 350Ω load cells max
<b>Cell Capacity</b>	1 thru 999,999
<b>Load Cell Excitation</b>	5 VDC
<b>Cell Units</b>	lbs, kgs, tons, tonne
<b>No. of Scales</b>	One (1) only
<b>Resolution</b>	10000d commercial 20000d non-commercial
<b>Scale Capacity</b>	100-999,999
<b>Division Size</b>	0.0001 thru 50
<b>Units</b>	lbs, kgs, tons, tonne
<b>Serial Input/ Output</b>	Three (3) RS232 COM Ports, one (1) Console Port, three (3) USB Ports
<b>Storage</b>	Up to 100,000 transactions
<b>Auto Zero Tracking</b>	Selectable – Off, 0.5d, 1.0d, 3.0d
<b>Motion Band</b>	Selectable – Off, 0.5d, 1.0d, 3.0d
<b>Zero Range</b>	Selectable – 2%, 100%

ENVIRONMENTAL	SPECIFICATION
<b>Enclosure</b>	NEMA 12 desk mount and Panel mount; NEMA 4X wall mount
<b>Operating Temperature</b>	14°F to 104°F, (–10°C to 40°C).
<b>Operating Humidity</b>	NEMA 12 non-condensing, not suitable for wash-down conditions.

POWER REQUIREMENTS	SPECIFICATION
<b>Incoming Voltage Requirement</b>	Instrument has an Auto-switching power supply. 100 VAC to 130 VAC, 50Hz\ 60Hz 200 VAC to 260 VAC, 50Hz\ 60Hz It is recommended to install a separate circuit from the circuit panel to the outlet used. There must not be more than 0.2VAC between AC neutral and ground
<b>Ground Requirements</b>	For proper performance, the ground should have no more than 3.0 Ω resistance to true earth ground.
<b>Power Consumption</b>	Less than (<) 40 watts
<b>ETL Listed</b>	Conforms to UL STD 60950-1. CAN/CSA C 22.2 NO.60950-1-03.
<b>Approvals</b>	CC# 12-099 MC# AM-5878

## **1.5. Users' Responsibility**

- ✓ **All electronic and mechanical calibrations and/or adjustments required for making this equipment perform to accuracy and operational specifications should be performed by trained service personnel.**
- ✓ **Absolutely no physical, electrical or program modifications other than selection of standard options and accessories are to be made to this equipment.**
- ✓ **Electrical connections other than those specified may not be performed, and physical alterations (holes, etc.) are not allowed.**



*Please call your local*  
**FAIRBANKS SCALES REPRESENTATIVE**  
*For any question, problems, or comments.*



---

## SECTION 2: STANDARD INSTALLATION

---

### 2.1. Introduction

Prior to installation, *always* verify that the equipment satisfies the customer's requirements as supplied, and as described in this manual.

If the equipment cannot satisfy the application and the application cannot be modified to meet the design parameters of the equipment, **the installation should *NOT* be attempted.**

The equipment consists of printed circuit assemblies which must be handled using **ESD handling procedures**, and must be replaced as units.

- ✓ Replacement of individual components is not allowed.
- ✓ The assemblies must be properly packaged in ESD protective material and returned intact for replacement credit per normal procedures.



It is **the customer/operator's responsibility** to ensure the equipment provided by Fairbanks Scales is operated within the parameters of the equipment's specifications, and is protected from accidental or malicious damage.


## 2.2. General Service Policy

Prior to installation, always verify that the equipment satisfies the customer's requirements as supplied, and as described in this manual.

- If the equipment cannot satisfy the application and the application cannot be modified to meet the design parameters of the equipment, **the installation should *NOT* be attempted.**
- Instructions within this manual apply to the instrument and its specific accessories. Installation procedures for printers and other peripherals are given in manuals specifically provided for those units. The instructions include a pre-installation checkout which must be performed either at the service center before the technician goes to the site, or at the site before he places the equipment in service.
- All electronic and mechanical calibrations and/or adjustments required to make this equipment perform to accuracy and operational specifications are considered to be part of the installation, and are included in the installation charge. **Only those charges which are incurred as a result of the equipment's inability to be adjusted or calibrated to performance specifications may be charged to warranty.**
- Absolutely no physical, electrical, or program modifications other than selection of standard options and accessories are to be made to this equipment. Electrical connections other than those specified may not be performed, and no physical alterations (mounting holes, etc.) are allowed and will immediately void warranty

***All load cells, load cell cables, and all interconnecting cables used for the scale components must be located a minimum of thirty-six inches (36") away from all single and multiple phase high energy circuits and electric current-carrying conductors.***

- This includes, but is not limited to **digital weight instruments, junction boxes, sectional controllers, and power supplies.**
- This includes any peripheral devices, such as **printers, remote displays, relay boxes, remote terminals, card readers, and auxiliary data entry devices.**
- Scale components themselves must also be at least **thirty-six inches (36") away** from other high energy components, including the following devices.
- Any machinery with outputs of **120, 240, or 480 VAC.**
- High voltage wiring runs and stations, AC power transformers, overhead or buried cables, electric distribution panels, electric motors, florescent and high intensity lighting which utilize ballast assemblies, electric heating equipment, traffic light wiring and power, and all relay boxes.
- Scale components are not designed to operate on internal combustion engine driven electric generators and other similar equipment.
  - *This includes all digital weight Instruments and peripheral devices.*
- Electric arc welding can severely damage scale components, such as digital weight Instruments, junction boxes, sectional controllers, power supplies, and load cells.
- The Service Technician's responsibility that all personnel are fully trained and familiar with the equipment's capabilities and limitations before the installation is considered complete.



## 2.3. Pre-Installation Guidelines

*The following points should be checked and discussed with the **Area Sales Manager and/or customer**, if necessary, before the technician goes to the site and installs the equipment.*

- If the installation process might disrupt normal business operations, tell the customer and ask that they make ample arrangements.
- Is properly-grounded power available at the installation location?
- Be sure that the equipment operator(s) are available for training.
- The service technician reviews the recommended setup with the Area Sales Manager or Area Service Manager, and together they identify all necessary variations to satisfy the customer's particular application.

*Follow these guidelines when unpacking all equipment.*

- Check in all components and accessories according to the customer's order.
- Remove all components from their packing material, checking against the invoice that they are accounted for and not damaged.
  - Advise the shipper immediately, if damage has occurred.
  - Order any parts necessary to replace those which have been damaged.
  - Keep the shipping container and packing material for future use.
  - Check the packing list.
- Collect all necessary installation manuals for the equipment and accessories.
- Open the equipment and perform an inspection, making certain that all hardware, electrical connections, and printed circuit assemblies are secure.
- Do not reinstall the cover if the final installation is to be performed after the pre-installation checkout.



*Position the equipment with these points in mind.*

- Intense direct sunlight can harm the display.
- Do not locate near magnetic material or equipment/instruments which use magnets in their design.
- Avoid areas which have extreme variations in room temperatures. Temperatures outside the instrument's specifications will affect the weighing accuracy of this product.



## 2.4. Overview of Installation steps

- A. **STANDARD INSTALLATION** of all physical and software components.
- B. **WIRING** electrical components, Setting up Switches, and Adjusting Jumpers.
- C. Configure the **POWER SUPPLY**.
- D. **PROGRAMMING** the Instrument.
- E. **CALIBRATING** the Weighment System.
- F. **TESTING AND TROUBLESHOOTING** the Weighment System, adjusting it as needed.
- G. Inputting all Product and Customer Data (the Client's task).

### **W A R N I N G !**

***Never perform any wiring with the instrument turned on!***  
***Damage to the system components is very likely.***

## 2.5. Base Board PCB Wiring, Switches & Jumpers


### 2.5.1 Base Board JP2 and JP3 Jumpers

The **JP2** jumpers of the **PCB Assembly Base Board (33143)** controls the RS485 communications.

- For **JP2 jumper** connections, see the table below.

Follow these steps to adjust the **JP2 Jumper**.

- Remove all power from the Instrument.
- Remove the four (4) screws in the top casing of the Instrument, then take off the cover.
- Using needle-nose pliers, remove the jumper from **JP2**.
  - JP2** is located on the left-hand side of the PCB Assembly Base Board.
- Reinstall the cover and four (4) screws, then



The standard default **JP2** position is placed over **Pins 1-3, 2-4**, leaving **5&6 open**. **Terminal Port J17** is used for Remote Switch wiring.

FUNCTION	JUMPER	FACTORY DEFAULT
RS232 receive as COM3 Input (RX)	<b>1 to 3</b>	YES
RS422/485 receive as COM3 Input (RX)	<b>3 to 5</b>	NO
RS485 TX ENABLE on COM3	<b>2 to 4</b>	YES
RS422 TX ENABLE on COM3	<b>4 to 6</b>	NO
<b>Do not use</b> COM3 Input ( <i>strongly suggested</i> )	<b>3 to NC</b>	NO
RS422/485 TX Enable is <b>always off</b>	<b>4 to NC</b>	NO

power-up the Instrument.

### 2.5.2 Remote Switch Wiring

The **J17 Termination Block** sets up **Remote Switches** that can be located anywhere on the scale site.


- There are four (4) different functions available for the button.

FUNCTION	J17	J17
Remote Zero Switch	<b>1</b>	<b>2</b>
Remote Print Switch	<b>3</b>	<b>4</b>
Remote Tare Switch	<b>5</b>	<b>6</b>
Remote Switch Undefined	<b>7</b>	<b>8</b>

### 2.5.3 Remote Display 20mA Wiring (J4)

#### A. Typical Connections – Active Instrument, Passive Display


J4	DESCRIPTION	1600 TB1	DESCRIPTION
3	Loop Output	7	C-Loop +
4	Loop Return	8	C-Loop -



**NOTE:** The Fairbanks Factory recommendation for the 20mA Output is **ACTIVE**.

#### B. Typical Connections – Passive Instrument, Active Display.

J4	DESCRIPTION	1600 TB1	DESCRIPTION
1	Loop +	1	+ 15VDC
3	Loop Output	7	C-Loop +
		2	GND
	Jumper	8	C-Loop -




**NOTE:** The Remote Switches and the 20mA share a ground wire.

- This means that remote switches, if used simultaneously with a remote display, **must NOT be grounded**. Otherwise they risk creating a ground loop through the instrument's main circuit board.
- Connect Switch Legs to non-grounded-bonded dry contact only. If the display is fully isolated (non-bonded), this is not an issue.

### 2.5.4 Analog Interface Card (30997)

The **ANALOG INTERFACE CARD** provides the communications interface to Fairbanks Analog Technology.

- Wire the Terminal Block as shown to the right, then Insert the **Analog PCB** into the Base Board PCB Assembly (**J6**).
- Keypad Stickers for **BASIC** Operating Mode




When using the **BASIC Operating Mode**, the Front Panel button configuration is different.

Adhere the four (4) **Replacement Button Stickers (32765)** onto the standard keypad overlay in the following locations.

1. Cover the blue IN button with the **GROSS / PRINT** sticker.
2. Cover the blue OUT button with the **TARE / PRINT** sticker.
3. Cover the blue TARE button with the **BLANK** sticker.
4. Cover the green PRINT button with the **BLANK** sticker.

**NOTE:** Replace the buttons with these stickers **only** when using the **BasicIn** or **BasicOut Operating Modes**.



---

# SECTION 3: SECURITY

---

## 3.1. Levels of Security

*There are three security levels for accessing the FB6001/2/3 programs.*

- **Security Levels One thru Three (1 – 3)** configures the hierarchy of the management functions, and limits privilege accesses from unauthorized employees.
- When making the employee hierarchy, employee duties should determine their security level.
- Each access level includes all of the rights of any access level(s) below it.

### FIRST LEVEL: OPERATOR ACCESS


- Accesses the Operator Menu and the Audit Trail Menu.
- **No Password** is necessary for this level of instrument access.

### SECOND LEVEL: SUPERVISOR ACCESS

- All of the Operator Access privileges.
- Supervisor Password is required.
- The *default first time use* password for the **Supervisor Access** is **“1”**.
  - *It is strongly recommended to change this password.*
- Second Level Users can also access the **Configuration Menu**.

### THIRD LEVEL: SERVICE TECHNICIAN ACCESS

- All of the previous level privileges.
- With the **Service Password**, the technician can also access **all** menus options, including the highest level programming **SERVICE MENU**.
- The *default first time use* password for **Technical Service Access** is **“2”**.
  - *It is strongly recommended to change this password.*

DEFAULT PASSWORD		
✓ <b>05819</b>		
<b>MOST</b>  <b>LEAST</b>	<b>PW: 2</b> Service Tech	<b>A C C E S S  L E V E L S</b>
	<b>PW: 1</b> Supervisor	
	<b>No PW</b> Standard User	

## 3.2. Factory Default Service Password

If the service password is lost or forgotten, follow these steps to input the **Factory Default Service Password** and access the **SERVICE MENU**.

1. Press **MENU**.
2. When **LOGIN** displays, press **ENTER**.

✓ **Factory Default Service Password = 05819.**

3. Press **ENTER**.



## 3.3. Different Programming Options

In addition to needing the correct password to access the different user levels, using some menu selections will access other programming options.

- One example of this is when configuring the **Attach Device** to a **COM Port**. Each device has different settings and menu options specific to its programming needs.
  - Selecting a printer offers numerous choices different from those of programming **Command PC**, for example.
  - See [9.2.1. Programming COM Ports](#).



---

## SECTION 4: WEB INTERFACE

---

The configuration of all FB60XX series scales with **software version 2.0.1** or higher can now be performed through the instrument **OR** through the *Web Interface*.

---

**NOTE:** *Scale calibration can **ONLY** be performed through the **Web Interface** with versions 2.2.0 and higher.*

---

The Web Interface can be accessed through most browsers (Internet Explorer, Firefox, Google Chrome) that is connected to a TCP/IP network **OR** by using an a crossover cable connected to a PC or tablet.

The first step in connecting remotely is to determine the connection address (IP address) of the instrument.

### 4.1. How to Connect Remotely to the FB60XX Series:

*There are two (2) connection types used with the FB60XX.*

- **DHCP (Dynamic Host Configuration Protocol)** – Automatically addresses each node the first time it connects to the company's Intranet. A **DHCP** connection may change every few weeks so if you are not able to connect, re-verify the IP address on the instrument (see, "**To obtain the current IP address of the FB60XX**")
- **STATIC** – Dedicated addresses assigned by the IT Department that are specific to each node, and do not change.

#### 4.1.1 To obtain the current IP address of the FB60XX:

1. Login to the FB60XX
2. Scroll *down* to **CONFIGURATION**, press **ENTER**
3. Scroll *up* to **NETWORK**, press **ENTER**
4. Scroll down to **DHCP Options**, press **ENTER**
5. **MY IP** is displayed, press **ENTER**
6. The FB60XX IP address is displayed (**XXX.XXX.XXX.XXX**)

Write down the IP address

7. Press the RED Traffic light button twice to return to the weigh screen

*Follow these steps to display, or to enter the Static addresses in the **NETWORK option**.*

---

**NOTE:** See [APPENDIX V](#) for step-by-step details on connecting to the FB60XX via EtherNet.

---

## 4.2. Logging In to the Web Interface

1. Locate the IP Address of the FB60XX Series Instrument


(See also 4.1.1. To obtain the current IP address of the FB60XX )

---

**NOTE:** In order to login to the Web Interface, you **MUST** logout of the FB60XX instrument. If you are **NOT** logged out, you will receive the message “**Front Panel in Use**” until you log out.

---

2. Input the correct IP Address of the FB60XX into the Address Bar of the web browser, then press **ENTER** on the remote computer.



3. Click on the **LOGIN** link.

4. Input the Default Service Password, then press the **LOG IN** button.


**Service Password = 2.**

The **Web Interface Home** screen appears.

After you are logged in successfully, the message

“**Remote Config in**

**Process**” will appear on the screen of the instrument.






## 4.3. Navigating the Web Interface

After successfully logging into the FB60XX Web Interface, the additional options of **Configuration Menu**, **Service Menu** and **Expansion Cards** will appear in the left-hand navigation. Additional options also will appear under **Operator Menu** and **Power Supply**.

### 4.3.1 Audit Trail

The following options will appear in the Web Interface under **Audit Trail**:




**Display:** Displays all configuration changes made to each scale with drop-down menus for **Audit Report**, **number of items per page** and an available **Search**.

**Print:** Print the records from the Audit Report with options for number of items to print and a drop-down menu of available printers.

**NJ Jumper State:** Lets you know if this feature is active or inactive. See section [7.2.6. NJ Jumper Required](#) for more information about this option.

**SW Revisions:** Provides **Image**, **Model**, **Main**, **Drivers**, **Interpreter**, **Webconfig** information.

### 4.3.2 Operator Menu



**New Tare:** Add a new tare from the scale.

**New Keyboard Tare:** Manually enter a new tare.

**Tare Delete:** Provides the same options of **New Tare**, **New Keyboard Tare** and deleting a tare. A drop-down menu of all the existing tares and a **Search** is available.

**Tare Report:** Provides the same options as **Tare Delete** and a **Print** option with a drop-down list of available printers.

**Time And Date:** Provides the options of **Format Time and Date** and **Set Time and Date**.

**Tickets:** Set the starting value of tickets under **Number**, print the last created ticket under **Print Last Ticket** or add the ticket number of a ticket you wish to re-print under **Print Duplicate Ticket**.


**Load Cell Diagnostics:** Provides a live count of the **Cell Outputs** and **Errors**.

**Utility:** Provides drop-down menus for **Display Intensity**, **Keypad Beep**, scale **Volume** ranging from 10% (lowest volume) to 100% (highest volume) and **Mute**.

**Options (Operator):** When processing Inbound Loops, **Outbound Auto Suggest** displays the next available. When processing Inbound Loops, **Auto Instrument Inbound ID** automatically uses the next available (without displaying it). **Show Looping ID Text** displays *all* the stated information about the Loop, including the ID number, truck description, or any related text.

### 4.3.3 Configuration Menu

The following options will appear in the Web Interface under **Configuration Menu**:



**Customer Password (Configuration Menu Password):** Change the login password of the instrument. This is highly recommended.

**Prompts:** Messages to the Operator that ask a question, offer a choice, or relay an instruction. The **Name** field is a text entry field for naming a prompt. "Prompt 1" is the name used by the system to identify the prompt. **GTN, Inbound, Outbound, Basic In,** and **Basic Out** are all drop-down menu items that may be enabled or disabled.

**Legends:** Allows you to change the **Loop ID** field to a custom prompt.

**Ticket Formats:** The connected printer displays in the **Printer** field. The **Mode** drop-down menu lets tickets print in **GTN, Inbound, Outbound, BasicIn,** or **Basic Out** formats.

---

**NOTE:** If a printer does not display in the **Printer** field, no printer has been added to a COM port. See, [9.2. COM Ports](#) to connect to an available printer.

---

**Remote Display:** Provides a drop-down menu to adjust **Display Mode** to continuous or print, **Type (Output)** to display by ticket number, Active Gross or Net Wt. **Enable 1605T** set to Yes or No.

**Com Ports:** Provides options for configuring the three input com ports and the single outgoing port. See section [9.2. COM Ports](#) for further details.

**Threshold Weights:** **Initial Weight** option provides up and down arrows to set the minimum amount the truck must weigh to initiate a weighment.

**Traffic Light Control:** **Control (Traffic Light)** either Automatic or Manual. The **Event to Signal** option lets the operator add a time to delay between 1-10 seconds to the signal. “Scale ID 1” is the name used by the system to identify the setting.

**Reports:** Provides options for displaying a report. **Type** provides an option for choosing Completed or Incomplete transactions. **Media** only shows “Jump Drive” in the drop-down menu. Reports must be generated to an inserted jump drive. **Sort By** provides the option of the report being sorted by Loop ID or Date/Time. **Delimiter** provides the option of generating a report in CSV or Tab format. See section [6.10. Reports](#)

**Network:** **DHCP Options** shows the network connectivity details of the instrument, **IP**, **Netmask**, **Gateway** and **DNS**. The **Network Output** provides an option for the **Type** output, of either Off or PC Continuous. The **Format** provides a choice of scale company output data. See also [Appendix 1 Data String Outputs](#) The **Local Port** provides up and down arrows to choose the correct port number on the outgoing PC.

- Network section under the **CONFIGURATION MENU** controls all network settings.
- Options include DHCP or STATIC IP (See **TIP2015-03**, for initial Network Setup)
- **DHCP OPTIONS or\* STATIC IP** : Reports the IP address, Netmask, Gateway, Primary DNS

\* Displayed value dependent on selected option of DHCP or STATIC.


**Network Output:** If configured, will send **NETWORK** continuous **SCALE** output.

**Type** is either OFF or PC Continuous.

**Format:** Select from 5 factory **DEFINED** formats:


Fairbanks, Toledo, Cardinal, Weigh-Tronix, Condec.

**Local Port:** default 5001, change only if requested by site.



**Speed:** This controls the speed and if full or half duplex is used on the network device. Default is AUTO and in most cases, is sufficient.


Network Output



**Transaction Files:** This option allows for file deletion by five different options: **All Transactions**, **By Ticket Number**, **By Date Range**, **By Ticket Range** and **Incompletes**.

### 4.3.4 Service Menu

The following options will appear in the Web Interface under **Service Menu**:



**Service Password:** This screen allows the service technician to change the service password. Complete the **Enter Password** and **Confirm Password** boxes with same new password. Then, click **Submit**. See [Section 4: Security](#) for more detail.

**Options (Service):** Provides options for choosing a **Mode** (Inbound /Outbound, GTN, or Basic Modes) See Section [7.2.1. Operating Modes](#) for details. **Dual Units** **also** may be changed (Yes or No) in this area. See Section [7.2.2. Dual Units](#) for details.

**Scales (Service):** Provides a live count of the **Cell Outputs** and **Errors**. This information also is located in the *Operator Menu* under *Load Cell Diagnostics*. In **Options (Scale)**, the **On Scale Alarm** may be turned Off and On and in **Reset Cell Errors**, the errors may be reset back to zero, if the drop-down is changed to Yes. Then, click **Submit**.


**Special Functions:** In **System Settings**, click **Com Port Test** to check the integrity of each port.

**Database Maintenance:** Provides the service tech to manually restore instrument defaults and perform backups. See Section [7.5. Database Maintenance](#) for details.

**Upgrade:** This function checks the **Micro SD Card** for any new program revisions.

### 4.3.5 Expansion Cards

The following options will appear in the Web Interface under **Expansion Cards**:



**NOTE:** The menu display changes depending on the card installed.

**Scale Interface:** Provides instrument data: **Revision Number**, **View Cells Found**, and number input boxes for **Update Rate (Ms)**, **Watchdogs**, **Bs\_Reboots**. See section [10.2.1. Scale Interface Card \(SIC\) Programming](#) for more details.

### 4.3.6 Scale Diagnostics

**Scale Diagnostics:** Provides real-time data of the load cell counts and weight. The following screens are available:

#### Scale Diagnostics – Counts with Weight

FB6001
Home Logout Help

**MAIN MENU**

[Home](#)

[Logout](#)

[Help](#)

**AUDIT TRAIL**

**OPERATOR MENU**

**CONFIGURATION MENU**

**SERVICE MENU**

**EXPANSION CARDS**

**SCALE DIAGNOSTICS**

## Scale Diagnostics

Weights
Cell Counts

Current Counts	Zero Counts	Cell	Scale	Cell	Zero Counts	Current Counts
			100000 lb	1	22093	260950

**Gross Weight: 100000 lb**

Scale Diagnostics shown with a single Load Cell (analog) and the Cell Counts Selected.

Provides the following data:

- Cell number and zero Counts it was calibrated to
- Cell number and current counts with weight on it
- Live Gross Weight of the scale

## Scale Diagnostics – Counts with ZERO Weight

FB6001

Home Logout Help

MAIN MENU

Home

Logout

Help

AUDIT TRAIL

OPERATOR MENU

CONFIGURATION MENU

SERVICE MENU

EXPANSION CARDS

SCALE DIAGNOSTICS

Scale Diagnostics

Weights

Cell Counts

Current Counts	Zero Counts	Cell	Scale	Cell	Zero Counts	Current Counts
			00 lb	1	22131	22134

Gross Weight: 00 lb


Scale Diagnostics shown with a single Load Cell (analog) and the Cell COUNTS Selected.

Provides the following data:

- Cell number and zero Counts it was calibrated to
- Cell number and current counts with no weight on it, comparable to the calibrated zero counts
- Live Gross Weight of the scale shows 00



## Scale Diagnostics – WITH Weight



The screenshot shows the 'Scale Diagnostics' web interface. The top header displays 'FB6001' on the left and 'Home Logout Help' on the right. A left sidebar contains a 'MAIN MENU' with links to 'Home', 'Logout', and 'Help', followed by 'AUDIT TRAIL', 'OPERATOR MENU', 'CONFIGURATION MENU', 'SERVICE MENU', 'EXPANSION CARDS', and 'SCALE DIAGNOSTICS' (which is highlighted). The main content area is titled 'Scale Diagnostics' and features two tabs: 'Weights' (selected) and 'Cell Counts'. Below the tabs is a table with the following structure:

Zero		Cell	Scale	Cell	Zero	
Weights	Counts				Counts	Weights
			100000 lb	1	22093	100000 lb

Below the table, a horizontal line separates the data from the summary text: 'Gross Weight: 100000 lb'.

Scale Diagnostics shown with a single Load Cell (analog) and the WEIGHTS Selected.

Provides the following data:

- Cell number and zero Counts it was calibrated to
- Cell number and current WEIGHT on that load cell
- Live Gross Weight of the scale shows same as Weight on the Load Cell

## Scale Diagnostics – With ZERO Weight

FB6001
Home Logout Help

MAIN MENU
Home
Logout
Help
AUDIT TRAIL
OPERATOR MENU
CONFIGURATION MENU
SERVICE MENU
EXPANSION CARDS
SCALE DIAGNOSTICS

### Scale Diagnostics

Weights
Cell Counts

Zero					Zero	
Weights	Counts	Cell	Scale	Cell	Counts	Weights
			00 lb	1	22131	00 lb

---

Gross Weight: 00 lb

Scale Diagnostics shown with a single Load Cell (analog) and the WEIGHTS Selected.

Provides the following data:

- Cell number and zero Counts it was calibrated to
- Cell number and current WEIGHT of 00 on that load cell
- Live Gross Weight of the scale shows same as Weight on the Load Cell

# SECTION 5: STANDARD PROGRAMMING

## 5.1. Programming the Instrument

KEYS	FUNCTION
RED & GREEN LIGHT	<ul style="list-style-type: none"> <li>Activates the Traffic Light function, if one is installed.</li> <li>When in the <b>Programming Mode</b>, pressing the <b>RED</b> button returns to the <b>Weight Display</b>, –Except when modifying an entry.</li> </ul>
TARE	Performs an <b>AutoTare</b> function.
IN & OUT BUTTONS	Manually selects the <b>INBOUND</b> or <b>OUTBOUND</b> mode. <ul style="list-style-type: none"> <li>When programming, the <b>OUT</b> key sends a script to the printer.</li> </ul>
UP & Down Arrows	Navigates through the menu selections.
MENU	<ul style="list-style-type: none"> <li>The basic <b>HOME</b> button.</li> <li>Initiates the programming process into the different menus.</li> <li>Backs up one level on the <b>Menu Tree</b>.</li> <li>If the <b>actions are not saved</b>, pressing the <b>MENU</b> button voids this input.</li> </ul>
Numeric Keys	<ul style="list-style-type: none"> <li>Enters values for passwords, weight amounts, and configuration inputs.</li> <li>These keys can shortcut to desired entries in a selection item (see <a href="#">5.1.2 Short-cut Method for Menu Navigations</a>).</li> </ul>
ENTER	Activates and saves data input.
UNITS	<ul style="list-style-type: none"> <li>Toggles and sets the unit types for the weight displayed.</li> <li>When programming, it inserts one line <b>before</b> the current one.</li> </ul>
B/G/NET	<ul style="list-style-type: none"> <li>Toggles active display between Gross and Tare, in the GTN mode.</li> <li>When programming, it inserts one line <b>after</b> the current one.</li> </ul>
ZERO	<ul style="list-style-type: none"> <li><b>ZERO</b>s the scale.</li> <li>When editing numbers or text, this clears the data.</li> </ul>
PRINT	<ul style="list-style-type: none"> <li>Initiates a print cycle.</li> <li>Toggles between editing and showing the name of the current menu choice.</li> <li>Prints a sample ticket while in the <b>Layout Menu</b>.</li> </ul>

\* When configured with the **BASIC Format**, the **IN** key becomes the **GROSS / PRINT** button, and the **OUT** key becomes the **TARE / PRINT** button. The **TARE** and **PRINT** keys become non-functional.



### 5.1.1 Login

1. Press the **MENU** button to toggle between Weight Display and Menu System.



2. To enter the MENU System, when **LOGIN** displays, press the **ENTER** button.
  - The display will be blank.
3. Input the Service Password, then press **ENTER**.



- ✓ Supervisor Password = 1
- ✓ Service Technician Password = 2

**OK** displays first, then **AUDIT TRAIL** follows.

4. Press the **DOWN ARROW** to navigate through the following main menus.

- Audit Trail
- Operator Menu
- Configuration Menu
- Service Menu
- Expansion Cards

5. Press **ENTER** to accept the option.

### 5.1.2 Defining the Programming Menus

The six (6) programming menus are briefly defined below.

<b>AUDIT TRAIL</b>	Identifies how many times and when changes have been made to the scale's Calibration or Configuration settings. <b>NO Password required</b>
<b>OPERATOR MENU</b>	Programs the Time/Date, Ticket Number, Load Cell Diagnostics, Tare Functions, Display Intensity and Keypad Sounds. <b>NO Password required</b>
<b>CONFIGURATION MENU</b>	Programs Customer Passwords, Communications Programming and Functions, Ticket Formats, Programmable Prompts and Legends, Device Input/Outputs, Weight Threshold, Report Configuration, Network Configuration, and Transaction Files Operations. <b>Default Password = 1</b>
<b>SERVICE MENU</b>	Programs the Service Password, <b>metrological parameters of the system</b> , such as Service and Scale Options (Scale Capacity, calibration, graduation size, etc.), Special System Functions Database Maintenance, and Upgrading Functions. <b>Default Password = 2</b>
<b>EXPANSION CARDS</b>	Programs the base configurations to the Expansion Modules in the system by establishing communications parameters for each board utilized. <b>Service Password required</b>

## 5.2. Audit Trail

The **Audit Trail** report displays all the configuration and calibration activities that were changed within the Instrument.

- Provided for Weights and Measures Officials.

### 5.2.1 Display

Filters the **Audit Trail Events** displayed, based on the selected option, after the **ENTER** button is pressed.

- This option is limited to **view only access**.

This example defines the **Audit Trail** report message.



- The unit is in the **INBOUND/OUTBOUND MODE** (Inbound/Outbound, GTN or Basic Mode).
- The UNIT is currently in the **INSTRUMENT MODE** (Instrument, Scale or Complete).
- There have been **28** "log-able" events performed on this instrument.
- The **DATE** and **TIME** of the last recorded event (#28, in this case).

### 5.2.2 Print

Sets up the print output for the **Audit Report**, then prints all Configuration and Calibration activities that were changed within the Instrument.

- Offers a choice of the available printers configured to a COM Port.
- Prints some or all of the records.
- The **PRINT OUT** function activates the printer according to the settings.

*Follow these steps to print an **AUDIT TRAIL** report.*

#### 1. Prepare the printer.

- In the **Audit Trail Menu**, select the correct printer.
- TM-U295                      • TM-U230                      • SP-700                      • SP-2000
- IDP-2550                      • TM-U590                      • SP-298                      • SP-2200
- DemandPC                      • TM-U220

---

**NOTE:** *The printer must be correctly configured before completing this option.*

---

#### 2. Select the Number or Records to include on the report.

- Last (record)                      • 10                      • 50                      • All (records)

#### 3. Select **PRINT OUT**, then press **ENTER**.

### 5.2.3 NJ Jumper State

See [Section 7.2.6. NJ Jumper Required](#) for complete details on how to enable and disable this feature.

### 5.2.4 SW Revision

*This option displays all the current revision information, used for troubleshooting.*

- **IMAGE** – Displays the Software Image revision number and software part number.
- **MODEL** – Displays which model is selected during the last software installation.
  - Either **FB6001** or **FB6001**.
- **MAIN** – Displays the current revision level of the Main Software Program..
- **DRIVERS** – Displays the current revision level of the software driver program.





- **INTERPRETER** – Displays the current revision level of the software interpreter.
- **WEBCONFIG** – Displays the current revision level of the **Web Configuration** software.

---

## SECTION 6: CONFIGURATION MENU

---

### 6.1. Change Customer PW

1. In the Configuration Menu, press **ENTER**.
2. When **CHANGE CUSTOMER PASSWORD** displays, press **ENTER**.
3. When **ENTER PASSWORD** displays, **ENTER**.
4. **Present Customer Password** displays.
5. Input the new Customer Password, then press **ENTER**.
6. When **CONFIRM PW** displays, press **ENTER** again.
  - If the password is entered incorrectly, **ERROR** displays, then the instrument returns to the previous step.

### 6.2. Prompts – Programmable

**PROMPTS** are messages to the Operator that ask a question, offer a choice, or relay an instruction.

1. In the Configuration Menu, press the **DOWN** arrow until **Prompts Programmable** displays.
2. Press **ENTER** when **PROMPT 1** displays.
3. When **NAME** displays, press **ENTER** to prompt the required text.
4. Enter the desired Entry Prompt 1 text heading.
  - The operator can enter alphanumeric text by either using the **UP** and **DOWN** arrows of the **keypad**, or using the **external keyboard**.
  - When **ENABLED**, this feature displays a **Programmable Prompt** text box.
  - Some examples for this field include “**Truck type**”, “**Driver’s last name**”, “**Special Notes**”, etc.
5. Press **ENTER** to save the Prompt 1 text, which then can be printed on the ticket.
  - This print command is activated with **<write (Prompt 1 Text)>**.

## 6.3 Prompts – Programmable, Continued

6. Press the DOWN arrow and choose **GTN, INBOUND, OUTBOUND, BASICIN** or **BASICOUT**, then press **ENTER**.
7. Press the DOWN arrow to select either **DISABLED** or **ENABLED**, then press **ENTER** to confirm this selection.
  - Selecting **ENABLED** initiates the prompt during the weighment transaction when that operating mode is used.

## 6.3. Legends – Programmable

1. In the Configuration Menu, press the DOWN arrow until **Legends - Programmable** displays.
2. Press **ENTER** when **LOOP ID** displays to edit this LEGENDS text.
3. Enter the desired LOOP ID text, then press **ENTER** to save it.
  - The Operator can enter alphanumeric text using the up/down arrows on the keypad, or using an external Keyboard..
  - This print command is activated with **<write (Loop ID Text)>**.

## 6.4. Ticket Formats

For complete descriptions and procedures, see [9.3. FORMATTING TICKETS](#).

---

**IMPORTANT NOTE:** Always configure the **COM Ports** first before formatting tickets

---

## 6.5. Remote Display

For complete descriptions and procedures, see [10.4. PROGRAMMING THE REMOTE DISPLAY](#).

## 6.6. COM Ports

For complete descriptions and procedures, see [9.2. COM PORTS](#).

## 6.7. Threshold Weights

**THRESHOLD WEIGHT** sets the minimum amount the truck must weigh to initiate a weighment.

- This feature is not used when the **Traffic Light Control** is set to **MANUAL**.

✓ **Valid values = 0 to 99,999**

✓ **Default setting = 1000**

*Follow these steps to set the THRESHOLD WEIGHT.*

1. In the **CONFIGURATION MENU**, press the **DOWN** arrow until **THRESHOLD WEIGHTS** displays.
2. Press **ENTER**.
3. When **INITIAL WEIGHT** displays, press **ENTER**.
4. Enter the desired Threshold Weights value, then press **ENTER**.

## 6.8. Traffic Light Control

---

**NOTE:** See, [10.3. PROGRAMMING THE TRAFFIC LIGHT CONTROL](#) for complete instructions on this topic.

---

## 6.9. Reports

Follow these steps to setup and generate the **TRANSACTION REPORTS**.

1. In the **CONFIGURATION MENU**, press the **DOWN** arrow until **REPORTS** displays, then press **ENTER**.
2. When **TYPE** displays, press **ENTER**.
3. Using the **DOWN** arrow, select either **COMPLETED TRANSACTIONS** or **INCOMPLETE TRANSACTIONS**, then press **ENTER**.
4. When **MEDIA TYPE** displays, press **ENTER**.
5. When **JUMP DRIVE** displays, press **ENTER**.
  - A **Jump Drive** must be inserted into a **USB port** for a report to be generated.
  - The **Jump Drive** must then be inserted into a printer or PC to print the document or process it further.
6. When **SORT BY** displays, use the **UP/DOWN** arrows to select the **LOOP ID**, **DATE/TIME** or the **TICKET#** for the desired method of sorting the data, then press **ENTER**.
7. When **DELIMITER** displays, using the **DOWN** arrow, select one of these options, then press **ENTER**.
  - **CSV** (**C**omma **S**eparated **V**alue) – Commas separate data items in the Transaction Report.
  - **TAB** – Tabs are used to separate data items in the Transaction Report.
8. When **GENERATE** displays, press **ENTER** to store the Report to the Jump Drive.
  - **SUCCESS TYPE\_YYYY-MM-DDTHM.XSV SAVED - MENU TO EXIT** displays with the data file name information when the report is stored.
    - Where **TYPE** is either **Completed** or **Incomplete**.
    - **YYYY** is the **year**; **M** is the **month**; **H** is the **hour**; **M** is the **minute**; and **X** is either **C** for **CSV** or **T** for **TAB**.
  - **NO USB DRIVE FOUND - MENU TO EXIT** will display if the USB drive is not installed.
9. Press **MENU** to exit.

## 6.10. Network

The **NETWORK option** displays and/or configures the connection addresses.

- These addresses are used for remotely creating ticket formats.

*There are two (2) connection types used with the FB6001.*

- **DHCP (Dynamic Host Configuration Protocol)** – Automatically addresses each node the first time it connects to the company's Intranet.
- **STATIC** – Dedicated addresses assigned by the IT Department that are specific to each node, and do not change.

*Follow these steps to display, or to enter the Static addresses in the **NETWORK option**.*

1. In the **CONFIGURATION MENU**, press the **DOWN arrow** until **NETWORK** displays, then press **ENTER**.
- 2a. When **USE DHCP?** displays, either press **ENTER**.
  - b. When **DHCP** displays, press **ENTER**.
  - c. When **DHCP OPTIONS** displays, press **ENTER**.
  - d. Open and record the **MY IP**, **MY NETMASK**, **MY GATEWAY**, and **MY DNS** addresses.

**OR...**

- 2a. When **USE DHCP?** displays, either press **ENTER**.
  - b. When **DHCP** displays, press the **DOWN arrow** and select **STATIC**, then. press **ENTER**.
  - c. Input the **STATIC Address** given from the company's **IT Department**, then press **ENTER**.



## 6.11. Transaction Files

Follow these steps to delete unneeded **TRANSACTION FILES**.

1. In the **CONFIGURATION MENU**, press the **DOWN** arrow until **TRANSACTION FILES** displays, then press **ENTER**.
2. Press the **DOWN** arrow to select one of the following options, then press **ENTER**.
  - **DELETE ALL TRANSACTIONS** removes every transactions.
  - **DELETE BY TICKET** removes one specific transaction.
  - **DELETE BY DATE RANGE** removes all transactions within a date range
  - **DELETE BY TICKET RANGE** removes all transactions within a ticket range.
  - **DELETE INCOMPLETE** removes all the Inbound transactions.

### **C A U T I O N**

Performing any of these **TRANSACTION FILES** functions will erase some or all the current transaction data records.

---

## SECTION 7: SERVICE MENU

---

The **SERVICE MENU** programs the technical parameters of the system, such as **Scale Capacity**, **Span**, and **Load Cell Data**.

### 7.1. Change Service PW

1. In the **SERVICE MENU**, when the **CHANGE SERVICE PASSWORD** displays, press **ENTER**.
2. When **ENTER PASSWORD** displays, press **ENTER**.
  - The current password displays.
3. Input the *new* Service Password, then press **ENTER**.
4. When **CONFIRM PW** displays, press **ENTER**.
  - The old password displays.
5. Input the *new* Service Password again, then press **ENTER**.
  - If the confirmation password does not match the new password, **ERROR** displays and cycles back to **Step 4**.
  - **CHANGE SERVICE PASSWORD** displays.

## 7.2. Options (Service)

The **OPTIONS MENU** sets the **Operating Mode**, **Display Rate**, **Zero Mode**, and the **Tare Options**.

### 7.2.1 Operating Modes

**INBOUND / OUTBOUND MODE** weighing consists of weighing a vehicle, inbound, either full or empty, then weighing the same vehicle outbound, full or empty, and printing a ticket with the two weights shown.

✓ **STANDARD DEFAULT = INBOUND/OUTBOUND MODE**

- The **Loop ID Number** entered for an INBOUND transaction can be a stored Tare ID number, which generates an OUTBOUND formatted Ticket; or a new Loop ID Number, which generates an INBOUND ticket, and store the Loop ID for future transactions.

---

**NOTE:** Revision 2.2.0 software and **lower**, Loop ID is limited to 3 numeric characters.

**Revision 2.4.2** software and **higher**, supports up to 15 alphanumeric characters.

---

- The Loop ID Number entered for an OUTBOUND Transaction is either a stored Tare ID or a previous Loop ID, generated during an INBOUND Transaction. In both cases, the ticket printed is in the OUTBOUND format.
- If a stored Tare ID is used, in either an Inbound or Outbound transaction, when a Loop ID is requested, the GROSS Weight on the scale is expected to be greater than the stored tare weight value.
  - **ERROR -. TARE IS HIGHER THAN GROSS WEIGHT** *displays if this is not true.*
- If a stored Tare ID is used with a creation date that is older than the **Expiration Days** as established in **Tare Options**, the following error message displays:
  - **TARE HAS EXPIRED -. TO MENU TO UPDATE DATABASE** *displays as needed.*

## 7.2.1 Operating Modes, Continued


The Instrument can be set for one of these Operating modes.

- ✓ **GTN Mode**
- ✓ **Inbound/Outbound Mode**
- ✓ **Basic Mode (BasicIn or BasicOut)**

**GTN MODE** weighs a vehicle as **Gross Weight** only or utilizing the Gross Weight with a Key Tare or Tare and a derived Net weight.

The **Net Weight** (product only) is the **Gross Weight** (all) minus the **Tare Weight** (container only).

$$\begin{array}{r} \text{Gross Weight} \\ - \text{Tare Weight} \\ \hline \text{NET WEIGHT} \end{array}$$




**BASIC (BasicIn/BasicOut) Mode** weighs the vehicle, then prints a ticket according to the defined ticket format for **BasicIn/BasicOut**.

- It weighs either the **Gross** or the **Tare** amount.
- This mode **does not** utilize **Stored Tares**.
- With a **loaded vehicle** on the scale, press the **GROSS / PRINT** key.
- With an **empty vehicle** on the scale, press the **TARE / PRINT** key.

### 7.2.1 Operating Modes, Continued

Follow these steps to setup the **OPERATING MODE**.

1. In the **SERVICE MENU**, press the **DOWN** arrow until the **OPTIONS (SERVICE)** displays, then press **ENTER**.
2. When **OPERATING MODE** displays, press **ENTER**.
3. When **MODE** displays, press **ENTER**.
4. Using the **UP/DOWN** Arrows, select **INBOUND / OUTBOUND MODE GTN MODE** or the **BASIC MODE**, then press **ENTER**.
  - **DUAL UNITS** displays



See also section [2.5.4. Analog Interface Card \(30997\)](#) and Keypad Stickers for **BASIC** Operating Mode.

### 7.2.2 Dual Units

Follow these steps to setup the **DUAL UNITS** option.

1. In the **SERVICE MENU**, press the **DOWN** arrow until the **OPTIONS (SERVICE)** displays, then press **ENTER**.
2. When **OPERATING MODE** displays, press **ENTER**.
3. Press the **DOWN** arrow until **DUAL UNITS** displays, then press **ENTER**.
4. Using the **UP/DOWN** arrows, select either **NO** or **YES**, then press **ENTER**.

When **YES** is selected, this feature prints two separate **UNIT types** on the ticket, when the ticket is formatted to accommodate this, converting each to the correct weights for easy comparisons.

- Very convenient for comparing pounds to kilograms, ounces to grams, etc.

When **DUAL UNITS** is set to **YES**, the following “**Write (\_\_\_\_\_)**” commands apply.

- **DUALGROSS** prints the **GROSS WEIGHT VALUE** for alternate units.
- **DUALTARE** prints the **GROSS TARE WEIGHT** value in alternate units.
- **DUALNET** prints the **NET WEIGHT** value in alternate units.
- **DUALINBOUND** prints the **INBOUND WEIGHT** value in alternate units.
- **DUALUNITSGROSS** prints the alternate **GROSS units** (i.e. lb, kg, etc.)
- **DUTANTUNITS** prints the alternate **TARE/NET units** (i.e. lb, kg, etc.)





### 7.2.3 Display Rate

Follow these steps to program the **DISPLAY [UPDATE] RATE**.

1. In the Service Menu, press **ENTER**.
2. Press the **DOWN** arrow once and the **OPTIONS (SERVICE)** will display.
3. Press **ENTER**.
4. When **DISPLAY RATE** displays, press **ENTER**.
5. Press **ENTER** when **RATE** displays.
- 6a. Either press **ENTER**, then input a value.
  - This value will be between **0.1** to **0.5** seconds in **0.1** intervals in the **DISPLAY RATE** option.

✓ **Default = 0.333**

**OR...**

- 6b. Press the **DOWN ARROW** once to access the **ALWAYS UPDATE** option.
7. When **NO** displays, either press **ENTER**, or press the **DOWN ARROW** once to change to **YES** to activate this option.
8. Press **ENTER**.

### 7.2.4 Zero Mode

The **ZERO MODE MENU** programs the functionality of the zero operation.

- The ability to disable the **Zero Switch** and set the range or limit of the amount which may be zeroed from the scale.
- Refer to your local Weights & Measurement regulations for the proper setting for Legal-for-Trade applications.

*Follow these steps to program the **ZERO MODE**.*

1. In the Service Menu, press **ENTER**.
2. Press the **DOWN** arrow once and the **OPTIONS (SERVICE)** will display.
3. Press **ENTER**.
4. When **ZERO MODE** displays, press **ENTER**.
5. Press **ENTER** when **SWITCH (ZERO)** displays.
  - This option enables and disables the keypad **ZERO** button.
6. Select **ENABLED** or **DISABLED**, then press **ENTER** .
7. Press the **DOWN** arrow.
8. Press **ENTER** when **RANGE (ZERO)** displays.
  - This option sets a **Percentage Range** for which the scale can **ZERO**.
  - This prevents **ZERO-ing** the scale by pushing the keypad button, while a full load is on the scale platform.



### 7.2.4 Zero Mode, Continued

9. Setting the **LIMIT (ZERO)** allows either **USA (100%)**, **CANADA (2%)** or **OFF** (use ZERO Range) .

---

**NOTE:** If this option is selected, go to **RANGE ENTRY (ZERO)** to set the desired percentage amount using the numeric keypad.

---

10. Using the keypad, set the numeric amount.

11. Press **ENTER**.

12. Press **ENTER** when **PRINT INHIBIT** displays.

- This option allows **ZERO-ing** the scale with a programmed amount for every load, and then allows only one weighment.

13a. Select Enabled or Disabled.

**OR...**

13b. Press **ENTER** when **ENABLE WEIGHT** displays.

14. Press **ENTER** to set the ZERO.

- ✓ This option sets the **ZERO Threshold Value** from **one(1)** to the **scale's capacity**.

15. Input the Threshold Value with the keypad, then press **ENTER**.

## 7.2.5 Tare Options

Follow these steps to program the TARE OPTIONS.

1. In the SERVICE MENU, press the DOWN arrow until the **OPTIONS (SERVICE)** displays, then press **ENTER**.
  2. Press the DOWN arrow until the **TARE OPTIONS** displays, then press **ENTER**.
  3. When **TARE ENABLED** displays, press **ENTER**.
  4. Using the UP and DOWN Arrows, select either **YES** or **NO**, then press **ENTER**.
    - **YES** enables the GTN TARE Function.
    - **NO** prevents the **PRINT** button from prompting a TARE when pressed, and also prevents the **TARE Key** from initiating an Auto Tare when pressed.
  5. When **MANUAL ID** displays, press **ENTER**.
  6. Using the UP/DOWN Arrows, select either **YES** or **NO**, then press **ENTER**.
    - **YES** allows the GTN Ticket Format to print an asterisk (\*) next to the Tare when the TARE Value was generated by a manual keyboard entry.
      - This can be either a saved New Keyboard Tare, used with an Outbound transaction, or a one-time manual keyboard tare entry used in a GTN transaction.
  7. When **EXPIRATION DAYS** displays, press **ENTER**.
  8. Enter the number of days for when a Tare entry will expire, using the numeric keypad, then press **ENTER**.
  9. When **AUTO CLEAR** displays, press **ENTER**.
  10. Using the UP/DOWN arrows, select either **YES** or **NO**, then press **ENTER**.
    - **YES** deletes the established Tare automatically after the GTN transaction is completed.
    - **NO** keeps the last Tare value established using the **TARE** key for use by subsequent GTN transactions.
- **TARE OPTIONS** displays.

### 7.2.6 NJ Jumper Required

The FB6001/2/3 Instrument provides a mechanical means of locking out the front panel from accessing the **Calibration Menu**.

- The **JP1 Jumper** on the **Base Board Assembly** creates a physical security to the system unmatched in any other form.
- Some Regional and State regulatory agencies, like those in New Jersey for example, require that each Instrument be sealed not only with password protection, but also a physically secure method. Moving the jumper remedies this need.

Follow these steps to install the **JP1 Jumper**.

1. **Unplug the Instrument.**
2. **Remove the Instrument cover.**
3. **Using needle-nose pliers, from the Base Board PCB Assembly, remove the jumper.**
- 4a. Either place the **JP1 Jumper** over BOTH PINS to *activate* the **NJ Jumper Security State**,

**OR...**

- 4b. Place the **JP1 Jumper** over **ONLY ONE PIN** to *disable* the **NJ Jumper Security State**.
5. **Reinstall the cover.**
6. **Power-up the Instrument.**



Installing the **JP1 Jumper** connection over both pins **prevents** accessing the **Configuration and Service Menus** from the front panel keypad



Disconnecting the **JP1 Jumper** and turning it side-ways **allows** access to the **Configuration and Service Menu** from the

### 7.2.6 NJ Jumper Required, Continued

Follow these steps to configure the **NJ Jumper Security State**.

1. In the **SERVICE MENU**, press the **DOWN** arrow once, and when the **OPTIONS (SERVICE)** displays, press **ENTER**.
2. Press the **DOWN** arrow until **NJ JUMPER REQUIRED?** displays, then press **ENTER**.
3. Press the **DOWN** arrow and select one of the following.
  - **YES** enables the **NJ Jumper Security State**, preventing configuration functions on the front panel,

**OR...**

- **NO** disables the **NJ Jumper Security State**, allowing configuration functions on the front panel.
4. Press **ENTER**.





## 7.3. Scales (Service)

### 7.3.1 Cell Outputs

1. In the SERVICE MENU, press the DOWN arrow until the **SCALES (SERVICE)** displays, then press **ENTER**.
2. When **ID 1** displays, Press **ENTER**.
3. When **CELL OUTPUTS** displays, press **ENTER**.
- 4a. When **COUNTS** displays, either press **ENTER**,

**OR...**

- b. Press the ▼ to select **ERRORS**, then press **ENTER**.
- c. When **CELL 1** displays, press the UP/DOWN arrows, select the desired cell number (**Cell 1** thru **Cell 16**), then press **ENTER**.
5. Either the current load cell counts or the error data for the selected load cell will display.

---

**NOTE:** If no errors have logged, then **NONE** will display.

---

The error message displays in the following format.

**ERROR -XXX ERROR DATE : MM/DD/YYYY GHOST : YES/NO**

6. When finished viewing data, press **MENU** until **CELL OUTPUTS** displays.

### 7.3.2 Calibration

See [Section 8: Calibration](#) for complete instructions.

### 7.3.3 Options (Scale), On Scale Alarm

*This function initiates an audible alarm and display a message when a weight exceeds the Initial Threshold Weight setting.*

1. In the Service Menu, press the DOWN arrow until **SCALES (SERVICE)** displays, then press **ENTER**.
2. When **ID 1** displays, Press **ENTER**.
3. When **CELL OUTPUTS** displays, press the DOWN arrow until **OPTIONS (Scale)** displays, then press **ENTER**.
4. When **On Scale Alarm** displays, then press **ENTER**.
5. Using the ▼, select either **ON** or **OFF**, then press **ENTER**.
  - Turning this feature **ON** programs a “**VEHICLE ON SCALE**” display message and sounds an alarm when the **Threshold Weight** is exceeded.
6. Press **MENU** to exit.

### 7.3.4 Options (Scale), Reset Cell Errors

*This function deletes all the Cell Errors, refreshing the memory being used.*

1. In the Service Menu, press the ▼ until **SCALES (SERVICE)** displays, then press **ENTER**.
2. When **ID 1** displays, Press **ENTER**.
3. When **CELL OUTPUTS** displays, press the ▼ until **OPTIONS (Scale)** displays, then press **ENTER**.
4. press the ▼ until **RESET CELL ERRORS** displays, then press **ENTER**.
5. Using the ▼, select either **ON** or **OFF**, then press **ENTER**.

## 7.4. Special Functions

### 7.4.1 System Settings

The **SYSTEM SETTINGS** option stores all the company information where the scale is located.

1. In the Service Menu, press the ▼ until **SPECIAL FUNCTIONS** displays, then press **ENTER**.
2. When **SYSTEM SETTINGS** displays, then press **ENTER**.
3. When **LOCATION INFORMATION** displays, press **ENTER**.
4. Input all the company information with the external keyboard by pressing the ▼, then press **ENTER**.

### 7.4.2 COM Port Test

The **COM PORT TEST** option checks the integrity of each port.

1. In the Service Menu, press the ▼ until **SYSTEM SETTINGS** displays, then press **ENTER**.
2. When **LOCATION INFORMATION** displays, press **ENTER**.
3. Input all the company information with the external keyboard by pressing the ▼, then press **ENTER**.
4. While **TEST/** is present, it will broadcast continuously to all three RS232 ports with the configured baud rate and device attached.

## 7.5. Database Maintenance

### 7.5.1 Defaults Set


*This option returns the Instrument to its original factory default settings.*

1. In the **SERVICE** menu, select **DATABASE MAINTENANCE**.
  2. Press the ▼ until **DEFAULTS SET** displays, then press **ENTER**.
  3. Press the ▼ to select either **NO** or **YES**, then press **ENTER**.
- **ON BOARD** feature is a small amount of flash memory located on the CPU module.
    - This memory can be used as a temporary data backup, and is always present, even with no SD or USB drive.
    - Any data within this programmed space is erased when the SD Card is flashed.
  - **SD CARD** is a small removable memory card for storing settings, weighment and other programming data. This card is located in the **Flash Card Holder J3** of the **Base Board Assembly**.
  - **USB DRIVE** is available when a USB Jump Drive is installed in one of the ports in the back of the Instrument.
    - If none is installed, **NO** displays for this option.

### 7.5.2 Backup

*This option backs up the current settings and transaction data, so these can be restored later if there is a problem.*

1. In the SERVICE MENU, select **DATABASE MAINTENANCE**.
2. Press the ▼ and select **ENTER** when **BACKUP** displays.
3. Using the ▼, select **ON BOARD, SD CARD**, or **USBDRIVE**, then press **ENTER**.
4. When the operation is complete, **DONE - PRESS ANY KEY TO EXIT** displays.



### 7.5.3 Restore

*This option restores the previous settings and data, if there is a problem.*


1. Restore data from the ONBOARD MEMORY by following these steps.
  - a. In the SERVICE MENU, select **DATABASE MAINTENANCE**.
  - b. Press the ▼ and select **ENTER** when **BACKUP** displays.
  - c. Press **ENTER** when ONBOARD displays to restore all data previously backed up in the ONBOARD MEMORY.
  - d. When the operation is complete, **DONE - PRESS ANY KEY TO EXIT** displays.

OR...

2. Restore data from the INTERNAL SD CARD by following these steps.
  - a. In the SERVICE MENU, select **DATABASE MAINTENANCE**.
  - b. Press the ▼ and select **ENTER** when **BACKUP** displays.
  - c. Press the ▼ and press **ENTER** when **SD CARD** displays to restore all the data previously backed up to the internal Mini SD Card.
  - d. When the operation is complete, **DONE - PRESS ANY KEY TO EXIT** displays.

OR...


3. Restore data from an External USB Flash Drive by the following steps.
  - a. Insert the Flash Drive with the previous Backup into the USB port of the Instrument.
  - b. In the SERVICE MENU, select **DATABASE MAINTENANCE**.
  - c. Press the ▼ and select **ENTER** when **BACKUP** displays.
  - d. Press the ▼, then select **ENTER** when **USB DRIVE** displays.
  - e. When the operation is complete, **DONE - PRESS ANY KEY TO EXIT** displays.
    - *This restores all the data previously backed up on the USB flash drive.*



### 7.5.4 Ticket Format Restore

This option restores only Ticket Format Data that was backed up previously, using the **BACKUP** option.

1. In the SERVICE MENU, press the ▼ until DATABASE MAINTENANCE displays, then press ENTER.
2. Press the ▼ and when TICKET FORMAT RESTORE displays, press ENTER.
3. Using the ▼, select ON BOARD, SD CARD, or USBDRIVE, then press ENTER.
  - DONE - PRESS ANY KEY TO EXIT displays when the Ticket Restore process is successful.
4. Press ENTER, and Database Maintenance displays.



### 7.6. Upgrade

This function checks the Micro SD Card for any new program revisions.

1. In the SERVICE MENU, press the ▼ until UPGRADE displays, then press ENTER.
2. When CHECK displays, press ENTER.
3. Press ENTER when prompted to upgrade the program.



---

## SECTION 8: CALIBRATION

---

### 8.1. Calibration

1. In the SERVICE MENU, press ▼ to **SCALES (SERVICE)**, then press **ENTER**.
2. **ID 1** displays, press **ENTER**.
3. Press ▼ to **CALIBRATION**, then press **ENTER**.

#### 8.1.1 Data (Calibration)

1. In Calibration, press ▼, to **DATA (CALIBRATION)**, press **ENTER**.
2. Press the ▲/▼ keys, followed by **ENTER**, to configure the following DATA (Calibration) options.
  - a. **DIVISION SIZE** – Using the ▲/▼ keys, input the appropriate amount according to the site's standard weightments.
  - b. **PRIMARY UNITS** – Using the ▲/▼ keys, select one of the following.
    - **lb**                      • **kg**                      • **ton**                      • **tonne**
  - c. **SECONDARY UNITS** – Using the ▲/▼ keys, select one of the following.
    - **lb**                      • **kg**                      • **ton**                      • **tonne**
  - d. **MOTION BAND** – Using the numeric keypad, select one of the following.
    - **0.5d**                      • **1.0d**                      • **3.0d**                      • **OFF**

### 8.1.1 Data (Calibration), Continued

- e. **AUTO ZERO TRACKING** – Using the ▲/▼ keys, select the appropriate Division.

• 0.5d • 1.0d • 3.0d • OFF

- Refer to the local Weights & Measures regulations for the proper setting for Legal-for-Trade applications.

- f. **DUAL RANGE** – Using the ▲/▼ keys, select **ON** or **OFF**.

- When **ON** is selected, the displayed Division Size increases to the next largest size available when a weight exceeds the DUAL THRESHOLD (DUAL RANGE).

- g. **DUAL THRESHOLD** – Using the numeric keypad, input the desired amount according to the capacity of the lower range.

- h. **SCALE CAPACITY** – Using the numeric keypad, input the maximum limit of the scale.

- i. **FILTER FACTOR** – – Using the ▲/▼ keys, select the best option, considering the usage of the scale.

- MEDIUM, HEAVY, OFF, MED/LIGHT, HVY/MED, ANIMAL or LIGHT.

- j. **CELL CAPACITY** – Enter the maximum limit for each cell of the scale.

- k. **CELL UNITS** – – Using the ▲/▼ keys, select from one of the following.

• Lb • Ton  
• kg • Tonne

- DATA (CALIBRATION) displays.

## 8.2. Cell Sensitivity

To pre-calibrate using a mV/V method:

### 8.2.1 Pre-calibrate All Cells Together

- In the Calibration menu, ▼ down to CELL SENSITIVITY, press ENTER.
- When CELL 1 displays, press ENTER
- When SENSITIVITY displays, press ENTER, then using the numeric keys, input the cells' rated mV/V value.
- ▼ down to RESISTANCE press ENTER.
- Using the numeric keys, input the cell's rated Ohm value, then press ENTER.

6. Press **MENU**
7. Press ▼ until **CALIBRATE (MV/V/OHM)** displays, press **ENTER**.
8. Press ▼ and either select **NO** to abort the calibration, or **YES** to calibrate the scale, then press **ENTER**.
9. When **UNLOAD SCALE PRESS ENTER** displays, do this.

**SUCCESS ! CELLS CALIBRATED !** displays once the process is complete.

Display with switch between this message weight on scale platform.

Press **red** traffic light button to return to weigh screen.

### 8.3. Trim (Cell/Section/Scale)

1. Go to the Calibration Menu, press ▼ to **TRIM (CELL/SECTION/ SCALE >** press **ENTER**.
2. When **SELECT REFERENCE TYPE** displays, press **ENTER**.
3. Using the ▲/▼ keys, select the desired Reference Type then press **ENTER**.
  - a. **SET ZERO REFERENCE** – Reestablishes a ZERO reference before trimming.
    - *The scale must be unloaded to establish a ZERO reference, then a known weight is applied and trimmed.*
  - b. **SET RECAL REFERENCE** – Calibrates the from an unknown zero.
    - *i.e. A huge, half full hopper cannot be unloaded for calibrating.*
    - *This uses the current weight on the scale as a 'resting' reference point.*
    - *A known weight is added and trimmed.*
    - *A ZERO point and the calibration are calculated, based on the trimming of this known weight.*
4. When **ENTER TEST WEIGHT** displays, press **ENTER**.
5. Using the numeric keypad, Input Test Weight , then press **ENTER**.
6. When **SPAN UNITS?** displays, press **ENTER**.
7. Using the UP/DOWN ARROWS, select one of the following UNITS, then press **ENTER**.
  - **lb**
  - **kg**
  - **ton**
  - **tonne**

## 8.3 Trim (Cell/Section/Scale), Continued

8. *Implement these steps only if SET ZERO REFERENCE was selected in Step 3*
  - a. When UNLOAD SCALE PRESS ENTER CCCCCC displays , remove all weight from Scale, then press ENTER.
    - Where CCCCCC = Counts.
  - b. When APPLY LOAD PRESS ENTER WWWWWW displays, add test load to scale, then press ENTER.
    - Where WWWWWW = Pre-trim weight reading.
  - c. Display shows TRIM COMPLETE !
  - d. Press ENTER & MULTI-POINT CALIBRATION? Displays
  - e. Select YES or NO.
  - f. If NO is selected, display returns to TRIM : CELL, SECTION, SCALE ,
  - g. If YES is selected, display shows ENTER TEST WEIGHT.
  - h. Press ENTER and key in test weight value.
  - i. APPLY LOAD TO SCALE displays. Apply the weight and press ENTER.
  - j. SCALE TRIM COMPLETE displays. Press ENTER.
  - k. MULTI-POINT CALIBRATION? displays. Press ENTER to return to **Step e.** or press the red traffic light button to exit and save calibration and return to the weigh screen. Process can be repeated up to 5 multi-points.
  - l. If NO is selected on **Step 8.e.**, display will return to TRIM : CELL, SECTION, SCALE,

OR...

9. *Implement these steps only if SET RECALL REFERENCE was selected in Step 3.*
  - a. When PRESS ENTER TO SET REFERENCE CCCCCC displays, with reference weight applied to selected section, press ENTER.
    - Where CCCCCC = Counts.
  - b. When APPLY LOAD TO SCALE X, PRESS ENTER WWWWWW displays, add test load to selected section, press ENTER.
    - Where WWWWWW = Pre-trim weight.
  - c. When SECTION RECALIBRATION COMPLETE ! displays, press ENTER.



If an error occurs or a step is missed, the display will show: **TRIM FAILED ! TRY AGAIN . . .**

---

**NOTE:** *When active units are LBs and SPAN units are KG, the entered Trim Weight value is converted from KGs to LBs, and the displayed weight values during the trim process will be in LBs.*

*For example, if 10,000 KGs is used for the trim weight, the FB60XX will display 22,046 (LBs.)*

---

---

## SECTION 9: SERIAL INPUT / OUTPUT

---

### 9.1. Printers

#### 9.1.1 Printer Switch Settings

ROLL TAPE PRINTER	SW 1 ON	SW 2 ON	SW 3 ON	SWITCH SETTINGS
iDP3550 (28810)	2, 3, 4, 8	1, 2, 3, 5, 6	—	9600 Baud, No Parity, 8 Data and 1 Stop Bit.

TICKET PRINTER	SW 1 ON	SW 2 ON	SW 3 ON	SWITCH SETTINGS
TM-U590 (24740)	1, 3, 7	All OFF	—	9600 Baud, No Parity, 8 Data and 1 Stop Bit.
TM-U295 (24741)	1, 3	All OFF	—	9600 Baud, No Parity, 8 Data and 1 Stop Bit.
SP298	All OFF	3	1, 5	9600 Baud, No Parity, 8 Data and 1 Stop Bit.
SP700	1 thru 7	1 thru 6	1, 5	9600 Baud, No Parity, 8 Data and 1 Stop Bit.
SP2000	All OFF	3	1, 5	2400 Baud, Even Parity, 7 Data and 2 Stop Bit.
SP2200	2, 3, 8	All OFF	All OFF	2400 Baud, No Parity, 7 Data and 2 Stop Bit.
TM-U230 (30954)	All OFF	2, 5, 8	—	9600 Baud, No Parity, 8 Data and 1 Stop Bit.

— No switch bank present inside the printer.

---

**NOTE:** The Fairbanks Scales standard default COM Port settings for all the printers is **9600 Baud, No Parity, 8 Bits, and 1 Stop Bit.**

---

#### 9.1.2 Printer Cabling

The chart below shows the connections for the two cable types used with the printers.

##### 14807 CABLE KIT


WIRE	DB-9 INSTRUMENT	COLOR	DB-25 PRINTER	DESC.
1	P1-2	R	P2-2	RX
2	P1-3	W	P2-3	TX
3	P1-5	G	P2-7	GROUND
4	P1-7	O	P2-8	JUMPERED

##### 14809 CABLE KIT

✓ Used only with the **3550 Printer**.

WIRE	DB-9 INSTRUMENT	COLOR	DB-25 PRINTER	DESC.
1	P1-3	R	P2-3	TX to PRINTER
2	P1-8	W	P2-20	BUSY
3	P1-5	G	P2-7	GROUND

### 9.1.3 iDP3550 Tape Printer Settings



DS2	ON	OFF	DS1	ON	OFF
1	X		1		X
2	X		2	X	
3	X		3	X	
4		X	4	X	
5	X		5		X
6	X		6		X
7		X	7		X
8		X	8	X	
			9		X
			10		X

BAUD	<b>9600</b>
PARITY	<b>No</b>
DATA BITS	<b>8</b>
STOP BIT	<b>1</b>

### 9.1.4 TM-U590 Ticket Printer Settings


- For FB6001/2/3 Instrument **Desktop** and **NEMA 4X SERIAL** communications, use cable **14807**.

BAUD	<b>9600</b>
PARITY	<b>No</b>
DATA BITS	<b>8</b>
STOP BIT	<b>1</b>

Set the printer **dip switches** as listed below.

**DSW 1:** 1, 3, and 7 = **ON** only.

**DSW 2:** All Switches = **OFF**






### 9.1.5 TM-U220 Tape Printer

- Uses **SERIAL** communication.
- Use cable **25932**.

BAUD	<b>9600</b>
PARITY	<b>No</b>
DATA BITS	<b>8</b>
STOP BIT	<b>1</b>



## WIRING

### Cable **25932** Wiring for COM 1-3

DB-9 INSTRUMENT	DESCRIPTION	WIRE COLOR	DB-25 PRINTER	DESCRIPTION
2	RxD	BR	2	TxD
3	TxD	R	3	RxD
4	DRT	O	6	DSR
5	SG	Y	7	SG
6	DSR	G	20	DTR
7	RTS	BL	5	CTS
8	CTS	BK	4	RTS

### Cable **25932** Wiring for Serial Expansion Module\*

RS232 PORT 1: COM7 XX	DESCRIPTION	WIRE COLOR	DB-25 PRINTER	DESCRIPTION
TB1a-2	RxD	BR	2	TxD
TB1a-3	TxD	R	3	RxD
TB1a-4	DRT	O	6	DSR
TB1a-5	SG	Y	7	SG
TB1b-6	DSR	G	20	DTR
TB1b-7	RTS	BL	5	CTS
TB1b-8	CTS	BK	4	RTS

\* Must remove the **9-pin connector**.

### 9.1.5 TM-U220 Tape Printer, Continued

#### DIP SWITCH 1 (Serial Interface)

SWITCH	FUNCTION	ON	OFF
1	Data receive error	Ignored	<b>Prints “?”</b>
2	Receive buffer capacity	40 bytes	<b>4KB</b>
3	Handshaking	XON/XOFF	<b>DTR/DSR</b>
4	Work length	7 bits	<b>8 bits</b>
5	Parity check	Yes	<b>No</b>
6	Parity selection	Even	<b>Odd</b>
7	Transmission speed	4800 bps	<b>9600 bps</b>
8	BUSY condition	Receive buffer full	<b>Receive buffer full or Offline</b>

**Default settings are in bold.**


#### DIP SWITCH 2 (Serial Interface)

SWITCH	FUNCTION	ON	OFF
1	Print Column	42/35	<b>40/33</b>
* 2	For internal use only (auto-cutter) (do not change)	<b>Enabled</b>	<b>Disabled</b>
3	Pin 6 reset signal	Used	<b>Not used</b>
4	Pin 25 reset signal	Used	<b>Not used</b>
5	Undefined	--	--
6	Internal use only (flash memory rewriting) (Do not change)	Enabled	<b>Disabled</b>
7	Undefined	--	--
8	Serial Interface section	Memory Switch	<b>Dip Switch</b>

**Default settings are in bold.**

\* The TM-U220 Tape Printer DAT (dk gray case, w/cutter) will have DSW2 switch #2 set to ON. TM-U220 Tape Printer (white case, no cutter) will have DSW2 switch #2 set to OFF. All other switch settings are identical between printers.

Access the **Dip Switches** by unfastening the screw and removing the cover plate, found on the bottom of the printer.



### 9.1.6 TM-U295 Ticket Printer Settings


- For FB6001/2/3 Instrument **Desktop** and **NEMA 4X SERIAL** communications, use cable **14807**.

BAUD	<b>9600</b>
PARITY	<b>No</b>
DATA BITS	<b>8</b>
STOP BIT	<b>1</b>

Set the printer **dip switches** as listed below.

**SW1:** 1 and 3 = **ON**

**Remainder** = **OFF**



### 9.1.7 SP298 Printer Settings

- For FB6001/2/3 Instrument **Desktop** and **NEMA 4X SERIAL** communications, use cable **14807**.


BAUD	<b>9600</b>
PARITY	<b>No</b>
DATA BITS	<b>8</b>
STOP BIT	<b>1</b>

### ACCESSING THE DIP SWITCHES

1. Remove all power from the printer, as well as all Network cables from between the printer and the Instrument.
2. Remove the **Printer Cover**.
3. Press down with a screwdriver at **Location "A"** marked in the illustration below, and carefully slide the Document Table in the direction indicated by the arrow until it is out of the way.
  - It is not necessary to remove the document table completely. Just move it enough to access the DIP Switches inside.
4. Set the **DIP Switches** into their correct positions.
5. Slide the Document Table back into place while pressing down at **Location "A"**.

### 9.1.7 SP298 Printer Settings, Continued

#### 6. Replace the **Print Cover**.



#### DIP Switch Settings (SERIAL INTERFACE)

SWITCH	FUNCTION	ON	OFF
1	Baud Rate	<i>See table below.</i>	
2			
3	Data Length	8 bits	7 bits
4	Parity Check	Disabled	Enabled
5	Parity	Odd	Even
6	Handshake	DTR/DSR	XON/XOFF
7	Command Emulation	<i>See table below</i>	
8			
9	Pin #6 (DSR) reset signal	Enabled	Disabled
10	Pin #25 (INIT) reset signal	Enabled	Disabled

#### Baud Rate Settings Table

BAUD RATE	SWITCH 1	SWITCH 2-2
4800 bps	OFF	ON
9600 bps	ON	ON
1920 bps	ON	OFF
3840 bps	OFF	OFF

## Command Emulation Table

COMMAND EMULATION	SWITCH 7	SWITCH 8
Star Mode	ON	ON
ESC/POS (TM-295)	ON	OFF
ESC/POS (TM-290)	OFF	OFF
Not used (*)	OFF	ON

\* Never set **Switch 7** to **OFF** at the same time that **Switch 8** is set to **ON**.



### 9.1.8 SP700 Printer Settings

- For FB6001/2/3 Instrument **Desktop** and **NEMA 4X SERIAL** communications, use cable **14807**.

BAUD	<b>9600</b>
PARITY	<b>No</b>
DATA BITS	<b>8</b>
STOP BIT	<b>1</b>

There are **two (2) dip switch** locations on the Star SP700 Printer.

- Underneath the printer, behind a protective cover is **DIP Switch 1**.
- DIP Switch 2** is on the Serial Interface Board.



SWITCH	FUNCTION	ON	OFF
1-1	Always ON	<b>Should be set ON</b>	
1-2	Auto Cutter *	<b>Invalid</b>	Valid
1-3	Always ON	<b>Should be set ON</b>	
1-4	Command Emulation	<b>Star</b>	ESC/POS
1-5	USB mode **	<b>Printer Class</b>	Vendor Class
1-6	2 Colors Printing	<b>Valid</b>	Invalid
1-7	Reserved		
1-8	Print head model ***	18-pin wire	<b>9-pin wire</b>

\* The factory settings for enabling/disabling the Auto Cutter are as listed below.

### 9.1.8 SP700 Printer Settings, Continued

- Models without Auto Cutter: Invalid (**Switch 1-2 = ON**).
- Models with Auto Cutter: Valid (**Switch 1-2 = OFF**).

---

**NOTE:** Only program the **Auto Cutter** function with models that have the **Auto Cutter Accessory** installed.

- This is models with a tear bar.
  - A mechanical error will occur.
- 

\*\* **USB Interface** model only.

\*\*\* Do not change the default setting (**Switch 1-8 = OFF**).

#### DIP Switch 2

SWITCH	FUNCTION	ON	OFF
2-1	Baud Rate	<b>See table below.</b>	
2-2			
2-3	Data Length	<b>8 bits</b>	7 bits
2-4	Parity Check	<b>Disabled</b>	Enabled
2-5	Parity	<b>Odd</b>	Even
2-6	Handshake	DTR/DSR	<b>XON/XOFF</b>
2-7	Pin #6 (DSR) reset signal	Valid	<b>Invalid</b>
2-8	Pin #25 (INIT) reset signal	Valid	<b>Invalid</b>

#### Baud Rate Settings Table

BAUD RATE	SWITCH 2-1	SWITCH 2-2
4800 bps	OFF	<b>ON</b>
9600 bps	<b>ON</b>	<b>ON</b>
1920 bps	<b>ON</b>	OFF
3840 bps	OFF	OFF

### 9.1.9 SP2000 Printer Settings


The SP2000 is a Dot Matrix ticket printer. The following switch settings and cable requirements will work with the default format.

- For FB6001/2/3 Instrument **Desktop** and **NEMA 4X SERIAL** communications, use cable **14807**.

BAUD	<b>2400</b>
PARITY	<b>EVEN</b>
DATA BITS	<b>7</b>
STOP BIT	<b>1</b>

Set the printer's **dip switches** according to the following:

- DSW 1:** All **OFF**.
- DSW 2:** **Three (3) ON** only.
- DSW 3:** **One (1) and five (5) ON** only.



### 9.1.10 SP2200 Printer Settings

The SP2200 is a Dot Matrix ticket printer. The following switch settings and cable requirements will work with the default format.

- FB6001/2/3 Desktop** and **NEMA 4X** use cable **14807**.

BAUD	<b>2400</b>
PARITY	<b>NO</b>
DATA BITS	<b>7</b>
STOP BIT	<b>2</b>


Set the printer's **dip switches** according to the following:

- DSW 1:** **Two (2), three (3), and eight (8) ON** only.
- DSW 2 and 3:** All **OFF**.



### 9.1.11 TM-U230 Printer Settings

- For FB6001/2/3 Instrument **Desktop** and **NEMA 4X SERIAL** communications, use cable **14807**.



BAUD	<b>9600</b>
PARITY	<b>No</b>
DATA BITS	<b>8</b>
STOP BIT	<b>1</b>

#### DIP Switch 1 Settings (SERIAL INTERFACE)

SWITCH	FUNCTION	ON	OFF
1	Data receive error	Ignored	<b>Prints “?”</b>
2	Receive buffer capacity	1KB	<b>16KB</b>
3	Handshaking	XON/XOFF	<b>DTR/DSR</b>
4	Work length	7 bits	<b>8 bits</b>
5	Parity check	Yes	<b>No</b>
6	Parity selection	Even	<b>Odd</b>
7	Transmission speed	4800 bps	<b>9600 bps</b>
8	BUSY condition	Receive buffer full	<b>Receive buffer full or Offline</b>

#### DIP Switch 2 Settings (SERIAL INTERFACE)


SWITCH	FUNCTION	ON	OFF
1	Sections number of characters per line (cpl) 7 x 9 font/ 9 x 9 font	42/35	<b>40/33</b>
2	For internal use only (Auto-cutter) (do not change)	<b>Enabled</b>	Disabled
3	Pin 6 reset signal	Used	Not used
4	Pin 25 reset signal	Used	Not used
5	PAPER OUT LED flashing pattern	<b>Flashes</b>	Lights on
6	For internal use only (flash memory rewriting) (Do not change)	Enabled	<b>Disabled</b>
7	For internal use only (Internal synchronization) (Do not change)	Asynchronous	<b>Synchronous with clock</b>
8	Internal buzzer	<b>Disabled</b>	Enabled

**NOTE:** For wiring table, see [Section 9.1.2. Printer Cabling](#).

## 9.2. COM Ports

The FB6001/2/3 Instrument has numerous ports and outlets allowing different Input/Output devices to be utilized.

- The back of the Instrument has a 120V outlet, but the unit also supports 220V Scale Input.
- The FB6001/2/3 instrument has three (3) standard **Serial Output COM Ports**.
  - These are configured for **RS-232** communications.
  - Serial Outputs can be customized to provide specific configured data string protocols, configuration parameters, using output modes such as **PC Polled, PC Continuous, Demand PC, Off, Remote Display**, and then **all printers** listed in [Section 9](#).
- The **Console Port** is a RS232 Connection.
  - Currently unused.
- There are three (3) **USB Ports** used for different external components, such as a keyboard, USB Flash Drive, etc.
- The three (3) **ACC holes** are used when wiring external component accessories, such as a remote display, traffic lights, etc.
- The Ethernet Port is used for the **WEB FORMATTING**.
  - *For completed details, see [Section 4: Web Interface](#)*



### 9.2.1 Programming COM PORTS

---

**NOTE:** Always configure the Printer before formatting the tickets.

---

Follow these steps to program the **FOUR (4) COM PORTS**.

1. In the **CONFIGURATION MENU**, press the **DOWN** arrow until **COM PORTS** displays.
2. Press **ENTER**.
3. Using the **DOWN** arrow, select the desired **COM PORT** to configure, then press **ENTER**.
  - COM Ports one thru three (1-3) are standard **Serial ports**.
  - COM Port four (4) is dedicated to **20 mA Output**, currently used only for the Remote Display.

---

**NOTE:** For complete wiring information, see [2.5.3. Remote Display 20mA Wiring \(J4\)](#).

---

### 9.2.2 Configuring the Remote Display Output

Follow these steps to program the **REMOTE DISPLAY**

4. In the **CONFIGURATION MENU**, press the **DOWN** arrow until **COM PORTS** displays.
5. Press **ENTER**.
6. Using the **DOWN** arrow, select the desired **COM 4 : 20 MA**, then press **ENTER**.
  - **DEVICE ATTACHED** is displayed. Press **ENTER**
  - Use the **UP/DOWN** arrows to display **REMOTE DISPLAY**, then press enter.
  - **LOAD DEFAULT SETTINGS?** is displayed, press **ENTER**.
  - Use the **UP/DOWN** arrow to display yes, then press **ENTER**.
    - This will load the default settings for Fairbanks 160x remote displays.
  - **SETTINGS** is displayed. If using a non-Fairbanks remote display or if the settings otherwise require changes, press **ENTER** to enter the setting menu.
  - The available settings include: **BAUD RATE**, **PARITY**, **STOP BITS**, **DATA BITS**, and **CHECKSUM**.



### 9.2.2. Configuring the Remote Display Output, Continued

7. Using the DOWN/UP arrows, select the proper communication settings for your remote display, then press **ENTER**
8. Select the correct setting for your remote display, then press **ENTER**.
9. After **CHECKSUM** is displayed, **SETTINGS** is displayed again. Press the red traffic light button once to return to the weigh screen.

---

**NOTE:** Reference section **10.4 PROGRAMMING THE REMOTE DISPLAY** for additional information.

---

### 9.2.3 Selecting the Printer

1. When **DEVICE ATTACHED** displays, press **ENTER**.
2. Using the DOWN/UP arrows, select the desired printer, then press **ENTER**.

- |                   |                  |                   |
|-------------------|------------------|-------------------|
| • <b>OFF *</b>    | • <b>TM-U230</b> | • <b>SP-2000</b>  |
| • <b>TM-U295</b>  | • <b>TM-U590</b> | • <b>SP-22000</b> |
| • <b>IDP-3550</b> | • <b>SP-700</b>  | • <b>SP-298</b>   |
| • <b>TM-U220</b>  |                  |                   |

\* Does not transmit weight amount.

3. When **LOAD DEFAULTS** display, press **ENTER**.
4. Using the UP/DOWN arrows, select **YES** or **NO**, then press **ENTER**.
5. When **SETTINGS** displays, press **ENTER**.
6. Using the DOWN/UP arrow, select the proper RS-232 Communication settings, then press **ENTER**.
  - The settings include **BAUD**, **RATE**, **PARITY**, **STOP**, **BITS**, **DATA BITS**, and **CHECKSUM**.
7. Input the correct setting, then press **ENTER**.

---

**NOTE:** The Fairbanks Scales standard default COM Port settings for all the printers is **9600 Baud, No Parity, 8 Bits, and 1 Stop Bit**.

- The **FORMAT option** does not appear when programming the printers.
-

### 9.2.4 Selecting the PC Data String Output

1. When **DEVICE ATTACHED** displays, press **ENTER**.
2. Pressing the **DOWN** arrow, select **PC CONTINUOUS** or **PC POLLED**, then press **ENTER**.
  - **PC CONTINUOUS** – Sends displayed weight continuously.
  - **PC POLLED** – The external device sends out a polling request. To test the output with a terminal program, press: “W” and [ENTER], and the instrument responds with return data.
3. Press **ENTER** when **FORMAT** displays.
4. Press the **DOWN**-arrow to select the correct standardized data string format.
  - **FAIRBANKS .**
  - **WEIGHTRONIX**
  - **TOLEDO**
  - **CONDEC**
  - **CARDINAL**
5. Press **ENTER** to confirm this selection.
6. When **LOAD DEFAULTS** displays, press **ENTER**.
7. Using the **DOWN/UP** arrow, select **YES** or **NO**, then press **ENTER**.
8. When **SETTINGS** displays, press **ENTER**.
9. Using the **DOWN/UP** arrow, select the proper RS-232 communication settings, then press **ENTER**.
  - The settings include **BAUD**, **RATE**, **PARITY**, **STOP**, **BITS**, **DATA BITS**, and **CHECKSUM**.
- 10a. When the current setting is displayed, either press **ENTER**,

**OR**

- b. Using the **Numeric Keypad** or **DOWN** arrow input the desired setting, then press **ENTER**.

### 9.2.5 DemandPC

This option transmits the weight data in the **Outbound format** whenever the **PRINT button** is pressed. It occurs in one of three situations, as listed below.

- When a **Gross/Tare/Net** print is made.
- An **Inbound Weighment** is completed.
- An **Outbound Weighment** is completed.
  - The instrument outputs information based on the configured ticket format. **GROSS/TARE/NET**, **INBOUND**, and/or **OUTBOUND format** respectively.
  - All data strings which have a **NON-ZERO VALUE** in the coordinates will be transmitted.
  - The order the data strings appear in the data transmission follows the order in which the data is listed in the ticket format.

*Follow these steps to format the **DemandPC** option.*

1. When **DEVICE ATTACHED** displays, press **ENTER**.
2. Pressing the DOWN arrow, select the **DEMANDPC OUTPUT** then press **ENTER**.
3. When **LOAD DEFAULTS** displays, press **ENTER**.
4. Using the DOWN/UP arrow, select **YES** or **NO**, then press **ENTER**.
5. When **SETTINGS** displays, press **ENTER**.
6. Using the DOWN/UP arrow, select the proper RS-232 communication settings, then press **ENTER**.
  - These settings include **BAUD, RATE, PARITY, STOP, BITS, DATA BITS**, and **CHECKSUM**.
7. When the current setting is displayed, either press **ENTER**.

**OR...**

8. Using the numeric keypad or DOWN arrow input the desired setting, then press **ENTER**.



## 9.3. Formatting Tickets

### 9.3.1 Standard Ticket Formatting Steps

Listed below are the standard steps for formatting a ticket.

1. Configure the Service Menu to the correct **OPERATING MODE**.
  - See [SECTION 7.2.1](#).
- The **OPERATING MODE** setup determines how the ticket prints.
  - The **GTN format** configures only the **GTN tickets**.
  - The **In/Out format** configures **In/Out tickets**.
  - The **Basic format** configures **BasicIn** and **BasicOut tickets**.
- Each **Mode of Operation** formats the weighment data in different positions on the ticket, printing only the needed data for that ticket.
- The ticket format can also vary due to the printer type that is used.
- Each ticket format can be adjusted to best suit the customer's needs.

---

**IMPORTANT NOTE:** Always configure the COM Ports before formatting tickets.

---


2. Set up the **COM Ports** in the Configuration Menu to a specific attached device.
  - For complete details, see [Section 9.2. COM PORTS](#).
3. Install, wire and configure the printer.
  - See [Section 9.1.1. Printer Switch Settings](#).
4. Access the **TICKET FORMAT** menu.
5. Insert a blank ticket, then press the **PRINT** key for a ticket self-test.
  - This identifies its current margin setup.
6. Press the **OUT** button to print out the complete Operating Mode format structure.
7. Using this self-test ticket, plan where to format the ticket margins and available print spaces.
  - a. Determine how the current ticket format might differ from the customer's needs.
  - b. Plan the needed changes according to their **SPACE** (*horizontal*) and **FEED** (*vertical*) coordinates of the ticket.
  - c. Mark up this ticket with a ruler and pencil as needed, using it as a guide.

### 9.3.1 Standard Ticket Formatting Steps, Continued

*Consider these factors for placement of data when formatting a ticket.*

### A. TOP MARGIN


The area between the ticket sensor, stop, tear-off and the first line of print is called the **Top Margin**. Printing is not possible in this part of the ticket.



## B. PRINTING AREA

There is a wide variation of printing area used between the different types of printers. This is determined by the physical characteristics of each particular one.

- To find the available space on a ticket, run a printer self-test.



## C. ENHANCED PRINT SIZE

Another factor that regulates how many lines can be placed on a ticket is the font size of the characters. This varies depending on the printer.

- Typically, the **Enhanced Print** feature doubles the standard default font size, making it bolded and emphasized on the page.
- It is recommended using Enhanced Print for only the most important characters on the ticket, such as **Truck ID**, **Net Weight**, etc.
- It also enhances the character size of **FEEDS** and **SPACES**.

### 9.3.2 Programming Tips

*Follow these guidelines when programming a **TICKET FORMAT**.*

- All commands are written in the specific order to the ticket. They flow downward, starting from the top-left of the printer-assigned margin.
- Each command first describes the action, then in brackets, it defines how many, the type of action, or exactly what text to print.
- To remove a printed item on the ticket, display the command, then press the **ZERO key**.

**WRITE (\_\_\_\_)** commands offer a standard list of **System Data Fields** to use when programming.

*Follow these steps to alter how a **WRITE** field appears.*

1. Use the **UP/DOWN** arrows to navigate thru the **WRITE** commands, then press **ENTER** to open one.
2. Using the **UP/DOWN** arrows, select the option that best suits the programming need, then press **ENTER**.
  - The **WRITE (\_\_\_\_)** option selected will display next on the ticket.
  - Certain commands offer two choices, followed by a printed response for one.

#### Example:

**HIDEWRITEONZERO (TARE/TARE)**

*This example means the following:*

- **Hide** (do not print) the **Tare amount** if it equals **ZERO (0)**.

- Write (print) the Tare amount if it is greater than ZERO (0).

#### Keypad Formatting Buttons

**UNITS:** Inserts new format line *before*.

**B/G/NET:** Inserts new format line *after*.

**ZERO:** Deletes the current format line.

**OUT:** Prints entire Format Script.

**MENU:** Saves ticket format.

- Steps back one level.

**ENTER:** Saves all data input..

**PRINT:** Prints a sample ticket.

**RED Button:** Exits to **Weigh Screen**.

**GREEN Button:** Deletes Format Script.

### 9.3.3 Programming Tips

Listed below are the **WRITE (\_\_\_\_\_)** commands.

- |                           |                      |                  |
|---------------------------|----------------------|------------------|
| • GROSS                   | • TICKET NUMBER      | • DUALGROSS      |
| • TARE                    | • LOOP, DEXT         | • DUALTARE       |
| • NET                     | • LOOP, DPROMPT 1EXT | • Dual Net       |
| • DATEIN                  | • PROMPT 1           | • Dual Inbound   |
| • DATEOUT                 | • INBOUND            | • DualUNITSGROSS |
| • TIMEIN                  | • MANUAL TARE        | • DualNETUnits   |
| • TIMEOUT                 | • DUPLICATE          | • Veh Desc       |
| • UNITSGROSS UNITSLARENET |                      |                  |

**WRITE (TEXT)** commands are programmable text fields, allowing legends or prompts to be altered to suit the application needs.

- These text fields can be any character(s) required to suit the customer's need.
- All data items are **left justified**, with a maximum of **fifteen (15) characters**.

---

**NOTE:** When inverting tickets, the **Invert "On"** command should be the first one in the format.

Turn the option **"Off"** as the last command before the ticket release, or the reports will invert when they print.

---

## QUICK FORMATTING BUTTONS

KEYPAD	EXT. KEYBOARD	PROGRAMMING FUNCTION	NORMAL FUNCTION
ZERO	DEL	Deletes current formatting line.	ZERO
UNITS	PgUp	Inserts a new line <i>before</i> the current line.	UNITS
PRINT	INSERT	Prints a sample ticket	PRINTS
B/G NET	END	Inserts a new line <i>after</i> the current line.	B/G NET Select
MENU	HOME	<ul style="list-style-type: none"> <li>Saves ticket format (YES/NO).</li> <li>Backs up one menu level.</li> </ul>	MENU
RED LIGHT	F1	Exits without saving.	Red Light ON
GREEN LIGHT	F2	Deletes the entire Ticket Format Script.	Green Light ON
IN	F4	N/A	INBOUND
OUT	F5	Prints the entire Ticket Format Script.	OUTBOUND
TARE	" "	N/A	Auto Tare

### 9.3.4 Ticket Format Commands

The **TICKET FORMAT** commands are defined below.

SPACE ( )	One (1) movement across (horizontal).
FEED ( )	One (1) movement downward (vertical).
INVERT ON/OFF	Prints the ticket from the bottom-to-the-top, placing data where it belongs according to the programmed coordinates.
WRITE TEXT (" ")	Programmable fields that allow <b>Legends</b> or <b>Prompts</b> to be altered to suit the application needs. Appears exactly as written within the quotation marks. <ul style="list-style-type: none"> <li>When programming <b>WRITE</b> fields, a <b>System Data</b> list displays.</li> </ul>
HIDEWRITEONZERO (TARE, NET)	If the Tare is <b>ZERO</b> , this prevents the <b>Net Weight</b> figure from being printed.
HIDEWRITETEXTONZERO ( /" ")	<b>HIDE</b> the message if the amount is <b>ZERO (0)</b> . <b>WRITE</b> the quoted word if there is a different amount. <ul style="list-style-type: none"> <li>Quotation marks within the command display the exact words)</li> </ul>
WRITE ( )	Without quotation marks, the printer writes out requested data of the command. <ul style="list-style-type: none"> <li>A command is sometimes blended with others together to print all the correct elements. <b>WRITE (UNITSTARENET)</b> is an example.</li> </ul>
WRITE (DUPLICATE)	<b>"Duplicate Copy"</b> appears on the ticket for a <b>TICKET REPRINT</b> . <ul style="list-style-type: none"> <li>This specialized command has one purpose, and cannot be altered.</li> </ul>
ENHANCE ("on")	Enlarges the font characters, and prints them in bold text.
ENHANCE ("off")	Reduces the font size, and prints them in standard text.
WRITE (GROSS)	Prints the <b>Gross Weight</b> .
WRITE (TARE)	Prints the <b>Tare Weight</b> .
WRITE (NET)	Prints the <b>Net Weight</b> .
WRITE (DATE IN)	Prints the <b>date</b> of the <b>first weighment</b> .
WRITE (DATE OUT)	Prints the <b>date</b> of the <b>final weighment</b> .
WRITE (TIME IN)	Prints the <b>time</b> of the <b>first weighment</b> .
WRITE (TIME OUT)	Prints the <b>time</b> of the <b>final weighment</b> .
WRITE (UNITS)	Prints the <b>Unit</b> choice.



WRITE (TICKET NUMBER)	Prints the current <b>ticket number</b> .
WRITE (LOOP ID TEXT)	Prints the legend in the <b>Loop ID</b> field, determined by the technician. — Truck Number, Rail Car Number, etc.
WRITE (LOOP ID)	Prints the <b>Loop ID</b> .
WRITE (PROMPT 1 TEXT)	Prints the <b>Legend</b> that prompts the user to enter an answer or to add data. — BOL Number, License, etc.
WRITE (PROMPT 1)	Prints the data from the <b>Prompt 1 Text</b> field.
INBOUND	Prints the <b>Inbound weight</b> .
WRITE (MANUAL TARE)	Prints an asterisk (*) next to the <b>TARE value</b> when it is a <b>MANUAL TARE</b> ..
RELEASE ( )	End of the ticket, this command <b>releases the ticket</b> from the printer.
CLAMP ( )	Clamps the printer paper.
CUTPAPER ( )	Cuts the printer paper.

### 9.3.5 Ticket Formats

Follow these steps to set up and configure the **TICKET FORMATS**.

1. In the **CONFIGURATION MENU**, press the **DOWN** arrow until **TICKET FORMATS** displays, then press **ENTER**.
2. When **PRINTER** displays, select the desired available printer.
  - a. If the printer is already selected, then press **ENTER**,

**OR...**

- b. Press **ENTER**, press the **DOWN** arrow to select the correct printer, then press **ENTER** again.
3. When **SELECT FORMAT** displays, press the **DOWN** arrow to select one of the five (5) default Ticket Formats, then press **ENTER**.
    - **GTN**
    - **Inbound**
    - **outbound**
    - **BasicIn**
    - **BasicOut**
  4. Press the **DOWN** arrow to enter either **DISABLED** or **ENABLED**, then press **ENTER** to confirm this selection.

5. When **FORMAT** displays, press **ENTER**.
6. Press the UP/DOWN arrows to navigate and format these ticket commands.
  - Press the **PRINT** key while in the **TICKET FORMAT** mode to print a test ticket.
  - Adjust the parameters for **FEED** and **SPACE** to align the information as required to fit the ticket.
  - Align and fit all the needed information on it.  
Repeat this process as needed, until all the data prints correctly on the ticket.
  - Remove a printed item from the ticket by pressing the **ZERO** key.

#### Keypad Formatting Buttons

**UNITS:** Inserts new format line *before*.

**B/G/NET:** Inserts new format line *after*.

**ZERO:** Deletes the current format line.

**OUT:** Prints entire Format Script.

**MENU:** Saves ticket format.

– Steps back one level.

**ENTER:** Saves all data input..

**PRINT:** Prints a sample ticket.

**RED Button:** Exits to **Weigh Screen**.

**GREEN Button:** Deletes Format Script.


The flow chart below displays samples of available options for **TICKET FORMATTING CONFIGURATION**.

Ticket Formatting Configurations				
GTN	INBOUND	OUTBOUND	BASICIN	BASICOUT
1-Space <4>	1-Space <4>	1-Space <4>	1-Write <TimeIn>	1-Feed <2>
2-Write <Duplicate>	2-Write <Duplicate>	2-Write <Duplicate>	2-Space <1>	2-Space <1>
3-Feed <1>	3-Feed <1>	3-Feed <1>	3-Write <DateIn>	3-Write <TimeOut>
4-WriteText <"TICKET NUMBER">	4-Feed <10>	4-WriteText <"TICKET NUMBER">	4-Space <1>	4-Space <1>
5-Space <8>	5-WriteText <"INBOUND">	5-Space <8>	5-Write <TicketNumber>	5-Write <DateOut>
6-Write <TicketNumber>	6-Space <6>	6-Write <TicketNumber>	6-Space <1>	6-Space <1>
7-Feed <14>	7-Write <Inbound>	7-Feed <14>	7-Write <UnitGross>	7-Write <Gross>
8-Space <4>	8-Space <6>	8-Space <4>	8-Space <1>	8-Space <1>
9-Write <DateOut>	9-Write <UnitGross>	9-Write <DateOut>	9-WriteText <"GROSS">	9-Write <UnitGross>
10-Space <10>	10-Feed <1>	10-Space <10>	10-Feed <1>	10-Space <1>
11-Write <TimeOut>	11-Write <LoopIDText>	11-Write <TimeOut>	11-Release <>	11-WriteText <"TARE">
12-Feed <2>	12-Space <8>	12-Feed <2>		12-Feed <1>
13-Enhance <"on">	13-Write <LoopID>	13-Enhance <"on">		13-Release <>
14-Write <Gross>	14-Feed <2>	14-Write <Gross>		
15-Space <1>	15-Space <4>	15-Space <1>		
16-Write <UnitGross>	16-Write <DateIn>	16-Write <UnitGross>		
17-Space <1>	17-Space <10>	17-Space <1>		
18-WriteText <"GROSS">	18-Write <TimeIn>	18-WriteText <"GROSS">		
19-Feed <1>	19-Feed <18>	19-Feed <1>		
20-Write <Tare>	20-Release <>	20-Write <Tare>		
21-Space <1>		21-Space <1>		
22-Write <UnitTareNet>		22-Write <UnitTareNet>		
23-Write <ManualTare>		23-Write <ManualTare>		
24-HideWriteTextOnZero <Tare, "TARE">		24-HideWriteTextOnZero <Tare, "TARE">		
25-Feed <1>		25-Feed <1>		
26-Write <Net>		26-Write <Net>		
27-Space <1>		27-Space <1>		
28-Write <UnitTareNet>		28-Write <UnitTareNet>		
29-Space <1>		29-Space <1>		
30-HideWriteTextOnZero <Tare, "NET">		30-HideWriteTextOnZero <Tare, "NET">		
31-Feed <2>		31-Feed <2>		
32-Enhance <"off">		32-Enhance <"off">		
33-Feed <10>		33-Write <LoopIDText>		
34-Release <>		34-Space <8>		
		35-Write <LoopID>		
		36-Feed <10>		
		37-Release <>		



### 9.3.6 G/T/N Ticket Formatting

Defined below is the structure and appearance of a **GROSS/TARE/NET** ticket.



FAIRBANKS SCALES KC, MO 1-800-821-3322

**WEIGHED ON A FAIRBANKS SCALE**

Duplicate Copy

TICKET NUMBER 13

10/18/12 02:58 PM

Enhance <"on">

35020 lb GROSS

12360 lb TARE

Enhance <"off">


22660 lb NET

Release

FAIRBANKS SCALE CAT. 96757

This image shows the printed areas and other defined elements of a **G/T/N Ticket**.

– All grey markings are for illustration purposes only.



FAIRBANKS SCALES KC, MO 1-800-821-3322

**WEIGHED ON A FAIRBANKS SCALE**

Duplicate Copy

TICKET NUMBER 13

CUSTOMER'S NAME \_\_\_\_\_

ADDRESS \_\_\_\_\_

COMMODITY \_\_\_\_\_

CARRIER \_\_\_\_\_

INBOUND DATE 10/18/12 TIME 02:58 PM

OUTBOUND DATE 10/18/12 TIME 02:58 PM

35020 lb GROSS

12360 lb TARE

22660 lb NET

DRIVER ON \_\_\_\_\_ OFF \_\_\_\_\_

SHIPPER \_\_\_\_\_

WEIGHER \_\_\_\_\_

FAIRBANKS SCALE CAT. 96757

Example of an actual **G/T/N**


GTN	
1-Space <4>	
2-Write <Duplicate >	
3-Feed <1>	
4-WriteText <"TICKET NUMBER" >	
5-Space <6>	
6-Write <TicketNumber >	
7-Feed <14>	
8-Space <4>	
9-Write <DateOut >	
10-Space <10>	
11-Write <TimeOut >	
12-Feed <2>	
13-Enhance <"on" >	
14-Write <GroSS >	
15-Space <1>	
16-Write <UnitSGroSS >	
17-Space <1>	
18-WriteText <"GROSS" >	
19-Feed <1>	
20-Write <Tare >	
21-Space <1>	
22-Write <UnitSTareNet >	
23-Write <ManualTare >	
24-HideWriteTextOnZero <Tare, "TARE" >	
25-Feed <1>	
26-Write <Net >	
27-Space <1>	
28-Write <UnitSTareNet >	
29-Space <1>	
30-HideWriteTextOnZero <Tare, "NET" >	
31-Feed <2>	
32-Enhance <"off" >	
33-Feed <10>	
34-ReleaSe < >	

The flow chart above outlines the coordinates for each element of the **G/T/N Ticket**.



### 9.3.7 Inbound Ticket Formatting

Defined below is the structure and appearance of an **INBOUND** ticket example.



The image above shows the printed areas and other defined elements of the ticket.

- All grey markings are for illustration purposes only, and not printed.

FAIRBANKS SCALES KC, MO 1-800-821-3322

**WEIGHED ON A FAIRBANKS SCALE**

Duplicate Copy

CUSTOMER'S NAME \_\_\_\_\_

ADDRESS \_\_\_\_\_

COMMODITY \_\_\_\_\_

CARRIER \_\_\_\_\_

INBOUND 35020 1b  
Loop ID 333

INBOUND DATE 10/18/12 TIME 03:00 PM  
OUTBOUND DATE TIME

DRIVER ON \_\_\_\_\_ OFF \_\_\_\_\_

SHIPPER \_\_\_\_\_


WEIGHER \_\_\_\_\_

FAIRBANKS SCALE CAT. 96757

Example of an **Inbound Ticket**.

### 9.3.8 Outbound Ticket Formatting

Defined below is the structure and appearance of an **OUTBOUND** ticket example.



The diagram shows a printed ticket with a coordinate system. The X-axis is horizontal and the Y-axis is vertical. The starting point is at the top left of the ticket. The ticket contains the following text:

FAIRBANKS SCALES KC, MO 1-800-821-3322

**WEIGHED ON A FAIRBANKS SCALE**

Duplicate Copy

TICKET NUMBER 15

10/18/12 05:22 PM


Enhance <"on"> 49980 lb GROSS  
35020 lb TARE  
14960 lb NET

Enhance <"off"> LOOP ID 333

Release

FAIRBANKS SCALE CAT. 96757

This image shows the printed areas and other defined elements of the **Outbound Ticket**.  
– All grey markings are for illustration purposes only.



The actual image of the outbound ticket shows the following layout:

FAIRBANKS SCALES KC, MO 1-800-821-3322

**WEIGHED ON A FAIRBANKS SCALE**

TICKET NUMBER 15

CUSTOMER'S NAME \_\_\_\_\_

ADDRESS \_\_\_\_\_

COMMODITY \_\_\_\_\_

CARRIER \_\_\_\_\_

INBOUND DATE 10/18/12 TIME 05:22 PM

OUTBOUND DATE 10/18/12 TIME 05:22 PM

49980 lb GROSS  
35020 lb TARE  
14960 lb NET

LOOP ID 333

DRIVER ON \_\_\_\_\_ OFF \_\_\_\_\_

SHIPPER \_\_\_\_\_

WEIGHER \_\_\_\_\_

FAIRBANKS SCALE CAT. 96757

Actual image of an **Outbound Ticket**  
(without any Inbound Ticket information).

OUTBOUND	
1-Space <4>	
2-Write <Duplicate >	
3-Feed <1>	
4-WriteText <"TICKET NUMBER" >	
5-Space <6>	
6-Write <TicketNumber >	
7-Feed <14>	
8-Space <4>	
9-Write <DateOut >	
10-Space <10>	
11-Write <TimeOut >	
12-Feed <2>	
13-Enhance <"on" >	
14-Write <Gross >	
15-Space <1>	
16-Write <UnitSGross >	
17-Space <1>	
18-WriteText <"GROSS" >	
19-Feed <1>	
20-Write <Tare >	
21-Space <1>	
22-Write <UnitSTareNet >	
23-Write <ManualTare>	
24-HideWriteTextOnZero <Tare, "TARE" >	
25-Feed <1>	
26-Write <Net >	
27-Space <1>	
28-Write <UnitsTareNet >	
29-Space <1>	
30-HideWriteTextOnZero <Tare, "NET" >	
31-Feed <2>	
32-Enhance <"off" >	
33-Write <LoopIDText >	
34-Space <6>	
35-Write <LoopID >	
36-Feed <10>	
37-Release < >	

This flow chart outlines coordinates for each element of the **Outbound Ticket**.

### 9.3.9 Completed Transaction Ticket Example

Shown below is a ticket example of a completed **INBOUND / OUTBOUND** transaction.

**INBOUND TICKET**  
includes the **LOOP ID**,  
**DATE**, **TIME**, and Initial  
Weight.

FAIRBANKS SCALES KO. MO. 1-800-821-3302

---

**WEIGHED ON A FAIRBANKS SCALE**

TICKET NUMBER 12

CUSTOMER'S NAME \_\_\_\_\_

ADDRESS \_\_\_\_\_

COMMODITY \_\_\_\_\_

CARRIER \_\_\_\_\_

INBOUND 20000 1b  
Loop ID 333

INBOUND DATE 10/18/12 TIME 02:54 PM  
OUTBOUND DATE 10/18/12 TIME 04:24 PM  
35020 1b GROSS  
20000 1b TARE  
15020 1b NET  
Loop ID 333

DRIVER ON \_\_\_\_\_ OFF \_\_\_\_\_

SHIPPER \_\_\_\_\_

WEIGHER \_\_\_\_\_

FAIRBANKS SCALE CAT. 96757

**OUTBOUND TICKET** includes  
the **DATE**, **TIME**, **GROSS**,  
**TARE** and **NET Weights**. Also  
includes the **TICKET NUMBER**  
and **LOOP ID NUMBER**.

#### Keypad Formatting Buttons

**UNITS:** Inserts new format line *before*.

**B/G/NET:** Inserts new format line *after*.

**ZERO:** Deletes the current format line.

**OUT:** Prints entire Format Script.

**MENU:** Saves ticket format.

– Steps back one level.


**ENTER:** Saves all data input..

**PRINT:** Prints a sample ticket.

**RED Button:** Exits to **Weigh Screen**.

**GREEN Button:** Deletes Format Script.

### 9.3.10 BasicIn and BasicOut Ticket Formatting



This image shows the printed areas and other defined elements of the **BasicIn** and **BasicOut** Tickets.

BASICIN	
1-Write <TimeIn >	
2-Space <1>	
3-Write <DateIn >	
4-Space <1>	
5-Write <GroSS >	
6-Space <1>	
7-Write <UnitSGroSS >	
8-Space <1>	
9-WriteText <"GROSS" >	
10-Feed <1>	
11-ReleaSe < >	

BASICOUT	
1-Feed <2>	
2-Space <1>	
3-Write <TimeOut >	
4-Space <1>	
5-Write <DateOut >	
6-Space <1>	
7-Write <GroSS >	
8-Space <1>	
9-Write <UnitSGroSS >	
10-Space <1>	
11-WriteText <"TARE" >	
12-Feed <1>	
13-ReleaSe < >	

**NOTE:** Tickets programmed in the **BasicIn** and **BasicOut** formats can be set up as the customer requests, within the boundaries of the ticket size.

– The one displayed above is shown as an **example only**.

### 9.3.11 Deleting a Ticket Format

Follow these steps to **DELETE** a ticket format, and then reset to the factory default.

1. In the **CONFIGURATION MENU**, press the DOWN arrow until **TICKET FORMATS** displays, then press **ENTER**.
2. When **PRINTER** displays, press **ENTER**.
3. Press the DOWN arrow until the desired printer displays, then press **ENTER**.
4. Press the DOWN arrow until **SELECT FORMAT** displays, then press **ENTER**.
5. Press the DOWN arrow the Ticket Format to be deleted displays, then press **ENTER**.
6. When **ENABLED** or **DISABLED** displays, press **ENTER**.
7. Press the DOWN arrow until **DELETE** displays, then press **ENTER**.
8. Press the DOWN arrow until **YES** displays, then press **ENTER** to delete the current ticket format and replace with the default format.

## 9.4. Formatting Web Interface Tickets

### 9.4.1 Logging In to the Web Interface

1. Locate the IP Address of the FB60XX Series Instrument  
(See also 4.1.1. To obtain the current IP address of the FB60XX )


---

**NOTE:** In order to login to the Web Interface, you **MUST** logout of the FB60XX instrument. If you are **NOT** logged out, you will receive the message “**Front Panel in Use**” until you log out.

---

2. Input the correct IP Address of the FB60XX into the Address Bar of the web browser, then press **ENTER** on the remote computer.

3. Click on the **LOGIN** link.




4. Input the Default Service Password  
then press the **LOG IN** button.

**Service Password = 2.**

The **Web Interface Home** screen appears.


After you are logged in successfully, the message “**Remote Config in Process**” will appear on the screen of the instrument.



For more complete detail regarding the Web Interface, see [Section 4: Web Interface](#).

### 9.4.2 Ticket Format


1. Click the drop-down arrow and **Select a printer**.
2. Click the drop-down arrow and **Select a mode**.



**IMPORTANT NOTE:** The printer must be configured in the **COM Port menu** before it is available here.

3. Click the **EDIT FORMAT** button.
4. Drag-and-Drop the **FIELDS** options into their place on the **TICKET LAYOUT** area.

5. To add or delete lines within the ticket format, click the **+ ADD LINE** or **- REMOVE LINE**.
6. Once formatting is complete, click **TEST PRINT** to print a sample.
7. Either **SAVE** or **DELETE** the format.



FB6000 Home Log Help

MAIN MENU

Home

Logout

CONFIGURATION MENU

Ticket Format

Ticket Format: TM-U295 / GTN

Fields

Gross

Tare

Net

DateIn

DateOut

TimeIn

TimeOut

UnitsGross

UnitsTareNet

TicketNumber

LoopIDText

LoopID

Prompt1Text

Prompt1

Inbound

ManualTare

Duplicate

DualGross

DualTare

DualNet

DualInbound

DualUnitsGross

DuTaUnits

VehDesc

Text

FF

Release

Clamp

OutPaper

Ticket Layout

Options

(DUPLICATE COPY)

TICKET NUMBER 10000

6/19/14 03:52 PM

6/19/14 03:52 PM

00000000 1b GROSS

11111111 1b TARE

22222222 1b NET

+ Add Line Line Count: 31 - Remove Line

Save Test Print Delete

Once completed, click **TEST PRINT**. Click either **SAVE** or **DELETE**.

Drag-and-drop the **FIELDS** options into their place on the **TICKET LAYOUT** area.

The printed ticket will appear similar to how it is formatted.

To add or delete lines within the ticket format, click **+Add Line** or **- Remove Line**.

The image above displays a ticket with the default GTN format using a TM-U295 printer.

### 9.4.3 Standard Default Formats

Shown below are images of the **standard default formats** for each of the Ticket Modes when using the TM-U295.

**Ticket Format: TM-U295 / GTN**

Fields	Ticket Layout	Options
Gross	(DUPLICATE COPY)	
Tare	TICKET NUMBER 10000	
Net		
DateIn	6/19/14 03:52 PM	
DateOut		
TimeIn		
TimeOut		
UnitsGross		
UnitsTareNet		
TicketNumber		
LoopIDText		
LoopID		
Prompt1Text		
Prompt1		
Inbound		
ManualTare	6/19/14 03:52 PM	
Duplicate		
DualGross	0000000 1b GROSS	
DualTare	1111111 1b TARE	
DualNet	2222222 1b NET	
DualInbound		
DualUnitsGross		
DuTaNUUnits		
VehDesc		
Text		
FF		
Release		
Clamp		
CutPaper		

Line Count:31

Save Test Print Delete

**Ticket Format: TM-U295 / Inbound**

Fields	Ticket Layout	Options
Gross	(DUPLICATE COPY)	
Tare		
Net		
DateIn		
DateOut		
TimeIn		
TimeOut		
UnitsGross		
UnitsTareNet		
TicketNumber		
LoopIDText		
LoopID		
Prompt1Text	INBOUND 0000000 1b	
Prompt1	Loop ID <LoopID>	
Inbound		
ManualTare	6/19/14 03:55 PM	
Duplicate		
DualGross		
DualTare		
DualNet		
DualInbound		
DualUnitsGross		
DuTaNUUnits		
VehDesc		
Text		
FF		
Release		
Clamp		
CutPaper		

Line Count:30

Save Test Print Delete

**Ticket Format: TM-U295 / Outbound**

Fields	Ticket Layout	Options
Gross	(DUPLICATE COPY)	
Tare	TICKET NUMBER 10000	
Net		
DateIn		
DateOut		
TimeIn		
TimeOut		
UnitsGross		
UnitsTareNet		
TicketNumber		
LoopIDText	LoopIDText	
LoopID		
Prompt1Text		
Prompt1		
Inbound		
ManualTare	6/19/14 03:57 PM	
Duplicate		
DualGross	0000000 1b GROSS	
DualTare	1111111 1b TARE	
DualNet	2222222 1b NET	
DualInbound		
DualUnitsGross		
DuTaNUUnits		
VehDesc	Loop ID <LoopID>	
Text		
FF		
Release		
Clamp		
CutPaper		

Line Count:31

Save Test Print Delete

**Ticket Format: TM-U295 / BasicIn**

Fields	Ticket Layout	Options
Gross	03:58 PM 6/19/14 0000000 1b GROSS	
DateIn		
TimeIn	[Release]	
UnitsGross		
Prompt1Text		
Prompt1		
DualGross		
DualUnitsGross		
Text		
FF		
Release		
Clamp		
CutPaper		

Line Count:1

Save Test Print Delete

**Ticket Format: TM-U295 / BasicOut**

Fields	Ticket Layout	Options
Gross		
DateOut	03:59 PM 6/19/14 0000000 1b TARE	
TimeOut		
UnitsGross	[Release]	
Prompt1Text		
Prompt1		
DualGross		
DualUnitsGross		
Text		
FF		
Release		
Clamp		
CutPaper		

Line Count:3


Save Test Print Delete



### 9.4.4 Exiting Without Saving

There are two warnings that display when the ticket format is closed without being saved.


**DELETE BUTTON** pressed without saving the format identifies the action.



### CLOSING THE PROGRAM WITHOUT SAVING

offers three buttons.

- **CANCEL** returns to the Ticket Interface.
- **SAVE BEFORE LEAVING** saves the format before exiting the interface.
- **JUST LEAVE (CHANGES WILL BE LOST)** closes the Ticket Interface without saving the current format.



## 9.5. 4-20mA Analog Card

The **4-20mA Expansion Card Accessory** is a 16 bit, high resolution, analog output, offering these two transmission options.

**ACTIVE** provides its own **18VDC** power source for the analog output circuit.

- The dedicated output interfaces the Instrument with PLC's, chart recorders, or other control systems requiring a 4-20mA signal.

ACTIVE, SUPPLIED POWER SOURCE	
<b>4-20mA Specifications</b>	16 bit resolution +/- .01 integral linearity
<b>Current Loop Voltage Compliance</b>	Fairbanks Instrumentation provides the scale's 18VDC power source.
<b>Full Scale Setting Time</b>	8mSecs
<b>Output Impedance</b>	25 Meg Ohms.
<b>Alarm Current</b>	3.5 to 24mA (underload/overload conditions), Offset at 25°C; +/- .1% of full scale. Offset drift; +/- 25 ppm of full scale per degree Celsius.
<b>Total Output Error</b>	(20mA) at 25°C: +/- .2% of full scale max
<b>Total Output Drift</b>	+/- 50 ppm of full scale per degree Celsius max

**PASSIVE** requires the customer supply the external power source of **7VDC** to **40VDC**.

PASSIVE, CUSTOMER-SUPPLIED POWER SOURCE	
<b>4-20mA Specifications</b>	16 bit resolution +/- .01 integral linearity



<b>Current Loop Voltage Compliance</b>	The negative (-) power of the supply <i>MUST</i> be isolated from chassis ground. A separate power supply must be furnished for each installed passive 4-20.
<b>Full Scale Setting Time</b>	8mSecs
<b>Output Impedance</b>	25 Meg Ohms.
<b>Alarm Current</b>	3.5 to 24mA (underload/overload conditions), Offset at 25°C; +/- .1% of full scale. Offset drift; +/- 25 ppm of full scale per degree Celsius.
<b>Total Output Error</b>	(20mA) at 25°C: +/- .2% of full scale max
<b>Total Output Drift</b>	+/- 50 ppm of full scale per degree Celsius max

**Requires minimum 100 Ohm resistance**

### 9.5.1 Active 4-20mA Kit Installation (33258)

The **4-20 mA ANALOG CARD (33252)** is an **ACTIVE** current loop device with 16-Bit High Resolution Output.

1. **Shut down the Instrument properly, and then unplug it.**
2. **Remove the cover.**
3. **Install the Card Guides (29966) onto the Expansion PCB Assembly.**
  - Note their orientation and location on the PCB Assembly, as they may be installed in any open slot.
  - The **4-20mA PCB Assembly** can be installed in any open location on the **Expansion PCB Assembly**.
4. **Remove one of the hole plugs on the back of the FB6000, then replace this with a Strain Relief Bushing (11020), used for the 4-20mA Interface Cable..**
5. **Connect the Active 4-20mA Interface Cable according to this chart.**
  - Using a **100-150Ω Resister** is recommended to complete this circuit.



4-20MA INTERFACE	OUTPUT CONNECTION
Output (-)	TB2-2
Output (+)	TB2-3



6. Access the FB6000 Instrument's internal configuration to setup the Active 4-20mA PCB Assembly, in order to test and calibrate the output.
7. Reassemble the instrument, then place it into operation.



### 9.5.2 Passive 4-20mA Kit Installation (30919)


The **4-20 mA ANALOG CARD (30738)** is a **PASSIVE** current loop device with 16-Bit High Resolution Output.

8. Shut down the Instrument properly, and then unplug it.
9. Remove the cover.
10. Install the Card Guides (29966) onto the Expansion PCB Assembly.
  - Note their orientation and location on the PCB Assembly, as they may be installed in any open slot.
  - The **4-20mA PCB Assembly** can be installed in any open location on the **Expansion PCB Assembly**.
11. Remove one of the hole plugs on the back of the FB2550, then replace this with a **Strain Relief Bushing (11020)**, used for the 4-20mA Interface Cable..
12. Connect the Passive 4-20mA Interface Cable according to this chart.
  - Using a **100-150Ω Resistor** is recommended to complete this circuit.



4-20MA INTERFACE	OUTPUT CONNECTION
Output (+)	TB2-1
Output (–)	TB2-3

13. Access the **FB6000 Instrument's internal configuration** to setup the Passive 4-20mA PCB Assembly, in order to test and calibrate the output.
14. Reassemble the instrument, then place it into operation.



---

# SECTION 10: ACCESSORIES


---

## 10.1. Installing Accessories

There are two optional **EXPANSION MODULES** for the FB6001/2/3 Instrument.

- ✓ **Only one of the two kits can be installed on the instrument, and not both.**

- **4-20mA Analog Kit (30919)** produces an analog output between 4 and 20mA, dependent on configuration and weight applied to scale.
  - **Relay PCB Assembly Kit (30920)** controls the **ON/OFF state** of the **Traffic Signal Lights** or **Relay Box**.
1. **Remove all external power from the Instrument.**
  2. **Remove the fastening screws on each side of the case.**
  3. **Using the needle-nose pliers at the base of the Expansion Module Mounting Pegs, insert each one onto the Base Board Assembly.**
    - Install each Mounting Peg **facing inward** in slots **M5** and **M6**.
    - Press each one firmly against the board until it snaps into place.
    - Removing one of these broken Mounting Pegs requires a razor knife.
  4. **Remove the hole cover in ACC 1 in the back wall of the instrument.**
  5. **Thread the Expansion Module Communications Cable through the Cable Insert in ACC 1, then assemble it into the back wall of the Instrument, leaving the mounting bolt still loose.**
  6. **Wire the Communications Cable to the Expansion Module according to the charts on the following pages.**
  7. **Insert and slide the Expansion Module down the two (2) Mounting Pegs, then plug it into dedicated Base Board Assembly sockets, J8.**
  8. **Pull any excess cable through the back of the ACC 1 Access Hole and push in the Cable Insert tightly.**
  9. **Turn on and test the system.**



*The **Relay PCB Assembly** is used to control the traffic lights, also optional.*

---

**NOTE:** For complete wiring information, see **Load Cell-to-Instrument Interfaces Installation Manual, 51326**

---

## 10.2. Expansion Modules (30919, 30920)

**EXPANSION MODULES** provide the physical connectivity between the FB6000 family of instruments and all scale and peripheral Input/ Output (I/O) devices.

Insert the **Analog Interface Card PCB assembly (30997)** into the dedicated **BASE BOARD SOCKET J6**.

Insert one of the two **Accessory Modules** into the other dedicated **BASE BOARD SOCKET J8**.

- **4-20mA Analog Kit (30919)**

OR...

- **Relay PCB Assembly Kit (30920)**

### 10.2.1 Analog Scale Card Programming

*Follow these steps to view the installed software revision, and program the **Data UPDATE RATE** for the ASC PCB.*

1. In the Expansion Cards menu, press the DOWN arrow until **SCALE INTERFACE** displays, then press **ENTER**.
2. When **REVISION NUMBER** displays, press **ENTER**, record the appropriate information, then press **ENTER**.
3. When **VIEW CELLS FOUND** displays, press **ENTER**.
4. Observe the number of cells found to verify correct scale interface, then press **ENTER**.
5. When **UPDATE RATE** displays, then press **ENTER**.
6. The current Update Rate displays, adjust the Update Rate as needed (**0.1** to **0.5ms**), then press **ENTER**.

✓ Default = **0.333ms**


The following are steps used **ONLY** when needing to update the revision of firmware on the ASC card.

7. With the USB jump drive inserted into the FB600X USB port, when **CHECK FOR UPDATES** displays, press **ENTER**
8. The system will scan for valid hex files that have been downloaded on the USB jump drive, and scroll to **FILE SELECT**, press **ENTER**
  - a) **NOTE:** The hex file must be placed on the root of the USB jump drive.

9. Press up or down to scroll through the list and press **ENTER** to select from the list. Display will scroll the revision of the selected file, press **ENTER**
10. The display will now indicate “**APPLY UPDATE**”. Press the **ENTER** key to show the options.
11. The display will indicate “**NO**” as a selection. Use the UP/DOWN arrows to display “**YES**” and press **ENTER**
12. The display will scroll **SENDING UPDATE PLEASE WAIT** and on completion will show **UPDATE SUCCESSFUL**

### 10.2.2 Relay PCB Assembly (30920)

The **RELAY CARD** is intended to **ONLY** be used with the **Fairbanks Relay Boxes** and the **ACC 777 Traffic Light**.



### COMPONENTS USING THE RELAY CARD

- |   |   |
|---|---|
| <b>A. ACC 777 LED Traffic Light</b><br>– Connects directly to the relay card. | <b>B. ACC 2018 Traffic Light Relay Box</b><br>– Solid state relays. |
| <b>C. ACC 703 Relay Box</b><br>– Dry Contact Relays.                          |   |

### RELAY CARD (30920) JUMPER SETTINGS

RELAY ACC	J1	J2	J3	J4
ACC 2018 (16163)	ON	ON	ON	ON
ACC 703 (13170)	OFF	OFF	OFF	OFF
ACC 2019 (13171)	OFF	OFF	OFF	OFF

---


**IMPORTANT NOTE:** *DO NOT* cross communication lines on the **RELAY CARD**.

---

### 10.2.3 ACC 777 LED Traffic Light (29001)

Wire the **Relay PCB Assembly Kit (30920)** to the **ACC 777 LED Traffic Light** according to the chart shown to the right.

- **ACC 777 (29700)** is a sub-assembly component within the **Traffic Light (29001)**.




*Install a temporary jumper from TB1 to TB3  
test the RED light. Jump TB2 to TB3 for  
testing the GREEN light.*

### 10.2.4 ACC 2018 Traffic Light Relay Box (16163)

The FB6001 controls one (1) set of traffic lights per scale when a **Relay Card (30919)** is interfaced to **ACC 703 Relay Box (13170)**.

- A ten foot (10') control cable is included with the **ACC 2018 relay box (16163)**.
- The customer supplies AC power source to the **ACC 2018 Relay Box**.




## WIRING

Follow these steps to install the **Traffic Light Relay Box**.

1. Remove all external power from the Instrument.

*The Control Cable (16160) needs field modification to connect to the Relay Card.*


2. Cut off factory wired plug.
3. Strip and wire to the relay card according to the chart on the following page.






## 10.2.4 ACC 2018 Traffic Light Relay Box (16163), Continued

### RELAY CARD CONNECTIONS



### AC TO LIGHTS WIRING



### 10.2.5 ACC 703 Relay Box (13170)

- The ACC 2019 Cutoff Relay Box and ACC 703 Relay Box are wired identically.
- The FB6001/2/3 can control up to **four (1) traffic lights** [two pair (2) per scale] when a **Relay Card (30920)** is interfaced to **ACC 703 Relay Box (13170)**.
  - **ACC 703 Relay Box** requires an AC power outlet, and is supplied with a ten foot (10') **Control Cable**.
  - The **ACC 703 Relay Box** **does not** supply AC power to the traffic lights, but switches externally supplied AC power, furnished by other components.


### WIRING

Follow these steps to install the **Traffic Light Relay Box**.

1. Properly shut down the FB6001/2/3 Instrument, and then remove all AC power **BEFORE** installing the Relay Card to the Expansion Module.

The **Control Cable (13133)** requires field modification to connect to the **Relay Card**.


2. Cut off factory wired plug.
3. Strip and wire to the relay card according to the chart on the following page.



### 10.2.5 ACC 703 Relay Box (13170), Continued

WIRE COLOR	1 ST ACC 703/ 2019– LIGHTS 1-2-3-4	2 ND ACC 703/ 2019 – LIGHTS 5-6-7-8
Black	Pin 1 (GND)	Pin 11 (GND)
Brown	Pin 2 (+5VDC)	Pin 12 (+5 VDC)
Red	Pin 3 (Out1A)	Pin 13 (Out1B)
Orange	Pin 4 (Out2A)	Pin 14 (Out2B)
Yellow	Pin 5 (Out3A)	Pin 15 (Out3B)
Green	Pin 6 (Out4A)	Pin 16 (Out4B)
Blue	Pin 7 (In1A)	Pin 17 (In1B)
Violet	Pin 8 (In2A)	Pin 18 (In2B)
Grey	Pin 9 (In3A)	Pin 19 (In3B)
White	Pin 10 (In4A)	Pin 20 (In4B)

### AC to LIGHTS WIRING



### 10.2.6 Relay Module [Expansion Card]

Follow these steps to program the Relay Module Expansion Card.

- Visible only if **Relay Card** is installed.
1. In the EXPANSION CARDS menu, press **ENTER**.
  2. Press the DOWN arrow to select **RELAY MODULE**.
  3. When **DEVICE ATTACHED** displays, press **ENTER**.
  4. Using the DOWN arrow, select either **20 18 ACC** for activating the Traffic Light Relay Box (**16163**), if it is attached; or select **OTHER** for the other items listed in **Section 10.2.4**, then press **ENTER**.
  5. Press the DOWN ARROW to display the **REVISION NUMBER**, then press **ENTER**.
  6. Record the information as needed for future references, then press **ENTER**.

### 10.2.7 D/A Module [Expansion Card]

Follow these steps to program the D/A Module Expansion Card.

- Visible only if **Relay Card** is installed. .
1. In the EXPANSION CARDS menu, press **ENTER**.
  2. Press the DOWN arrow to select **D/A Module**, then press **ENTER**.
  3. Using the DOWN arrow, select one of the following options, then press **ENTER**.
    - Revision Number
    - Units
    - Idle
    - Scale
    - Low Limit
    - Test
    - High Limit
  4. Press **ENTER** to adjust the current parameters for each of these options.
  5. Press **ENTER** to save and close the new settings.

## 10.3. Traffic Light Control

The **Traffic Light Control** sets the operational modes of the traffic light. It is typically controlled automatically by the instrument weightment cycle.

- Each **I/O RELAY CARD** supports **two (2)** sets of lights operated in parallel.

### 10.3.1 Control (Traffic Light)

*Follow these steps to setup the TRAFFIC LIGHT CONTROL.*

1. In the **CONFIGURATION MENU**, press the **DOWN** arrow until **TRAFFIC LIGHT CONTROL** displays.
2. Press **ENTER**.
3. When **SCALE ID 1** displays, press **ENTER**.
4. When **CONTROL TRAFFIC LIGHT** displays, press **ENTER**.
5. When **AUTOMATIC** displays, either press **ENTER** to select it,

**Or...**

6. Press the **DOWN** arrow to enter the **MANUAL** option, then press **ENTER**.

### 10.3.2 Event to Signal

Follow these steps to setup the **EVENT TO SIGNAL** OPTION.

1. In the Configuration Menu, press the DOWN arrow until **Traffic Light Control** displays.
2. Press **ENTER**
3. When **SCALE ID 1** displays, press **ENTER**.
4. Press the DOWN arrow until **CONTROL TRAFFIC LIGHT** displays, then press **ENTER**.
5. Press the DOWN arrow until **EVENT TO SIGNAL** displays, then press **ENTER**.
6. When **X SECOND TIME DELAY** displays, where "X" is the delay setting, input a value from **2** to **10** (seconds), then press **ENTER**.

✓ Default = **6 Seconds**

## 10.4. Programming the Remote Display

### 10.4.1 Display Mode

Follow these steps to setup the **DISPLAY MODE**.

1. In the **CONFIGURATION MENU**, press the DOWN arrow until **REMOTE DISPLAY** appears.
2. Press **ENTER**.
3. When **DISPLAY MODE** appears, press **ENTER**.
4. When **CONTINUOUS** displays, either press **ENTER** to select it, or press the DOWN arrow to enter **ON PRINT**.
5. Press **ENTER**.

---

**NOTE:** For installation details, see [2.5.3. Remote Display 20mA Wiring \(J4\)](#).

---

### 10.4.2 Type (Output)

This option formats what will appear on the REMOTE DISPLAY.

1. In the **REMOTE DISPLAY** menu, press the DOWN arrow until **TYPE OUTPUT** displays, then press **ENTER**
2. Press the DOWN arrow to select **Gross Wt**, **Net Wt**, **Ticket Number**, **Active Gross** or **Net Wt**.
3. Press **ENTER**.

### IMPORTANT PROGRAMMING CONSIDERATIONS

- When **Display mode** is set to **CONTINUOUS**, and the **Active Gross** or **NetWt** is also set, the remote display follows what appears on the instrument display.
  - The operator can toggle between **Gross Wt** and **Net Wt** by pressing the **B/G NET** button.
  - If the output type is set to **Gross Wt**, the instrument will only display the Gross Weight, regardless of what appears on the instrument.
  - This is the same for **Net Wt**. The remote display indicates the Net Weight.

### IMPORTANT PROGRAMMING CONSIDERATIONS, CONTINUED

- When display **Type (Output)** is set to **TICKET NUMBER**, the next **Ticket Number** displays until a print occurs and the printed vehicle leaves the scale.
  - The weight drops below a threshold, either the **Initial Weight** threshold entry or **25 divisions of zero**, whichever is higher.
  - At that point, the next new ticket number displays.
- If display **Type (Output)** is set to **TICKET NUMBER**; the 1601/5/5T Remote Display must be configured first.
  - Set the Annunciator (**ANNUN**) to **SCALE 1**.
  - Set the Annunciator to **NO**.

✓ **Failure to do this will constitute an NTEP violation!**

---

**NOTE:** For further information, see **SECTION 4.3.4** of the 1600 Series Remote Display Manual (51157).

---



### 10.4.3 Enable 1605T

Follow these steps to enable the 1605T Display Instrument.

1. In the CONFIGURATION MENU, press the DOWN arrow until **REMOTE DISPLAY** appears, then press **ENTER**.
2. Press the DOWN arrow until **ENABLE 1605T** displays, then press **ENTER**.
3. Select **YES** or **NO**, then press **ENTER**.

---

**NOTE:** For the Traffic Light function on the 1605T to work, the Display Mode must be set to **CONTINUOUS**.


---



# SECTION 11: USER OPERATIONS

## 11.1. Front Panel Key Functions

KEYS	FUNCTION
RED & GREEN LIGHT BUTTONS	<ul style="list-style-type: none"> <li>Activates the <b>Traffic Light function</b>, if one is installed.</li> <li>When in the <b>Programming Mode</b>, pressing the <b>RED</b> button returns to the <b>Weight Display</b> (except when modifying an entry).</li> <li>The <b>GREEN</b> button deletes the <b>Ticket Format</b>, when in the Ticket Format menu.</li> </ul>
TARE	Performs an <b>AutoTare</b> function.
IN & OUT BUTTONS	<ul style="list-style-type: none"> <li>Manually selects the <b>INBOUND</b> or <b>OUTBOUND</b> mode.</li> <li>The <b>OUT</b> button prints the current Ticket Format, when in the Ticket Format menu.</li> </ul>
UP & DOWN Arrows	Navigates through the menu selections.
MENU	<ul style="list-style-type: none"> <li>The basic <b>HOME</b> button.</li> <li>Initiates the programming process into the different menus.</li> <li>Backs up one level on the Menu Tree.</li> <li>If the actions are not saved, pressing the <b>MENU</b> button voids this input.</li> </ul>
NUMERIC Keys	<ul style="list-style-type: none"> <li>Enters values for passwords, weight amounts, and configuration inputs.</li> <li>These keys can shortcut to desired entries in a selection item</li> <li>See <b>4.1.2. SHORT-CUT METHOD FOR MENU NAVIGATIONS</b>.</li> </ul>
ENTER	Activates and saves data input.
UNITS	<ul style="list-style-type: none"> <li>Toggles and sets the unit types for the weight displayed.</li> <li>When programming, it inserts data if additional items are needed.</li> <li>Data-insert function happens before the item that is currently being viewed, while in the Format Menu.</li> </ul>
B/G/NET	<ul style="list-style-type: none"> <li>Toggles active display between <b>GROSS</b> and <b>TARE</b>, in the <b>GTN</b> mode.</li> <li>Deletes one character in text/number.</li> </ul>
ZERO	<ul style="list-style-type: none"> <li><b>ZERO</b>s the scale.</li> <li>When editing numbers or text, this clears the data.</li> </ul>
PRINT	<ul style="list-style-type: none"> <li>Initiates a <b>PRINT</b> cycle.</li> <li>Toggles between editing and showing the name of the current menu choice.</li> <li>Prints a sample ticket while in the <b>Layout Menu</b>.</li> </ul>



## 11.2. Operational Procedures

### 11.2.1 Gross Weighing


The truck drives on the scale and the operator prints the result.

1. Press the **ZERO** key.
2. Drive the vehicle to be weighed on the platform.
3. Once the display stabilizes, press the **PRINT** key.
  - A **GTN** ticket prints with the **Gross Weight**.

### 11.2.2 Basic Weighing

**BASIC MODE** weighs the vehicle, then prints a ticket displaying the **Time**, **Date** and **Weight Amount** (either **Tare** or **Gross**). *This is its only function.*

- See [Section 7.2.1](#) to configure the Instrument for the **BASIC Operating Mode**.
  - This mode **does not** have In/Out or Tare functions, (including storing Tares).
  - This mode requires specialized **keypad overlay stickers**.
- 1. With a loaded vehicle on the scale, press the **GROSS / PRINT** key
  - This is the **IN key**, before the template sticker was added.
- 2. With an empty vehicle on the scale, press the **TARE / PRINT** key.
  - This is the **Out key**, before the template sticker was added.




---


**NOTE:** See [2.5.4. Analog Scale Card for BASIC Operating Mode](#) for complete details.

---

### 11.2.3 Gross-Tare-Net Weighing

- See [Section 7.2.1](#) to configure the Instrument for the **GTN Operating Mode**.

- Press the **ZERO** key.
- Drive the empty vehicle to be weighed on the platform.
- Press the **TARE** button.
  - Displayed weight is the captured **Tare Weight**.
- Exit the scale and load the vehicle with product.
- Drive back onto the scale.
- Once the display stabilizes, press the **PRINT** key and a Gross-Tare-Net Ticket will be printed.



**OR...**

- With the scale unloaded, press the **ZERO** key.
- Drive the loaded vehicle to be weighed on the platform.
- When the display stabilizes, press the **PRINT** key.
- When **KEY IN TARE AND PRESS ENTER** displays, enter a known **TARE amount** from an earlier weighment using the numeric keypad, then press **ENTER**.
  - A **GTN Ticket** will be printed.

---

**NOTE:** For printing only **Gross Weight**, enter **ZERO (0)** when prompted to enter a Tare amount.

---



## 11.2.4 Inbound/Outbound Weighing

Noted below are a few tips for the **Inbound/Outbound Weighing Mode**.

- With software revision **2.2.0 and lower**, **Loop ID** input can only be a **NUMERIC value** with a maximum of **three** characters.

Revision **2.4.2 and higher**, supports up to **15 alphanumeric characters**.

- The **Loop ID** is replaced by saving a new tare, or a saving a new keyboard tare ID.

See [Section 7.2.1](#) to configure the Instrument for the **INBOUND/OUTBOUND Operating Mode**.

- Press the **ZERO** key.
- Drive the vehicle onto the platform, whether it is either full or empty.
- Once the display stabilizes, press the **IN** (Inbound) key.
- When the **Loop ID** legend text displays, enter the **Loop ID number** using the numeric keypad, then press **ENTER**.
  - For complete information, see [Section 6.4. Legends – Programmable](#).

**OR...**

- Press **ENTER** to have the FB6001 auto-assign a **Loop ID number**.
- Drive off the scale and process the trailer, by either filling or emptying it.
- The same vehicle returns to the scale, either full or empty.
- Once the display stabilizes, press the **OUT** (Outbound) key.
- When the **Loop ID legend text** displays, enter the **LOOP ID Number** from an Inbound Transaction or saved TARE ID number, then press **ENTER**.

**OR...**



### 11.2.4 Inbound/Outbound Weighing, Continued

- 3a. With the scale unloaded, press the **ZERO** key.
- b. Drive the loaded vehicle to be weighed on the platform.
- c. When the display stabilizes, press the **PRINT** key.
- d. When **KEY IN TARE AND PRESS ENTER** display, using the enter a known **TARE amount** from an earlier weighment, then press **ENTER**.
  - A **GTN Ticket** will print.

---

**NOTE:** For **Gross Weight** only to be printed, enter **ZERO (0)** when prompted to enter a *Tare amount*.

---

#### OR...

- 4a. With the scale unloaded, press the **ZERO** key.
- b. Drive the loaded vehicle to be weighed on the platform.
- c. When the display stabilizes, press the **IN** or **OUT** key.
- d. When the **Loop ID legend text** displays, enter a **Tare ID number** from a stored **NEW TARE** or stored **NEW KEYBOARD TARE**, then press **ENTER**.
  - For complete information, see [Section 6.4. Legends – Programmable](#).

***The transaction is processed and an Outbound ticket prints***

## 11.3. Programming the Operator Menu

*Shown below is the complete flow chart of the Operator Menu.*

### 11.3.1 Format Time & Date

Use the **UP/DOWN Arrows**, **Numeric keys**, **MENU** and **ENTER** buttons to format the Time and Date.

1. While in the OPERATOR MENU, select the **TIME AND DATE** option, then press **ENTER**.
2. When **FORMAT TIME AND DATE** display, use the UP/Down Arrow keys to select one of the following options, then press **ENTER**.
  - H:M
  - H:M:S
  - HH:MM
  - HH:MM:SS
3. When **AM/PM** display, press **ENTER**.
4. Using the DOWN arrow, select **12 HOUR** or **24 HOUR** format, then press **ENTER**.
5. When **DATE FORMAT** displays, Press **ENTER**.
6. Using the UP/DOWN arrows, select the best formate for the customer's needs, then press **ENTER**.
7. When **DATE SEPERATOR** displays, press **ENTER**.
8. Using the DOWN arrow, select one of the available formats, (which include a **(SPACE)**, **/**, and **-**), then press **ENTER**.

### 11.3.2 Set Time & Date

Use the **Arrow**, **Numeric** and **ENTER** Keys to set the time and date.

1. While in the **TIME** and **DATE** MENU, select the **SET TIME AND DATE** option, then press **ENTER**.
2. Input the **YEAR**, then press **ENTER**.
3. Input the **MONTH**, then press **ENTER**.
4. Input the **DAY**, then press **ENTER**.
5. Input the **HOUR**, then press **ENTER**.
6. Input the **MINUTE**, then press **ENTER**.
7. When **SAVE TIME AND DATE** displays, press **ENTER**.

---

**NOTE:** To set a PM time in the 12 hour format, enter it using the 24 hour format.  
• i.e. Enter **13** to set the Instrument for 1PM.

---

### 11.3.3 Ticket Number

Follow these steps to access a specific ticket by entering the **Ticket Number**.

1. While in the **OPERATOR MENU**, select the **TICKET NUMBER** option, then press **ENTER**.
- 2a. When **NUMBER** displays press **ENTER**.
  - b. Using the numeric keypad, in the **Ticket Number**, press **ENTER**.
    - Allows a maximum entry of **six (6) digits**.
    - This sets the value for the **Ticket Number** to be used in the next printing transaction.
  - c. Press the **DOWN arrow** until the **LAST TICKET - PRINT** option displays, then press **ENTER**.
    - This prints a duplicate of the last ticket transaction.

**OR...**

- 2a. Press the **DOWN arrow** until the **DUPLICATE - PRINT** option displays, then press **ENTER**.

- b. When **ENTER TICKET NUMBER** appears, enter the desired ticket number, then press **ENTER**.
  - This option prints a duplicate ticket for the number as input by the operator.)

### 11.3.4 Load Cell Diagnostics

**Load Cell Diagnostics** gives a quick snapshot of how each load cell is performing, used for easier troubleshooting capabilities.

1. While in the **OPERATOR MENU**, select the **LOAD CELL DIAGNOSTICS** option, then press **ENTER**.
2. When **ID** displays, press **ENTER**.
3. When **CELL OUTPUTS** displays, press **ENTER**.
- 4a. When **DISPLAY** appears, press **ENTER**.
- b. When **COUNTS** displays, press **ENTER**.
- c. Using the **DOWN/UP arrows**, select the desired load cell (**CELL1** thru **CELL 16**), then press **ENTER**.
  - The counts for the selected load cell will be displayed.
- d. Press **ENTER** to return to **Cell Selection**.
- e. Press **MENU** to return to **DISPLAY MENU**.
- f. Press **DOWN** arrow until **ERRORS** displays, then press **ENTER**.
  - If **NONE** appears, then there are no errors to display.
- e. If errors do occur, use the **DOWN arrow** to select one of the listed Cell numbers that have recorded an error, then press **ENTER**.
  - The **ERROR TYPE**, **DATE**, and **GHOST STATUS** for the recorded error will be displayed.
  - Press **ENTER** three times to return to **Cell Outputs Menu**.

### OR...

- 4a. Press the **DOWN arrow** until **PRINT** displays, then press **ENTER**.
- b. When **PRINTER** displays, press **ENTER**.
- c. Press the **DOWN arrow** to select a printer if multiple printers are configured, then press **ENTER**.
- d. When **COUNTS** displays, press **ENTER** to print the **Cell Counts**.



### 11.3.4 Load Cell Diagnostics, Continued

The following categories are noted on the **COUNTS** print-out.

**CELL NUM** – Identifies the load cell in the scale platform.

**CAL COUNTS** – the zero load cell count stored at calibration.

**CURRENT** – the current load cell counts.


**WEIGHT** – the current weight value.

### 11.3.5 New Tare

Follow these steps to store a **New Tare**, using the scale platform, then recalled later as a saved **Tare Weight**.

1. In the Operator Menu, press the DOWN arrow until **NEW TARE** displays, then press **ENTER**.
2. When **ID (TARE)** displays, Press **ENTER**.
3. When the last stored Tare ID number displays, input the new tare number, then press **ENTER**.
4. When **WEIGHT (TARE)** displays, press **ENTER**.
5. The current weight on the platform is displayed with annunciator on front panel lit to identify active units; press **ENTER** to capture the weight.
  - If there is motion on the platform at that time; **"MOTION \_ PLEASE WAIT"** displays until the scale settles, and then the weight can be captured.
6. When **VEHICLE DESCRIPTION** displays, press **ENTER**.
7. When the current Vehicle Description displays. input the new Vehicle Description , then press **ENTER**.
  - This can be the truck drivers' plate number, the vendor ID, or another designated identifying number.

**GROSS WEIGHT – TARE WEIGHT = NET WEIGHT**



### 11.3.5 New Tare, Continued

8. When **SAVE** displays, press **ENTER**.
9. Using the **DOWN ARROW**, select either **YES** or **NO**, then press **ENTER**.
  - **YES** saves the captured TARE Weight Value, ID, and Vehicle Description.
  - **NO** does not save the Tare Data.

---

**NOTE:** If the Tare ID entered in Step 3 is a duplicate of an existing Stored Tare, then **OVERWRITE? - NO** will display.

---

10. To abort saving the tare, press **ENTER**.
  11. To overwrite the existing tare data with the new tare data, press the **DOWN** arrow until **OVERWRITE? - YES** displays, then press **ENTER**
- **NEW TARE** displays.

### 11.3.6 New Keyboard Tare

Follow these steps to store a **New Tare**, using the keyboard, to be recalled later as a saved tare weight.

1. In the Operator Menu, press the **DOWN** arrow until **NEW KEYBOARD TARE** displays, then press **ENTER**.
2. When **ID (TARE)** displays, press **ENTER**.
3. The last stored Tare ID number is displayed, input the new tare number, then press **ENTER**.
4. When **WEIGHT (TARE)** displays, press **ENTER**.
5. The last tare entry weight is displayed; enter a new tare value via the keyboard, then press **ENTER**.
6. When **UNITS** displays, press **ENTER**.
7. When the current Units setting displays, use the **UP/DOWN** arrows to select the correct one, then press **ENTER**.
  - **lb, kg, ton, or tonne**
8. When **Vehicle Description** displays, press **ENTER**.
9. When the current Vehicle Description displays; input the new Vehicle Description, then press **ENTER**.

- This can be the truck drivers' plate number, the vendor ID, or another designated identifying number.

10. When **SAVE** displays, press **ENTER**.

11. Using the **DOWN** arrow, select either **YES** or **NO**, then press **ENTER**.

- Selecting **YES** saves the **Tare**.
- Selecting **NO** does not save the **Tare**.

---

**NOTE:** If the **Tare ID** entered in **Step 3** is a duplicate of an existing **Stored Tare**, then **OVERWRITE? - NO** will display.

---

12. To abort saving the tare, press **ENTER**.

13. To overwrite the existing tare, press the **DOWN ARROW** until **OVERWRITE?** displays, then press **ENTER** when **YES** displays.

### 11.3.7 Tare Delete

This option displays a list of all the stored **New Tare** and **New Keyboard Tare** entries.

*Follow these steps to delete a stored Tare.*

1. While in the **OPERATOR MENU**, press the **DOWN** arrow and select the **TARE DELETE**, then press **ENTER**.
2. Press the **DOWN/UP** arrows to scroll through the stored tares.
3. To delete a tare, press the **ZERO** key.

### 11.3.8 Tare Report

This option displays each of the stored **New Tares** and **New Keyboard Tares**, then prints a **Report** as selected by the operator.

*Follow these steps to set the Tare Report.*

1. While in the **OPERATOR MENU**, press the **DOWN** arrow and select the **TARE REPORT**, then press **ENTER**.
- 2a. When **DISPLAY** appears, press **ENTER**.
  - This shows the **Stored Tares**, listing the **Tare ID Number**, **Weight**, **Date**, and the **Tare Description**.
- b. Use the **UP/DOWN** arrows to scroll through the list.
- c. Press **MENU** to return to the **Tare Menu**.

**OR...**

### 11.3.8 Tare Report, Continued

- 2a. Use the **DOWN** arrows to select **PRINT**, then press **ENTER**.
- b. Press **ENTER** when **PRINTER** displays.
- c. Select an available **PRINTER**.
- d. Press **ENTER** when **PRINT OUT** displays for the Tare Report.
- e. Press **MENU** when **PRINTING COMPLETE --- MENU TO CONTINUE** displays.

### 11.3.9 Utility – Set Display Intensity

1. While in the OPERATOR MENU, press the DOWN arrow and select the **UTILITY** option, then press **ENTER**.
2. Press **ENTER** when **Set Display Intensity** appears.
3. Select **LOW**, **MEDIUM** or **HIGH**, then press **ENTER**.

### 11.3.10 Utility – Key Pad Beep, Set Volume, Mute

#### KEY PAD BEEP

1. In the UTILITY MENU, press the DOWN arrow and select the **KEY PAD BEEP** option, then press **ENTER**.
2. Select **ON** or **OFF**, then press **ENTER**.

#### SET VOLUME

3. In the UTILITY MENU, press the DOWN arrow and select the **SET VOLUME** option, then press **ENTER**.
4. Adjust the BEEP volume to the desired level.

#### MUTE

5. In the UTILITY MENU, press the DOWN arrow and select the **MUTE** option, then press **ENTER**.
  - This silences the **Key Pad Beep** until it is reversed.

### 11.3.11 Options (Operator)

1. While in the OPERATOR MENU, press the DOWN arrow and select **OPTIONS (OPERATOR)**, then press **ENTER**.
2. Press the DOWN arrow and press **ENTER** to select one of these options.
  - **OUTBOUND AUTO SUGGEST** – When processing Inbound Loops, this selection displays the next available one.
  - **AUTO INSTRUMENT INBOUND ID** – When processing Inbound Loops, this options automatically uses the next available one (without displaying it).
  - **SHOW LOOPING ID TEXT** – This selection displays *all* the stated information about the Loop, including the ID number, truck description, or any related text.

# SECTION 12: SERVICE & MAINTENANCE

## 12.1. Basic Troubleshooting

ERROR CONDITION(S)	SOLUTION(S)
<b>CHECK THAT SCALE IS EMPTY .</b> If Scale is empty, Call for Service. Load Cell(s) bad.	<b>A large amount of weight has been zeroed.</b> –Press <b>OK</b> and continue weighing. –Possible load cell damage, check load cells
<b>LOAD CELL FAILURE (S)</b> Flashing and displays "-- -- -- --"	<b>Check cells</b> –Access the <b>Load Cell Diagnostics Menu</b> to verify the load cell status. –Count stability or change of counts. –Contact the local service for further trouble-shooting.
<b>SC CELLS FOUND NONE</b>	<b>Possible damaged load cell cable.</b> –Defective Analog Interface Module.
<b>INTERR</b>	<b>System Error.</b> –Restore Backup, if possible to recover. –Otherwise, replace the PCB Assembly Base Board (33143).
<b>POWER SUPPLY ERROR: AC OUTPUT OPEN</b>	<b>Check home run cable for cuts</b>
<b>COMMUNICATION ERROR</b>	<b>Can be caused by numerous transmission problems, including bad Load Cell, faulty cable, conflicting programming, etc.</b>
<b>CELL 1 OUT OF RANGE</b>	<b>Possible bad load cell</b> <b>Possible load cell cable issue</b> <b>Normal condition after board replacement</b> – Reconfigure and recalibrate
<b>ASC CARD DOES NOT MATCH UNIT, RECONFIGURE</b>	<b>Normal condition after board replacement.</b> –Reconfigure and recalibrate




## 12.2. Replacing the Analog Interface PCB Assembly (30997)

### NECESSARY ASSEMBLY TOOLS

- ✓ Phillips screwdriver
- ✓ Needle nose pliers
- ✓ Anti-Static Wrist Band

Follow these steps to replace an Analog Interface PCB Assembly (ASC).

1. Unplug the Instrument from all external power.
2. Remove the screws of the outer instrument case and pull it off, setting it aside.
3. Unplug the Terminal Connector Plug from the non-functioning Analog Interface Assembly.
4. Pull away the security tabs on each side mounting peg and remove the defective Analog Interface Assembly.
5. Slide the new Analog Interface Assembly down onto the mounting pegs, inserting it in the two (2) **J6** sockets of the Base Board. Snap the mounting peg tabs into place on the new Analog Interface Assembly.
  - This will be installed in the same location as where the defective Analog Interface Assembly was removed.
6. Be certain the load cell wiring is according to the lower-right image.
7. Reassemble the Instrument case, fastening it together with the screws.
8. Apply power to the instrument.
9. Recalibrate the instrument.




**NOTE:** Instrument may indicate **CELL 1 OUT OF RANGE** or **ASC CARD DOES NOT MATCH, RECONFIGURE** This is normal when replacing the ASC.



## 12.3. Replacing the Keypad (32060) and Display Assembly (34291C)

Follow these steps to replace the Front Panel Keypad Assembly.

1. Remove all external power from the Instrument.
2. Remove the fastening screws on the case.
3. Unplug the Keypad Assembly from **Terminal J14** of the Base Board Assembly.
4. Remove the screws that fasten the Instrument Keypad (Assembly) to the Instrument frame.
5. Turn the Assembly over, then unplug the Power, Communications and Grounding Cables from the LED Display Assembly.
6. Remove the nuts and washers that fasten the LED Display to the Keyboard Assembly.
7. Replace the defective component(s).
8. Reassemble the new Keypad Assembly exactly as the defective one was taken apart.
9. Replace the Instrument case, fastening it together with the screws.
10. Turn on and test the instrument.





## 12.4. Base Board PCB Assembly (33143) Replacement

1. Remove all external power from the Instrument.
2. Unscrew the fasteners on each side of the case.
3. Unscrew the fastening screws from the defective Base Board Assembly, lifting it out carefully.
4. Install the new Base Board PCB Assembly, securing it with the screws.
5. Turn ON the **SW2-2** switch.
6. Replace the Instrument case, fastening it together with the screws.
7. Power-up the instrument.
8. When the Instrument displays **FLASH?**, and then scrolls the part number, press the **DOWN** arrow once to select **YES**, then press **ENTER**.
  - Numerous messages display during the boot-up. **LEAVE ALL THE KEYS ALONE!**
9. When **Instrument Type** displays, press the **UP/DOWN** arrows to select **FB6001**, then press **ENTER**.
10. When **FORMAT SDR** displays, press the **DOWN** arrow and select **NO**, then press **ENTER**.
11. When **RUN THE PEP?** displays, press the **DOWN** arrow and select **NO**, then press **ENTER**.
12. When **SET SW2-2 TO OFF AND REBOOT** displays, power-down the Instrument.
13. Restart, then configure and calibrate the Instrument, as required.



## 12.5. Replacing the Power Supply PCB Assembly (31873)

1. Remove all external power from the Instrument.
2. Unscrew the fasteners on each side of the case.
3. Unscrew the mounting fasteners from the Power Supply PCB Assembly, lifting it out carefully.
4. Unplug the communication cable from the Analog Interface Assembly and the home run cable.
5. Install the new Power Supply PCB Assembly, securing it with the screws.
6. Plug the previously removed cables back in their original locations.
7. Replace the Instrument case, fastening it together with the screws.
8. Turn on and test the instrument.



### FINAL NOTES

With an external keyboard, while in the **Weigh Screen**, press **CTRL + ALT +SHIFT + D** to perform a **Display Sequence Test**.

- Once the test is underway, pressing **any key stops** the process.

With an external keyboard, while in the **Weigh Screen**, press **CTRL + ALT +SHIFT + R** to perform a **Relay Card Test**.

Press this again to stop it.

---

**NOTE:** Instrument may indicate **CELL 1 OUT OF RANGE** or **ASC CARD DOES NOT MATCH, RECONFIGURE** This is normal when replacing the baseboard.

---

## SECTION 13: GENERATION 2 PARTS

### 13.1. FB6001 Desktop Model (31675)


#### 13.1.1 Parts List

ITEM	PART NO.	QTY	DESCRIPTION
1	31671	1	BASE ASSY
2	31672	1	FRONT PANEL ASSY
3	31673	1	COVER
4	34327	1	FRONT PANEL ASSY WITH KEYBOARD OVERLAY
5	33143	1	PCB ASSY, BASE BOARD ASSY
6	31873	1	PCB ASSY, POWER SUPPLY
7	34291C	1	PCB ASSY, LED DISPLAY
8	32060	1	KEYBOARD, INSTRUMENT
10	30997	1	PCB ASSY, A/D CONVERTER (ASC)
11	30467	1	POWER CORD ASSY, 6 FOOT
12	32316	1	CABLE ASSY, DISPLAY
14	17534	1	CONNECTOR, LIQUID TIGHT
16	30915	1	MEMORY CARD, 2 GB MICRO SD
	33468	1	MEMORY CARD, 2 GB MICRO SD, FACTORY LOADED WITH FB6000 APPLICATION
17	14225	3	PLUG, HOLE .50 DIA
20	12103	4	FOOT
21	10902	6	MACHINE PHILIIPS SCREW 8-32 X 0.38
23	31674	2	HEX SPACER, 6-32 X 3.25 long
24	10306	2	MACHINE PHILIPS SCREW 6-32 X 0.38
26	31093	8	MACHINE PHILLIPS SCREW WITH INT LOCK WASHER
28	10201	4	LOCK EXT. TOOTH WASHWER NO. 6
29	10103	5	HEX NUT 6-32
30	10310	1	PLAIN WASHER NO. 6
33	10202	2	LOCK EXT. TOOTH WASHWER NO. 8
35	13468	4	SEALING SCREW 8-32 X 0.50
36	11495	4	PLAIN NYLON WASHER
37	29574	1	LABEL
38	32814	1	NAMEPLATE SPECIFICATION
39	29081	1	ETL MARK LABEL
40	32444	1	BACK PANEL LABEL
42	11175	1	AMPHENOL RUBBER BUSHING
43	11176	1	BUSHING
45	12083	1	LABEL, NORMAL CAPACITY
46	11193	1	LABEL, CLC / SECTIONAL CAPACITY
47	12189	2	WIRE SEAL
N/S*	15820	1	LITHIUM BATTERY
N/S*	32765	1	LABELS, KEYCAPS



\* **N/S** means **Not Shown** in the **Parts Diagram**, on the following page.  
The two (2) components that are different between **GENERATION 1** and **2** are highlighted in yellow.

### 13.1.2 Parts Diagram



## 13.2. FB6002 NEMA 4X Hostile Model (32575)

### 13.2.1 Parts List

ITEM	PART NO.	QTY	DESCRIPTION
1	52555	1	BOX ASSEMBLY
2	32552	1	STAND, INSTRUMENT
3	32546	1	BRACKET, SUPPORT
4	32547	1	BRACKET, PCB MOUNTING
5	32556	1	COVER, USB
6	32557	1	GASKET, USB
7	32548	1	BRACKET, CABLE
8	32549	2	BRACKET, HINGE
9	32550	1	BRACKET, ANGLED
10	32551	1	BRACKET, LINK
11	-	-	-
12	33143	1	PCB ASSY, BASE BOARD * *
13	31873	1	PCB ASSY, POWER SUPPLY
14	34291C	1	PCB ASSY, LED DISPLAY
15	32567	1	KEYBOARD, INSTRUMENT
16	32650	1	PCB ASSY, CONNECTOR (MAKE CABLE)
17	30997	1	PCB ASSY, A/D CONVERTER (ASC)
18	-	-	-
19	30467	1	POWER CORD ASSY, 6 FOOT
20	32620	1	CABLE ASSY, DISPLAY
21	31273	1	CABLE ASSY, USB
22	17534	2	CONNECTOR, LIQUID TIGHT
23	12342	2	O-RING
24	30915	1	MEMORY CARD, 2GB MICRO SD
	33468	1	MEMORY CARD, 2 GB MICRO SD, FACTORY LOADED WITH FB6000 APPLICATION
25	14827	1	COVER, HOLE
26	-	-	-
27	11146	3	SCREW, MACH, PH, PHIL 6-32 X .38
28	31093	13	SCREW MACH, PH, PHIL, W/ INT. LOCK WASHER 6-32 X .31
29	11075	2	SCREW, CAP, HEX HD 10-32 X .50
30	11495	2	WASHER, PLAIN NYLON NO. 10
31	11120	2	WASHER, PLAIN 1/4"
32	15745	2	KNOB
33	12621	2	WASHER, RETAINER (RUBBER)
34	11998	4	SPACER, HEX 6-32 THREADS X .50 LONG
35	32651	2	SPACER, HEX 6-32 THREADS X 2.13 LONG
36	12103	4	FOOT
37	11138	4	SCREW, MACH, PH, PHIL 8-32 X .38
38	11191	12	WASHER, LOCK, EXT. TOOTH #6
39	11102	9	NUT, HEX
40	11124	1	WASHER, PLAIN #6

### 13.2.1 Parts List, Continued


ITEM	PART NO.	QTY	DESCRIPTION
41	<b>11182</b>	3	NUT, STOP 6-32
42	-	-	-
43	-	-	-
44	<b>32562</b>	3	GASKET, TOP
45	<b>32563</b>	2	GASKET, SIDE
46	<b>32564</b>	1	GASKET, CABLE
47	<b>25355</b>	1	VENT, MEMBRANE
48	<b>25356</b>	1	VENT, NUT
49	<b>12011</b>	1	ROD, NYLON .38 O.D. X 1.00 LONG
50	-	-	-
51	-	-	-
52	-	-	-
53	<b>29574</b>	1	LABEL, ELECTRIC SHOCK HAZARD
54	<b>32558</b>	1	NAMEPLATE
55	<b>29081</b>	1	ETL MARK LABEL
56	-	-	-
57	<b>11175</b>	1	BUSHING, AMPHENOL RUBBER
58	<b>11176</b>	1	BUSHING, AMPHENOL RUBBER
59	<b>12356</b>	1	LABEL, NORMAL CAPACITY
60	<b>12083</b>	1	LABEL, NORMAL CAPACITY
61	<b>11193</b>	1	LABEL, CLC / SECTIONAL CAPACITY
62	<b>12189</b>	2	SEAL, WIRE
N/S	<b>32765</b>	1	LABELS, BLANK, GROSS PRINT, TARE PRINT
N/S	<b>15820</b>	1	LITHIUM BATTERY

\* **N/S** means **Not Shown** in the Parts Diagram on the following page.

\*\* When replacing **33143 Rev. A** or **B** with **33143 Rev. C** or **higher**, in a NEMA 4X or Panel Mount FB6000, you must also order cable **34332** (not shown)



## 13.2.2 Parts Diagram





## 13.3. FB6003 Panel Mount (32675)


### 13.3.1 Parts List

ITEM	PART NO.	QTY	DESCRIPTION
1	32659	1	BASE ASSY
2	32660	1	FRONT PANEL ASSY
3	32658	1	COVER
5	33143	1	PCB ASSY, BASE BOARD * *
6	31873	1	PCB ASSY, POWER SUPPLY
7	34291C	1	PCB ASSY, LED DISPLAY
8	32567	1	KEYBOARD, INSTRUMENT
10	30997	1	PCB ASSY, A/D CONVERTER (ASC)
11	30467	1	POWER CORD ASSY – 6 FOOT
12	32316	1	CABLE ASSY, DISPLAY
13	31273	1	CABLE ASSY, USB
14	17534	1	CONNECTOR, LIQUID TIGHT
16	30915	1	MEMORY CARD, 2 GB MICRO SD
	33468	1	MEMORY CARD, 2 GB MICRO SD, FACTORY LOADED WITH FB6000 APPLICATION
17	14225	3	PLUG, HOLE .50 DIA
19	32556	1	COVER, USB
20	32557	1	GASKET, USB
21	32677	4	GASKET, TOP
22	32678	4	GASKET, SIDE
23	11661	4	SPACER, HEX 6-32 THREADS X 1.00 LONG
26	31093	12	SCREW, MACH, PH, PHIL W/INT LOCK WASHER 6-32 X .31
28	10201	4	WASHER, LOCK, EXT. TOOTH NO. 6
29	11102	5	NUT, HEX 6-32
30	11124	1	WASHER, PLAIN #6
33	11086	8	SCREW, CAP, HEX HD 10-32 X 1.13
34	11075	2	SCREW, CAP HEX HD 10-32 X .50
35	13468	4	SCREW, SEALING 8-32 X .50
36	11495	14	WASHER, PLAIN, NYLON
37	29574	1	LABEL, ELECTRIC SHOCK HAZARD
38	32679	1	NAMEPLATE
39	29081	1	ETL MARK LABEL
40	32444	1	LABEL, BACKPANEL
42	11175	1	BUSHING, AMPHENOL RUBBER
43	11176	1	BUSHING, AMPHENOL RUBBER
45	12083	1	LABEL, NORMAL CAPACITY
46	11193	1	CLC/SECTIONAL CAPACITY LABEL
47	12189	2	SEAL, WIRE
N/S	32765	1	LABEL KEYCAPS
N/S	15820	1	LITHIUM BATTERY



- \* **N/S** means **Not Shown** in the Parts Diagram on the following page.
- \* \* When replacing **33143 Rev. A** or **B** with **33143 Rev. C** or **higher**, in a NEMA 4X or Panel Mount FB6000, you must also order cable **34332** (not shown)

### 13.3.2 Parts Diagram



**INSTRUMENT ASSY  
FB6013-INTALOGIX  
32813**



## 13.4. Optional Accessories

PART NO.	DESCRIPTION
<b>30919</b>	4-20mA Analog Kit *
<b>30920</b>	Relay PCB Assy Kit *
<b>25498</b>	Mini USB Keyboard (87 key)
<b>31036</b>	Standard USB Keyboard (104 key)
<b>15892</b>	SVP/ Uninterruptable Power Supply (USB)

\* Only one or the other of these accessories may be used in the FB6001/2/3 Series Instrument.

---

# APPENDIX I: DATA STRING OUTPUTS

---

## A. Remote Display Output

### DATA FORMAT

**<STX><A><0><SP/-><XXXXXX><ETX>**

---

### NOTES:

1. Characters denoted by X are characters 0-9.
  2. Leading zeroes are suppressed.
  3. Polarity indication for a positive value is a space (SP).
    - Negative values are not transmitted.
  4. Identifier code <4><0> = Gross weight.
    - Transmission is Gross Only.
  5. Transmission for the DEMAND Mode occurs when a carriage return (CR) HEX 0D is received.
  6. See APPENDIX V for more ID Codes.
- 

## B. Configure Output

The Continuous Computer Output is an uninitiated, unrequested output that gets transmitted at a fixed time interval.

### FAIRBANKS/TOLEDO DATA FORMAT

**<STX><A><B><C><GGGGGG><TTTTTT><CR>**

---

### Character String Description:

**STX** - Start of Text character (02 Hex)

**A** - Status Word A

**B** - Status Word B

**C** - Status Word C

**G (gross weight data)** - xxxxxx Displayed Weight : x = Weight

- 6 characters if the graduation size does not have a decimal point.

- 5 characters if the graduation size does have a decimal point.

The decimal point is not sent as part of the character string.

**T (tare weight data)** - xxxxxx Tare Value : x = Tare

- (6 characters if the graduation size does not have a decimal point.)

- (5 characters if the graduation size does have a decimal point.

The decimal point is not sent as part of the character string.

**CR** - Carriage Return Character: (0D hex)

**CS** - CheckSum Character: If enabled, this character consists of the last eight bits of the binary sum of all characters transmitted up to this checksum character.

---

## B. Configure Output, Continued

### STATUS CODE (WORD) A

Bit #	X00	X0	X	X.X	X.XX	X.XXX	X.XXXX	X.XXXXX
0	0	1	0	1	0	1	0	1
1	0	0	1	1	0	0	1	1
2	0	0	0	0	1	1	1	1

### FAIRBANKS/TOLEDO DATA FORMAT

#### INCREMENT SIZE

Bit #		Count By 1		Count by 2		Count by 5
3		1		0		1
4		0		1		1
5				Always Logic 1		
6				Always Logic 0		
7				Parity Bit		

### STATUS CODE (WORD) B

Bit #	Description			
0		Gross = 0		Net = 1
1		Positive = 0		Negative = 1
2		In Range = 0		Overcapacity = 1
3		No Motion = 0		Motion = 1
4		Lb = 0		Kg = 1
5		Always Logic 1		
6		Normal = 0		Power Up = 1
7		Parity Bit		

## B. Configure Output, Continued

### STATUS CODE (WORD) C

Bit #	Description			
0		Always Logic = 0		
1		Always Logic = 0		
2		Always Logic = 0		
3		Normal = 0		Print Switch Pushed = 1
4		Always Logic = 0		
5		Always Logic = 0		
6		Normal = 0		Keyboard Tare = 1
7		Parity Bit		

### CARDINAL 738 CONTINUOUS SCOREBOARD DATA FORMAT

**<CR><P><WWWWW>Period (.)<m><SP><u><SP><g><SP><SP><ETX>**

#### Character String Description:

**CR** – Carriage return

**P** – Polarity (+ = Positive weight, - = Negative weight)

**W** – Displayed weight

- 6 characters if the graduation size does not have a decimal point.

- 5 characters if the graduation size does have a decimal point.

**m** – Motion or o = Overload

**SP** – Space

**U** - Units (lb = pounds, kg = kilograms)

**g** – Gross or **n** = Net

**ETX** - End of text

- Leading zeros are not suppressed
- If division size has no decimal point, set the decimal to "trailing".
- If division size has a decimal point, set the decimal to "floating".

## B. Configure Output, Continued

### WEIGHTRONIX DATA FORMAT

**<SP><G><WWWWW><SP><U><U><CR><LF>**

---

#### Character String Description:

**SP** – Space

**g** – Gross or **n** = Net

**W** – Displayed weight

- 6 characters if the graduation size does not have a decimal point.
- 5 characters if the graduation size does have a decimal point.

**SP** – Space

**U** – Units (lb = pounds, kg = kilograms)

**M** – Motion

**CR** – Carriage return

**LF** – Line feed

- Leading zeros are not suppressed.
  - There is no motion character.
- 

### CONDEC CONTINUOUS DATA FORMAT

**<STX><SP><SP><WWWWW><U><G><M><CR>**

---

#### Character String Description:

**STX** – Start of Text character (02 Hex)

**SP** – Space

**SP** – Space

**W** – Displayed weight

- 6 characters if the graduation size does not have a decimal point.
- 5 characters if the graduation size does have a decimal point.

**U** – Units (L = pounds, K = kilograms)

**G** – Gross; N = Net

**M** – Motion

**CR** – Carriage return.

- Leading zeros are suppressed.
-



---

## APPENDIX II: REMOTE DISPLAY CODES FOR 20MA OUTPUT

---

CODE	UNITS	WEIGHT	SCALE #
00 – Displays all data			
40	Lbs	Gross	1
41	Lbs	Net	1
42	Lbs	Tare	1
43	Kg	Gross	1
44	Kg	Net	1
45	Kg	Tare	1

## APPENDIX III: REMOTE SERIAL COMMANDS

COMMAND	DESCRIPTION
<b>A</b>	Sets the <u>A</u> uto Tare Weight on scale.
<b>G</b>	Turns the traffic light <u>G</u> reen. — Used in Manual Mode only.
<b>LA</b>	Changes Traffic <u>L</u> ight to <b>Automatic Mode</b> .
<b>LM</b>	Changes Traffic <u>L</u> ight to <b>Manual Mode</b> .
<b>R</b>	Turns Traffic Light <u>R</u> ed. — Used in the <b>Manual Mode</b> only.
<b>Txxxxx</b>	Sets <u>T</u> are on scale — Where <b>xxxxx</b> equals the tare weight value required.
<b>U</b>	Toggles <u>U</u> nits on scale.
<b>Z</b>	<u>Z</u> eroes the scale.
<b>P</b>	<u>P</u> rints a ticket for the active scale.
<b>W</b>	<b>Demand Request</b> for a <u>W</u> eight output using <b>PC Polled</b> .

# APPENDIX IV: FB6001/02/03, GENERATION 1

## PARTS

### A. Desktop Model (31675)

#### Parts List

ITEM		QTY	PART NO.	DESCRIPTION
1		1	31671	BASE ASSY
2		1	31672	FRONT PANEL ASSY
3		1	34673	COVER
4		1	34327	FRONT PANEL ASSY WITH KEYBOARD OVERLAY
5		1	31751	PCB ASSY, BASE BOARD ASSY, INCLUDES PROCESSOR MODULE CARD (MATCHED PAIR)
6		1	31873	PCB ASSY, POWER SUPPLY
7		1	34291C	PCB ASSY, LED DISPLAY
8		1	32060	KEYBOARD, INSTRUMENT
10		1	30997	ANALOG LOADCELL INTERFACE CARD (ASC)
11		1	30467	POWER CORD ASSY, 6 FOOT
12		1	32316	CABLE ASSY, DISPLAY
14		1	17534	CONNECTOR, LIQUID TIGHT
16		1	30915	MEMORY CARD, 2 GB MICRO SD
17		3	14225	PLUG, HOLE .50 DIA
20		4	12103	FOOT
21		6	10902	MACHINE PHILIIPS SCREW 8-32 X 0.38
23		2	31674	HEX SPACER, 6-32 X 3.25 long
24		2	10306	MACHINE PHILIPS SCREW 6-32 X 0.38
26		8	31093	MACHINE PHILLIPS SCREW WITH INT LOCK WASHER
28		4	10201	LOCK EXT. TOOTH WASHWER NO. 6
29		5	10103	HEX NUT 6-32
30		1	10310	PLAIN WASHER NO. 6
33		2	10202	LOCK EXT. TOOTH WASHWER NO. 8
35		4	13468	SEALING SCREW 8-32 X 0.50
36		4	11495	PLAIN NYLON WASHER
37		1	29574	LABEL
38		1	32062	NAMEPLATE SPECIFICATION
39		1	29081	ETL MARK LABEL
40		1	32444	BACK PANEL LABEL
42		1	11175	AMPHENOL RUBBER BUSHING
43		1	11176	AMPHENOL RUBBER BUSHING
44		1	12356	LABEL, NORMAL CAPACITY
45		1	12083	LABEL, NORMAL CAPACITY
46		1	11193	LABEL, CLC / SECTIONAL CAPACITY
47		2	12189	WIRE SEAL




N/S		1	15820	LITHIUM BATTERY
N/S		1	32765	LABELS – BLANK, GROSS PRINT, TARE PRINT

\* **N/S** means the item is **Not S**hown.

---

**NOTE:** The **Base Board Assy** is compatible with both generations of Instruments.

- It is preferable to use the newest PCB whenever possible.
-



REFERENCE  
LOAD CELL CONNECTIONS

TB1-1	(-) EXC
TB1-2	(-) SENSE
TB1-3	(+) EXC
TB1-4	(+) SENSE
TB1-5	SHIELD
TB1-6	(+) SIG
TB1-7	(-) SIG
TB1-8	GND
TB1-9	GND
TB1-10	GND

INSTRUMENT ASSY  
FB6001-ANALOG  
31675

## B. FB6002 NEMA 4X Hostile Model (32575)

### Parts List

ITEM	PART NO.	QTY	DESCRIPTION
1	52555	1	BOX ASSEMBLY
2	32552	1	STAND, INSTRUMENT
3	32546	1	BRACKET, SUPPORT
4	32547	1	BRACKET, PCB MOUNTING
5	32556	1	COVER, USB
6	32557	1	GASKET, USB
7	32548	1	BRACKET, CABLE
8	32549	2	BRACKET, HINGED
9	32550	1	BRACKET, ANGLED
10	32551	1	BRACKET, LINK
12	31751	1	PCB ASSY, BASE BOARD INCLUDES PROCESSOR MODULE CARD (MATCHED PAIR)
13	31873	1	PCB ASSY, POWER SUPPLY
14	34291C	1	PCB ASSY, LED DISPLAY
15	32567	1	KEYBOARD, INSTRUMENT
16	32650	1	PCB ASSY, CONNECTOR (MAKE CABLE)
17	30997	1	ANALOG LOAD CELL INTERFACE CARD (ASC)
19	30467	1	POWER CORD ASSY, 6 FOOT
20	32620	1	CABLE ASSY, DISPLAY 16"
21	31273	1	CABLE ASSY, USB
22	17534	2	CONNECTOR, LIQUID TIGHT
23	12342	2	O-RING
24	30915	1	MEMORY CARD, 2GB MICRO SD
25	14827	1	COVER, HOLE
27	11146	3	SCREW, MACH, PH, PHIL 6-32 X .38
28	31093	13	SCREW MACH, PH, PHIL, W/ INT. LOCK WASHER 6-32 X .31
29	11075	2	SCREW, CAP, HEX HD 10-32 X .50
30	11495	2	WASHER, PLAIN NYLON NO. 10
31	11120	2	WASHER, PLAIN 1/4"
32	15745	2	KNOB
33	12621	2	WASHER, RETAINER (RUBBER)
34	11998	4	SPACER, HEX 6-32 THREADS X .50 LONG
35	32651	2	SPACER, HEX 6-32 THREADS X 2.13 LONG
36	12103	4	FOOT
37	11138	4	SCREW, MACH, PH, PHIL 8-32 X .38
38	11191	12	WASHER, LOCK, EXT. TOOTH #6
N/S	15820	1	LITHIUM BATTERY

\* N/S means the item is Not Shown.

**NOTE:** The **Base Board Assy** is compatible with generations of Instruments.


- It is preferable to use the newest PCB whenever possible.

**Parts List, Continued**

ITEM	PART NO.	QTY	DESCRIPTION
39	11102	9	NUT, HEX
40	11124	1	WASHER, PLAIN #6
41	11182	3	NUT, STOP 6-32
44	32562	3	GASKET, TOP
45	32563	2	GASKET, SIDE
46	32564	1	GASKET, CABLE
47	25355	1	VENT, MEMBRANE
48	25356	1	VENT, NUT
49	12011	1	ROD, NYLON .38 O.D. X 1.00 LONG
53	29574	1	LABEL
54	32558	1	NAMEPLATE SPECIFICATION
55	29081	1	ETL MARK LABEL
57	11175	1	BUSHING, AMPHENOL RUBBER
58	11176	1	BUSHING, AMPHENOL RUBBER
59	12356	1	LABEL, NORMAL CAPACITY
60	12083	1	LABEL, NORMAL CAPACITY
61	11193	1	LABEL, CLC / SECTIONAL CAPACITY
62	12189	2	SEAL, WIRE
N/S	32765	1	LABELS, BLANK, GROSS PRINT, TARE PRINT

\* **N/S** means the item is **Not Shown**.

## Parts Diagram







## C. FB6003 Panel Mount (32675)

### Parts List

ITEM	PART NO.	QTY	DESCRIPTION
1	32659	1	BASE ASSY
2	32660	1	FRONT PANEL ASSY
3	32658	1	COVER
4	-	-	-
5	31751	1	PCB ASSY, BASE BOARD
6	31873	1	PCB ASSY, POWER SUPPLY
7	34291C	1	PCB ASSY, LED DISPLAY
8	32567	1	KEYPAD OVERLAY
9	34327	1	FRONT PANEL ASSY WITH KEYPAD OVERLAY – (INCLUDES PART #32660 & 32567)
10	30997	1	ANALOG LOAD CELL INTERFACE CARD (ASC)
11	30467	1	POWER CORD ASSY – 6 FOOT
12	32316	1	CABLE ASSY, DISPLAY
13	31273	1	CABLE ASSY, USB
14	17534	1	CONNECTOR, LIQUID TIGHT
15	-	-	-
16	30915	1	MEMORY CARD, 2 GB MICRO SD
17	14225	3	PLUG, HOLE .50 DIA
18	-	-	-
19	32556	1	COVER, USB
20	32557	1	GASKET, USB
21	32677	4	GASKET, TOP
22	32678	4	GASKET, SIDE
23	11661	4	SPACER, HEX 6-32 THREADS X 1.00 LONG
24	-	-	-
25	-	-	-
26	31093	12	SCREW, MACH, PH, PHIL W/INT LOCK WASHER 6-32 X .31
28	10201	4	WASHER, LOCK, EXT. TOOTH NO. 6
29	11102	5	NUT, HEX 6-32
30	11124	1	WASHER, PLAIN #6
31	-	-	-
32	-	-	-
33	11086	8	SCREW, CAP, HEX HD 10-32 X 1.13
34	11075	2	SCREW, CAP HEX HD 10-32 X .50
35	13468	4	SCREW, SEALING 8-32 X .50
36	11495	14	WASHER, PLAIN, NYLON
37	29574	1	LABEL, ELECTRIC SHOCK HAZARD
38	32679	1	NAMEPLATE SPECIFICATION
39	29081	1	ETL MARK LABEL
40	32444	1	LABEL, BACKPANEL
42	11175	1	BUSHING, AMPHENOL RUBBER
43	11176	1	BUSHING, AMPHENOL RUBBER
44	12356	1	LABEL, NORMAL CAPACITY
45	12083	1	LABEL, NORMAL CAPACITY
46	11193	1	CLC/SECTIONAL CAPACITY LABEL


47	12189	2	SEAL, WIRE
N/S	32765	1	LABELS
N/S	15820	1	LITHIUM BATTERY

\* N/S means the item is **Not Shown**.

**NOTE:** The **Base Board Assy** is compatible with both generations of Instruments.

- It is preferable to use the newest PCB whenever possible.

## Parts Diagram



---

# SECTION 14: APPENDIX V: CONNECTING TO THE FB60XX VIA ETHERNET

---

## *Connecting via the Web Utility using an Ethernet crossover cable*

---

**NOTE:** If you are not using a keyboard and mouse on your PC or if you are using a Tablet, touch and hold will act as a 'Right Click'.

---

### **To access the current IP address of the FB60XX:**

1. Login to the FB60XX
2. Scroll *down* to **CONFIGURATION**.  
Press ENTER
3. Scroll *up* to **NETWORK**  
Press ENTER
4. Use **DHCP?** is displayed.  
Press ENTER  
Depending on how the FB60XX has been configured **DHCP** or **STATIC** will display. Follow the instructions below for **DHCP** or **STATIC**:

### ***If DHCP is displayed...***

5. Scroll down to **STATIC** and press ENTER:
6. Use **DHCP?** is displayed.  
Scroll down to **STATIC IP** and press ENTER
7. **IP ADDRESS** is displayed  
Enter the IP ADDRESS as:  
**192.168.100.XXX** and press ENTER  
XXX must be **greater** than 001
8. **IP ADDRESS** is displayed and press ENTER
9. Scroll *down* to **NETMASK** and press ENTER  
Enter the **NETMASK** as:  
**255.255.255.000** and press ENTER
10. Scroll *down* to **GATEWAY** and press ENTER  
Enter the **GATEWAY** as:  
**192.168.100.001** and press ENTER

11. Scroll down to **PRIMARY DNS** and press ENTER  
Enter the **PRIMARY DNS** as:  
**008.008.008.008** and press ENTER
12. Scroll down to **APPLY CHANGES**  
Scroll down to **YES** and press ENTER
13. Press the **RED** Traffic light button twice to return to the weigh screen


### ***If STATIC is displayed...***

5. Press ENTER
6. **IP ADDRESS** is displayed and press ENTER
7. The FB60XX IP address is displayed  
**XXX.XXX.XXX.XXX**
8. Use the right arrow to scroll to see the whole IP address
9. Write down the IP address


### **Procedure:**

1. **FOR TABLET USERS ONLY** - Plug in your USB to Ethernet adaptor  
a. If you are using a PC with **Windows 8**, proceed directly to step 2


2. Right click on the **Start menu** (Windows Logo)



3. Click on **Network Connections**




4. Right click on **Ethernet Connection** for the adapter (it may state **ETHERNET 2**)



5. Click on **Properties**




6. Click on internet protocol **Ver. 4**  
**TCP/IP 4**



7. Then click on **Properties**


8. Click **Use the following IP address:**



☐ Obtain an IP address automatically  
☒ Use the following IP address:

IP address:   
 Subnet mask:   
 Default gateway:


9. Enter the IP address of the instrument here, but make the last number in the IP address **at least 1 number higher** than the instrument.



☒ Use the following IP address:

IP address:   
 Subnet mask:   
 Default gateway:

10. Click in the Subnet Mask box and enter 255.255.255.0 as shown.



☒ Use the following IP address:

IP address:   
 Subnet mask:   
 Default gateway:


11. Click in the Default Gateway box and enter 192.168.100.001 as shown.



☒ Use the following IP address:

IP address:   
 Subnet mask:   
 Default gateway:

12. Click in the Preferred DNS server box and enter 008.008.008.008 as shown.



☒ Use the following DNS server addresses:


Preferred DNS server:   
 Alternate DNS server:

13. Click **OK** close this window.

14. Connect your PC or Tablet to the instrument using the ethernet cable.

15. Open your browser (Internet Explorer, Chrome or FireFox)

16. Enter the IP address of the instrument in the browser address bar



*WHEN USING CERTAIN BROWSERS, YOU MAY NEED TO INCLUDE LEADING ZEROS WHEN ENTERING THE IP ADDRESS.*



**FAIRBANKS SCALES, INC.**

821 Locust

Kansas City, MO 64106

[www.fairbanks.com](http://www.fairbanks.com)

## **FB6000 Series Instrumentation**

**FB6001 In/Out/GTN Analog Desktop  
instrument**

**FB6002 In/Out/GTN Analog NEMA 4X Wall  
Mount Instrument**