



WI-127 Indicator Service Manual

Table of Contents

Table of Contents	
Specifications	4
Introduction	5
Error Messages	5
Service Menu Structure	6
Moving Through Menus	6
Accessing the Menu	7
Exiting the Menu	7
Using the Service Menu	8
About Menu	8
Audit Menu	9
Test Menu	
Setup Menu	
Top Level of 110 Menu	
110 Adjust Menu	
110 Scale Menu	
Tips on setting up and using the Harmonizer [®] filtering	
110 Options Menu	
110 Serial Menu	
110 Seal Menu	
Top Level of 127 Menu	
127 Adjust Menu	
127 Scale Menu	26
Tips on setting up and using the Harmonizer [®] filtering	30
127 Options Menu	31
127 Serial Menu	35
127 BCD Out Menu	
127 Analog Menu	
127 Outputs Menu	37
127 Inputs Menu	38
127 Seal Menu	30
127 Transfer Menu	40
Reset Menu / Master Clear	
Calibrating the WL127	
Entering the Calibration Manu	
Weight Calibration	
Count Calibration	
Adding Calibration Deinte	
Deleting Calibration Points	
Customizing the Serial Output	
Dredefined Drint Layoute	
ASCII Strings	
Step by Step Instructions	
Step by Step Instituctions	
Creating AGOII Stillings	
Creating Croups	
Creating Groups	
Diodocasi	
Aulustinu	
Using inputs and Outputs on the WI-127	
wi-121 Disassembly and Reassembly	
Installing Option Caros	
Inbound/Outbound (GTN) Soltware	
In-Iniotion Software	
recinical illustrations	
Service Menu	100-102

WI-127 Specifications*

Power requirements:

115 Volts AC, +10% to -15% @ 0.3Amp maximum 230 Volts AC, +10% to -15% @ 0.15 AMP maximum 50/60 Hz

Excitation: 10 Volts DC

Supports up to twelve 350-ohm weight sensors

Operational keys:

Five yellow standard keys: Zero, Tare, Print, Units, Select Three function keys: F1, F2, F3 Numeric keys: 0-9

Operational annunciators:

Gross, Tare, Net, Print, Zero, Motion Under, Accept, Over, Cutoff, ID, Three units of measure

Display: Eight digit, seven segment, 0. 8-inch high LED

Display rate: Selectable (1, 2, 5, 10)

Analog to digital conversion rate: 60 times per second

Unit of measure:

Three, independently programmable: Pounds, kilograms, grams, ounces, ton, tonne, custom, Off

Capacity selections:

999,999 with decimal located from zero to five places

Incremental selections:

Multiples and sub-multiples of 1, 2, 5

Programmable selections:

Zero range, motion detection, automatic zero tracking, five-point linearization.

Time and date/RAM:

Battery backed up real time clock and RAM are standard

Internal resolution: 6,291,456 counts per mV/V per sec.

Harmonizer[™] digital filtering:

Fully programmable to ignore noise and vibration

Standard inputs:

Seven configurable logic level inputs for functions such as PB tare, print, zero, units, select, gross and net.

Standard outputs:

Three outputs, open collector design Relay power supply, 24 VDC at 150mA Bi-directional serial port (RS-232 or RS-422/485 or 20mA current loop)

Serial Command Inputs

Programmable serial response to ASCII character input

Self diagnostics:

Display, keys, inputs, outputs, serial port, A to D converter, loadcell output display, voltages

Circuitry protection: RFI, EMI, and ESD protection

Options:

Two additional serial ports BCD parallel 10 cutoffs Analog output 0-5, 0-10 volts 1-5, 4-20, 10-50 mA

Operating temperature:

-40 to 140° F (-40 to 60° C) 100% relative humidity including washdown

Enclosure: NEMA 4X stainless steel enclosure

Dimensions:

12" W x 8" H x 4" D (without mounting bracket) 12.3" W x 11.0" H x 5.3" D (with mounting bracket)

Weight: 12.5 lb, 5.7 kg

Agencies:

NTEP Class III/IIIL:10,000d, COC #96-140.A1 Consumer and Corporate Affairs, Canada, #AM-5167 UL/CUL/CSA FCC Class A

Introduction

When installing the WI-127, the power socket-outlet must be nearby and easily accessible.



This equipment uses double pole/neutral fusing

This manual covers the service issues for the WI-127 indicator. The manual is divided into the following sections:

- Introduction
- Error Messages
- Service Menu Structure
- Using the Service Menu
- About Menu
- <u>Audit</u>Menu
- <u>Test</u>Menu
- <u>Setup</u>Menu
- Reset Menu
- Calibrating the WI-127
- Customizing the Serial Output
- WI-127 Service Menu
- Technical Illustrations

Main sections of this manual are set apart by the large black bar as seen above. Subsections are labeled in the left column of each page. Notes, cautions and warnings are also listed in the left hand column.

If you find inaccuracies in this manual or have suggestions on how to improve it, please call 507-238-4461 or 800-368-2039 and ask for a technical writer.

Error Messages

The following are displays you may see if problems occur or if invalid operations are attempted with your WI-127:

Display	Description
O. LoAd	Overrange weight.
	Underrange weight.
	Recovering from lockup or out of range condition.
Loc' up	A-D converter is not functioning.
L.C. Error	A-D converter subjected to an input signal beyond ± 5.0000 mV/V
Can't	The unit cannot perform a function. Displayed only while key is held down.
Flashing *	Corrupted data in the reset menus. See the <i>Reset Menu/</i> <i>Master Clear</i> section. (* = RESET, SETUP, or CAL)
Sealed	Displayed while a key is pressed when attempting to modify a sealed selection without edit privileges.

Auto. 0
Lo. Volt
1 Busy

Displayed while waiting for a stable, valid weight to use as a zero reference on power-up.

Displayed when input voltage to excitation regulator drops below 10.5 VDC. Will clear when input voltage rises above 11.5 VDC.

Displayed when the ready/busy handshake has exceeded its time out limit. Default is 2 seconds. This can also apply to optional 2nd and 3rd serial ports.

Service Menu Structure



Accessing the Service Menu

Caution

Do not break any seal on the indicator unless absolutely necessary. This may cause the need for the indicator to be recertified and resealed. Entering the service menu disables all outputs and inputs, disables/stops all serial output, B.C.D. output and analog output.

To enter the service menu structure, key in the default password (127) then press and hold the **ESCAPE** key for two seconds. If you do not know the password you may remove the nylon plug on the back of the WI-127 and press the SEAL switch inside. If you do not want to make any changes in the service menu but want to view the items, enter the menu without keying in a password.

If your password has been changed since leaving the factory, enter your current password instead of the default.

The display should show *About*. This is the first item in the menu structure. The following section explains the menu items.

Exiting the Service Menu

If you do not press **SELECT** with **Save** displayed, none of your configuration changes will be saved. You may exit the service menu and return to weight display mode at any time by pressing **SELECT**.

If you made changes to the menu, the indicator will display **SAVE** (asking you if you wish to save your changes) before returning directly to weight display mode.



To exit and save menu changes:

1. With *SAVE* displayed, press **SELECT**...

To exit without saving changes:

- 1a. With **SAVE** displayed, press
- MENU... OR
- 1b. With SAVE displayed, press ESCAPE...

2. Press SELECT...

The indicator will return to weight display mode and your changes are saved.

no SAVE is displayed.

Indicator returns to weight display mode.

Indicator returns to weight display mode without saving any changes.

Using the Service Menu

The complete service menu structure can be viewed on the last fold out pages in the back of this manual.

To exit back to normal weighing mode, press the SELECT key and save changes as needed by pressing ENTER with SAVE? displayed. Figures 2 through 19 show the service menu structure in the WI-127. Following each figure are explanations for each of the service menu items.



<u>About</u> Menu	Information about the software
<u>Audit</u> Menu	Audit counters for calibration and configuration
<u>Test</u> Menu	For testing the hardware of the indicator.
<u>Setup</u> Menu	For setup of the indicator as a 127 or a 110 clone

<u>About</u> Menu



Audit menu



<u>Test</u> Menu

Figure 5 shows the <u>Test</u> menu. Use this menu to check functions of the WI-127. The description of each menu item follows Figure 5.



Figure 5 Test menu

These are the items listed in the Test menu from left to right:

Display	Press ENTER ▼ to start and stop a continuous display test. With the test stopped press the (← O or MENU) key to move backward or forward one step at a time. Press ENTER ▼ again to resume the automatic test or press ESCAPE ▲ to stop the test and return to <i>diSPLAy</i> .
Buttons	This provides a test of the keypad. The name of the key that is pressed appears on the display. If no key is pressed, <i>nOnE</i> is displayed. Press MENU ▶ to return to <i>buttonS</i> .
A to D	Press this key to see the current A to D value. The displayed resolution is 1 part in 20,000 per mV/V. This test exists so that the offset and gain of the electronics can be checked. The offset is initially set to the nominal offset of the electronics, but you can press the ZERO key to establish the actual offset, allowing the gain to be evaluated.

	Loadcell	With <i>LOAdCELL</i> displayed, press the ENTER → key to see a live display of the current counts coming from the loadcell. <i>400400</i> is the example shown in Figure 5. Press the UNITS key to toggle between the counts display mode and the mV/V display, which appears in this format: 2.00200 . This stands for 2.002 mV/V. The decimal indicates you are looking at mV/V and not current counts.
	Serial	This item accesses the internal port serial tests. With <i>SEriAL</i> displayed, press the ENTER ✓ key. <i>Port 1</i> is displayed. This is always the internal serial port. When the optional serial boards are installed in the same stack, port two is always on the bottom. When installed in different stacks (side by side), port two is always closest to the power supply. Press the ◀ ◀ or MENU ▶ key to select the port you wish to test.
To exit back to normal weigh- ing mode, press the SELECT key and save changes as needed by pressing ENTER with SAVE? displayed.	Ready/ Busy	With the port you want to test displayed, press the ENTER key. <i>rEAdy</i> or <i>bUSy</i> is displayed telling you if the hardware input line is ready or busy. This is useful in tracking down serial output problems.
	Loop/ No Loop	Press the MENU key to see the Loop - No Loop test. Connect the transmit line to the receive line at some point in the cabling. The WI-127 checks if it receives the same characters that it transmits. If it can, <i>LOOP</i> is displayed. If it cannot, <i>no</i> <i>LOOP</i> is displayed. This is useful in isolating serial output problems to the WI-127, cable, or connected device by looping back at the corresponding points.
	Outputs	This test allows you to check the operation of the onboard and optional outputs. The onboard outputs are copies of the first three outputs on the optional I/O board when it is installed.
	Sequence	This is the first item in the Outputs submenu. Press the ENTER ✓ key to test the outputs. Each output is turned on and off sequentially. The display will show <i>Out. nn</i> . The <i>nn</i> being the number of the output being tested. The outputs will sequence every half second. Press the ENTER ✓ or ESCAPE ▲ key to end the test and return to the <i>SEqUENCE</i> display.
With motors connected to external circuits, this is a good way to test your hardware.	Out 1-3 or (Out 1-8) (Out 9-16)	This is the second item in the Outputs submenu. This allows you to enable or disable any of the outputs 1-3 (1-16 if the optional boards are installed). Press the ENTER ▼ key to see the display of the outputs status.
		The screen has 0s and 1s displayed in this format: 00.010000 . In this example, output #4 is active. The zeros and ones represent the status of each output. A 1 means it is activated and a 0 means it is deactivated. The left digit is output #1 or #9.
		To change the status of an output, press the ◀ ← or MENU ▶ key to move the decimal point to the right of the output you want to change. Press the ENTER ▼ key to toggle the output from one status to the other.
		Press the ESCAPE A key to exit the test. The outputs remain as selected until you exit the <u>Test</u> menu. Returning to the normal weigh mode returns the control of the outputs to the cutoff values.

This allows you to test your remote push button switches (ie. remote zero, print, etc.)	Inputs	This test allows you to check the operation of the onboard and optional inputs. Press the ENTER ▼ key to access the submenu.
	Standard	This submenu item lets you check the status of the onboard inputs. In this example, 1000100 , inputs #1 and #5 are active. The inputs are ordered 1-8 from left to right. A 1 means activated and a 0 means deactivated.
		As you view the inputs, #8 is actually a flag that is dependent on the states of inputs 6 and 7. Input 6 resets flag #8 to a false 0. Input 7 sets flag #8 to a true 1. Input 8 does not terminate at a connector.
	Option	This menu item is available only if the option board is installed. It works the same way as the Standard example above.
	Voltages	The submenu under <i>VoltAgES</i> lets you see the power supply voltages. The voltage readings are updated 2 times per second.
	13 volts	This test displays the unregulated weight sensor excitation power supply voltage. If the voltage drops below 10.5 the display will show <i>Lo. Volt</i> . The error condition will not clear until voltage reaches 11.5.
	- 5 volts	This test displays the -5 volt excitation voltage.
	10 volts	This test displays the unregulated 5 volt logic supply voltage.
	24 volts	This test display shows the relay supply voltage. If this voltage drops too far it may not be possible to activate certain relays. Nominal level for this power supply voltage is 22.8.

<u>etup</u> Menu



Top Level of 110 Menu	The top leve	I menu items of the 110 menu are shown in Figure 7.
	A Fig	110 djust Scale Options Serial Seal See See See See See gure 8 Figure 9 Figure 10 Figure 11 Figure 12
		Figure 7 110 Menu
	Adjust	Use this submenu for calibration of the scale.
To exit back to normal weigh- ing mode, press the SELECT key and save changes as needed by pressing ENTER with SAVE ? displayed.	Scale	Use this submenu for configuring units, capacity, divisions, zero, stability, A.Z.T., update rate, averaging and filtering.
	Options	Use this submenu to configure the buttons on the front panel.
	Serial	Use this submenu to setup the baud rate, data bits, parity and stops of the serial ports.
	Seal	Use this submenu to setup a custom password and to set

110 Adjust Menu

Be sure the correct capacity and division sizes have been selected before calibrating.

Press the **ZERO** key to delete a displayed calibration point.

Below is the 110 Adjust submenu. If the factory calibration has become corrupt, the word *AdJUSt* will flash on and off. You may use the indicator under this condition by calibrating with real weights, not by entering previously recorded count values. See note at left.

the sealing choices for the unit.



13

	Points	See the section <i>Calibrating the WI-127</i> for indepth instructions.
To exit back to normal weigh- ing mode, press the SELECT key and save changes as needed by pressing ENTER with SAVE ? displayed.		In this submenu you may view, edit, insert or delete calibra- tion points in a list. The WI-127 allows calibration using up to five calibration points.
		The WI-127 comes from the factory with two calibration points: 0 and 5000 lbs. (These weight values may differ depending on your unit of measure.)
		These points may be calibrated in two ways: 1) by standard weight calibration or 2) by entering count values. Counts are calibrated to a 1 mV/V signal from the factory.
	A 0	When you access the Points submenu the first item is A 0 . This stands for A pply 0 weight. This is the zero calibration point.
	A 5000	The next calibration point in the default list is the calibration point for full capacity. Your indicator is factory calibrated to 5000 lbs (1 mV/V). You may keep this value or key in a new value for full capacity.
	Deadload	Lets you view the count value for the current deadload. Press the UNITS key to change the display to mV/V.
Reset is very helpful if you get	Display	Shows the weight display without having to exit the menus. An example of what is shown— <i>d</i> 5000 . The <i>d</i> indicates a live display of weight and reminds you that the unit is in calibration. The value you see depends on the selected unit of measure, the calibration and the weight applied. The UNITS key works in this mode.
confused and would like to put working values back in the WI-127 calibration menu.	Reset	Use this item to reset the calibration points to factory default values. If you choose yES the values are set to 0 lbs at 0 mV/V and 5000 lbs at 1 mV/V.

110 Scale Menu

The next item in the 110 menu structure is *Scale*. In this group of submenus you set scale related parameters. Figure 9 shows the Scale menu.



Figure 9 110 Scale menu

Units	This submenu lets you select what unit of measure will be assigned to the three annunciators on the front panel.
Unit 1	The unit of measure you choose for this item will be as- signed to the annunciator labeled "lb" on the front panel. You can choose from the following list of units of measure:
	Pounds = pounds 1000g = kilograms g = grams Oz = ounces Tons = tons Tonnes = tonnes (metric tons) None = no unit of measure is assigned.
Unit 2	The unit of measure you choose for this item will be as- signed to the annunciator labeled "kg" on the front panel. You can choose a unit of measure from the same list as above.
Unit 3	The unit of measure you choose for this item will be as- signed to the annunciator labeled "oz" on the front panel. You can choose a unit of measure from the same list as above.

Don't forget to re-calibrate your system after you change capacity.	Capacity	The next scale menu item is capacity. Use this item to view or edit the capacity of the unit in any unit of measure configured under Units . With <i>CAPACity</i> displayed, press the ENTER → key. The current capacity is displayed. Use the numeric keypad to key in a new value and press ENTER → to accept it and return to the <i>CAPACity</i> display. You can view the capacity in other units of measure by pressing the UNITS key.
If you change capacity or division size in any unit of measure, this automatically changes all the other enabled units of measure as well. If you want leading zeroes in your printouts or broadcast and autosend information, key in	Division	This selection allows you to view and edit the division size of the enabled units of measure. You can enter any division size. The indicator will use the closest division size for each enabled unit of measure (1, 2 or 5 divisions). You can view the division in other units of measure by pressing the UNITS key. The number is stored in the resolution you enter but is displayed in the closest valid division size.
leading zeroes when setting division size.	Zero	Use this menu item to set pushbutton zero related options. Zero range is specified as a percent of capacity referenced from the deadload. There are two items in the submenu: - <i>Range</i> and <i>Range</i> .
	-Range	Use this to set the negative range (below reference zero) within which the unit may be zeroed. 100% is the default value.
	Range	Use this to set the positive range (above reference zero) within which the unit may be zeroed. 100% is the default value.
To exit back to normal weigh- ing mode, press the SELECT key and save changes as	Stable	Use this menu item to set the motion detection parameters. There are two items in the submenu: <i>Range</i> and <i>Display</i> .
needed by pressing ENTER with SAVE? displayed.	Range	Specifies the number of \pm divisions for the motion window. Use the numeric keypad to enter appropriate value. Most common settings are 0.5, 1, or 3 divisions.
	Display	Choose ON to if you want the display on while the indicator senses scale motion. Choose OFF to blank the display while there is scale motion.
	A.Z.T.	This stands for Automatic Zero Tracking. <i>Range</i> is the only item in this submenu.
	Range	Use this item to set the range within which the indicator will automatically adjust the zero balance towards zero. Use the numeric keypad to enter appropriate value. Most common settings are 0.5, 1, or 3 divisions.
	Update	Use this to set the display update rate from these choices: 1 One update per second. 2 Two updates per second 5 Five updates per second 10 Ten updates per second.

	Average	The next menu item is <i>Average</i> . This can be entered in one of two methods: <i>x disp.</i> or <i>x a-ds</i> . Press the UNITS key to switch back and forth between the two choices.
		The suggested method of setting the average is by picking a value for <i>x disp</i> . Doing this insures that a multiple of the display rate is always being averaged. This results in a steadier weight display.
		Use <i>x a-ds</i> if you need an exact number of A-D conversions for your particular situation.
Changing the update rate changes the x disp. or x a-ds value based on the new update rate.		<i>x disp. 1 disp.</i> is the default display when you access this item. <i>x</i> is the number of display interval(s) over which the data is internally averaged prior to being displayed. The number of A-Ds averaged is based on the display update rate you set under the <i>Update</i> menu item. Default is <i>1 disp</i> .
		<i>x a-ds x</i> is the number of a-d conversions to average for each display.
		The A-D weight conversion happens 60 times per second in this indicator. <i>Average</i> is the number of conversions you want to average for the weight that is displayed. Default is <i>12 a-ds</i> when <i>Update</i> is at default of 5 and <i>x disp.</i> is at default value of 1.
Harmonizer [®] filter is used only if the average value will not filter out the vibration by itself.	Filter	Use this menu item to configure the Harmonizer [®] filter settings. <i>Constant</i> and <i>ThreshId</i> are the two items you can configure in this submenu.
	Constant	This number represents the amount of filtering. Choose a setting between 1 and 10. Choose 1 for the least amount of filtering but the fastest response. Choose 10 for the most filtering but the slowest response. Choose Off to disable the Harmonizer functions and default to the lowest filtering.
Values change with unit of measure.	Threshld	This is the window, in the current unit of measure, within which weight changes are altered according to the constant. <i>10.0</i> is the default value shown in Figure 9. You should set the threshold value between 130 and 150% of the weight swings that need to be suppressed.

Tips on setting up and using the Harmonizer® filtering

To find the best settings for your filter needs, follow the steps listed below.

1. What to Do: Determine the amount of positive and negative force exerted by the vibration on the scale.

How to Do It: Set Threshld to 0.0, Constant to OFF, and Average to 1.0 A-Ds. Return to weigh mode and observe the weight swings. Record the difference between the highest and lowest displayed weight values. Add 30 to 50% to this value. This is a good starting value for the Threshld setting. Do not set your indicator to this value until told to in step 7.

2. Setting the Average to higher values increases the filtering effect.

What to Do: Set Threshld to 0.0, Constant to OFF and Average to 15.0 A-Ds. Check the stability of the scale.

How to Do It: Save changes and exit to normal weight mode. Observe the Center of Zero light. If it is on all the time your scale is stable within ¼ division. If the Center of Zero light blinks more filtering is required. Go to step 3.

- 3. Repeat step 2 but increase the Average by 15.0 A-Ds. Keep repeating steps 2 and 3 until the scale is stable or you've tried the entire range of Average (300 A-Ds). If the scale is still not stable go to step 4.
- 4. Setting the Constant to higher values increases the filtering effect.

What to Do: Set Threshld to 0.0, Constant to 1.0 and Average to 300 A-Ds. Check the stability of the scale.

How to Do It: Save changes and exit to normal weight mode. Observe the Center of Zero light. If it is on all the time your scale is stable within ¼ division. If the Center of Zero light blinks more filtering is required. Go to step 5.

- 5. Repeat step 4 but increase the Constant by 1.0. Keep repeating steps 4 and 5 until the scale is stable or you've tried the entire range of Constant (10). If the scale is still not stable, decrease your display update rate and start over at step 1 using the new, slower display rate.
- 6. After the Constant value is established you may wish to lower the Average value to improve display response time.
- 7. After a final value for Constant and Average has been set, enter the Threshld value established in step 1. If this value is too small your scale will act as if the filtering is off or not working. Increase the Threshld value until your scale stabilizes.

If the Threshld value is too high your scale will react slowly to weight changes.

When Harmonizer is properly adjusted the scale will be stable at zero and will rapidly display a stable test weight value.

The third item in the 110 menu structure is <u>Options</u>. Figure 10 shows the Options Menu. Use this menu to enable/disable and configure the buttons on the front panel.



Figure 10 110 Options menu

Select	Enables or disabled the SELECT key.		
Units	Enables or disables the UNITS key.		
Tare	This parameter enables or disables the pushbutton tare and numeric tare entry.		
PB Tare	Options under this item are Yes (allows pushbutton tare for all nonnegative values), Non-Zero (enables pushbutton tare for all nonnegative values excluding zero), and No (disables pushbutton tare).		
n Tare	Enables and disables numeric tare entry.		

Print

To exit back to normal weighing mode, press the **SELECT** key and save changes as needed by pressing ENTER with SAVE? displayed.

PB Print This item determines which layouts are sent to which ports for pushbutton print. Press ENTER - and Group is displayed. From this item you may either disable the pushbutton print option, or select a group to print. To select a group, press **ENTER** - again. Using the keypad, enter the number of the group you wish to print. To disable, press **MENU**, then **ENTER** -. The four default print groups are as follows:

	 1 = Displayed weight 2 = Gross, Tare, Net (default) 3 = Gross and Net 4 = Net and Tare.
Zero	Enables or disables the ZERO key.
User	Enables or disables the User's Menu.
F1	Enables or disables the F1 key. The default setting for this key accesses the tare registers.
F2	Enables or disables the F2 key. The default setting for this

key accesses the identification number entry. F3 Enables or disables the F3 key. The default setting for this key accesses the cutoff values.

110 Serial Menu

The fourth item in the 110 menu structure is Serial. This submenu sets up the baud rate, data bits, parity, and stops of the serial port(s). Figure 11 below outlines the Serial Menu.



Figure 11 110 Serial menu

Port 1, 2 & 3 Port 1 is the onboard serial port. Any additional boards installed are configured under Ports 2 & 3. Ports 2 & 3 show up in the Serial Menu only if additional boards are installed. Enables or disables the ready/busy input. If the ready/busy **Busy** input is enabled, you may enter a timeout period. This value determines how long a port can be busy before the indicator displays a port busy message. Baud Select a baud rate. Choices are: 9600 (default), 19200, 300, 600, 1200, 2400, 4800. Choose between 7 (default) & 8 data bits. Data Parity Choices are: No -Specifies that no parity bit is to be included. Even - Specifies that a parity bit which insures an even number of logic one bits is transmitted. (default) (7, 1or 2, even) A flashing value Odd -Specified that a parity bit which insures an odd indicates an number of logic one bits is transmitted. (7, 1 or 2, invalid combination. odd) Clear - Specified that a logic zero bit is always transmitted after the data bits (space parity). (8, 1, none) Set -Specifies that a logic one bit is always transmitted after the data bits (mark parity). (7, 2, none) Stops Select the number of stop bits. Choices are 1 or 2.

110 Seal Menu

The last item in the 110 <u>Setup</u> menu is Seal. Use this submenu to set up a custom password and to set the sealing choices for the unit. Items in the <u>Setup</u> menu (Figure 6) can be protected from unrecorded changes.

Two internal counters record changes to items in the Setup menu. View these counters under **AUDIT** in the Service menu (Figure 4). These counters cannot be reset and thus can be used by auditors or inspectors to check if changes have been made. One counter is for scale calibration items and the other for configuration items. The level of protection is set in the Seal menu. The Seal menu is shown in Figure 12.



Figure 12 110 Seal Menu

- Code No.This item allows you to enter a personalized security code
number. Digits are not shown on the display as you key
them in, so the display prompts you to enter the code
number twice.All a BlueThe two encoders in the CEAL means are All and Blue
- All & Phys. The two parameters in the SEAL menu are All and Phys. Below are explanations of the choices you can make.

ALL set to YES

Any time you access the setup menu and change any item in Table 1, the appropriate counter increments one count. Changing multiple items on one visit to the menu increments the counter only one count. It's the number of visits with changes that are counted, not the number of changes per visit.

ALL set to NO

With this setting the calibration internal counter will increment when you access the setup menu and change any calibration item in Table 1. The internal configuration counter will increment only if you change one of the configuration items in **bold** print from Table 1.

To exit back to normal weighing mode, press the SELECT key and save changes as needed by pressing ENTER with SAVE? displayed. If **PHYS.** is set to **NO**, you can still press the internal switch and have instant setup menu access and editing privileges.

Phys. set to Yes

If *Phys.* is set to *Yes*, you must remove the physical seal (rear sealing plug) of the WI-127 to access an internal switch. When you press this switch you have full editing privileges and the display shows the first item in the Service menu, *About*, without the need to enter the password.

If you enter the Service menu using the password and not the internal switch, you can change only the configuration items in Table 1 that are in normal, not **bold**, print.

PHYS set to NO

If *PHYS.* is set to *NO*, correct password entry is the only way to have editing privileges of all the items in Table 1 without breaking the physical seal. See note to left.

If the password is not entered correctly, the setup menu items can be viewed but not edited.

Calibration Items	Configuration Items
Any item in the Adjust menu	Any item in the Scale menu
	Any item in the Options menu
	Any item in the Seal menu
	Any item in the Serial menu
	Any item in the Analog menu
	Any item in the B.C.D. Out menu

Table 1Calibration and Configuration list

This is the end of the 110 section. The next section covers the 127 section of the \underline{Setup} menu.

Top Level of 127 Menu

The top level menu items of the 127 menu are shown in Figure 13.



Figure 13 127 Menu

Adjust	Use this submenu for calibration of the scale.
Scale	Use this submenu for configuring units, capacity, divisions, zero, stability, A.Z.T., update rate, averaging, filtering, and overload.
Options	Use this submenu to configure the buttons on the front panel.
Serial	Use this submenu to setup the baud rate, data bits, parity and stops of the serial ports.
B.C.D. Out	Use this submenu to configure the output of an optional B.C.D. board. This menu will not appear if the optional board is not installed.
Analog	Use this to configure the analog output option board.
Outputs	Use this to configure the WI-127's outputs.
Inputs	Use this to configure the WI-127's hardwired inputs (ie. PB Tare).
Seal	Use this submenu to setup a custom password and to set the sealing choices for the unit.
Transfer	Use this submenu to setup the WI-127 to receive or send print formats from the WI-127 downloader software package in your PC.

To exit back to normal weighing mode, press the **SELECT** key and save changes as needed by pressing **ENTER** with **SAVE**? displayed.

127 Adjust Menu

Be sure the correct capacity and division sizes have been selected before calibrating.

A step-by-step description of calibrating the WI-127 and using the Adjust menu can be found in the section titled **Calibrating the WI-127.** Below is the Adjust submenu for the 127. If the factory calibration has become corrupt, the word *AdJUSt* will flash on and off. To correct this you must send it to the factory. You may use the indicator under this condition by calibrating with real weights, not by entering previously recorded count values. See note at left.

I27 Adjust Points A 0	A 5000 End 2 or more cal. points. Cal. Counts Delete Busy 2400 No Yes d 0
	Figure 14 127 Adjust menu
Points	See the section <i>Calibrating the WI-127</i> for indepth instruc- tions.
	In this submenu you may view, edit, insert or delete calibra- tion points in a list. The WI-127 allows calibration using up to five calibration points.
	The WI-127 comes from the factory with two calibration points: 0 and 5000 lbs. (These weight values may differ depending on your unit of measure.)
	These points may be calibrated in two ways: 1) by standard weight calibration or 2) by entering count values. Counts are calibrated to a 1 mV/V signal from the factory.
A 0	When you access the Points submenu the first item is A 0 . This stands for A pply 0 weight. This is the zero calibration point.
A 500	The next calibration point in the default list is the calibration point for full capacity. Your indicator is factory calibrated to 5000 lbs (1 mV/V). You may keep this value or key in a new value for full capacity.
Deadlo	ad Lets you view the count value for the current deadload. Press the UNITS key to change the display to mV/V.
Display	Shows the weight display without having to exit the menus. An example of what is shown— <i>d</i> 5000. The <i>d</i> indicates a live display of weight and reminds you that the unit is in calibration. The value you see depends on the selected unit of measure, the calibration and the weight applied. The UNITS key works in this mode.
Reset	Use this item to reset the calibration points to factory default values. If you choose yES the values are set to 0 lbs at 0 mV/V and 5000 lbs at 1 mV/V.
Print	Use this item to print the calibration information shown in the left column from port 1 by choosing yes. These numbers can be valuable if you have an indicator failure.

Press the **ZERO** key to delete a displayed calibration point.

Reset is very helpful if you get confused and would like to put working values back in the WI-127 calibration menu.

10:39 AM	12/31/99
mV/V	16
0.00000	
2.00000	5000
	Serial No.

127 Scale Menu

The next item in the 127 menu structure is Scale. In this group of submenus you set scale related parameters. Figure 15 shows the Scale menu.



Figure 15 127 Scale menu

	Units	This submenu lets you select what unit of measure will be assigned to the three annunciators on the front panel.
	Unit 1	The unit of measure you choose for this item will be as- signed to the annunciator labeled "lb" on the front panel. You can choose from the following list of units of measure:
		Pounds = pounds 1000g = kilograms g = grams Oz = ounces Tons = tons Tonnes = tonnes (metric tons)
veigh- _ECT as FER		Other = This allows you to enter the information to create a custom unit of measure. You need to enter the ratio values for the custom unit based upon another unit of measure and a string of text to use in serial output.
		Under <i>Basis</i> choose the unit and amount upon which the custom unit is based. Under <i>Equals</i> enter the equivalent custom unit value.

To exit back to normal weighing mode, press the SELECT key and save changes as needed by pressing ENTER with SAVE? displayed.

Example 1: To create a 'stone' unit of measure, the Basis would be 14 pounds and Equals should be 1 stone. Example 2: To create an ounce unit of measure, the Basis would be 1 pound and Equals should be 16 ounces. Example 3: To create a kg unit of measure, the Basis would be 10 pounds and Equals should be 4.5359237 kilograms. Ten pounds is used so all eight digits can be entered as the *Equals* value. Under Label you create the serial label for the custom unit of measure. With the first ASCII value Refer to the ASCII character displayed you can use the keys to do the following: chart located in the section Customizing the Serial Output. ENTER keyaccepts the displayed value and returns to *Label* display. MENU key accepts the displayed value and Custom label can be a maximoves to the next ASCII character value. ESCAPE key exits the display without making a change. +/- key -Inserts a new ASCII value before the currently displayed ASCII value. Key in the ASCII value and continue by pressing another key. ZERO key deletes the currently displayed ASCII value. Continue editing, inserting, and deleting until you are done. Press **ESCAPE** • to exit the label entry. None = no unit of measure is assigned. Unit 2 The unit of measure you choose for this item will be assigned to the annunciator labeled "kg" on the front panel. You can choose a unit of measure from the same list as above. Unit 3 The unit of measure you choose for this item will be assigned to the annunciator labeled "oz" on the front panel. You can choose a unit of measure from the same list as above. Don't forget to re-calibrate your Capacity The next scale menu item is capacity. Use this item to view system after you change or edit the capacity of the unit in any unit of measure capacity. configured under **Units**. With **CAPACity** displayed, press the **ENTER** • key. The current capacity is displayed. Use the numeric keypad to key in a new value and press **ENTER** • to accept it and return to the **CAPACity** display. You can view the capacity in other units of measure by pressing the **UNITS** key. The number is stored in the resolution you enter but is displayed in the division size stored in **Division**.

mum of 16 characters in length.

If you change capacity or division size in any unit of measure, this automatically changes all the other enabled	Division	This selection allows you to view and edit the division size of the enabled units of measure. You can enter any division size. The indicator will use the closest division size for each enabled unit of measure.		
units of measure as well. If you want leading zeroes in your printouts or broadcast and autosend information, key in leading zeroes when setting division size.		You can view the division in other units of measure by pressing the UNITS key. The number is stored in the resolution you enter but is displayed in the closest valid division size. Any additional resolution is used in calculating division size in the other units of measure.		
	Zero	Use this menu item to set zero related options. Zero range is specified as a percent of capacity referenced from the deadload. There are three items in the submenu: <i>-Range</i> , <i>Range</i> and <i>Start</i> .		
	-Range	Use this to set the negative range (below reference zero) within which the unit may be zeroed. 100% is the default value.		
	Range	Use this to set the positive range (above reference zero) within which the unit may be zeroed. 100% is the default value.		
This feature keeps the indicator from functioning at power up in an unstable environment.	Start	Use this parameter to determine whether or not the indicator must reach a stable reading within the above range before it will exit the start-up sequence, automatically zero the scale and begin weighing. While trying to acquire a stable zero the unit displays <i>Auto. 0</i> . Select <i>No</i> if you want no start-up zero restrictions. Choose <i>Yes</i> if you want the start-up zero restriction.		
	Stable	Use this menu item to set the motion detection parameters. There are three items in the submenu: <i>Range</i> , <i>Delay</i> and <i>Display</i> .		
	Range	Use this to specify the number of \pm divisions for the motion window. Default is 1.0 division.		
	Delay	Use this to specify the number of seconds during which the weight must be within range (described above) before a no- motion condition is displayed. Default value is 0.4 seconds.		
	Display	Choose ON to if you want the display on while the indicator senses scale motion. Choose OFF to blank the display while there is scale motion. Default is ON.		
	A.Z.T.	This stands for Automatic Zero Tracking. There are two items in this submenu; <i>Range</i> and <i>Net</i> .		
To exit back to normal weigh- ing mode, press the SELECT	Range	A.Z.T. adjusts the zero balance towards zero at the rate of .1 divisions per second after being within the range given for at least 2 seconds.		
key and save changes as needed by pressing ENTER with SAVE? displayed	Net	You may also enable or disable automatic zero tracking of net weight.		
	Update	 Use this to set the display update rate from these choices: 1 One update per second. 2 Two updates per second 5 Five updates per second 10 Ten updates per second. 		

	Average	The next menu item is <i>Average</i> . This can be entered in one of two methods: <i>x disp.</i> or <i>x a-ds</i> . Press the UNITS key to switch back and forth between the two choices.
		The suggested method of setting the average is by picking a value for <i>x disp</i> . Doing this insures that a multiple of the display rate is always being averaged. This results in a steadier weight display.
Changing the update rate		Use <i>x a-ds</i> if you need an exact number of A-D conversions for your particular situation.
changes the x disp. or x a-ds value based on the new update rate.	x disp.	1 disp. is the default display when you access this item. x is the number of display interval(s) over which the data is internally averaged prior to being displayed. The number of A-Ds averaged is based on the display update rate you set under the Update menu item. Default is 1 disp .
	x a-ds	x is the number of a-d conversions to average for each display.
Harmonizer® filter is used only		The A-D weight conversion happens 60 times per second in this indicator. <i>Average</i> is the number of conversions you want to average for the weight that is displayed. Default is <i>12 a-ds</i> when <i>Update</i> is at default of 5 and <i>x disp.</i> is at default value of 1.
if the average value will not filter out the vibration by itself		
See Tips on setting up and using the Harmonizer filter- ing on the next page.	Filter	Use this menu item to configure the Harmonizer filter settings. <i>Constant</i> and <i>Threshld</i> are the two items you can configure in this submenu.
	Constant	This number represents the amount of filtering. Choose a setting between 1 and 10. Choose 1 for the least amount of filtering but the fastest response. Choose 10 for the most filtering but the slowest response. Choose Off to disable the Harmonizer functions and default to the lowest filtering.
Values change with unit of measure.	Threshld	This is the window, in the current unit of measure, within which weight changes are altered according to the constant. 10.0 is the default value shown in Figure 15. You should set the threshold value between 130 and 150% of the total weight oscillations that need to be suppressed. If weight changes are +20 lbs and -10 lbs, set this value to 130 to 150% of 30 lbs.
	Over	This submenu lets you setup the overload and capacity setting which cause the <i>O. load</i> error message.
When using overload or over capacity alone, set the other menu item to its maximum	Overload	This value is expressed as a percent of capacity referenced from the deadload determined by calibration. Overload is restricted to 200% or lower. 105% is the default value.
value to disable any conflicts.	Over Cap.	This value expressed as a number of divisions over the capacity referenced from the zero value. A value of 9 satisfies UK requirements. Configurable from 0 to 999999 divisions. Default is 9 divisions.

Tips on setting up and using the Harmonizer® filtering

To find the best settings for your filter needs, follow the steps listed below.

1. What to Do: Determine the amount of positive and negative force exerted by the vibration on the scale.

How to Do It: Set Threshld to 0.0, Constant to OFF, and Average to 1.0 A-Ds. Return to weigh mode and observe the weight swings. Record the difference between the highest and lowest displayed weight values. Add 30 to 50% to this value. This is a good starting value for the Threshld setting. Do not set your indicator to this value until told to in step 7.

2. Setting the Average to higher values increases the filtering effect.

What to Do: Set Threshld to 0.0, Constant to OFF and Average to 15.0 A-Ds. Check the stability of the scale.

How to Do It: Save changes and exit to normal weight mode. Observe the Center of Zero light. If it is on all the time your scale is stable within ¼ division. If the Center of Zero light blinks more filtering is required. Go to step 3.

- 3. Repeat step 2 but increase the Average by 15.0 A-Ds. Keep repeating steps 2 and 3 until the scale is stable or you've tried the entire range of Average (300 A-Ds). If the scale is still not stable go to step 4.
- 4. Setting the Constant to higher values increases the filtering effect.

What to Do: Set Threshld to 0.0, Constant to 1.0 and Average to 300 A-Ds. Check the stability of the scale.

How to Do It: Save changes and exit to normal weight mode. Observe the Center of Zero light. If it is on all the time your scale is stable within ¼ division. If the Center of Zero light blinks more filtering is required. Go to step 5.

- 5. Repeat step 4 but increase the Constant by 1.0. Keep repeating steps 4 and 5 until the scale is stable or you've tried the entire range of Constant (10). If the scale is still not stable, decrease your display update rate and start over at step 1 using the new, slower display rate.
- 6. After the Constant value is established you may wish to lower the Average value to improve display response time.
- 7. After a final value for Constant and Average has been set, enter the Threshld value established in step 1. If this value is too small your scale will act as if the filtering is off or not working. Increase the Threshld value until your scale stabilizes.

If the Threshld value is too high your scale will react slowly to weight changes.

When Harmonizer is properly adjusted the scale will be stable at zero and will rapidly display a stable test weight value.

127 Options Menu

The third item in the 127 menu structure is Options. Figure 16 below shows the Options Menu. Use this menu to configure the keys on the front panel as well as define print layouts.



Figure 16 127 Options Menu

Buttons					
Select	Enables or disabled the SELECT key.				
Units	Enables c	or disables the UNITS key.			
Tare	This parameter enables or disables the pushbutton tare and numeric tare entry.				
	PB Tare	Options under this item are Yes (allows pushbut- ton tare for all nonnegative values), Non-Zero (enables pushbutton tare for all nonnegative values excluding zero), and No (disables push- button tare).			
	n Tare	Enables and disables numeric tare entry.			
Print					
	PB Print	This item determines which layouts are sent to which ports for pushbutton print. Press ENTER - and <i>Group</i> is displayed. From this item you may either disable the pushbutton print option, or select a group to print. To select a group, press ENTER - again. Using the keypad, enter the number of the group you wish to print. The four default print groups are as follows:			
		 1 = Displayed weight 2 = Gross, Tare, Net 3 = Gross and Net 4 = Net and Tare. 			
	n Print	This item enables or disables group print entry. If enabled, you may print any group from the front panel. To use this feature during normal weigh- ing operations, key in the number of the group you wish to print, then press PRINT .			
Zero	Enables or disables the ZERO key.				
User	Enables or disables access to the User's menu.				
F1	Enables or disables the F1 key. The default setting for this key accesses the tare registers.				
F2	Enables or disables the F2 key. The default setting for this key accesses the identification number entry.				
F3	Enables or disables the F3 key. The default setting for this key accesses the cutoff values.				
Display	The Display submenu allows you to customize the order in which the WI-127 cycles through its weight display modes and units of measure.				
Select	Customize the list of weight display modes here. The default list is: Gross→Tare→Net. Repeatedly pressing SELECT while in the weight display mode will cycle through the list in that order. You may customize the list by inserting and/or deleting items in the list. The list can contain a maximum of four items.				

If Net is removed from Select mode, the **SELECT** key cannot enable net mode, but taring a nonzero value will put the indicator temporarily into the net mode.

To add an item: Determine where in the list you wish to insert an item. Display the item which will immediately follow the one you are inserting. Press +/-. The ACCEPT annunciator illuminates. Cycle through the options by pressing the A → and MENU > keys until the item you wish to insert is displayed, then press ENTER -. That item is now included in the list. To delete an item: With that item displayed, press **ZERO**. That item is deleted from the list. Units Customize the list of units of measure here. The default list is: Unit 1àUnit 2àUnit 3. Repeatedly pressing **UNITS** while displaying a weight in the weight display mode will cycle through the list in that order. You may customize the list by inserting and/or deleting items in the list. The list can contain a maximum of four items. To add an item: Determine where in the list you wish to insert an item. Display the item which will immediately follow the one you are inserting. Press +/-. The ACCEPT annunciator illuminates. Cycle through the options by pressing the **∢ ←** and **MENU →** keys until the item you wish to insert is displayed, then press ENTER -. That item is now included in the list. To delete an item: With that item displayed, press **ZERO**. That item is deleted from the list. Define Refer to the section "Customizing your Serial Output" for detailed instructions about this submenu. The Define submenu allows you to customize printouts, build ASCII strings, create groups and enable continuous send. ASCII The WI-127 can store up to sixteen ASCII strings, each containing up to 32 individual ASCII characters. The WI-127 contains one default ASCII string. You may customize this string as well as build fifteen additional ones. Layouts The WI-127 has sixteen available print layouts (of which eight have default settings) which may include a combination of sixteen items. Build your custom layouts by choosing among nineteen print items, including ASCII strings, weight values, time and date, and other layouts. Groups Here is where you specify which ports will print which layouts. A total of nine groups is available. Within each group, up to three ports can output layouts. Port 1 is standard; ports 2 & 3 are offered only if additional serial boards are installed. Each port is then assigned a layout to print. Broadcast Enables or disables continuous send. To enable continuous send, a group number must be entered under *GrouP*. This number defines the group to be activated at each display update. Autosend Enables or disables autosend. To enable auto send, a group number must be entered under GrouP. This number defines the group to be printed each time weight stabilizes above 1% capacity. The weight must fall below 1% capacity

for the indicator to initiate another print.

To exit back to normal weighing mode, press the **SELECT** key and save changes as needed by pressing **ENTER** with **SAVE**? displayed. Except for **Reply** the actions at right can only be executed if the character is received while the indicator is in the Display mode. **Protocol** A protocol is defined as the set of input characters assigned to specific actions for each port. Under this item you choose a port, choose an input number, assign an ASCII character (decimal value) to the action, and choose the associated response or action from the following list (see note at left):

- *Print* Causes a Print to occur. You can specify which group to output.
- *Reply* Causes a Print to occur. You can specify which group to output. This runs as a background fuction without regard for motion. **Reply** can be executed when the indicator is in Display mode and also in the User Menu.
- *Zero* Performs a Zero function.
- *None* Assigns no function.
- **Units** Switches indicator to the next available unit of measure.
- Unit 1 Switches indicator to Unit 1, if available.
- Unit 2 Switches indicator to Unit 2, if available.
- Unit 3 Switches indicator to Unit 3, if available.
- **Select** Switches indicator to next available display mode.
- Gross Switches display to the gross mode.
- *Net* Switches display to the net mode.
- Tare Switches display to the tare mode.
- **P.B.Tare** Causes a pushbutton tare operation.
- Example: This is how you would set up the indicator if you want to zero the scale through a serial port from a computer or PLC:
 - Select a port (1, 2 or 3) under *Protocol*.

Connect a cable between this port and your computer or PLC.

Configure a serial *Input* to perform an action. A maximum of 16 serial inputs may be configured.

Under the selected input, under *Ch* (Channel), choose an ASCII character, for example Z, represented by decimal value 90. See Table 5 in the *WI-127 Service Manual* for a complete list of ASCII characters.

Go over from *Ch* to *Action*. Under *Action* drop down and select *Zero* from the menu choices.

Now when you send a Z from your PC or PLC to the serial port, this will cause the display to zero out, the same as if you pressed the front panel **ZERO** key.

The fourth item in the 127 menu structure is Serial. Figure 17 below shows the Serial Menu. Use this menu to configure serial ports and communications protocols.



Figure 17 127 Serial Menu

Ports 2 and 3 present if op- tional hardware is installed.	Port 1, 2 & 3	Port 1 is the onboard serial port. Any additional boards installed are configured under Ports 2 & 3. Ports 2 & 3 shou up in the Serial Menu only if additional boards are installed		
By default the WI-127 ports accept an enquire (ENQ) (05) character. If an ENQ character is received, the group selected	Busy	Enables or disables the ready/busy input. If the ready/busy input is enabled, you may enter a timeout period. This value determines how long a port can be busy before the indicator displays a port busy message.		
for the pushbutton print will be output. This is configurable under Define Protocol for	Baud	Select a baud rate. Choices are: 9600 (default), 19200, 300, 600, 1200, 2400, 4800.		
each serial port separately.	Data	Choose between 7 (default) & 8 data bits.		
	Parity	Choices are:		
		No - Even -	Specifies that no parity bit is to be included. Specifies that a parity bit which insures an even number of logic one bits is transmitted. (default) (7, 1or 2, even)	
A flashing value indi- cates an invalid combi- nation.		Odd -	Specified that a parity bit which insures an odd number of logic one bits is transmitted. (7, 1 or 2, odd)	
		Clear -	Specified that a logic zero bit is always transmit- ted after the data bits (space parity). (8, 1, none) Set - Specifies that a logic one bit is always transmitted after the data bits (mark parity). (7, 2, none)	
	Stops	Select the	number of stop bits. Choices are 1 (default) or 2.	

127 BCD Out Menu

The next item in the 127 menu structure is B.C.D. Out. Figure 19 below shows this menu. This submenu configures what the BCD output board will print. It is offered only if the BCD board is installed. Choices are: off, displayed weight, gross weight, and net weight.

If you choose displayed weight, BCD will output gross weight or net weight depending on what you are using at the time. If you access the user menu, the BCD output will be whatever was last displayed. If you use the **SELECT** key to access the tare display mode, BCD output will be Gross if tare = 0, Net if tare ¹ 0.



OutputThis item specifies which weight the analog output will
follow. Choices are: off, displayed weight, gross weight, or
net weight.FullWhen selected, the indicator will display the last value used
or the default value. You enter the full capacity of the analog
output which may be less than or greater than the capacity
of the scale. For example, the capacity of the indicator
might be 5000 lb, but it may be desirable to have 3000 lbs
as the full capacity of the analog output. In any case, the
	analog output has nominal under and over range limits of 20%. After entering this value, press UNITS to select the unit of measure for the value. (This selection is not offered if off is selected under Output.)
Adjust	These choices—Zero and Full—allow the zero and the span of the analog outputs to be adjusted without actually putting weights on and off the scale.
	Selecting Zero lets you adjust the zero of the analog output for a zero weight reading. Adjust the zero by entering a percent value or by pressing ◀ ← and MENU ▸ to make incremental adjustments. The number on the display gives a visual representation of the zero setting with 00.000 being the nominal value The zero adjustment has a +/- 10% range, -10.000 to +10.000 on the display.
	Selecting Full lets you adjust the span of the analog output for the full capacity weight reading. Adjust the span by entering a percent value or by pressing \checkmark and MENU to make incremental adjustments. Holding these keys will cause the values to change faster and faster. The number on the display gives a visual representation of the zero setting with 100.000 being the nominal value The zero adjustment has a +/- 10% range, 90.000 to 110.000 on the display. Weight does not have to be on the scale to perform this task.

127 Outputs Menu	This submenu, outputs.	shown in Figure 20, is where you configure the WI-127's
	Update	Choose an update display rate for the cutoffs.
* denotes default settings	Display*	This selection updates the cutoffs at the indicator's config- ured display update rate:
ucholes uchauk settings		1, 2, 5 or 10 times per second.
	Fast	This selection updates the cutoffs at 20 times per second. The indicator will continue to update at its configured display update rate.
	Onboard	Choose the configuration of the onboard outputs.
	Cutoff*	This selection configures the onboard outputs as cutoffs.
	Bounds	This selection configures the onboard outputs as over, under and accept outputs.
127 Adjust Scale Options See See Figure 13 Figure 14	Serial E See S Figure 17 Fig	Analog Outputs See See Onboard ure 18 Figure 19 Update Onboard Display Fast Cutoff Bounds
	Fig	gure 20

Outputs menu

127 Inputs Menu

Use this submenu, shown in Figure 20a, to assign actions to the onboard hardware inputs. The action for each input is selectable from this list: Print; Reply; Zero; None; Units; Unit 1; Unit 2; Unit 3; Select; Gross; Net; Tare; P.B. Tare. See the explanations for each of these at the bottom of the page.



Figure 20a 127 Inputs Menu

See the table below for the default assignments. Use this submenu, shown in Figure 20a, to assign actions to the onboard hardware inputs. See the table below for the default assignments.

	Inputs-	Onboard default assignments
	Input	Action
		Zero Key
	2	Print Key
	3	Net Display Mode
	4	Gross Display Mode
	5	Push Button Tare
	6	Select Key
	7	Units Key
Print -	Causes a loutput.	Print to occur. You can specify which group to
Reply -	Causes a l output. Thi motion. R Display mo	Print to occur. You can specify which group to is runs as a background fuction without regard for eply can be executed when the indicator is in ode and also in the User Menu.
Zero -	Performs a	a Zero function.
None -	Assigns no	o function.
Units -	Switches in	ndicator to the next available unit of measure.
Unit 1 -	Switches in	ndicator to Unit 1, if available.
Unit 2 -	Switches in	ndicator to Unit 2, if available.
Unit 3 -	Switches in	ndicator to Unit 3, if available.
Select -	Switches in	ndicator to next available display mode.
Gross -	Switches of	lisplay to the gross mode.
Net -	Switches of	lisplay to the net mode.
Tare -	Switches of	lisplay to the tare mode.
P.B.Tare -	Causes a	pushbutton tare operation.

Except for **Reply** the actions at right can only be executed if the character is received while the indicator is in the Display mode. The next item in the 127 <u>Setup</u> menu is Seal. Use this submenu to set up a custom password and to set the sealing choices for the unit. The Seal Menu is shown in Figure 21.



Figure 21 127 Seal Menu

Items in the <u>Setup</u> menu (Figure 6) can be protected from unrecorded changes.

Two internal counters record changes to items in the Setup menu. View these counters under **AUDIT** in the Service menu (Figure 4). These counters cannot be reset and thus can be used by auditors or inspectors to check if changes have been made. One counter is for scale calibration items and the other for configuration items. The level of protection is set in the Seal menu. The Seal menu is shown in Figure 22.



To exit back to normal weighing mode, press the **SELECT** key and save changes as needed by pressing **ENTER** with **SAVE?** displayed.

All set to Yes

Any time you access the setup menu and change any item in Table 2, the appropriate counter increments one count. Changing multiple items on one visit to the menu increments the counter only one count. It's the number of visits with changes that are counted, not the number of changes per visit.

All set to No

With this setting the calibration internal counter will increment when you access the setup menu and change any calibration item in Table 2. The internal configuration counter will increment only if you change one of the configuration items in **bold** print from Table 2.

Phys. set to Yes

If *Phys.* is set to *Yes*, you must remove the physical seal (rear sealing plug) of the WI-127 to access an internal switch. When you press this switch you have full editing privileges and the display shows the first item in the Service menu, *About*, without the need to enter the password.

If you enter the Service menu using the password and not the internal switch, you can change only the configuration items in Table 2 that are in normal, not **bold**, print.

Phys. set to No

If *Phys.* is set to *no* correct password entry is the only way to have editing privileges of all the items in Table 2 without breaking the physical seal. See note to left.

If the password is not entered correctly, the setup menu items can be viewed but not edited.

Calibration Items	Configuration Items
Any item in the Adjust menu	Any item in the Scale menu
	Any item in the Options menu
	Any item in the Seal menu
	Any item in the Serial menu
	Any item in the Analog menu
	Any item in the B.C.D. Out menu

Table 2Calibration and Configuration list

Use this submenu to setup the WI-127 to receive or send print formats from the WI-127 downloader software package in your PC. See Figure 21.

This is the end of the 127 section.

If **Phys.** is set to **No**, you can still press the internal switch and have instant setup menu access and editing privileges.

127 Transfer Menu

Reset Menu / Master Clear

User Master Clear as a last resort before sending in the unit for repair.

You must press the Seal switch if the unit is physically sealed.

The reset menu may not contain all three items shown in Figure 23. If an item is at default and not corrupted it will not appear in the menu.

Corrupted items will flash. Items not at default and not corrupted will appear but will be solid (not flashing). These items are not required to be reset.

If the **SEAL PHYS**. selection is corrupted, the unit assumes that the selection is **YES**.

You can press the **ESCAPE** key to exit the Reset Menu when you don't want to reset any more items.

A software change **requires** a reset. You must press the seal switch to force the reset to occur properly.

The reset menu shown in Figure 23 appears in two cases.

- 1. If you do a Master Clear (powering up the unit with both the **MENU** and **F2** keys pressed).
- 2. If setup, calibration, or data becomes corrupted.

In case 1, you will need to enter the password the same way as explained in the Service menu. After correctly entering, the reset menu will be displayed.

With *Reset* displayed, press the ENTER ▼ key...

The first menu item will be displayed. See note at left.

No is displayed.

- 2. Press the ENTER ▼ key...
- Choose Yes* to reset to default values or No to leave the values as they are. Toggle between the choices with the < < → or MENU > key. When the choice you want is displayed, press the ENTER ▼ key...
- 4. Repeat steps 2 and 3 for each item in the menu. . .

* If the unit is physically sealed, you must press the internal switch to select **YES**.

If you reset the item, the display will show the next item. When you reset an item to defaults it disappears from the menu.

When all items are either accepted or reset the indicator reboots automatically.



In case 2, the display bypasses the password and goes right to *Reset*. Repeat steps 1 through 4 above.

Calibrating the WI-127

Any changes you make within the calibration menu will be immediately implemented, so take care when recalibrating your system.

While in the Calibration menu, you may print the calibration data out of port #1 by selecting YES. See sample below.

10:39 AM	12/31/99
m∀⁄V	1b
0.00000	0
2.00000	5000
	Serial No.

The WI-127 allows calibration using up to five calibration points. These points can be any weight value in any unit of measure. Standard calibration generally uses two calibration points; for linearization, more than two may be used.

The WI-127 comes from the factory with two calibration points: 0 and 5000 lbs. (These weight values may differ depending on your unit of measure.) To perform linearization, you can insert more calibration points (up to a total of five points). These points appear in a list and may be inserted and deleted. The unit will order the points based on increasing count values.

These points may be calibrated in two ways: 1) by standard weight calibration or 2) by entering count values. Counts are calibrated to a 1 mV/V signal from the factory. This allows you to view the deadload, calibration point counts, and loadcell test in our standard count value (200,000 counts per mV/V) or press **UNITS** to view and edit the real mV/V. There are benefits to this feature:

- You can enter these values into a new indicator hooked up to the same scale. This is useful if the old indicator needs servicing and a quick turnaround is needed.
- Another benefit is the ability to enter the profile of a weight sensor without having to calibrate the indicator conventionally. This profile is used mostly in batching bars and force measurement devices, which have a standard or known output and are more difficult to calibrate in the field.

Entering the	To calibrate your indicator you must enter the calibration menu. See note at left before following these instructions:			
Be sure the correct capacity and division sizes have been	 From weight display mode, key in the security code (default code is 1 2 7) 	The code number is displayed.		
selected before calibrating.	 2a. Press and hold ESCAPE ▲ for two seconds 	<i>About</i> is displayed.		
	2b. Press the SEAL switch inside the WI-127	<i>About</i> is displayed.		
	3. Press ◀◀━━	SEtUP is displayed.		
To exit back to normal weigh-	4. Press ENTER ▼	110 or 127 is displayed.		
ing mode, press the SELECT key and save changes as	5. Press ENTER ▼····	<i>AdJuSt</i> is displayed.		
with SAVE? displayed.	6. Press ENTER ▼	<i>PointS</i> is displayed. You are now in the calibration menu.		

Weight Calibration	То	calibrate your scale using live weig	pht calibration, follow these steps:
	1.	With <i>PointS</i> displayed, press ENTER ▼	<i>A 0</i> is displayed. This is the zero calibration point.
To view or edit the weight in another configured unit of measure, press the UNITS key	2.	To calibrate your scale's zero point, press ENTER ▼	<i>CAL.</i> is displayed.
at any time during calibration.	3.	Remove all weight from the scale and press ENTER	bUSy is displayed for at least ½ second while the unit obtains a stable value, then d 0 is dis- played. Note: Pressing ESCAPE
BUSY will be displayed for several seconds. Correct the filtering and recalibrate			while <i>bUSy</i> is displayed will abort the calibration and the indicator will return to the previous display.
	4.	Press ENTER ▼	<i>A</i> 0 is displayed.
	5.	Press MENU ▶	<i>A</i> 5000 is displayed. This is the full capacity calibration point. Full capacity is factory calibrated at 1 mV/V input
	6.	You may use 5000 lbs to calibrate this point, or you may change the value for this calibration point. To change this calibration point, key in the new value now and press ENTER • or to use the current value,	
		press ENTER	CAL. is displayed.
	7.	Put the appropriate weight calibration value on the scale and press ENTER	bUSy is displayed for at least ½
After your system is fully calibrated, write down and save the COUNT values for each calibration point. If your indicator ever needs replacing you can key these values into your new indicator and be			second while the unit obtains a stable value, then <i>d</i> XXXX is displayed. Note: Pressing ESCAPE ← while <i>bUSy</i> is displayed will abort the calibration and the indicator will return to the previous display.
assured the calibration will be correct.	8.	Press ENTER ▼····	A XXXX is displayed. You have now calibrated the two standard calibration points using live weight.
To exit back to normal weigh- ing mode, press the SELECT key to save changes.	9.	Press SELECT to save your calibration.	

Count Calibration

To view or edit the weight in another configured unit of measure, press the **UNITS** key at any time during calibration.

Α 0 is displayed. This is the zero press ENTER -... calibration point. 2. Press ENTER -... CAL. is displayed. 3. Press MENU ... CountS is displayed. 4. Press ENTER -... Current count value is displayed. Press UNITS to view and edit the count in mV/V. 5. Key in the count value for the zero calibration point. . . Value is displayed. Value is accepted and CountS is 6. Press ENTER -... displayed. 7. Press ESCAPE ... 0 is displayed. Α 8. Press ENTER -... A 5000 is displayed. This is the full capacity calibration point. Full capacity is factory calibrated at 1 mV/V input.. 9.a You may leave this point at 5000 lbs, or you may change the value for this calibration point. To change this calibration point, key in the new value now and press ENTER -... CAL. is displayed. 9.b To leave the point at 5000 lbs, press ENTER -... CAL. is displayed. 10. Press **MENU** ▶... CountS is displayed. 11. Press ENTER -Current count value is displayed. Press UNITS to view and edit the count in mV/V. 12. Key in the count value for the A XXXXX calibration point. . . Value is displayed. 13. Press ENTER -Value is accepted and CountS is displayed. 14. Press ESCAPE ... A XXXX is displayed. You have now calibrated the standard two calibration points using count calibration.

To calibrate your scale using count calibration, follow these steps:

1. With *PointS* displayed,

15. Press **SELECT** to save your calibration.

key to save changes.

correct.

After your system is fully

calibrated, write down and

save the COUNT values for each calibration point. If your

indicator ever needs replacing

you can key these values into your new indicator and be

assured the calibration will be

To exit back to normal weighing mode, press the **SELECT**

Adding Calibration Points

You have the option of adding one, two or three additional calibration points for

linearization. You may add these points at the same time you are calibrating the zero load and full capacity points. Points do not have to be inserted in the correct order. The WI-127 will automatically order the points based on count values.

To add linearization points:

1.	With A XXXX displayed, press +/	A is displayed.
2.	Key in the calibration value for the new point	A XXXX is displayed.
3.	Press ENTER	CAL. is displayed.
To 4a.	perform a live weight calibration: 1. Put the correct weight on the scale and press ENTER ▼	bUSy is displayed for at least ½ second while the unit obtains a stable value, then d XXXX is displayed.
	2. Press ENTER ▼	A XXXX is displayed.
To 4b.	perform a count calibration: 1. Press MENU ►	<i>CountS</i> is displayed. Press UNITS to view and edit the count in mV/V.
	2. Key in the correct count and press ENTER ▼	<i>CountS</i> is displayed.
	3. Press ESCAPE	A XXXX is displayed.
5.	To add more calibration points, repeat steps 1-4 above.	
6.	Press SELECT to save changes.	

To exit back to normal weighing mode, press the **SELECT** key to save changes.

Deleting Calibration Points

There are two methods of deleting calibration points. NOTE: You may not have less than two calibration points.

Method A

1.	With the point you wish to delete displayed	A XXXX
2.	Press ZERO	Point is deleted.

Method B:

- 1. With the point you wish to delete displayed... *A XXXXX*
- 2. Press ENTER -... CAL. is displayed.

3. Press MENU	<i>CountS</i> is displayed.
4. Press MENU → again	<i>dELEtE</i> is displayed.
5. Press ENTER ▼	<i>no</i> is displayed.
6. Press MENU ▶	yES is displayed.
7. Press ENTER ▼	The point is deleted and A XXXX (next calibration point) is displayed.

To exit back to normal weighing mode, press the **SELECT** key to save changes.

8. Press **SELECT** to save changes.

Customizing the Serial Output

Predefined Print Layouts	The WI-127 has sixteen available print layouts. Nine have default settings. Examples of the nine default layouts are shown below in printout form. Their actual layout codes are shown on the following pages.		
	Pressing the #6.	PRINT key on a new indicator will automatically print Layout	
	Layout 1	Prints the weight label, gross weight, and unit of measure.	
	Layout 2	Prints the tare register number, weight label, tare weight, and unit of measure.	
	Layout 3	Prints the tare register number, weight label, net weight, and unit of measure.	
		N 2500 lb	
	Layout 4	Prints the weight label, displayed weight, and unit of mea- sure.	
		G 4000 lb	
	Layout 5	Prints Layout 4 (weight label, displayed weight, and unit of measure) plus a form feed.	
		G 4000 lb	
	Layout 6	This is the default printout when the PRINT key is pressed. Prints Layouts 1, 2 & 3 (tare register numbers, weight labels, gross, tare and net weights, and units of measure) plus a form feed.	
		G 4000 lb 2 T 1500 lb N 2500 lb	
	Layout 7	Prints Layouts 1 & 3 (tare register numbers, weight labels, gross and net weights, units of measure) plus a form feed.	
		G 4000 lb N 2500 lb	
	Layout 8	Prints Layouts 3 & 2 (tare register numbers, weight labels, net and tare weights, units of measure) plus a form feed.	
		N 2500 lb 2 T 1500 lb	
	Layout 9	Prints weight label, displayed weight, unit of measure, time and date.	
	G	4000 lb 09:13:06 11-22-96	

Use the **MENU** key to move down the list of printable items in Table 3. Use the **(** key move up the list.

Status byte = 8 bits

Transmitted as a single character. The bits appear as follows: 0011LEBM L has a weighted value of 8 E has a weighted value of 4 B has a weighted value of 2 M has a weighted value of 1

where L is set to logic 1 when a Low voltage condition exists; logic 0 otherwise. E is set to 1 when an a-d Error condition exists; 0 otherwise. B is 1 when the weight is beyond displayable range (over- or under-capacity); 0 otherwise. And M is set to logic 1 when an in-motion condition exists; set to logic 0 when the weight is stable. The upper four bits are set to 0011 to cause the value to be printed as a digit or symbol in row 3 of the ASCII character set.

These are the most common characters you will see on a terminal: "0" = Stable "1" = In-motion "2" = Range error "4" = A-D error "8" = Low voltage

END and **DELAY** are not printable items.

Just as in other Weigh-Tronix indicators (WI-125, WI-150, etc.) the layouts within the WI-127 may be customized. If the nine default layouts do not fit your specific applications, or if you wish to include, for example, custom wording, you may easily customize a print layout. This is done within the "Options" menu of the service menu. See the section *Step by Step Instructions / Entering the Define Submenu* located just before Figure 24. But please read the following section in order to understand what items are available for customization.

The WI-127's layouts can be a maximum of sixteen items long. Any combination of the following nineteen items (up to sixteen maximum) may be used to form a layout. These printable items, along with their descriptions, are listed below.

	Table 3: Layout Print Items (Blocks)				
	Print Items	Description			
	GROSS NET DISPLAY	Gross weight is transmitted. Net weight is transmitted. Current displayed live weight is transmitted (gross or net),			
	TARE T. REG	Current tare (general or numbered register) is transmitted. Current tare register number is transmitted (a space is transmitted for the general tare register).			
	SELECTED	Currently selected item from the select list is transmitted (gross, tare or net).			
		Current time is transmitted. Current date is transmitted.			
3	STATUS *LABEL	 Current status is transmitted. See note at left. Weight label is transmitted. Five choices are available: gross-outputs the gross label net-outputs the net label display-outputs gross or net depending on the displayed live weight tare-outputs the tare label selected-outputs the label gross, tare or net following 			
	UNITS *LAYOUT	Unit of measure label is transmitted A predefined layout may be included within another layout. For example, Layout 6 includes Layouts 1, 2, & 3. Note: A "layout error" will occur if a layout uses its own layout within itself or if a "loop" of layouts is used (for example, Layout 1 cannot use Layout 2 if Layout 2 includes Layout 1)			
	*DELAY END *ASCII *Ch. *SPACES *CRS *LFS FF	Pauses serial port output by this many seconds (0-255) Insert to delete any printable items that follow A configurable ASCII string can be inserted and transmitted A character (ASCII value) can be entered to be transmitted A configurable number of spaces is transmitted A configurable number of carriage returns is transmitted A configurable number of line feeds is transmitted A form feed is transmitted			
	* denotes iter is inserted v "SP" is inse	ns that require detailed information. For example: if "LABEL" vithin a layout, you must specify the label to be printed; if rted, you must specify the number of spaces to be transmit-			

ted.

Listed below are the predefined print layouts. You may customize these, or create up to seven new layouts.

Layout 1



ASCII Strings

As mentioned in the previous section, the layouts may include a number of items, one of which is ASCII strings. These ASCII strings allow you to customize your printouts with custom wording.

ASCII is an acronym for **A**merican **S**tandard **C**ode for Information Interchange. ASCII codes are simply numbers (code values) a computer can translate into letters, numbers and actions.

The WI-127 can store up to sixteen ASCII strings, each containing up to 32 individual characters. These strings are numbered 1-16. Below is a worksheet to help define several ASCII strings. Write in your custom wording in the white boxes, then convert the characters to ASCII code values using the table on the next page. Write these values in the gray boxes. If a letter or action is repeated several times, place a decimal point after the code value, then insert the number of times it is to be repeated. For example, 13.3 means three successive carriage returns.

The WI-127 contains one default ASCII string. String #1 will spell out "WEIGH-TRONIX WI-127" when added to a customized layout. Feel free to fill in the worksheet below to keep track of your custom defined ASCII strings.

Complete instructions for programming these ASCII strings into the WI-127 can be found in the section *Step by Step Instructions* preceding Figure 24.

											T	ab	le 4	4: /	٩S	CII	Str	ing	W	ork	she	et					
1	87	69	73	71	72	45	84	82	79	78	73	88	32	87	73	45	49	50	55	end							
	W	Е	I	G	н	-	Т	R	0	Ν	I	Х	sp	w	I	-	1	2	7								
2																											
3																											
4																											
5																											
6																											
7																											
8																											
9																											
10																											
11																											
12																											

Code #	Control Character						
0	NUL	33	!	66	В	99	с
1	SOH	34	"	67	С	100	d
2	STX	35	#	68	D	101	е
3	ETX	36	\$	69	E	102	f
4	EOT	37	%	70	F	103	g
5	ENQ	38	&	71	G	104	h
6	ACK	39	ļ	72	н	105	i
7	BEL	40	(73	I	106	j
8	BS	41)	74	J	107	k
9	НТ	42	*	75	К	108	I
10	Line Feed	43	+	76	L	109	m
11	VT	44	,	77	М	110	n
12	Form Feed	45	-	78	N	111	0
13	Carriage Return	46		79	0	112	р
14	S0	47	1	80	Р	113	q
15	S1	48	0	81	Q	114	r
16	DLE	49	1	82	R	115	s
17	DC1	50	2	83	S	116	t
18	DC2	51	3	84	Т	117	u
19	DC3	52	4	85	U	118	v
20	DC4	53	5	86	V	119	w
21	NAK	54	6	87	W	120	x
22	SYN	55	7	88	х	121	У
23	ETB	56	8	89	Y	122	z
24	CAN	57	9	90	Z	123	{
25	EM	58	:	91	[124	l
26	SUB	59	•	92	١	125	}
27	ESC	60	<	93]	126	~
28	FS	61	=	94	۸	127	Delete
29	GS	62	>	95	_		
30	RS	63	?	96	×		
31	US	64	@	97	а		
32	Space	65	А	98	b		

Table 5 ASCII Control Code Values

NOTE: To repeat a control code a number of times, enter the control code #, a decimal, then the number of times you want it repeated. Spaces, letters, or carriage returns can easily be repeated this way.

Step by Step	To customize layouts and ASCII of the Service Menu, then follow	strings you must enter the Define submenu the flowchart pictured below.
Instructions	Follow these instructions:	
Entering the Define submenu	 From weight display mode, I in the security code (default is 1 2 7) 	key code The code number is displayed.
	 2a. Press and hold ESCAPE ▲ two seconds OR 	for About is displayed.
	2b. Press the SEAL switch insid the WI-127	e About is displayed.
	3. Press (◄ —	SEtUP is displayed.
	4. Press ENTER ▼	110 or 127 is displayed.
	If 110 is displayed, press MENU ▶	127 is displayed.
	5. Press ENTER ▼	AdJuSt is displayed.
	6. Press MENU	SCALE is displayed.
	7. Press MENU ▶	OPtionS is displayed.
	8. Press ENTER ▼	buttonS is displayed.
	9. Press MENU ▶	diSPLAy is displayed.
	10. Press MENU ▶	<i>dEFINE</i> is displayed. You are now in



the Define submenu shown below.

Figure 24 Define menu The default labels are: "G" for gross, "N" for net, "T" for tare, and ID for ID. You can customize the labels and use up to 16 characters. It is within the ASCII submenu that you create/customize the ASCII strings to be used in your layouts.

LabelThis item allows you to edit the gross, net, tare, and ID labels.

1.	With <i>LAbEL</i> displayed, press ENTER ▼	GroSS is displayed.
2.	Press ENTER ▼ again	71 (the ASCII value for the letter "G") is displayed.
3a.	Press ENTER – if you don't wish to make a change or your are done.	<i>GroSS</i> is displayed.
	or	
3b.	To change this label, press the +/- key	A — (dash) is displayed.
	Key in your next ASCII value(s) and press MENU ⊦	ENd is displayed.
4.	Press MENU ▶	NEt is displayed.
5.	Repeat steps 1-4 for Net, Tare, and ID.	

Viewing strings 1. With StringS displayed, press ENTER ▼ ASCII 01 (default string) is displayed. 2. Press ENTER ▼ The first ASCII value in the string is displayed. 3. Press (← and MENU) to scroll through the entire string of ASCII values. ASCII values. 4. When you are finished viewing the values, press ESCAPE ► ASCII 01 is displayed. 5. Press MENU) On a new indicator. End is displayed. 6. Press MENU) On a new indicator. End is displayed. 7. delete the displayed ASCII value 1. With StringS displayed, press ENTER ▼ 7. delete the displayed ASCII value press the ZERO key. 1. With ASCII 02 displayed, press ENTER ▼ 7. delete the displayed ASCII value press the ZERO key. 2. Press +f 6. Press +f End is displayed. 7. Continue repeating steps 5 & 6 (until you have entered all your ASCII values. If you make an error, refer to the next section: Editing strings. End is displayed. 8. To view your newly entered ASCII values. If you make an error, refer to the next section: Editing strings. The indicator scrolls through all the values. 8. To view your newly entered ASCII string strings are needed. 8. To view your newly entered ASCII value. The indicator scrolls through all the values.	Strings	Thi nev stri	is item allows the creation of up to s w indicator, there is one default ASC ing as well as create up to fifteen me	ixteen different ASCII strings. On a CII string. You may edit the existing ore.
2. Press ENTER • The first ASCII value in the string is displayed. 3. Press • (and MEN) • to scroll through the entire string of ASCII values, press ESCAPE • ASCII 01 is displayed. 4. When you are finished viewing the values, press ESCAPE • ASCII 01 is displayed. 5. Press MENU • On a new indicator, End is displayed. 6. View strings 1. With StringS displayed, press ENTER • ASCII 01 (string #1) is displayed. 7. O delete the displayed ASCII value, press FNTER • End is displayed. End is displayed. 7. O delete the displayed ASCII value in the string in the list will be added. On a new indicator, this were interest on the string. End is displayed. 7. View press the ZERO key. 1. With ASCII 02 displayed, press ENTER • End is displayed. 7. O delete the displayed ASCII value, press the ZERO key. 2. Press the XIII 02 displayed, press ENTER • End is displayed. This means that there is on a then press the XIII value press the ZERO key. 6. Key in your first ASCII value, then press MENU • — is displayed. The value is stored and End is displayed. 7. Continue repeating types 5 & 6	Viewing strings	1.	With <i>StringS</i> displayed, press ENTER ▼	ASCII 01 (default string) is dis- played.
3. Press (← and MENU) to scroll through the entire string of ASCII values. 4. When you are finished viewing the values, press ESCAPE 5. Press MENU 6. Press MENU 7. On a new indicator, End is displayed. This means that there is only one ASCII string (ASCII 01) defined so far. You may create up to fifteen more. 1. With StringS displayed, press ENTER 2. Press MENU > until 2. Press MENU > until 3. Press +/ 3. Press +/ 4. With ASCII 02 displayed, press ENTER 5. Press #ENU > until 6. Press #ENU > until 7. delete the displayed ASCII value press the ZERO key. 4. With ASCII 02 displayed, press ENTER FINTER 5. Press +/ 6. Key in your first ASCII value, then press MENU > 7. Continue repeating steps 5 & 6 until you have entered all your ASCII values. If you make an error, refer to the next section: Editing strings. 8. To view your newly entered ASCII values. 9. Repeat steps 2-7 as new ASCII strings are needed.		2.	Press ENTER	The first ASCII value in the string is displayed.
4. When you are finished viewing the values, press ESCAPE * ASCII 01 is displayed. 5. Press MENU · On a new indicator, End is displayed. This means that there is only on eASCII string (ASCII 01) defined so far. You may create up to fifteen more. Creating new strings 1. With StringS displayed, press ENTER * ASCII 01 (string #1) is displayed. 2. Press MENU · until End is displayed. The next ASCII string (ASCII 01) defined so far. You may create up to fifteen more. To delete the displayed ASCII value press the ZERO key. 9. Press */ End is displayed. 5. Press */ End is displayed. On a new indicator, this will be added. On a new indicator, this will be ASCII 02. 4. With ASCII 02 displayed, press ENTER * End is displayed. This means that there are no ASCII values entered for this string. 5. Press */ — is displayed. End is displayed. 6. Key in your first ASCII value, then press MENU > The value is stored and End is displayed. 7. Continue repeating steps 5 & 6 until you have entered all your ASCII values. If you make an error, refer to the next section: Editing strings. The indicator scrolls through all the values. 8. To view your newly entered ASCII values. 9. Repeat steps 2-7 as new ASCII The indicator scrolls through all the values.		3.	Press (and MENU) to scroll through the entire string of ASCII values.	
5. Press MENU> On a new indicator, End is displayed, This means that there is only one ASCII string (ASCII 01) defined so far. You may create up to fifteen more. Creating new strings 1. With StringS displayed, press ENTER T ASCII 01 (string #1) is displayed. 2. Press MENU> until End is displayed. 3. Press +/ End is displayed. 3. Press +/ The next ASCII string in the list will be added. On a new indicator, this will be ASCII 02. 4. With ASCII 02 displayed, press ENTER T End is displayed. This means that there are no ASCII values entered for this string. 5. Press +/ End is displayed. This means that there are no ASCII values entered for this string. 5. Press +/ — is displayed. 6. Key in your first ASCII value, then press MENU> The value is stored and End is displayed. 7. Continue repeating steps 5 & 6 until you have entered all your ASCII values. If you make an error, refer to the next section: Editing strings. The value is stored and End is displayed. 8. To view your newly entered ASCII values, press MENU> The indicator scrolts through all the values. 9. Repeat steps 2-7 as new ASCII The indicator scrolts through all the values.		4.	When you are finished viewing the values, press ESCAPE •	ASCII 01 is displayed.
Creating new strings1.With StringS displayed, press ENTER *ASCII 01 (string #1) is displayed.2.Press MENU > untilEnd is displayed.3.Press */The next ASCII string in the list will be added. On a new indicator, this will be ASCII 02.7. delete the displayed ASCII value press the ZERO key.With ASCII 02 displayed, press ENTER *The next ASCII string in the list will be added. On a new indicator, this will be ASCII 02.7. delete the displayed ASCII value press the ZERO key.Fress */End is displayed. This means that there are no ASCII values entered for this string.6.Key in your first ASCII value, then press MENU >The value is stored and End is displayed.7.Continue repeating steps 5 & 6 until you wave entered all your ASCII values, press MENU >The value is stored and End is displayed.8.To view your newly entered ASCII values, press MENU >The indicator scrolls through all the values.9.Repeat steps 2-7 as new ASCII strings are needed.The indicator scrolls through all the values.		5.	Press MENU	On a new indicator, <i>End</i> is displayed. This means that there is only one ASCII string (ASCII 01) defined so far. You may create up to fifteen more.
2. Press MENU > until End is displayed. 3. Press +/ The next ASCII string in the list will be added. On a new indicator, this will be ASCII 02. 4. With ASCII 02 displayed, press ENTER ~ End is displayed. This means that there are no ASCII values entered for this string. 5. Press +/ — is displayed. 6. Key in your first ASCII value, then press MENU > The value is stored and End is displayed. 7. Continue repeating steps 5 & 6 7. Continue repeating steps 5 & 6	Creating new strings	1.	With <i>StringS</i> displayed, press ENTER ▼	ASCII 01 (string #1) is displayed.
3. Press +/ The next ASCII string in the list will be added. On a new indicator, this will be added. On a new indicator, this will be ASCII 02. 4. With ASCII 02 displayed, press ENTER ~ End is displayed. This means that there are no ASCII values entered for this string. 5. Press +/ is displayed. 6. Key in your first ASCII value, then press MENU > The value is stored and End is displayed. 7. Continue repeating steps 5 & 6 until you have entered all your ASCII values. If you make an error, refer to the next section: Editing strings. The indicator scrolls through all the values. 8. To view your newly entered ASCII values, press MENU > repeatedly The indicator scrolls through all the values. 9. Repeat steps 2-7 as new ASCII Strings are needed.		2.	Press MENU I until	<i>End</i> is displayed.
 Value press the ZERO key. 4. With ASCII 02 displayed, press ENTER End is displayed. This means that there are no ASCII values entered for this string. 5. Press +/ 6. Key in your first ASCII value, then press MENU > 7. Continue repeating steps 5 & 6 until you have entered all your ASCII values. If you make an error, refer to the next section: Editing strings. 8. To view your newly entered ASCII values, press MENU > 9. Repeat steps 2-7 as new ASCII strings are needed. 	To delete the displayed ASCII	3.	Press +/-	The next ASCII string in the list will be added. On a new indicator, this will be ASCII 02 .
 5. Press +/ – is displayed. 6. Key in your first ASCII value, then press MENU > The value is stored and End is displayed. 7. Continue repeating steps 5 & 6 until you have entered all your ASCII values. If you make an error, refer to the next section: Editing strings. 8. To view your newly entered ASCII values, press MENU > repeatedly The indicator scrolls through all the values. 9. Repeat steps 2-7 as new ASCII strings are needed. 	value press the ZERO key.	4.	With <i>ASCII 02</i> displayed, press ENTER ▼	<i>End</i> is displayed. This means that there are no ASCII values entered for this string.
 6. Key in your first ASCII value, then press MENU The value is stored and End is displayed. 7. Continue repeating steps 5 & 6 until you have entered all your ASCII values. If you make an error, refer to the next section: Editing strings. 8. To view your newly entered ASCII values, press MENU > repeatedly The indicator scrolls through all the values. 9. Repeat steps 2-7 as new ASCII strings are needed. 		5.	Press +/-	— is displayed.
 7. Continue repeating steps 5 & 6 until you have entered all your ASCII values. If you make an error, refer to the next section: <i>Editing strings</i>. 8. To view your newly entered ASCII values, press MENU → repeatedly P. Repeat steps 2-7 as new ASCII strings are needed. 		6.	Key in your first ASCII value, then press MENU ▶	The value is stored and <i>End</i> is displayed.
 8. To view your newly entered ASCII values, press MENU> repeatedly 9. Repeat steps 2-7 as new ASCII strings are needed. 		7.	Continue repeating steps 5 & 6 until you have entered all your ASCII values. If you make an error, refer to the next section: <i>Editing strings</i> .	
9. Repeat steps 2-7 as new ASCII strings are needed.		8.	To view your newly entered ASCII values, press MENU ▶ repeatedly	The indicator scrolls through all the
		9.	Repeat steps 2-7 as new ASCII strings are needed.	values.

Editing strings	There are two keys to remember when inserting or deleting ASCII values in a string: +/- will insert and ZERO will delete. We will use the following example to illustrate how to edit strings: remove and then replace the hyphen from the default string ASCII 01: WEIGH-TRONIX WI-127.					
	 With <i>StringS</i> displayed, press ENTER ▼ 	ASCII 01 is displayed.				
	2. Press ENTER ▼	<i>87</i> , the first ASCII value in the string, is displayed.				
	3. Press (← or MENU) to scroll through the entire string of ASCII values. Stop when the ASCIIvalue you want to delete (in this case, 45-hyphen) is displayed	45 is displayed.				
	 With <i>45</i> displayed, press ZERO 	The hyphen character is deleted and the next value in the list 84 is displayed.				
	5. To insert a character, scroll through the ASCII string until the value that the character will precede is displayed	<i>84</i> is displayed.				
	6. Press +/-	— is displayed.				
	 Key in your ASCII value, then press ENTER ▼ 	The character is inserted in the string and the string name (ASCII 01) is displayed.				
Creating Layouts	After your labels and strings are define that you create/customize the items w	ed, it is within the Layouts submenu hich will be transmitted to a printer.				
	The WI-127 allows the creation of up t indicator contains nine default layouts or create seven additional, new layout	to sixteen different layouts. A new . You may edit any or all of these nine, s.				
Viewing layouts	 With <i>LAYOutS</i> displayed, press ENTER ▼ 	<i>LAY. 01</i> (the first default layout) is displayed.				
	2. Press ENTER ▼	The first item in the layout is dis- played.				
	 Press (← or MENU) to scroll through all the items in the entire layout. 					
	 When you are finished viewing the items, press ESCAPE ▲ 	LAY. 01 is displayed.				

	5.	Press MENU	<i>LAY. 02</i> is displayed. On a new indicator, the nine default layouts are present. You may create up to seven more.
	6.	Repeat steps 1-5 above to view all the layouts.	
Creating new layouts	1.	With <i>LAYOutS</i> displayed, press ENTER ▼	LAY. 01 (string #1) is displayed.
	2.	Press MENU + until	<i>End</i> is displayed.
	3.	Press +/	The next layout in the list will be added. On a new indicator, this will be LAY. 10 .
	4.	With the new layout displayed, press ENTER ▼	<i>End</i> is displayed. This means that there are no items entered for this layout.
	5.	Press +/-	GroSS is displayed and the AC- CEPT annunciator illuminates indicating that you are selecting items.
	6.	Scroll through the list of available layout items (blocks) (see Table 3) by pressing the MENU → key. When the item you wish to insert in the layout is displayed, press ENTER ▼	The ACCEPT annunciator goes off and that item is displayed. Some items (the ones with asterisks in Table 3) require that additional information be entered after select- ing the item. For example, if you choose <i>LF</i> , you must next enter a value for the number of line feeds you want, then press ENTER ▼ once again.
	7.	Continue repeating steps 5 & 6 until you have entered all your layout items. If you make an error, refer to the next section: <i>Editing Layouts</i> .	
	8.	To view your newly entered layout, press MENU ► repeatedly	The indicator scrolls through all the layout items.

Editing layouts	The laye am fror	ere are two keys to remember when out: +/- will insert and ZERO will dele ple to illustrate how to edit layouts: r m default layout 01.	inserting or deleting items in a ete. We will use the following ex- emove and then replace the line feed
	1.	With <i>LAYoutS</i> displayed, press ENTER ▼	LAY. 01 is displayed.
	2.	Press ENTER ▼	<i>1 SP</i> , the first item in the layout is displayed.
<i>To delete any displayed block, press the ZERO <i>key.</i></i>	3.	Press MENU to scroll through the layout. Stop when the item you want to delete <i>1 LF</i> (one line feed)is displayed	1 LF is displayed
	4.	With <i>1 LF</i> displayed, press ZERO	The item is deleted and the next itemin this case, <i>End</i> is displayed.
	5.	To insert an item in a layout, you must display the item it will <u>precede</u> . In this example, we will insert a line feed in front of <i>End</i>	<i>End</i> is displayed.
	6.	Press +/-	<i>GroSS</i> is displayed and the AC- CEPT annunciator illuminates indicating that you are selecting items.
	7.	Scroll through the list in Table #3 of available items by pressing the MENU key until <i>LFS</i> is displayed	<i>LFS</i> is displayed.
	8.	Press ENTER	0 is displayed.
	9.	Key in the number of line feeds you want, 1 for this example, and press ENTER ▼	<i>1 LF</i> is displayed.
	10.	Press ESCAPE to return to	LAY. 01

Creating Groups

The default for the **PRINT** key is Group 2.

You may print other groups by keying in the correct group number, then pressing **PRINT**. Note: This option must be enabled in the service menu first. A group is the combination of your layout and the assigned serial port through which the data is sent. The Groups submenu is where you specify which ports will print which layouts.

A total of nine groups is available. Within each group, up to three ports can output layouts. Port one is standard; **ports 2 & 3 are offered only if addi-tional serial boards are installed**. Each port is then assigned a layout to print.

The default group settings are:

Group 1:	Port 1 prints Layout 5
Group 2:	Port 1 prints Layout 6
Group 3:	Port 1 prints Layout 7
Group 4:	Port 1 prints Layout 8

Here are two examples of how the groups might be set up using three serial ports:

Group 1:	Port 1 prints Layout 1	Group 2:	Port 1 prints Layout 5
	Port 2 prints Layout 2		Port 2 prints nothing
	Port 3 prints Layout 3		Port 3 prints Layout 2

Follow the instructions below to set up your groups.

1.	With <i>GrouPS</i> displayed, press ENTER ▼	GrouP 1 is displayed.
2.	Press MENU → to scroll through the list of available groups. To insert a new group, with <i>End</i> displayed, press +/ A total of nine groups is available. When the group you wish to define is displayed, press ENTER ▼	<i>Port 1</i> is displayed.
3.	Press ENTER ▼····	LAYOut is displayed.
4.	a. If you do not want to print from this port, press MENU ►	<i>NONE</i> is displayed.
	 b. If you do want to print from this port, press ENTER ▼, then key in the correct layout number 	XX (layout number) is displayed.
5.	Press ENTER ▼	Port 1 is displayed. (If you are only setting up this one port, go to step 8.)
6.	You may now select a layout for Port 2 (if available). With <i>Port 1</i> displayed, press MENU ▸	<i>Port 2</i> is displayed.
7.	Repeat steps 3-5 to set up Port 2. Press MENU ► to set up Port 3 (if available)	<i>Port 3</i> is displayed.
8.	Repeat steps 3-5 to set up Port 3. Press MENU	Inhibit is displayed.

With more than one serial port installed, the group# must assign a layout# or the choice NONE for each serial port for every group used.

	9. Press ENTER ▼	YES is displayed.
	10. a. If you wish to inhibit the printout when motion is detected, press ENTER ▼	Yes is selected and <i>Inhibit</i> is displayed.
	 b. If you do not wish to inhibit the printout when motion is detected, press MENU ▶, then press ENTER ▼ 	No is selected and <i>Inhibit</i> is displayed.
	11. Press	GrouP 1 is displayed.
	12. Press MENU .	GrouP 2 is displayed.
	13. Press ENTER ▼	Port 1 is displayed.
	14. Repeat steps 3-13 above to set up	all the remaining groups.
Broadcast	This item enables or disables continuc group number must be defined.	ous send. If you enable this feature, a
	 With <i>broAdcSt</i> displayed, press ENTER ▼ 	no is displayed. If you do not wish to enable continuous send, STOP HERE.
	2. To enable, press MENU	<i>GrouP</i> is displayed.
<i>If you want leading zeroes in your printouts or broadcast and autosend information, key in leading zeroes when setting</i>	 Press ENTER ▼ Key in the group number you want continuously sent, then press ENTER ▼ 	<i>1</i> is displayed. The new group is selected and
division size.		broAdcSt is displayed.
Autosend	This item enables or disables autosen motion ceases with weight on the scale autosend the scale must go below 1% stable weight. If you enable this feature	d. Autosend is automatic print after e above 1% of capacity. To retrigger stable weight and then above 1% e, a group number must be defined.
The 1% trigger threshold cannot be altered.	 With <i>AutoSEnd</i> displayed, press ENTER ▼ 	no is displayed. If you do not wish to enable autosend, STOP HERE.
	2. To enable, press MENU	GrouP is displayed.
	3. Press ENTER ▼	<i>1</i> is displayed.
	 Key in the group number you want sent, then press ENTER ▼ 	. The new group is selected and <i>AutoSEnd</i> is displayed.

Using Inputs and Outputs on the WI-127

Standard Inputs (defaults shown)

The inputs are configurable. See *127 Inputs Menu* section.

For Inbound/Outbound or In-Motion defaults see the appropriate section in the back of this manual.

<u>Input</u>	Connection	Action
#1	TB15-2	Remote Zero Key
#2	TB15-3	Remote Print Key
#3	TB15-4	Go to Net Mode
#4	TB15-5	Go to Gross Mode
#5	TB15-6	Remote (pushbutton) Tare Key
#6	TB15-7	Remote Select Key
#7	TB15-8	Remote Unit Key
	TB15-9	Ground

To activate an input, wire them through a normally open switch to ground on TB15.

To cause the related action to occur, activate the input. If the action is not able to be performed (i.e. because of motion), the indicator will keep trying while the input is activated. Individually, an input must be deactivated before it can perform the action again.

Standard Outputs	<u>Output</u>	Connection	<u>Cutoff</u>	<u>Bounds</u>
		TB14-1	+22.8 VD0	2
		TB14-2	Positive R	elay Voltage
	#1	TB14-3	Cutoff 1	Follows Under Annunciator
	#2	TB14-4	Cutoff 2	Follows Accept Annunciator
	#3	TB14-5	Cutoff 3	Follows Over Annunciator
Optional Cutoff Card	<u>Output</u>	<u>Action</u>	Connec	tion
	#1	Cutoff 1	TB22-1	
	#2	Cutoff 2	TB22-2	
	#3	Cutoff 3	TB22-3	
	#4	Cutoff 4	TB22-4	
	#5	Cutoff 5	TB22-5	
	#6	Cutoff 6	TB22-6	
	#7	Cutoff 7	TB22-7	
	#8	Cutoff 8	TB22-8	
	#9	Cutoff 9	TB23-1	
	#10	Cutoff 10	TB23-2	
	#11	Motion	TB23-3	
	#12	Gross	TB23-4	
	#13	Spare		
	#14	Spare		
	#15	Spare		
	#16	Fault	TB23-8	
		+22.8 VDC	TB25-2	
		output		
		GND	TB25-4	

WI-127 Disassembly and Reassembly

Follow the instructions in this section to disassemble the WI-127.

- 1. Unplug the WI-127 from the power source.
- 2. Remove the back of the WI-127 by removing the sixteen acorn nuts and pulling the back cover from the case. See Figure 25.



3. If you need to remove the mother board disconnect all the wires and the ribbon cable leading to the mother board and remove the ten hold-down screws shown in Figure 26.



4. To reassemble the unit reverse the above procedure.

Installing Option Cards

When serial boards are installed in the same stack, port two is always on the bottom. When installed in different stacks (side by side) port two is always closest to the power supply.

- 1. Follow the disassembly instructions on previous page.
- 2. Option cards plug into J19 or J20 on the mother board. Remove the four hold-down screws shown in Figure 27 for J19 or J20.
- 3. Install the standoffs in these holes and plug in the option card.
- 4. Attach the option card to the standoffs with the screws.



- Main board
- 5. Reassemble the unit.

WI-127 Inbound/Outbound Software

This section of the WI-127 Service manual covers the optional inbound/ outbound software. This software has the following additions made to the service menus. The complete service menus are included at the end of this section. Below are descriptions of each additional item.

G.T.N. (After Define in the Options menu)

These parameters configure the items that affect the inbound/outbound functionality of the indicator.

Inbound Selects the print group for the inbound transaction. If Group is selected, you may then key in the group number to print. If **None** is selected, a group will not be printed. Group 2 is the default. Outbound Selects the print group for the outbound transaction. If **Group** is selected, you may then key in the group number to print. If None is selected, a group will not be printed. Group 3 is the default. Report Selects the print group for the channel report. If **Group** is selected, you may then key in the group number to print. If **None** is selected, a group will not be printed. Group 5 is the default. Edit Allows editing of the inbound/outbound function. If Sealed is selected, you may not edit the inbound/outbound data. If **Unsealed** is selected, editing is allowed. Sealed is the deafult.

Tares (After G.T.N. in the Options menu)

This parameter configures the items that affect the tare register functionality of the indicator.

ReportSelects the print group for the tare register part of the
indicator.If Group is selected, you may then key in the group number
to print. If None is selected, a group will not be printed.

Group 6 is the default.

WI-127 Inbound/Outbound Serial Communications

Serial communication in the WI-127 involves layouts, ASCII strings, and groups. Their relationship is this: The **ASCII strings** allow entry of alphanumeric characters that can be assigned to a layout; the **layouts** contain the information sent out each port; and the **groups** set up each port and what is transmitted from it.

The WI-127 Inbound/Outbound indicator has a total of 32 available print layouts. These layouts replace the sixteen found in the standard WI-127.

Twenty-nine of these layouts are predefined. You may use them as they are, or you may customize them to fit your particular application.

Six of these layouts are used as defaults. Below you will find examples of these regularly used default printouts. Note that the layouts use other layouts within themselves (see the italics to the right of each element of the printouts). This allows for a high degree of customization. You will find all the predefined layouts mapped out on the following pages.

Layout #1: Displayed Weight

N 2500 1b

hannanananan

Layout #25: Inbound ticket

Date 04-07-97	Layout 2
Inbound Time 10:30 AM	Layout 3
Truck# 4	Layout 4
Transaction 1	Layout 5
Weight 1500 lb	Layout 6
1	

Layout # 26: Outbound Ticket

Date 8	4-07-97	Layout 7
Inbour	d Time 10:30 AM	Layout 3
Outbou	nd Time 10:30 AM	Layout 8
Truck	4	Layout 4
Transa	ction 1	Layout 5
Gross	3000 1b	Layout 9
Tare	1500 lb	Layout 10
Net	1500 lb	Layout 11

.ayouts

Layout # 28: Inbound/Outbound Report

18:31 AM	04-07-97	Layout
Truck#	Net Total	Layout
	1000 15	Lavout
2	1500 lb	Layout
3	1000 15	Layout
4	1500 lb	Layout
5	0 1b	Layout
Truck	Inbound	Layout
5	2000 15	Layout

Layout # 27: Stored Tare Transaction

10:46	AM 04-07-97	Layout 12
Taret	4	Layout 13
Gross	3000 1b	Layout 14
Tare	2000 1b KP	Layout 15
Net	1000 15	Layout 16

Layout # 29: Stored Tare Report

10:46 A	1 04-07-97	Layout
Tare#	Net Total	Layout
1	0 1b	Layout
2	1500 lb	Layout
3	0 1b	Layout
4	1000 lb	Layout
5	0 1b	Layout
Tare#	Tare wt.	Layout
1	500 1b PB	Layout
2	1000 1b KP	Layout
3	1500 lb PB	Layout
4	2000 1b KP	Layout
5	1000 1b PB	Layout

Predefined layouts

Below are the actual layout codes for the 29 predefined layouts. They are numbered in the same order in which they are available in the indicator.





Layout items

Print layouts are constructed using various elements including ASCII strings/ characters, print items, and other layouts. Following are 16 print items which have been added to the WI-127 Inbound/Outbound indicator. The standard WI-127 has 19 items. Adding these 16, you will have a total of 35 items with which to build print layouts. These items are found in the "Layouts" section of the Options Sub-Menu of the Service Menu.

As you scroll through the list of items, you will find the following new items:

Print Items	Description
Channel	Currently selected inbound/outbound channel is transmitted.
Hour in	Time of the inbound/outbound weighment for the currently selected channel is transmitted.
Day in	Date of the inbound/outbound weighment for the currently selected channel is transmitted.
Inbound	Inbound weight for the currently selected channel is trans- mitted.
Ch Gross	Inbound/outbound gross weight for the currently compleyed transaction is transmitted.
Ch Tare	Inbound/outbound tare weight for the currently completed transaction is transmitted.
Ch Net	Inbound/outbound net weight for the currently completed transaction is transmitted.
Ch Total	Inbound/outbound net accumulator value for the currently selected channel is transmitted.
Ch Count	Inbound/outbound transaction counter value for the currently selected channel is transmitted.
Register	Currently selected tare register number is transmitted.
Rg Type	Source of the tare weight for the currently selected tare register is transmitted. The two default values are "Pb" (pushbutton) and "KP" (keypad).
Rg Total	Net accumulator value for the currently selected tare register is transmitted.
Rg Count	Transaction counter value for the currently selected tare register is transmitted.
nn By Ch	"Layout nn" is used once for every inbound/outbound channel in existence, in ascending order. This supports the ability to generate inbound/outbound database reports.
nn By In	"Layout nn" is used once for every inbound/outbound channel that has an inbound weight, in ascending order. This supports the ability to generate inbound/outbound database reports.
nn By Rg	"Layout nn" is used once for every tare register in existence, in ascending order. This supports the ability to generate tare database reports.

ASCII strings

As mentioned in the previous section, layouts may include a number of elements, on of which is ASCII strings. These ASCII strings allow you to customize your printouts with custom wording.

The WI-127 Inbound/Outbound can store up to sixteen ASCII strings, each containing up to 32 individuals characters. These strings are numbered 1-16.

The WI-127 Inbound/Outbound contains 15 default ASCII strings. Below is a table containing the 15 default strings. Use these, or develop your own custom messages.

	Table 6: ASCII String Worksheet																			
1	87	69	73	71	72	45	84	82	79	78	73	88	32	87	73	45	49	50	55	end
	W	Е	I	G	Н	-	Т	R	0	N	I	х	sp	w	1	-	1	2	7	
2	68	97	116	101	32	end														
	D	а	t	е	sp															
3	84	105	109	101	32	end														
	Т	i	m	е	sp															
4	73	110	98	111	117	110	100	32	end											
	I	n	b	0	u	n	d	sp												
5	79	117	116	98	111	117	110	100	32	end										
	0	u	t	b	0	u	n	d	sp											
6	84	114	117	99	107	35	32	end												
	Т	r	u	с	k	#	sp													
7	84	97	114	101	35	32	end													
	Т	а	r	е	#	sp														
8	84	114	97	110	115	97	99	116	105	111	110	32	end							
	Т	r	а	n	s	а	С	t	i	0	n	sp								
9	87	101	105	103	104	116	32	end												
	W	е	i	g	h	t	sp													
10	78	101	116	32	84	111	116	97	108	end										
	Ν	е	t	sp	Т	0	t	а	I											
11	45.6	32.3	45.13	CR	LF															
	6 -	3 sp	13 -	carriage return	line feed															
12	84	97	114	101	32	119	116	46	end											
	Т	а	r	е	space	w	t	-												
13	71	114	111	115.2	end															
	G	r	0	2 s																
14	84	97	114	101	32	end														
	Т	а	r	е	space															
15	78	101	116	32.2	end															
	Ν	е	t	2 sp																

Printing Groups

In order to print, the layouts in the WI-127 are assigned to groups. These groups are in turn assigned to specific serial ports. A group may contain several layouts or only one layout.

Each group can have up to three serial ports. Each port can have a different layout assigned to it. Port #1 is always the onboard seril port; ports #2 and #3 are add-on option cards.

The default group settings in the WI-127 are as follows:

Group #	Port 1	Port 2	Port 3	Inhibit
1	Layout 1	None	None	Yes
2	Layout 25	None	None	Yes
3	Layout 26	None	None	Yes
4	Layout 27	None	None	Yes
5	Layout 28	None	None	No
6	Layout 29	None	None	No

Each group can be printed separately by using the "N print" feature under "Print" in the set-up menu. The operator presses the number of the group before pressing the **PRINT** key. The information assigned to that group number will be printed. Pressing **1** and **PRINT** will print group #1, pressing **2** and **PRINT** will print group #2, etc.



An additional parameter is added to the Inbound/Outbound Reset Menu.

User Menu Modifications

User Menu

These items are offered in the user menu.

G.T.N. - Accesses inbound/outbound function.

Tares - Accesses multiple tare registers.

Hour - View/edit the time.

Day - View/edit the date.

Id - View/edit the ID number.

Bounds - Accesses the checkweighing parameters.

- F1 G.T.N. Accesses inbound/outbound weighing function.
- F2 Tares Accesses multiple tare registers.
- F3 Cutoffs Accesses the cutoff registers.


Push SELECT to exit the menu







Inbound/Outbound Service Menu Part 2













WI-127 In-Motion Software

This section of the WI-127 Service manual covers the optional in-motion software for Conveyor/Monorail scales. This software has the following additions made to the service menus. The complete service menus are included at the end of this section. Below are descriptions of each additional item.

Conveyor (After Define in the Options menu)

Choose this if you want the indicator to operate as normal. The inputs used for in-motion weighing are ignored. The cutoffs, analog output, B.C.D. output, and displayed weight, all work as normal.

Choose this to use the indicator for in-motion weighing. The indicator uses the built in reset/set inputs to start and stop averaging weight readings. An in-motion weighment is the average of all these weight readings. Every time an in-motion weighment is calculated, the indicator does the following:

Updates the Gross and Net variables with the new weighment

Updates the Cutoff outputs, Checkweighing outputs, B.C.D. output and the Analog output for the new weight

Triggers an auto-print, if enabled

Displays the new weighment for 7 seconds or until the next weighment begins (dashes) or an error occurs.

Tare (After Conveyor in the Options menu)

It is always possible to enter tare to any resolution but this selection determines how gross, tare, and net are displayed, printed, and calculated.

- **0.1 d*** The net weight is calculated internally to 10 times the resolution, but displayed and printed to the nearest division. Tare values are printed and displayed at 0.1 division.
- **1 d** Allows no extra resolution on the tare value. The net weight is calculated as on a standard indicator.

Default Setup Modifications

Scale

No

Yes

Capacity 100 lb Division .02 lb AZT 3 divisions Update 1 Update/Second

Filter/Threshold

Filter constant = 3

100 lb (The filter threshold should be set at the configured capacity as a minumum.)

Options

Define *Autosend* Group 1 (Displayed Weight) Buttons *Print/P.B. Print* Group 1 (Displayed Weight)

Autoprint

While in the in-motion mode, autoprint changes functionality to automatically print each time an in-motion weighment is made through the in-motion logic. The default group for Autoprint is 1. (Displayed weight) While in in-motion mode, the autoprint functions in the background.

Cutoffs/Checkweigh

While in the in-motion mode, the cutoffs and over/under/accept outputs are only updated as each in-motion weighment is made. The outputs follow the displayed in-motion weighments (gross or net) If an erroneous in-motion weighment is made, the outputs drop out until the next valid weighment is made.

Analog output/B.C.D. output

The weight output cards follow the in-motion weighments while in the inmotion mode. As usual configuration determines whether to follow the gross, net, or displayed weighments.

Dynamic Weighment Serial Output

The **Gross** and **Net** weights in the layout menus follow the in-motion weighments while in the in-motion modes. Each time the indicator calculates a new average, the gross and net weights are calculated based on the new weighment. The **gross** and **net** change from the last In-motion weighment value when the indicator returns to live weight display. Dashes are printed if 'no' is selected for 'inhibited' for that group and dashes are on the display to indicate in-motion sampling.

User Menu

These items are offered in the user menu.

Id - View/edit the ID number.

Hour - View/edit the time.

Day - View/edit the date.

F1

Tare Registers - View/Edit the 10 tare registers.

F2

Over - View/edit the over register.

Under - View/edit the under register.

Target - View/edit the target register.

F3

Cutoffs - View/edit the cutoff registers.

New Layout Items

Label Averaged

Outputs an ASCII string defined to represent the status of the Selected weight, Averaged or Live. The default for an averaged weight is "AVERAGED". The default for a static weighment is a null string. Configuration for the two ASCII strings appear in the **ASCII/** Labels menu under the headings "Averaged" and "Live".

Layouts and Groups

No changes are made to the default layouts and groups.

Inputs-Onboard

Inputs are redefined.

Input	In-Motion Assignments*
I	Remote Zero Key
2	Remote Print Key
3	Remote Select Key
4	Remote Units Key
5	Remote (push-button) Tare Key
6	In-Motion Sensor Input Entrance
7	In-Motion Sensor Input Exit

Display modes

In these display modes, the only function that is offered from the front panel is the entrance into the Service menus. After entering the service menus, the indicator stops the in-motion functionality.

	If the indicator is in a user menu or editing a register, these display modes do not appear on the display. In this case the in-motion operations appear to occur in the background.		
	This indicates that the indicator is sampling the current item on the scale. As soon as the sampling is completed, the weight is calculated and displayed.		
	Annunciator 5 (ID) This annunciator is used to indicate that the display is showing the current in-motion weighment. This display appears for seven seconds after each in-motion weighment is calculated. This mode can be interrupted by a new weighment (dashes).		
Weighing	Sampling occurs from leading edge to trailing edge of the reset/set input. The leading edge must correspond to the weight being entirely on the live rail, and the trailing edge must correspond to the weight just ready to begin leaving the live rail.		
Errors	 Six seconds maximum are allowed from arrival to exit. This supports a 12 inch package at a minimum speed of 30 ft/min on a 4 ft conveyor scale. If 6 seconds elapse, an error message is displayed, and auto- print is not initiated. The error message persists until a new weighment is begun, but no longer than 7 seconds (unless retriggered by a subse- quent weighment.) After 7 seconds, the display reverts to live weight. 		
	2) At least two samples are required to be accumulated to consider a weighment to be valid. This corresponds to 1/30 th of a second (or 1/10 ft at 180 ft/min). This requirement is violated when boxes are too long or a conveyor is moving too fast. If less than 2 samples are accumulated, the weighment is considered to be in error and is handled in the same manner as (1) above.		
	 Weighments less than the upper limit of the AZT window are considered to be in error and are handled in the same manner as (1) above. 		

WI-127 to Conveyor and Monorail Wiring Information

conveyor scale or in-motion monorail scale is as follows:				
Photocell J-box (conveyor only)	Wire (Conv.)	Color (Mono)	WI-127	Function
TB1-2	White	White	TB15-8	Set input (exit trigger)
TB1-3	Red	NA	TB14-1	+22 VDC Power
TB1-4	Black	Black	TB15-9	Logic Gnd
TB1-5	Green	Red	TB15-7	Reset input (entrance trigger)
	Shield	Shield	Chassis	Shield

The wiring information to connect a WI-127 indicator to a CVC/CVCS

In-Motion Conveyor Miscellaneous Information

The WI-127 would need to have the special in-motion software installed to be compatible with the CVC operation. The recommended filter settings for the in-motion operation is a Filter time constant of 3 and a threshold equal to full scale capacity. The in motion system will only weigh and transmit data properly if there is only one package on the scale at a time. With packages identical in size, this means front edge to front edge spacing of at least the length of the conveyor. With varying length package applications there are two criteria which must be met:

- 1) With a package on the conveyor scale, the next one coming on the scale must not break the entrance photocell beam prior to the one on the scale breaking the exit beam.
- 2) With a package on the conveyor scale, the exiting package must clear the exit beam prior to the package entering the scale clearing the entrance beam.

If either of these rules are violated erroneous weights may be transmitted or weight values not transmitted at all.

This simple formula will help you figure the minimum package spacing needed for unequal package sizes.

Package spacing = Conveyor length + (longest package - shortest package) (front edge to front edge)

The diagram below shows a formula for figuring throughput of identically sized packages.





Push SELECT to exit the menu







In-Motion Service Menu Part 2

Out. 1-8 is restricted to 1-3 when optional I/O board is not installed		
Outputs	Inputs	Voltages
Sequence Out 1-8 Out 9-16	Standard Option	13 Volts -5 Volts 10 Volts 24 Volts
Out. nn 00.01000 00.01000	11111111 11111111	13.0 -5.0 10.7 22.8
Out. 9-16 is not offered when Op optional I/O board is not installed	otion is not offered if option I/O board is not installed.	nal













WI-127 INDICATOR (115/230VAC) PARTS AND ASSEMBLY

DESCRIPTION	W-T P/N	QTY
nclosure,SST	49057-0017	1
ezel Gasket	49061-0011	1
eypad / Backer Plate Assy (standard)	49060-0012	1
eypad / Backer Plate Assy (GTN)	49060-0038	1
lain Pc Board Assy (115VAC)	49067-0015	1
lain Pc Board Assy (230VAC)	49067-0023	1
lear Cover Gasket	49062-0010	1
lear Cover	49063-0019	1
ep Nut,#8-32	1025-00125	23
crew,Sem, #6-32 X .25" L	14473-0223	10
Cap Nut,Modified,#10-32	26513-0013	2
lylon bolt	1019-11926	1
lat Washer	1030-12680	1
Cap Nut,#10-32	15786-0016	14
Cap Nut,#38-16	15771-0070	2
ooth Washer, .38"	15698-0179	2
lat Washer, .38"	16163-0017	2
leoprene Pad	19563-0025	2
crew, #8-32 X .44	14473-0363	4
lubber Bumper	15349-0024	4
ock Washer, #8	14474-0040	4
Cap Nut,#8-32	15771-0039	4
tand Bracket	49367-0012	1
ock Nut	17777-0021	2
leoprene Washer	26357-0053	2
train Relief	15257-0057	2
train Relief	15257-0024	3
leoprene Washer	26357-0046	3
leoprene Washer, (Used W/ Pwr Cord)	26357-0038	1
train Relief (Used W/ Pw Cord)	15257-0040	1
Power Cord W/ Plug End (USA)	49180-0017	1
Ground Wire Assy	48712-0032	1
witch/Cable Assy	48178-0021	1
Decal (FCC compliance)	29941-0019	1
Decal (115VAC / FCC compliance)	49849-0036	1
Decal (230VAC / FCC compliance)	49849-0044	1
Decal (Fuse Type) 115VAC	29348-0034	1
Decal (Fuse Type) 230VAC	29348-0026	1
Decal (Fuse Warning)	20958-0018	1
Decal (Torque Specs)	48933-0019	1
use, 1.0 amp 115VAC (Slo Blow)	48561-0141	2
use, 0.5 amp 230VAC (Slo Blow)	48561-0117	2
lut, Hex, 3/8 x 16 UNC	14471-0225	2
anel Mount Bracket	49645-0016	2
anel Mtg Gasket	49647-0014	1



92





NOTE:

WI-127 INDICATOR (115/230VAC) MAIN PC BOARD P/N 49067-0015 (115VAC) P/N 49067-0023 (230VAC)

When using barriers, the two pin jumper is not connected and should be stored on pin-1. The barrier should drop the excitation voltage down to the range of (2.0 to 3.8 volts) . If only one load cell is being used, the voltage could be greater than 3.8 volts. In this case, add a load resistor to increase the current through the barrier to drop the voltage.

SITION		
P10		
1 - 2		

WI-127 INDICATOR (115/230VAC) **OPTION BOARDS** ANALOG OUTPUT AND SERIAL IO



ONLY.

TB21-2

TB21-3

≤ load

10 TD 50 mo

1

0=0FF 1=0N

ACTIVE

(INTERIOR PWR SUPPLY)

94

ORT # 2 or 3 JUMPER POSITION			
ΡE	P31	P32	P33
32	1 - 2		
22		1 - 2	
85		1 - 2	
nt			1 - 2

NDTE: SOME TEXT, SUCH AS REFERENCE DESIGNATORS, SIGNAL DESIGNATION, ETC. MAY BE IN DIFFERENT LOCATIONS ON YOUR ACTUAL BOARD. THE DIFFER-ENCES ON THIS PAGE ARE FOR CLARITY ONLY.





DATA DUTPUTS: There are 5 1/4 decades of data using the following lines; 100,000, 80,000, 40,000, 20,000, 10,000, 8,000, 4,000, 2,000, 1,000, 800, 400, 200, 100, 80, 40, 20, 10, 8, 4, 2 and 1. The data is left justified with an implied decimal point. For example, scales with capacities of 1, 10, 100, 1,000, etc. will use the 100,000 line for the most significient digit. Scales with capacities of 2, 40, 500, 6,000, 80,000, etc. will use 80,000, 40,000, 20,000 and 10,000 lines (as appropriate) for the most significant digit.

WI-127 INDICATOR (115/230VAC) **OPTION BOARDS CUTOFF & INPUT AND BCD PARALLEL**

WI-127 INDICATOR (115/230VAC) KEYPAD OVERLAY P/N49058-0016 (STANDARD) KEYPAD OVERLAY P/N49058-0024 (GTN) AND MATRIX



<u>GTN VERSION</u>



<u>Keypad Matrix</u>



WI-127 INDICATOR (115/230VAC) OPTION BOARD PROCEDURE AND INSTALLATION

M			
-	DESCRIPTION	W-T P/N	QTY
	Nut, Kep, #6-32	1025-00114	4/board
	NO PART		
	Standoff, m/f, 6-32 x .56L	15437-5000	4/board
	Screw, Sem, #6-32 x .25L	1006-02600	4/board
	Analog Output Power Cable Assy	49375-0053	1
	Analog Output pc. Board Assy	49148-0018	
	<0 <i>r</i> >	50097-0017	
	Serial I/O pc Board Assy	49152-0011	
	Cutoff & Input pc Board Assy	49156-0017	
	BCD Parallel Output pc Board Assy	49160-0011	





-4.61 MAX-

WI-127 WALL MOUNT INSTRUCTIONS

TO MOUNT THE WI-127 TO A WALL, USE 5/16" STEEL BOLTS THROUGH THE FOUR 11/32" (.343) DIA. KEYHOLE SLOTS IN THE MOUNTING BRACKET. DIRECTLY MOUNTING INT SHEETROCK OR PLASTER WITHOUT REINFORCEMENT IS NOT RECOMMENDED.

FOR MOUNTING ONTO SHEET METAL USING 5/16" BOLTS, NUT, AND LOCK WASHERS, MINIMUM RECOMMENDED MATERIAL THICKNESS IS 16 GAGE (.059" THICK)STEEL DR .080"THICK ALUMINUM. FOR BOLTING INTO THREADED HOLES INTO METAL, MINIMUM 1/4" THREAD LENGTH IS RECOMMENDED.

FOR FASTENING INTO WOODEN STRUCTURES SUCH AS WALL STUDS, USE 5/16" DIA. LAG BOLTS WITH 3/4" MINIMUN DEPTH INTO WOOD.





GASKET

SUPPLIED WITH THE PANEL MOUNTING KIT. THE INDICATOR IS SECURED TO THE PANEL USING FOUR 1/4" BOLTS, LOCK WASHERS AND NUTS (NOT INCLUDED) . THE RECOMMENDED THICKNESS FOR THE MOUNTING PANEL IS 0,075" FOR STEEL AND 0.090" FOR ALUMINUM.

WI-127 INDICATOR (115/230VAC) PANEL MOUNT OUTLINE DRAWING



Weigh-Tronix

1000 Armstrong Dr. Fairmont, MN 56031 USA Telephone: 507-238-4461 Facsimile: 507-238-4195 e-mail: industrial@weigh-tronix.com www.weigh-tronix.com

Weigh-Tronix Canada, ULC 217 Brunswick Blvd. Pointe Claire, QC H9R 4R7 Canada Telephone: 514-695-0380 Facsimile: 514-695-6820



Weigh Bar® is a registered trademark of Weigh-Tronix Inc. 07/06/00 127SERVC.P65 PN 29633-0012e2 Printed in USA Weighing Products & Systems