



Visit us at www.TestEquipmentDepot.com

## Ranger RD Compact Scales Instruction Manual



## Table of contents

Page
------

<b>1</b> 1.1 1.2 1.3	Introduction	<b>4</b> 4 5 9
<b>2</b> 2.1 2.2 2.3 2.4 2.5 2.6 2.7	Operation         Switching on and off         Zeroing / Zero point correction         Simple weighing         Weighing with tare         Dynamic weighing         Printing results         Cleaning	11 11 12 13 13 14
<b>3</b> 3.1 3.2 3.3 3.4 3.5 3.6 3.7	Settings in the menu Operating the menu Overview Scale settings (SCALE) Application settings (APPLICATION) Terminal settings (TERMINAL) Configuring interfaces (COMMUNICATION) Diagnosis and printing out of the menu settings (DIAGNOS)	15 15 17 19 21 22 23 26
<b>4</b> 4.1 4.2 4.3	Interface description OHAUS interface commands SICS interface commands TOLEDO Continuous mode	<b>27</b> 27 29 32
5	Event and error messages	34
<b>6</b> 6.1 6.2	<b>Technical data and accessories</b> Technical data Accessories	<b>36</b> 36 40
<b>7</b> 7.1 7.2 7.3 7.4	Appendix Information for certified scales in EC countries Safety checks Table of Geo Values Sample protocols	<b>41</b> 41 42 45
8	Index	46

## **1** Introduction

## 1.1 Safety instructions

#### **CAUTION!**

Do not use RD..S / RD..S IP65 / RD..M in hazardous areas! Our product range includes special devices for hazardous areas.



#### **CAUTION!**

Use only scales with Protection Class IP65, if:

- the scale is used in wet areas
- wet cleaning is necessary
- the scale is used in a dusty environment

Even with Protection Class IP65, the scale must not be used in environments with corrosion risk.

▲ Never flood the scale or immerse it in liquid.

## DANGER!

Electric shock hazard!

▲ Always pull out the mains plug before any work on the device.

#### DANGER!

Electric shock hazard if the mains cable is damaged!

- Check the mains cable for damage regularly and replace it immediately if it is damaged.
- ▲ On the rear side of the device, maintain a clearance of at least 3 cm in order to prevent the mains cable bending too much.

## CAUTION!

On no account open the device!

The warranty is void if this stipulation is ignored. The device may only be opened by authorized persons.

▲ Call OHAUS Service.







#### CAUTION!

Handle the compact scale with care.

The scale is a precision instrument.

- ▲ When the weighing pan has been removed, never clean the area under the load plate holder with a solid object!
- $\blacktriangle$  Do not put excessive loads on the scale.
- Avoid banging the weighing pan.

#### Disposal

→ Observe the valid environmental regulations when disposing of the scale.

If the device has a rechargeable battery:

The battery contains heavy metals and therefore must not be disposed of with normal waste.

→ Observe the local regulations for disposing of environmentally hazardous materials.

#### Note Use with foodstuffs

Parts coming into contact with foodstuffs have smooth surfaces and are easy to clean. The materials used do not splinter and are free of harmful substances.

With foodstuffs, it is recommended to use the supplied protective cover.

- → Clean the protective cover regularly and carefully.
- → Replace damaged or very dirty protective cover immediately.

### 1.2 Description

This user manual applies to the following types of compact scales:

- Ranger RD..S with strain gauge weighing cell, Protection Class IP43
- Ranger RD..S IP with strain gauge weighing cell, Protection Class IP65
- Ranger RD..M with MonoBloc, Protection Class IP43

The compact scales are available in a small and large size in various capacities and resolutions.

The power supply is carried out via a built-in power supply device, an internal rechargeable battery with an external mains adapter or an external battery.

One of the following options can also be ordered:

- Additional interface RS232 or RS485
- Ethernet interface
- USB interface
- Digital I/O

#### 1.2.1 Overview

- 1 Display
- 2 Scale specifications
- 3 Load plate
- 4 Adjustable foot
- 5 Keys



- 1 Power supply connection
- 2 Fast and fine pressure equalization, only with Protection Class IP65
- 3 Optional interface
- 4 RS232 interface



#### 1.2.2 Display



- **1** Active interface
- 2 Weighing range display
- **3** Battery charge level; only present on scales with a battery
- 4 Symbol for displaying net values
- **5** Symbol for dynamic weighing
- 6 Weight units
- 7 7-segment display, 7 digits, with decimal point
- 8 Stability monitor (goes out when a stable weight value is reached)
- 9 Sign
- **10** Identification for changed or calculated weight values, e. g. higher resolution, minimum weight not reached

#### 1.2.3 Keypad

#### Main functions

Кеу	Function in operating mode	Function in the menu
ON/OFF Exit	Switching device on / off, abort	To the last menu item -End-
ZERO	Setting scale to zero	Scrolling back
TARE	Taring scale	Scrolling forward
PRINT MENU Yes	Transfer key Long key press: Calling up menu	Activating menu item Accepting selected setting

#### Additional functions

Кеу	Function
Units	Switching weight unit
Clear	Clear key

#### Putting into operation 1.3

#### 1.3.1 Selecting or changing the location

The correct location is crucial to the accuracy of the weighing results!



→ Select a stable, vibration-free and if possible a horizontal location.

The ground must be able to safely bear the weight of the fully loaded scale.

Observe the following environmental conditions:

- No strong drafts •

No direct sunlight

No excessive temperature fluctuations •



#### Aligning the scale

Only scales that have been aligned precisely horizontally provide accurate weighing results. The certified scales have a spirit level to simplify alignment.

→ Turn the adjustable feet of the scale until the spirit level's air bubble is inside the inner circle.

**Major geographical** location changes

The manufacturer adjusts each scale to the local gravity conditions (GEO value). In the event of major geographical location changes, this setting must be adjusted by a service technician. Certified scales must also be recertified observing the national certification regulations. These steps are not necessary for scales with an internal calibration weight.



#### 1.3.2 Connecting the power supply

#### **CAUTION!**

Before connecting the scale to the mains, check whether the voltage value printed on the rating plate corresponds with the local mains voltage.

- Never connect the device if the voltage value printed on the rating plate is different to the local mains voltage.
- $\rightarrow$  Plug the mains plug into the socket.

After connection, the device performs a self-test. When the zero display appears, the device is ready to weigh.

- → Calibrate the device in order to obtain the greatest possible precision, see Section 3.3.1.
- **Note** Partially certified scales (scales with first-level certification) must be certified by an authorised body or by the OHAUS Service.
  - → Call OHAUS Service.



Scales with a built-in battery can work independently from the mains for approximately 30 hours in normal operation. A prerequisite for this is that the background lighting is switched off and that no peripheral devices are connected.

The device automatically switches to battery operation as soon as the mains supply is interrupted. When the mains supply is restored, the device automatically switches back to mains operation.

The battery symbol indicates the present charging level of the battery. 1 segment corresponds to approx. 25 % capacity. When the symbol flashes the battery must be charged (min. 4 hours). The charging period is extended if work is continued during charging. The battery is protected against overcharging.

Note

- The battery's charging capacity can be reduced under continuous mains operation.
  - → To maintain the charging capacity, after a maximum of 4 weeks discharge the battery completely before recharging it.

## 2 Operation

## 2.1 Switching on and off

#### Switching on → Press ON/OFF.

The scale conducts a display test. When the weight display appears, the scale is ready to weigh.

#### Switching off $\rightarrow$ Press ON/OFF.

Before the display goes out, -OFF- appears briefly.

#### 2.2 Zeroing / Zero point correction

Zeroing corrects the influence of slight changes on the load plate.

- Manual 1. Unload scale.
  - 2. Press ZERO.

The zero display appears.

**Automatic** In the case of scales that cannot be certified, the automatic zero point correction can be deactivated in the menu or the amount can be changed.

As standard, the zero point of the scale is automatically corrected when the scale is unloaded.

### 2.3 Simple weighing

- 1. Place weighing sample on scale.
- 2. Wait until the stability monitor **O** goes out.
- 3. Read weighing result.

## 2.4 Weighing with tare

#### 2.4.1 Taring

→ Place the empty container on the scale and press TARE. The zero display and the symbol NET appear. The tare weight remains saved until it is cleared.

#### 2.4.2 Clearing the tare

→ Unload scale and press TARE.

The symbol **NET** goes out, the zero display appears.

or

#### → Press Clear.

The symbol **NET** goes out, the gross weight appears in the display.

If  ${\tt A.CL-tr}$  is activated in the menu, the tare weight is automatically cleared as soon as the scale is unloaded.

#### 2.4.3 Automatic taring

#### Prerequisite

A-tArE is activated in the menu, the symbol **T** flashes in the display.

→ Place the container or packaging material on the scale.

The packaging weight is automatically saved as the tare weight, the zero display and the symbol **NET** appear.

#### 2.4.4 Chain tare

#### Prerequisite

The tare function CHAIn.tr is activated in the menu.

With this function it is possible to tare several times if, for example, cardboard is placed between individual layers in a container.

1. Place the first container or packaging material on the scale and press TARE.

The packaging weight is automatically saved as the tare weight, the zero display and the symbol **NET** appear.

- 2. Weigh the weighing sample and read/print out the result.
- 3. Place the second container or packaging material on the scale and press **TARE** again.

The total weight on the scale is saved as the new tare weight. The zero display appears.

- 4. Weigh the weighing sample in the second container and read/print the result.
- 5. Repeat the last two steps for other containers.

## 2.5 Dynamic weighing

With the dynamic weighing function, it is possible to weigh restless weighing samples such as live animals. If this function is activated, the symbol a appears in the display.

With dynamic weighing, the scale calculates the mean value from 56 weighing operations within 4 seconds.

#### With manual start Prerequisite

AVErAGE -> MAnuAL is selected in the menu.

The weighing sample must be heavier than 5 scale divisions.

- 1. Place the weighing sample on the scale and wait until it has stabilized.
- 2. Press **PRINT** to start dynamic weighing.

During dynamic weighing, horizontal segments appear in the display, and the dynamic result is then displayed with the symbol \*.

3. Unload the scale to be able to start a new dynamic weighing operation.

#### With automatic start Prerequisite

AVErAGE -> AUtO is selected in the menu.

The weighing sample must be heavier than 5 scale divisions.

1. Place the weighing sample on the scale.

The scale starts the dynamic weighing automatically.

During dynamic weighing, horizontal segments appear in the display, and the dynamic result is then displayed with the symbol \*.

2. Unload the scale to be able to perform a new dynamic weighing operation.

### 2.6 Printing results

If a printer or computer is connected to the scale, the weighing results can be printed out or sent to a computer.

→ Press **PRINT**.

The display contents are printed out and transferred to the computer. See Section 7.4 for sample protocols.





## 2.7 Cleaning

#### CAUTION!

Electric shock hazard!

▲ Before cleaning with a damp cloth, pull out the mains plug to disconnect the unit from the power supply.

#### **CAUTION!**

When the weighing pan has been removed, never clean the area under the load plate holder with a solid object!

This could damage the weighing cell.

Other cleaning information:

- Use damp cloths.
- Do not use any acids, alkalis or strong solvents.
- Do not clean using a high-pressure cleaning unit or under running water.
- If very dirty, remove the weighing pan, protective cover (if present) and adjustable feet and clean these items separately.
- Follow all the relevant instructions regarding cleaning intervals and permissible cleaning agents.

## 3 Settings in the menu

Settings can be changed and functions can be activated in the menu. This enables adaptation to individual weighing requirements.

The menu consists of 6 main blocks containing various submenus on several levels.

### 3.1 Operating the menu

#### 3.1.1 Calling up the menu and entering the password

The menu differentiates between 2 operating levels: Operator and Supervisor. The Supervisor level can be protected by a password. When the device is delivered, both levels are accessible without a password.

- **Operator menu** 1. Press **MENU** and keep it pressed until COdE appears.
  - 2. Press MENU again.

The menu item terminic appears. Only the submenu device is accessible.

- **Supervisor menu** 1. Press **MENU** and keep it pressed until COdE appears.
  - 2. Enter the password and confirm with  $\ensuremath{\textbf{Yes}}$  .

The first menu item SCALE appears.

Note No supervisor password has been defined when the device is first delivered. Therefore respond to the password inquiry with MENU when you call up the menu for the first time. If a password has still not been entered after a few seconds, the scale returns to weighing mode.

#### Emergency password for Supervisor access to the menu

If a password has been issued for Supervisor access to the menu and you have forgotten it, you can still enter the menu:

→ Press **ZERO** 3 times and confirm with **Yes**.



#### 3.1.2 Selecting and setting parameters

- Scrolling on one level
- → Scroll forward: Press No.
- → Scroll back: Press Back.
- Activating menu items/ accepting selection

→ Press Yes.

Exiting menu 1. Press Exit.

The last menu item END appears.

2. Press Yes.

The inquiry SAVE appears.

- 3. Confirm inquiry with **Yes** to save the settings and return to weighing mode. -or-
- $\rightarrow$  Press No to discard changes and return to weighing mode.

Level 1	Level 2	Level 3	Level 4	Level 5	Level 6	Page
SCALE	CAL	-				19
	display	UNIt1	g, <b>kg</b> , oz,	lb, t		19
		UNIt2	<b>g</b> , kg, oz,	lb, t		
		rESOLU				
		UNt.rOLL	ON, OFF			
	tArE	A-tArE	ON, OFF			19
		ChAIn.tr <b>ON</b> , OFF				
		A.CL-tr	ON, OFF			
	ZErO	AZM	OFF; 0.5 d;	1 d; 2 d;	5 d; 10 d	20
	rEStArt	ON/ <b>OFF</b>				20
	FILtEr	VibrAt	LOW, MEd, H	IIGH,		20
		PrOCESS	UNIVEr, dOS	ING		
		StABILI	FASt, StAnd	rd, Precise		
	FACt	tEMP	OFF, 1K, 2K, 3K, <b>5K</b>			20
	Min.WEiG	ON/OFF ON, <b>OFF</b>				21
	rESEt	SUrE?				
APPLIC	AVErAGE	OFF, AUtO, MAnuAL				
	rESEt	SUrE?				21
tERMINL	device	SLEEP	OFF, 1 min,	3 min, 5 m	in	22
		PWr OFF	YES, NO			
		b.LIGHt	ON, OFF			
	ACCESS	SUPErVI				22
	rESEt	SUrE?				22
COMMUNI	COM 1/COM 2	MOde	Print			23
			A.Print			
			CONTINU			
			dIALOG			
			CONt.OLd			
			dIAL.OLd			
			dt-b	GrOSS	ON, OFF	
				tArE	ON, OFF	
				nEt	ON, OFF	

## 3.2 Overview

Level 1	Level 2	Level 3	Level 4	Level 5	Level 6	Page
			dt-G	GrOSS	ON, OFF	
				tArE	ON, OFF	1
				nEt	ON, OFF	1
			COnt-Wt		1	
			2nd.dISP			
		PriNtEr	tEmPLat	StdArd, tEM tEMPLt2	IPLt1,	23
			ASCi.Fmt	LINE.FMt	MULti Single	
				LENGtH	1100	1
				SEPArAt	, ;	
				Add LF	09	
		PArAMEt	bAUd	300 38400		23
			PAritY	7 nonE, 8 n 8 odd, <b>7 E</b> V	onE, 7 odd, <b>7EN</b> , 8 EVEN	
			H.SHAKE	NO, <b>XONXOFE</b> nEt 485	,nEt 422,	
			NEt.Addr	0 31		
			ChECSuM	ON, <b>OFF</b>		-
			Vcc	ON, OFF		1
		rSt.COMx	SUrE?			24
COMMUNI	OPtION	EtH.NEt	IP.AddrS, S	SUBNEt, GATE	WAY	24
		USb	USb tESt			24
		diGitAL	IN 14	<b>OFF</b> , ZErO, Print, CLEA	tArE, Ar, Unit	24
			OUT 1 4	<b>OFF</b> , StAbLE AbV.Min, Ur OVErLd, StA	E, bEL.Min, ndErLd, Ar	
	dEF.PrN	tEmPLt1/ tEMPLt2	LINE 1 LINE 20	NOt.USED, H GrOSS, tArf StArLN, CrI	EAdEr, E, nEt, JF, F FEEd	25
diagnos	test sc	intErN/ExtB	L ErN	,	•	26
	KboArd					-
	display					-
	SNr					
	LiSt					-
	rESEt.AL SURE?				-	

## 3.3 Scale settings (SCALE)

#### 3.3.1 CAL – calibration (adjustment)

This menu item is not available for certified scales without internal calibration weight.

Internal	For scales with an internal calibration weight:
	1. Unload scale.
	2. Activate menu item CAL with <b>Yes</b> . The scale calibrates with the internal calibration weightInt CAL- appears in the display. After calibration is completed, -donE- appears briefly in the display, and the scale automatically returns to weighing mode.
External	For scales without an internal calibration weight:
	1. Unload scale.
	2. Activate menu item CAL with <b>Yes</b> . The scale determines the zero point. -0- appears in the display. The calibration weight to be placed on the scale then flashes in the display.
	3. If necessary, change the weight value displayed with No.
	4. Place the calibration weight on the scale and confirm with Yes.
	The scale calibrates with the calibration weight loaded. After calibration is completed, $-donE-$ appears briefly in the display, and the scale automatically returns to weighing mode.

#### 3.3.2 DISPLAY – weighing unit and display accuracy

UNIt1	Select weighing unit 1: g, kg, oz, lb, t	
UNIt2	Select weighing unit 2: g, kg, oz, lb, t	
rESOLU	Select readability (resolution), model-dependent	
UNt.rOLL	When UNT.rOLL is switched on, the weight value can be displayed in all available units with <b>Units</b> .	
Notes	<ul> <li>On certified scales, the weighing units oz and Ib are displayed with the symbol *.</li> <li>On certified scales, resolutions that deviate from the scale definition are displayed without a weighing unit and with the symbol *.</li> <li>On dual-range/dual interval scales, resolutions marked with I&lt;-&gt; 1/2I are divided up into 2 weighing ranges / intervals, e.g. 2 x 3000 d.</li> </ul>	

#### 3.3.3 TARE – tare function

A-tArE	Switching on/off automatic taring
CHAIn.tr	Switching on/off chain tare
A.CL-tr	Switching on/off automatic taring with automatic clearing of the tare weight when the load is removed from scale

	3.3.4	ZERO – automatic zero update
AZM		On certified scales, this menu item does not appear.
		Switching on/off automatic zero update and selecting zeroing range.
		Possible settings: OFF; 0.5 d; 1 d; 2 d; 5 d; 10 d

#### 3.3.5 RESTART – automatic saving of zero point and tare value

ON/OFF	When the Restart function is activated, the last zero point and tare value are saved.
	After switching off / on or after a power interruption, the device continues to work with
	the saved zero point and tare value.

#### 3.3.6 FILTER – adaptation to the ambient conditions and the weighing type

VIbrAt	Adaptation to the ambient conditions
LOW	• Very steady and stable environment. The scale works very quickly, but is very sensitive to external influences.
MEd	Normal environment. The scale operates at medium speed.
HIGH	• Restless environment. The scale works more slowly, but is insensitive to external influences.
Process	Adaptation to the weighing process
UNIVEr	Universal setting for all weighing samples and normal weighing goods
dOSING	Dispensing liquid or powdery weighing samples
StAbILI	Adjusting the weighing speed
FASt	The scale operates very fast.
StAndrd	The scale operates at medium speed.
PrECISE	The scale operates with the greatest possible reproducibility.
	The slower the scale works, the greater the reproducibility of the weighing results.

#### 3.3.7 FACT – automatic temperature-dependent adjustment

This menu item appears only on scales with an internal calibration weight.

TEMP	Defining the temperature difference for automatic calibration
OFF	Switching off automatic calibration in the case of a temperature difference
1K/2K/3K/5K	• Automatic calibration in the case of a temperature change of 1 K, 2 K, 3 K or 5 K since the last adjustment

#### 3.3.8 MIN.WEIG – minimum weight

This menu item appears only if the service technician has saved a minimum weight.

ON/OFF	Switching minimum weight function on/off
	If the weight on the scale falls below the stored minimum weight, an * appears on the display in front of the weight indicator.

#### 3.3.9 **RESET** – resetting scale settings to factory settings

SUrE?	Confirmation inquiry
	Reset the scale settings to factory settings with Yes
	Do not reset scale settings with No

## 3.4 Application settings (APPLICATION)

#### 3.4.1 AVERAGE – determining the average weight for an unstable load

OFF	Calculating average weight switched off
AUtO	Calculating average weight with automatic start of the weighing cycle
MAnuAL	Calculating average weight with manual start of the weighing cycle via <b>PRINT</b>

#### 3.4.2 **RESET** – resetting application settings to factory settings

SUrE?	Confirmation inquiry
	Reset the application settings to factory settings with Yes
	Do not reset the application settings with No

## 3.5 Terminal settings (TERMINAL)

#### 3.5.1 DEVICE – Sleep mode, energy-saving mode and display backlighting

SLEEP	This menu item only appears on devices in mains operation.
	When SLEEP is activated, the scale switches off display and backlighting after the time period set when not in use. The display and backlighting are switched on again at the press of a key or if the weight changes.
	Possible settings: OFF, 1 min, 3 min, 5 min
PWr OFF	This menu item only appears on devices in battery operation.
	When PWr OFF is activated, the device switches itself off automatically after approx. 3 minutes when not in use.
b.LIGHt	Switching the display backlighting on/off.
	On scales with a battery, the background lighting switches itself off automatically if there has been no activity on the scale for 5 seconds.
Note	This menu item is accessible without a Supervisor password.

#### **3.5.2** ACCESS – password for Supervisor menu access

SUPErVI	Password entry for Supervisor menu access
ENtER.C	Request to enter password
	→ Enter the password and confirm with Yes
rEtYPE.C	Request to repeat the password entry
	→ Enter the password again and confirm with Yes
Notes	The password can consist of up to 4 characters.
	<ul> <li>The <b>PRINT</b> key must not be part of the password. It is required for confirming the password.</li> </ul>
	• The key <b>ZERO</b> may only be used in combination with another key.
	• If you enter an impermissible code or make a typing error in the repetition, COdE.Err. appears in the display.

#### 3.5.3 **RESET** – resetting terminal settings to the factory settings

SUrE?	Confirmation inquiry
	Reset terminal settings to the factory settings with Yes
	Do not reset the terminal settings with No

## **3.6 Configuring interfaces (COMMUNICATION)**

#### 3.6.1 COM1/COM2 -> MODE – operating mode of the serial interface

Print	Manual data output to the printer with <b>PRINT</b>
A.Print	Automatic output of stable results to the printer (e.g. for series weighing operations)
CONTINU	Ongoing output of all weight values via the interface
dIALOG	Bi-directional communication via OHAUS or MT-SICS commands, control of the scale via PC
CONt.OLd	As per CONtINU, see above, but with 2 fixed blanks in front of the unit (compatible with Spider 1/2/3)
dIAL.OLd	As per dIALOG, see above, but with 2 fixed blanks in front of the unit (compatible with Spider 1/2/3)
dt-b	DigiTOL-compatible format.
GROSS	Transfer of the gross weight, identified with "G"
tArE	Transfer of the tare weight
nEt	Transfer of the net weight
dt-G	As per dt-b, see above, gross weight identified with "G"
COnt-Wt	TOLEDO Continuous mode
2nd.dISP	For connecting a second display (automatically activates the 5-V voltage supply at Pin 9)

#### 3.6.2 COM1/COM2 -> PRINTER – settings for protocol printout

This menu item only appears if the mode "Print" or "A.Print" is selected.

tEmPLat	Selecting protocol printout
StdArd	Standard printout
tEmPLt1	Printout in accordance with Template 1
tEmPLt2	Printout in accordance with Template 2
ASCi.FmtT	Selecting formats for the protocol printout
LINE.Fmt	Line format: MULTI (multi-line) or SINGLE (single-line)
LENGtH	• Line length: 0 100 characters, appears only with line format MULtI
SEPArAt	• Separator: , ; . / \ _ and space; appears only with line format SINGLE
Add LF	• Line feed: 0 9

#### 3.6.3 COM1/COM2 -> PARAMET – communication parameter

bAUd	Selecting baud rate: 300, 600, 1200, 2400, 4800, 9600, 19200, 38400 baud
PAritY	Selecting parity: 7 none, 8 none, 7 odd, 8 odd, 7 even, 8 even
H.SHAKE	Selecting Handshake: NO, XONXOFF, nEt422, nEt485 (network operation as per RS485 standard via the optional RS422/RS485 interface, only for COM1)

NET.Addr	Assigning network address: 0 31, only for NET 485
ChECSuM	Activating checksum byte (appears only in TOLEDO Continuous mode)
Vcc	Switching 5V voltage, e.g. for a bar code reader, on / off

# 3.6.4 COM1/COM2 -> RESET COM1/RESET COM2 – resetting serial interface to factory settings

SUrE?	Confirmation inquiry
	Reset interface settings to factory settings with Yes
	Do not reset the interface settings with No

#### **3.6.5 OPTION** – configuring options

If no option is installed or is not yet configured, N.A. appears in the display.

EtH.NEt	Configuration of the Ethernet interface								
IP.AddrS	Enter IP address								
SUBNEt	Enter Subnet address								
GATEWAY	Enter Gateway address								
USb	Configuration of the USB interface								
USb TEST	• Test of the USB interface. After the test has been passed, rEAdY appears in the display.								
diGitAL	Configuration of the digital inputs/outputs								
IN 1 4	Configuring inputs 1 4								
OFF	Input not assigned								
ZErO	• ZERO Key								
tArE	• TARE Key								
PriNt	PRINT Key								
CLEAr	Clear Key								
UNIt	Units Key								
OUT 1 4	Configuring outputs 1 4								
OFF	Output not assigned								
StAbLE	Stable weight value								
bEL.MIN	Minimum weight not reached								
AbV.MIN	Minimum weight reached or exceeded								
UNdErLd	Insufficient load								
OVErLd	Overload								
StAr	Changed/calculated value								

tEMPLt1/tEMPLt2	Selecting Template 1 or Template 2
LINE 1 20	Select line
NOt.USEd	Line not used
HEAdEr	• Line as header. The contents of the header must be defined via an interface com- mand, see Section 4.1.
GROSS	Gross weight
tArE	Tare weight
nEt	Net weight
Starln	Line with ***
CrLF	Line feed (blank line)
F FEEd	Page feed

3.6.6 DEF.PRN – configuring templates

	3.7	Diagnosis and prinning out of the menu sentings (DIAGNOS)
tESt SC		

Internal	Testing scale with internal calibration weight
	• -Int CAL- appears in the display during the test.
	• After completion of the test, ideally *d=0.0g briefly appears in the display, after which the scale changes to the next menu item KboArd.
External	Testing scale with external calibration weight
	1. The scale checks the zero point0- appears in the display. The test weight flashes in the display.
	2. If necessary, change the weight value displayed with No.
	3. Put the calibration weight on the scale and confirm with Yes.
	4. The scale checks the calibration weight put on them.
	5. After the test is completed, the deviation from the last calibration briefly appears in the display, ideally *d=0.0g, after which the scale changes to the next menu item KboArd.
KboArd	Keyboard test
PUSH 1 6	• Press the keys <b>ON/OFF</b> , <b>ZERO</b> , <b>TARE</b> , <b>PRINT</b> , <b>Units</b> , <b>Clear</b> keys in order. If the key works, the scale changes to the next key.
	Note
	You cannot abort the keyboard test!
	If you have selected the menu item KboArd, you must press all keys.
display	Display test: The scale displays all functioning segments
SNr	Display of the serial number
LiSt	Printout of a list of all menu settings
rESEt.AL	Resetting all menu settings to the factory settings
SUrE?	Confirmation inquiry
	Reset all menu settings to the factory settings with Yes
	Do not reset the menu settings with No

## 3.7 Diagnosis and printing out of the menu settings (DIAGNOS)

## 4 Interface description

## 4.1 OHAUS interface commands

The Ranger RD scales support the OHAUS command set. With OHAUS commands, it is possible to configure, query and operate the scale from a PC.

#### 4.1.1 Available OHAUS commands

Command	Meaning
OS	Set to print weight value immediately (stable or unstable) after P command
15	Set to print stable weight value after P command
SA	Set to print stable weight value automatically
CA	Set to print weight value continuosly
хА	Set to print weight value at specified interval, where $x = 1$ to 3600 (seconds)
Р	Print displayed weight value
Z	Zero the scale
Т	Tare the scale
хT	Define the Preset Tare, where $x = tare$ weight in grams
H x "y"	Define the Header H <space>x<space>"y", where <math>x = 1, 2, 3, 4, 5</math> (line number) and "y" = header text in quotes (up to 24 characters).</space></space>
PSI	Change to MT-SICS command set
POH	Return to OHAUS command set

NOTE: All commands must be followed by a carriage return, line feed <CR><LF>

#### 4.1.2 Requirements for communication between scale and PC

- The scale must be connected to the RS232, RS485, USB or Ethernet interface of a PC with a suitable cable.
- The interface of the scale must be set to "Dialog" mode, see Section 3.6.1.
- A terminal progam must be available on the PC, e.g. HyperTerminal.
- The communication parameters baud rate and parity must be set in the terminal program and on the scale to the same values, see Section 3.6.3.

#### 4.1.3 Notes on network operation via the optional interface RS422/485

Up to 32 scales can be networked with the optional RS422/485 interface. In network operation, the scales must be addressed from the computer before commands can be sent and weighing results received.

### 4.1.4 Output format

Resp	ons	e to	o th	ie F	) C(	omi	na	nd												
Field	Field																			
1	2		3			4	5		6	7	8	9			10					
POL	SP	SP	W	W	W	W	W	W	W	SP	UN	UN	SP	ST	SP	Ν	Ν	Ν	CR	LF
Field Field Field Field	Field 1: POL = polarity, space if positive, - if negative Fields 2, 4, 6, 8: SP = space Field 3: W = weight up to 6 digits plus the decimal point Field 5: UN = unit of measure 1 or 2 characters																			
Field Field Field	Field 3: ON = drift of medsure 1 of 2 characters Field 7: ST = stability status, space when stable, ? when unstable, Field 9: N = NET or B/G Field 10: CR LF = carriage return, line feed																			

Resp	on	se	to ti	ne P	rint	key	/																						
Line	Fi	eld																											
	1							2	3																				
1	S	С	Α	L	Е	:	SP	SC	CR	LF																			
	1	2													3	4							5	6		7	8	9	
2	G	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	POL	W	W	W	W	W	W	W	SP	UN	UN	SP	ST	CR	LF
3	Τ	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	POL	W	W	W	W	W	W	W	SP	UN	UN	SP		CR	LF
4	Ν	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	POL	W	W	W	W	W	W	W	SP	UN	UN	SP	ST	CR	LF
Line Field Field Field Field Field Field Field Field Field Field	1 1:2:3:2/ 1:2:3:4:5,6:8:9:	SC SC CR 3, G = SP V V 7: UN ST CR	ALE = s LF 4 = GI = s U = s U = t = s LF	:SP scale = cc pole pole veigh = sp unit tabil =:cc	= he e ide arria , T = e, u arity ht, u bace of m lity s arria	eadi entifi ge 1 = Ta p to y, sp p to meas statu ge 1	ing er, retui 13 ace 6 c sure us, s retui	and 1 = rn, l e if p digit , 1 space rn, l	spo sco ine Net oosil s pl or 2 ce w	tive, tive, us t cha /her feed	, 2 - if he d arac	= s neg lecir ters ble,	cale lativ mal	e 2 re poi	nt n uns	stab	le,	doe	es r	not (	abt	bly	to L	ine	3				

## 4.2 SICS interface commands

The Ranger RD compact scales support the command set MT-SICS (METTLER TOLEDO Standard Interface Command Set). With MT-SICS it is possible to configure, query and operate the scale from a PC. SICS commands are divided up into various levels.

To use the MT-SICS commands, first send the OHAUS command PSI. To return to the OHAUS command set, send the OHAUS command POH.

	Command	Meaning
LEVEL O	@	Reset the scale
	10	Inquiry of all available SICS commands
	11	Inquiry of SICS level and SICS versions
	12	Inquiry of scale data
	13	Inquiry of scale software version
	14	Inquiry of serial number
	S	Send stable weight value
	SI	Send weight value immediately
	SIR	Send weight value repeatedly
	Z	Zero the scale
	ZI	Zero immediately
LEVEL 1	D	Write text into display
	DW	Weight display
	K	Keyboard check
	SR	Send and repeat stable weight value
	Т	Tare
	TA	Tare value
	TAC	Clear tare
	TI	Tare immediately
LEVEL 2	C2	Calibrate with the external calibration weight
	C3	Calibrate with the internal calibration weight
	110	Inquire or set scale ID
	111	Inquiry of scale type
	P100	Print out on the printer

#### 4.2.1 Available SICS commands

	Command	Meaning						
	P101	Print out stable weight value						
	P102	Print out current weight value immediately						
	PWR	Power On/Off						
	SIRU	Send weight value in the current unit immediately and repeat						
	SIU	Send weight value in the current unit immediately						
	SNR	Send stable weight value and repeat after every weight change						
	SNRU	nd stable weight value in the current unit and repeat after every weight chang						
	SRU	Send weight value in the current unit and repeat						
	ST	After pressing the Transfer key, send the stable weight value						
	SU	Send stable weight value in the current unit						
	TST2	Start test function with external weight						
	TST3	Start test function with internal weight						
LEVEL SPECIAL	CLR	Clear						
	131	Header for the printout						
	ICP	Send configuration of the printout						
	LST	Send menu settings						
	M01	Weighing mode						
	M02	Stability setting						
	M03	Autozero function						
	M19	Send calibration weight						
	M21	Inquire/set weight unit						
	Р	Print text						
	P130	Weight value, unit and price						
	PRN	Print out at every printer interface						
	RST	Restart						
	SFIR	Send weight value immediately and repeat quickly						
	SIH	Send weight value immediately in high resolution						
	SWU	Switch weight unit						
	SX	Send stable data record						
	SXI	Send data record immediately						
	SXIR	Send data record immediately and repeat						
	U	Switch weight unit						

#### 4.2.2 Requirements for communication between scale and PC

- The scale must be connected to the RS232, RS485, USB or Ethernet interface of a PC with a suitable cable.
- The interface of the scale must be set to "Dialog" mode, see Section 3.6.1.
- A terminal progam must be available on the PC, e.g. HyperTerminal.
- The communication parameters baud rate and parity must be set in the terminal program and on the scale to the same values, see Section 3.6.3.

#### 4.2.3 Notes on network operation via the optional interface RS422/485

Up to 32 scales can be networked with the optional RS422/485 interface. In network operation, the scales must be addressed from the computer before commands can be sent and weighing results received.

Des	scription of the steps	Host	Direction	Scale
1.	Host addresses the scale, e.g. with the address 3A hex.	<esc> 3A</esc>	>	
2.	Host sends a SICS command, e.g. SI	SI <crlf></crlf>	>	
3.	The scale confirms receipt of the command and sends the address back		<	<esc> 3A</esc>
4.	The scale responds to the command and returns control of the bus to the host		<	S_S45.02_kg <crlf></crlf>

## 4.3 TOLEDO Continuous mode

#### 4.3.1 TOLEDO Continuous commands

The scale supports the following input commands in TOLEDO Continuous mode:

Command	Meaning
P <cr><lf></lf></cr>	Print out the current result
T <cr><lf></lf></cr>	Tare the scale
Z <cr><lf></lf></cr>	Zero the display
C <cr><lf></lf></cr>	Clear the current value
Tx.xxx <cr><lf></lf></cr>	Define tare

#### 4.3.2 Output format in TOLEDO Continuous mode

Weight values are always sent in the following format in TOLEDO Continuous mode:

	Status			Field	1					Field 2							
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
STX	SWA	SWB	SWC	MSD	_	_	-	-	LSD	MSD	-	-	-	_	LSD	CR	CHK
Field	1 6 digits for the weight value that is sent without					nout a	decimal point and unit										
Field 2 6 digits for the					e tare	weigh	nt that	is sen	t withc	out a de	ecima	l poin	t and i	unit			
STX			ASCII characters 02 hex, characters for "start of text"														
SWA,	VA, SWB, SWC Status words A, B, C, see below																
MSD			Most s	significo	ant dig	lit											
LSD			Least	signific	ant dig	git											
CR			Carria	ge Retu	rn, AS	CII ch	aracte	rs 0D	hex								
СНК			Check charao	Checksum (2-part complement of the binary sum of the 7 lower bits of all previously sent characters, incl. STX and CR)							sent						

Status word A									
		Status Bit							
Function	Selection	6	5	4	3	2	1	0	
Decimal	X00	0	1			0	0	0	
position	ХО					0	0	1	
	Х					0	1	0	
	0.X					0	1	1	
	0.0X					1	0	0	
	0.00X					1	0	1	
	0.000X					1	1	0	
	0.0000X					1	1	1	
Numerical	X1			0	1				
increment	X2			1	0				
	X5			1	1				

Status word B	
Function / value	Bit
Gross / net: Net = 1	0
Sign: Negative = 1	1
Overload = 1	2
Movement = 1	3
lb/kg: kg = 1	4
1	5
Powerup = 1	6

Status word C	
Function / value	Bit
0	0
0	1
0	2
Print request = 1	3
Extended = 1	4
1	5
Manual taring, only kg = 1	6

## 5 Event and error messages

Error	Cause	Remedy
Display Dark	Back lighting set too dark	→ Set back lighting (b.LIGHt) brighter
	No mains voltage	→ Check mains
	Unit switched off	→ Switch on unit
	Mains cable not plugged in	$\rightarrow$ Plug in mains plug
	Brief fault	→ Switch device off and back on again
Insufficient load	Load plate not on the scale	→ Place load plate on the scale
	Weighing range not reached	→ Set to zero
Overload	Weighing range exceeded	→ Unload scale
r		→ Reduce preload
	Result not yet stable	➔ If necessary adjust vibration adapter or weigh dynamically
00	Function not permissible	→ Unload scale and set to zero
r - n a - 7	<ul> <li>Zeroing not possible with over- load or insufficient load</li> </ul>	→ Unload scale
Err 6	No calibration	<ul> <li>→ Unplug the mains plug then plug it back in; switch unit off and then back on in battery mode</li> <li>→ Calibrate scale</li> <li>→ Call OHAUS Service</li> </ul>
Frr 17	Printout not yet ended	→ End printout
	Switching the weighing unit	→ End dynamic weighing
Err 18	impermissible during dynamic weighing	→ Switch weighing unit
Err 53	EAROM checksum error	<ul> <li>→ Unplug the mains plug then plug it back in; switch unit off and then back on in battery mode</li> <li>→ Call OHAUS Service</li> </ul>

Error	Cause	Remedy
Weight display unstable	Restless installation location	→ Adjust vibration adapter
	• Draft	→ Avoid drafts
	Restless weighing sample	→ Dynamic weighing
	<ul> <li>Contact between weighing pan and/or weighing sample and surroundings</li> </ul>	→ Remedy contact
	Mains fault	→ Check mains
Incorrect weight display	Incorrect zeroing	→ Unload scale, set to zero and repeat weighing operation
	Incorrect tare value	→ Clear tare
	<ul> <li>Contact between weighing pan and/or weighing sample and surroundings</li> </ul>	→ Remedy contact
	Scale tilted	→ Level scale

## 6 Technical data and accessories

### 6.1 Technical data

#### 6.1.1 Type key

The Ranger RD compact scales are available with various capacities. and platforms that can be seen from the complete type designation.

#### Example

RD6RS	compact scale with capacity 6 kg and small platform
RD35LM	compact scale with capacity 35 kg and large platform
RD3SM	compact scale with capacity ${\bf 3}~{\bf kg}$ and ${\bf extra-small}~{\bf platform}$

#### 6.1.2 General data

RDS, RDS IP, RDM						
Applications	Weighing					
	Dynamic weighing					
Settings	Resolution selectable					
Weighing unit selectable: g, kg, oz, lb, t						
	• Taring function: manual, c	utomatic, chain tare				
	Automatic zero point correction when the scale is switched on and duri ation					
	• Filter for adapting to the ar	nbient conditions (vibration adapter)				
	• Filter for adapting to the weighing type, e.g. dispensing (weighing process adapter)					
<ul> <li>Switch-off function, sleep mode for mains-operated devices, energy-se mode for battery operation</li> </ul>						
	Display lighting					
Accuracy class OIML/NTEP	• RDS	III				
	• RDM	II				
Display	LCD (liquid crystal display	), digits 16 mm high, with back lighting				
Keypad	Pressure point membrane	keypad				
	Scratch-proof labeling					
Housing	Diecast aluminum housing	g; chromium nickel steel weighing pan				
	• Dimensions, see Page 37					
Protection Class (IEC 529,	• RDS, RDM	IP43 (not with Ethernet interface)				
DIN 40050, EN60529)	RDS IP	IP65				

RDS, RDS IP, RDM		
Mains connection	<ul> <li>Direct connection to the mains (MAINS suthe nominal voltage):</li> <li>230 V, 50 Hz, 70 mA</li> <li>240 V, 50 Hz, 70 mA</li> <li>120 V, 60 Hz, 90 mA</li> <li>100 V, 50/60 Hz, 90 mA</li> <li>For battery operation:</li> <li>Connection via mains adapter: 90 – 2</li> <li>Infeed on the unit: 24 V, 1.3 A</li> </ul>	upply voltage fluctuations up to $\pm 10\%$ of 264 V, 47 – 63 Hz, 300 mA
Battery operation	If the voltage supply is interrupted, the un operation	it automatically switches over to battery
Ambient conditions	<ul> <li>Use</li> <li>Altitude</li> <li>Temperature range RDS</li> <li>Temperature range RDM</li> <li>Overvoltage category</li> <li>Contamination level</li> <li>Relative humidity</li> </ul>	Indoor use only up to 2000 m -10 +40 °C / 14 104 °F +10 +30 °C / 50 86 °F II 2 Maximum relative humidity 80 % for temperatures up to 31 °C / 88 °F, decreasing linearly to 50 % relative humidity at 40 °C / 104 °F
Interfaces	<ul><li>1 RS232 interface integrated</li><li>1 other optional interface possible</li></ul>	

#### 6.1.3 Weighing ranges and readability RD..S

The RD..S compact scales with strain gauge weighing cells are supplied in the configuration  $2 \times 3000$  d. Higher readabilities are available from the factory with the optional "Premium" weighing cells.

Capacity	Configuration								
	2 x 3000 d (sto	indard)	1 x 6000 d (with optional "Premium" weighing cells						
	Weighing ranges	Readability (certified)	Weighing range	Readability (certified)					
3 kg	1.5 kg / 3 kg	0.5g/1g	3 kg	0.5 g					
6 kg	3 kg / 6 kg	1g/2g	6 kg	1 g					
15 kg	6 kg / 15 kg	2 g / 5 g	15 kg	2 g					
35 kg	15 kg / 35 kg	5 g / 10 g	35 kg	5 g					
60 kg	30 kg / 60 kg	10 g / 20 g	60 kg	10 g					

#### 6.1.4 Weighing ranges and readability RD..M

Configurations up to 1 x 60.000 e are possible with the RD..M compact scales with MonoBloc technology. Certified RD..M compact scales are supplied as standard with an internal calibration weight.

Model	Weighing interval(s)	Readability d	Verification value e
RD3DSM	600 g / 3,100 g	0.01 g / 0.1 g	0.1 g
RD3SM	3,100 g	0.01	0.1 g
RD6DSM	1,200 g / 6,100 g	0.01 g / 0.1 g	0.1 g
RD6SM	6,100 g	0.01	0.1 g
RD6DRM	1,200 g / 6,100 g	0.1g/1g	1 g
RD6RM	6,100 g	0.2 g	0.2 g
RD15DLM	3,500 g / 15,100 g	0.1g/1g	1 g
RD15LM	15,100 g	0.5 g	0.5 g
RD35DLM	7,000 g / 35,100 g	0.1g/1g	1 g
RD35LM	35,100 g	0.1 g	1 g

#### 6.1.5 Dimensions



	Α	В	C	D	E	F	G	Η	I	K	L
RDS <sup>1)</sup>	335	265	100	240	200	46	276	208	216	165	165
RDR <sup>1)</sup>	335	265	100	240	200	46	276	208	216	_	_
RDL <sup>1)</sup>	370	360	115	350	240	52	310	304	310	_	_

<sup>1)</sup> Dimenions in mm

## 6.1.6 Net weights

Model	without battery	with battery	with internal calibration weight (without battery)
RDRS	4.6 kg	5.3 kg	-
RDRS IP	4.7 kg	5.4 kg	-
RDLS	8.2 kg	8.9 kg	-
RDLS IP	8.3 kg	9.0 kg	-
RDSM	4.9 kg	5.6 kg	5.4 kg
RDRM	4.7 kg	5.4 kg	5.2 kg
RDLM	10.5 kg	11.2 kg	11.7 kg

#### 6.1.7 Interface connections

The compact scale can be fitted with a maximum of 2 interfaces. The following combinations are possible:

COM1	COM2	Note
RS232	_	
RS232	RS232	
RS485	RS232	COM1 can be optionally operated as RS422 or RS485
RS232	Ethernet	not for RDS IP
RS232	USB	
RS232	Digital I/O	

#### 6.1.8 Assignment of the interface connections

Pin	RS232	RS422	RS485	Digital I/O
	(COM1/COM2)	(4-wire, COM1)	(2-wire, COM1)	(COM2)
1	-	-	-	GND
2	TxD1/2	TxD1-	TxD1–/RxD1–	OUTO
3	RxD1/2	RxD1–	-	OUT1
4	-	-	-	OUT2
5	GND	GND	GND	OUT3
6	-	-	-	INO
7	-	TxD1+	TxD1+/RxD1+	IN1
8	-	RxD1+	-	IN2
9	VCC	VCC	VCC	IN3

#### 6.2 Accessories

Designation	Order number
In Use Cover for RDR	21203719
In Use Cover for RDL	21203720
RS232 Cable for PC	80500525
RS232 Cable for Second Scale	80500526
RS232 Cable for SF42 Printer	80500571
Anti-theft Device	80850000
Carrying Case for RDR	80850083
Carrying Case for RDL	80850084
Printer	SF42

## 7 Appendix

## 7.1 Information for certified scales in EC countries



Weighing instruments verified at the place of manufacture bear the preceding mark on the packing label and green "M" sticker on the descriptive plate. They may be set to work immediately.



Weighing instruments which are verified in two steps have no green "M" on the descriptive plate and bear the preceding identifaction mark on the packing label. The second step of the verification must be carried out by the approved OHAUS Service, or by the W&M authorities. Please contact OHAUS Customer Service.

The first calibration step of the verification has been carried out at the manufacturing plant. It comprises all tests according to EN45501-8.2.2. Scales with analog connection to the weighing platform require an additional test according to EN45501-3.5.3.3. However, this test is not mandatory if the terminal bears the same serial number as the weighing platform.

If national regulations in individual countries limit the period of validity of the certification, the operator of such a scale is himself responsible for its timely re-certification.

## 7.2 Safety checks

The compact scales of the Ranger RD series have been checked by accredited testing institutions. They have passed the safety checks listed below and carry the relevant test symbols. Production is subject to production monitoring by the inspection offices.

Country	Test symbol	Standard
Canada		CAN/CSA-C22.2 No. 1010.1-92
USA	c SP us	UL Std. No. 61010A-1
Other countries	CB Scheme	IEC/EN61010-1:2001
	(no identification)	

### 7.3 Table of Geo Values

For weighing instruments verified at the manufacturer's, the geo value indicates the country or geographical zone for which the instrument is verified. The geo value set in the instrument (e.g. "Geo 18") appears briefly after switch-on or is specified on a label.

Table GEO VALUES 3000e shows the geo values for European countries.

Table **GEO VALUES 6000e/7500e** shows the geo values for different gravitation zones.

#### 7.3.1 GEO VALUES 3000e, OIML Class III (European Countries)

Geographical latitude	Geo value	Country
46°22' – 49°01'	18	Austria
49°30' – 51°30'	21	Belgium
41°41' – 44°13'	16	Bulgaria
42°24' – 46°32'	18	Croatia
48°34' – 51°03'	20	Czechia
54°34' – 57°45'	23	Denmark
57°30' - 59°40'	24	Estonia
59°48' - 64°00'	25*	Finland
64°00' – 70°05'	26	
41°20' – 45°00'	17	France
45°00' – 51°00'	19*	
47°00' – 55°00'	20	Germany
34°48' – 41°45'	15	Greece
45°45' – 48°35'	19	Hungary
63°17' – 67°09'	26	Iceland
51°05' – 55°05'	22	Ireland
35°47' – 47°05'	17	Italy
55°30' – 58°04'	23	Latvia
47°03' – 47°14'	18	Liechtenstein
53°54' – 56°24'	22	Lithuiania
49°27' – 50°11'	20	Luxemburg
50°46' – 53°32'	21	Netherlands
57°57' – 64°00'	24*	Norway
64°00' – 71°11'	26	
49°00' - 54°30'	21	Poland
36°58' – 42°10'	15	Portugal
43°37' – 48°15'	18	Romania

Geographical latitude	Geo value	Country
47°44' – 49°46'	19	Slovakia
45°26' – 46°35'	18	Slovenia
36°00' – 43°47'	15	Spain
55°20' – 62°00'	24*	Sweden
62°00' - 69°04'	26	
45°49' – 47°49'	18	Switzerland
35°51' – 42°06'	16	Turkey
$49^{\circ}00' - 55^{\circ}00'$	21*	United Kingdom
55°00' – 62°00'	23	

\* factory setting

Geograhical latitude	Geo value
00°00' - 12°44'	5
05°46' – 17°10'	6
12°44' – 20°45'	7
17°10' – 23°54'	8
20°45' - 26°45'	9
23°54' – 29°25'	10
26°45' – 31°56'	11
29°25' – 34°21'	12
31°56' – 36°41'	13
34°21' – 38°58'	14
36°41' – 41°12'	15
38°58' – 43°26'	16
41°12' – 45°38'	17
43°26' – 47°51'	18
45°38' - 50°06'	19
47°51' – 52°22'	20
50°06' - 54°41'	21
52°22' – 57°04'	22
54°41' – 59°32'	23
57°04' – 62°09'	24
59°32' – 64°55'	25
62°09' – 67°57'	26
64°55' – 71°21'	27
67°57' – 75°24'	28
71°21' – 80°56'	29
75°24' – 90°00'	30

#### 7.3.2 GEO VALUES 6000e/7500e OIML Class III (Height $\leq$ 1000 m)

#### 7.4 Sample protocols

#### Weighing with tare

#### **Dynamic weighing**

43.52 kg

3.78 kg

#### Printout with header

G	0.1085 kg	Dyn	WT
Т	0.0145 kg	Т	
Ν	0.0940 kg		

G = Gross weight

N = Net weight

T = Tare

Dyn WT = dynamically determined weight

#### Protocol of the scale settings (menu point List, see page 26)

SOFTWARE VER	7-0-1.01b			COMMUNICAT	FION
SCALE	_			COM 1 MODE	1:Print
METROLO : SNR : Scale Build	NO APPr 0000000			PriNtEr tEmPLat	1:StdArd
SCAL TVP	2MIILT RN			LINE FN	- /ጦ1•MIII.ͲΤ
BAS UNTT .	ka			LENGTH	1.0
CT CAP1	1 5000 kg				1.0
DECOT 1	1.0000  kg				1.0
CCL CAD2	2.0005  kg			PARAMEI	1.0600
SCL.CAPZ :	0.001 lea			BAUD Data: MV	1.9000
RESOL.Z :	0.001 Kg			PATITY	1:8 none
GEO :	19			H.SHAKE	1:XONXOFF
DISPLAY				ChECSUM	1:OF'F'
UNIt1 :	kg			Vcc	1:0FF
UNIt2 :	g			COM 2	
RESOLU :	0.0005 kg			MODE	2:DIALOG
UNt.rOLL :	ON			PARAMET	
tArE				BAUD	2:9600
A-TARE :	OFF			PAriTY	2:8 nonE
CHAIn.tr :	OFF			H.SHAKE	2:XONXOFF
A.CL-tr :	OFF			ChECSUM	2:0FF
PB.TArE :	ON			Vcc	2:0FF
ZERO				OPTION	
Z-CAPT :	-2 18			EtH.NEt	:N.A.
AZM :	2 d			USB	:N.A.
RESTART :	ON			DEF.PrN	
FILTER				tEmPLt1	
VIBRAT :	MED			LINE 1	:HEAdEr
PROCESS :	UNIVEr			LINE 2	:CrLF
StABILI :	FASt			LINE 3	:GROSS
Min.WEiG				LINE 4	:tArE
SEt.VAL :	0.200 kg			LINE 5	:nEt
ONOFF :	OFF			LINE 6	:F FEEd
	011			LINE 7	:STARLN
				LINE 8	·CrLF
	_			t.EmPLt2	.0111
DVNAMTC .	OFF				
DINAMIC :	OFF				
TERMINAL					
	-				
DEVICE	0.77				
SLEEP :	OFF				
B.LIGHt :	OF.F.				
L		1	l		

OHAUS www.ol	CORP. naus.com	
G	0.1085	kg
T	0.0145	kg
N	0.0940	kg

#### Index 8

## A

Accessories	40
Adjustment	19
Alignment	. 9
Ambient conditions	37
Applications	36
Average 13,	21

## С

Calibrate	19
Chain tare	12
Continuous mode	31

#### D

-	
Dimensions	39
Display	. 7
Display accuracy	19
Dynamic weighing 13,	21

## E

Error messages	34
F	
Filter	20

# l Int

terfaces	
Configure	23
Connections	40

#### K

Keyboard	 8

### Μ

Mains connection	37
Menu	
Application	21
Communication	23
Diagnosis	26
Operation	15
Overview	17
Scale	19
Terminal	22
Menu structure	16

#### 0

OHAUS commands	.27
Operator menu	15
Options 5,	24

# Password

Ρ

Password Power supply Protocol	15 10 13
R Readability Reset	38
Application	21
Interface	24
Scale	21
Terminal RS422/RS485	22 31

## S

Safety checks	41
	1
Sample protocols	45
Scales types	5
Settings	36
SICS commands	29
Supervisor menu	15
Switching off	11
Switching on	11

# T To

	Idre	
3	Automatic	12
0	Chain tare	12
•	Clear	12
	Terminal settings	22
8	TOLEDO Continuous	31
	Type key	36

### W

Weighing ranges	38
Weighing unit	19
Weight	39

## Ζ

Zeroing 1	1
-----------	---

#### LIMITED WARRANTY

Ohaus products are warranted against defects in materials and workmanship from the date of delivery through the duration of the warranty period. During the warranty period Ohaus will repair, or, at its option, replace any component(s) that proves to be defective at no charge, provided that the product is returned, freight prepaid, to Ohaus.

This warranty does not apply if the product has been damaged by accident or misuse, exposed to radioactive or corrosive materials, has foreign material penetrating to the inside of the product, or as a result of service or modification by other than Ohaus. In lieu of a properly returned warranty registration card, the warranty period shall begin on the date of shipment to the authorized dealer. No other express or implied warranty is given by Ohaus Corporation. Ohaus Corporation shall not be liable for any consequential damages.

As warranty legislation differs from state to state and country to country, please contact Ohaus or your local Ohaus dealer for further details.



Ohaus Corporation

with offices worldwide



P/N 22017161 ©2007 Ohaus Corporation, all rights reserved

Printed in Germany

Test Equipment Depot - 800.517.8431 - 99 Washington Street Melrose, MA 02176 - TestEquipmentDepot.com