


NavigatorTM Motion Processor

Programmer's Reference



P M D

Performance Motion Devices, Inc.
12 Waltham St.
Lexington, MA 02421

Revision 1.2, December 2000

NOTICE

This document contains proprietary and confidential information of Performance Motion Devices, Inc., and is protected by federal copyright law. The contents of this document may not be disclosed to third parties, translated, copied, or duplicated in any form, in whole or in part, without the express written permission of PMD.

The information contained in this document is subject to change without notice. No part of this document may be reproduced or transmitted in any form, by any means, electronic or mechanical, for any purpose, without the express written permission of PMD.

Copyright 1998, 1999 by Performance Motion Devices, Inc.

Navigator and **C-Motion** are trademarks of Performance Motion Devices, Inc

Warranty

PMD warrants performance of its products to the specifications applicable at the time of sale in accordance with PMD's standard warranty. Testing and other quality control techniques are utilized to the extent PMD deems necessary to support this warranty. Specific testing of all parameters of each device is not necessarily performed, except those mandated by government requirements.

Performance Motion Devices, Inc. (PMD) reserves the right to make changes to its products or to discontinue any product or service without notice, and advises customers to obtain the latest version of relevant information to verify, before placing orders, that information being relied on is current and complete. All products are sold subject to the terms and conditions of sale supplied at the time of order acknowledgement, including those pertaining to warranty, patent infringement, and limitation of liability.

Safety Notice

Certain applications using semiconductor products may involve potential risks of death, personal injury, or severe property or environmental damage. Products are not designed, authorized, or warranted to be suitable for use in life support devices or systems or other critical applications. Inclusion of PMD products in such applications is understood to be fully at the customer's risk.

In order to minimize risks associated with the customer's applications, adequate design and operating safeguards must be provided by the customer to minimize inherent procedural hazards.

Disclaimer

PMD assumes no liability for applications assistance or customer product design. PMD does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right of PMD covering or relating to any combination, machine, or process in which such products or services might be or are used. PMD's publication of information regarding any third party's products or services does not constitute PMD's approval, warranty or endorsement thereof.

Related Documents

Navigator Motion Processor User's Guide (MC2000UG)

How to set up and use all members of the Navigator Motion Processor family.

Navigator Motion Processor Programmer's Reference (MC2000PR)

Descriptions of all Navigator Motion Processor commands, with coding syntax and examples, listed alphabetically for quick reference.

Navigator Motion Processor Technical Specifications

Four booklets containing physical and electrical characteristics, timing diagrams, pinouts, and pin descriptions of each series:

- MC2100 series, for brushed servo motion control (MC2100TS);
- MC2300 series, for brushless servo motion control (MC2300TS);
- MC2400 series, for microstepping motion control (MC2400TS);
- MC2500 series, for stepping motion control (MC2500TS).

Navigator Motion Processor Developer's Kit Manual (DK2000M)

How to install and configure the DK2000 developer's kit PC board.

Table of Contents

Warranty..... iii

Safety Notice iii

Disclaimer..... iii

Related Documents..... iv

Table of Contents..... v

1 The Navigator Family 7

2 Instruction Reference..... 9

 2.1 How to use this reference 9

3 Instruction Summary Tables..... 119

 3.1 Descriptions by Functional Category 119

 3.2 Alphabetical Listing 123

 3.3 Numeric Listing..... 125

1 The Navigator Family

	MC2100 Series	MC2300 Series	MC2400 Series	MC2500 Series
# of axes	4, 2, or 1	4, 2 or 1	4, 2 or 1	4, 2, or 1
Motor type supported	Brushed servo	Brushless servo	Stepping	Stepping
Output format	Brushed servo (single phase)	Commutated (6-step or sinusoidal)	Microstepping	Pulse and direction
Incremental encoder input	✓	✓	✓	✓
Parallel word device input	✓	✓	✓	✓
Parallel communication	✓	✓	✓	✓
Serial communication	✓	✓	✓	✓
Diagnostic port	✓	✓	✓	✓
S-curve profiling	✓	✓	✓	✓
Electronic gearing	✓	✓	✓	✓
On-the-fly changes	✓	✓	✓	✓
Directional limit switches	✓	✓	✓	✓
Programmable bit output	✓	✓	✓	✓
Software-invertable signals	✓	✓	✓	✓
PID servo control	✓	✓	-	-
Feedforward (accel & vel)	✓	✓	-	-
Derivative sampling time	✓	✓	-	-
Data trace/diagnostics	✓	✓	✓	✓
PWM output	✓	✓	✓	-
Motion error detection	✓	✓	✓ (with encoder)	✓ (with encoder)
Axis settled indicator	✓	✓	✓ (with encoder)	✓ (with encoder)
DAC-compatible output	✓	✓	✓	-
Pulse & direction output	-	-	-	✓
Index & Home signals	✓	✓	✓	✓
Position capture	✓	✓	✓	✓
Analog input	✓	✓	✓	✓
User-defined I/O	✓	✓	✓	✓
External RAM support	✓	✓	✓	✓
Chipset part numbers	MC2140 (4 axes) MC2120 (2 axes) MC2110 (1 axis)	MC2340 (4 axes) MC2320 (2 axes) MC2310 (1 axis)	MC2440 (4 axes) MC2420 (2 axes) MC2410 (1 axis)	MC2540 (4 axes) MC2520 (2 axes) MC2510 (1 axis)
Developer's Kit p/n's:	DK2100	DK2300	DK2400	DK2500

Introduction

This manual describes the format of instructions supported by the Navigator family of Motion Processors from PMD. These devices are members of PMD's second-generation motion processor family, which consists of 12 separate products organized into 4 series.

Each of these devices are complete chip-based motion processors. They provide trajectory generation and related motion control functions. Depending on the type of motor controlled they provide servo loop closure, on-board commutation for brushless motors, and high speed pulse and

direction outputs. Together these products provide a software-compatible family of dedicated motion processors that can handle a large variety of system configurations.

Each of these chips utilize a similar architecture, consisting of a high-speed DSP (Digital Signal Processor) computation unit, along with an ASIC (Application Specific Integrated Circuit). The computation unit contains special on-board hardware that makes it well suited for the task of motion control.

Along with similar hardware architecture these chips also share most software commands, so that software written for one chipset may be re-used with another, even though the type of motor may be different.

Each chipset consists of two PQFP (Plastic Quad Flat Pack) ICs: a 100-pin Input/Output (I/O) chip, and a 132-pin Command Processor (CP) chip.

The four different series in the Navigator family are designed for a particular type of motor or control scheme. Here is a summary description of each series.

Family Summary

MC2100 Series (MC2140, MC2120, MC2110) – This series outputs motor commands in either Sign/Magnitude PWM or DAC-compatible format for use with brushed servo motors, or with brushless servo motors having external commutation.

MC2300 Series (MC2340, MC2320, MC2310) – This series outputs sinusoidally commutated motor signals appropriate for driving brushless motors. Depending on the motor type, the output is a two-phase or three-phase signal in either PWM or DAC-compatible format.

MC2400 Series (MC2440, MC2420, MC2410) – This series provides microstepping signals for stepping motors. Two phased signals per axis are generated in either PWM or DAC-compatible format.

MC2500 Series (MC2540, MC2520, MC2510) – These chipsets provide high-speed pulse and direction signals for stepping motor systems.

2 Instruction Reference

2.1 How to use this reference

This document is in two parts: first, a detailed description of all host instructions, and second, a set of summary tables listing the instructions by functional group, alphabetically by instruction mnemonic, and numerically by hexadecimal code.

In the reference section, instructions are arranged alphabetically, **except** that all "Set/Get" pairs (for example, **SetVelocity** and **GetVelocity**) are described together. Each description begins on a new page; most occupy no more than a page. The page is organized as follows:

Name	The instruction mnemonic is shown at the left, its hexadecimal code at the right.
Syntax	The instruction mnemonic and its required arguments are shown with all arguments separated by spaces.
Arguments	There are two types of arguments: encoded-field and numeric. Encoded-field arguments are packed into a single 16-bit data word, except for axis, which occupies bits 11-8 of the instruction word. The Name of the argument is that shown in the generic syntax. Instance mnemonic used to represent the data value. Encoding is the value assigned to the field for that instance. For numeric arguments, the parameter Value, the Type (signed or unsigned integer) and Range of acceptable values are given. Numeric arguments may require one or two data words. For 32-bit arguments, the high-order part is transmitted first.
Buffered	Certain parameters and other data written to the chipset are buffered, that is, they are not acted upon until the next Update or MultiUpdate command is executed. These parameters are identified by the word buffered in the instruction heading.
Packet structure	This is a graphic representation of the 16-bit words transmitted in the packet: the instruction, which is identified by its name, followed by 1, 2, or 3 data words. Bit numbers are shown directly below each word. For each field in a word, only the high and low bits are shown. For 32-bit numeric data, the high-order bits are numbered from 31 to 16, the low-order bits from 15 to 0. The hex code of the instruction is shown in boldface. Argument names are shown in their respective words or fields. For data words, the direction of transfer—read or write—is shown at the left of the word's diagram. Unused bits are shaded. In data words and instructions sent (written) to the motion processor, all unused bits must be 0.
Description	Describes what the instruction does and any special information relating to the instruction.
Restrictions	Describes the circumstances in which the instruction is not valid, that is, when it should not be issued. For example, velocity, acceleration, deceleration, and jerk parameters may not be issued while an S-curve profile is being executed.
see	Refers to related instructions.


AdjustActualPosition

F5h

Syntax AdjustActualPosition *axis position*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1	0		
		Axis2	1		
		Axis3	2		
		Axis4	3		
		Type	Range	Scaling	Units
	<i>position</i>	signed 32 bits	-2^{31} to $2^{31}-1$	unity	counts steps

Packet structure



Description

The *position* specified as the parameter to AdjustActualPosition is summed with the actual position register (encoder position) for the specified *axis*. This has the effect of adding or subtracting an offset to the current actual position. At the same time, the current commanded position is replaced by the new actual position value minus the current actual position error. This prevents a servo "bump" when the new axis position is established. The destination position (see SetPosition) is also modified by this amount so that no trajectory motion will occur when the update instruction is issued. In effect, this instruction establishes a new reference position from which subsequent positions can be calculated. It is commonly used to set a known reference position after a homing procedure.

Note: On the MC2400 and MC2500 series, the current actual position error is zeroed.

AdjustActualPosition takes effect immediately, it is not buffered.

Restrictions


see

GetPositionError; GetActualVelocity, Set/GetActualPositionUnits, Set/GetActualPosition

Syntax ClearInterrupt

Arguments none

Packet structure



Description ClearInterrupt resets the HostInterrupt signal to its inactive state. If interrupts are still pending, the HostInterrupt line will return to its active state within one cycle. It is used after an interrupt has been recognized and processed by the host. This command does not affect the Event Status Register. If this command is executed when no interrupts are pending it has no effect.


Restrictions

see GetInterruptAxis, Set/GetInterruptMask

Syntax ClearPositionError *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3

Packet structure




Description ClearPositionError sets the current profile's commanded position equal to the actual position (encoder input), thereby clearing the position error for the specified *axis*. This command can be used when the axis is at rest, or when it is moving. If it is used when the axis is moving the host should be aware that the trajectory destination position (used in trapezoidal and s-curve modes) is not changed by this command.

Restrictions ClearPositionError is a buffered command. The new value set will not take effect until the next **Update** or **MultiUpdate** instruction is entered.

This command cannot be executed while the chip is performing an s-curve profile.

see GetPositionError, MultiUpdate, Set/GetPositionErrorLimit, Update

Syntax	GetActivityStatus <i>axis</i>		
Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3
Returned data	<i>status</i>	<i>see below</i>	

Packet structure**Description**

GetActivityStatus reads the 16 bit activity status register for the specified *axis*. Each of the bits in this register continuously indicate the state of the chipset without any action on the part of the host. There is no direct way to set or clear the state of these bits, since they are controlled by the chip set.

The following table shows the encoding of the data returned by this command.

<i>Name</i>	<i>Bit Number</i>	<i>Description</i>																				
Phasing initialized	0	Set to 1 if phasing is initialized (MC2300/MC2800 series only)																				
At maximum velocity	1	Set to 1 when the trajectory is at maximum velocity. This bit is determined by the trajectory generator, not the actual encoder position.																				
Tracking	2	Set to 1 when the axis is within the tracking window																				
Current profile mode	3-5	Contains trajectory mode encoded as follows: <table><tr><td>bit 5</td><td>bit 4</td><td>bit 3</td><td>Profile Mode</td></tr><tr><td>0</td><td>0</td><td>0</td><td>trapezoidal</td></tr><tr><td>0</td><td>0</td><td>1</td><td>velocity contouring</td></tr><tr><td>0</td><td>1</td><td>0</td><td>s-curve</td></tr><tr><td>0</td><td>1</td><td>1</td><td>electronic gear</td></tr></table>	bit 5	bit 4	bit 3	Profile Mode	0	0	0	trapezoidal	0	0	1	velocity contouring	0	1	0	s-curve	0	1	1	electronic gear
bit 5	bit 4	bit 3	Profile Mode																			
0	0	0	trapezoidal																			
0	0	1	velocity contouring																			
0	1	0	s-curve																			
0	1	1	electronic gear																			
<i>reserved</i>	6	not used, may be 0 or 1																				
Axis settled	7	Set to 1 when the axis is settled																				
Motor on/off	8	Set to 1 when motor mode is on, 0 when off.																				
Position capture	9	Set to 1 when a value has been captured by the high speed position capture hardware but has not yet been read. The GetCaptureValue command must be executed before another capture can occur.																				
In-motion	10	Set to 1 when the trajectory generator is executing a profile on the axis.																				
In positive limit	11	Set to 1 when the positive limit switch is active																				

<i>Name</i>	<i>Bit Number</i>	<i>Description</i>
In negative limit	12	Set to 1 when the negative limit switch is active
Profile segment	13-15	Only used during S-curve profile mode. Contains value of 0 when the profile is at rest. Contains phase number 1-7 when profile is in motion.

Restrictions


see GetEventStatus, GetSignalStatus

Syntax GetActualVelocity *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3

Returned data	Type	Range	Scaling	Units
velocity	signed 32 bits	-2^{31} to $2^{31}-1$	$1/2^{16}$	counts/cycle

Packet structure



Description

GetActualVelocity reads the current actual velocity for the specified **axis**. This value is the result of the last encoder input, so it will be accurate to within one cycle.

Scaling example: If a value of -1,234,567 is retrieved by the GetActualVelocity command (high word: 0FFEDh, low word: 2979h) this corresponds to a velocity of -1,234,567/65,536 or -18.8380 counts/cycle.

Restrictions


see Set/GetActualPosition

Syntax GetCaptureValue *axis*

Arguments	<i>Name</i>	<i>Instance</i>	<i>Encoding</i>
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3

Returned data	<i>Type</i>	<i>Range</i>	<i>Scaling</i>	<i>Units</i>
<i>captured position</i>	signed 32 bits	-2^{31} to $2^{31}-1$	unity	counts

Packet structure



Description GetCaptureValue returns the contents of the Position Capture Register for the specified *axis*. This command also resets the capture hardware to allow another capture to occur.

Restrictions


see Set/GetCaptureSource

Syntax GetChecksum

Returned data

checksum	<i>Type</i> unsigned 32 bits
----------	---------------------------------

Packet structure



Description GetChecksum reads the chips internal 32-bit checksum value. The value should be 12345678 (hex) for a correctly manufactured chipset.

Restrictions


see

Syntax GetCommandedAcceleration *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3

Returned data	Type	Range	Scaling	Units
<i>acceleration</i>	signed 32 bits	-2^{31} to $2^{31}-1$	$1/2^{16}$	counts/cycle ²

Packet structure



Description GetCommandedAcceleration returns the current commanded acceleration value for the specified *axis*. Commanded acceleration is the instantaneous acceleration value output by the trajectory generator.

Scaling example: If a value of 114,688 is retrieved using this command then this corresponds to $114,688/65,536 = 1.750$ counts/cycle² acceleration value.

Restrictions This command functions when the profile mode is set to Trapezoidal, S-curve, or Velocity Contouring. It does not function when the profile mode is set to electronic gearing.

see GetCommandedPosition, GetCommandedVelocity

GetCommandedPosition


1Dh

Syntax GetCommandedPosition *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3

Returned data	Type	Range	Scaling	Units
<i>position</i>	signed 32 bits	-2^{31} to $2^{31}-1$	unity	counts

Packet structure



Description GetCommandedPosition returns the current commanded position for the specified *axis*. Commanded position is the instantaneous position value output by the trajectory generator.

This command functions in all profile modes.

Restrictions


see GetCommandedAcceleration, GetCommandedVelocity

Syntax GetCommandedVelocity *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3

Returned data	Type	Range	Scaling	Units
<i>velocity</i>	signed integer	-2^{31} to $2^{31}-1$	$1/2^{16}$	counts/cycle

Packet structure



Description GetCommandedVelocity returns the current commanded velocity value for the specified *axis*. Commanded velocity is the instantaneous velocity value output by the trajectory generator.

Scaling example: If a value of -1,234,567 is retrieved using this command (FFEDh in high word, 2979h in low word) then this corresponds to $-1,234,567/65,536 = -18.8380$ counts/cycle velocity value.

This command functions in all profile modes.

Restrictions


see GetCommandedAcceleration, GetCommandedPosition

Syntax GetCurrentMotorCommand *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3

Returned data	Type	Range	Scaling	Units
<i>motor output command</i>	signed 16 bits	-2^{15} to $2^{15}-1$	$100/2^{15}$	% output

Packet structure



Description GetCurrentMotorCommand returns the current motor output command for the specified *axis*. In closed-loop mode, this is the output of the servo filter; in open-loop mode it is the contents of the motor output command register.

Scaling example: To convert the retrieved value to units of % of full scale motor output multiply by $100/32,768$. For example if the value -123 is retrieved by the GetCurrentMotorCommand, this represents $-123 \cdot 100/32,768$ or $-.3754\%$ of full scale output.

Restrictions This command is not available on the MC2500 chipset.

see Set/GetMotorCommand


Syntax GetDerivative *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3

Returned data

	Type	Range	Scaling	Units
derivative	signed 16 bits	-2^{15} to $2^{15}-1$	unity	counts/cycle

Packet structure



Description

GetDerivative returns the derivative of the current position error as calculated by the servo filter. The derivative value is defined as the previous position error subtracted from the current position error.

See **SetDerivativeTime** for details on setting the derivative sampling time.

Restrictions

This value is available only when the chipset is in closed-loop operation.

This command is not valid on the MC2400 and MC2500.

see


GetIntegral, Set/GetDerivativeTime

Syntax GetHostIOError

Arguments none

Returned data	<i>Name</i> <i>error code</i>	<i>Instance</i>	<i>Encoding</i>
		No error	0
		Processor Reset	1
		Invalid instruction	2
		Invalid axis	3
		Invalid parameter	4
		Trace running	5
		<i>reserved</i>	6
		Block out of bounds	7
		Trace buffer zero	8
		Bad serial checksum	9
		Not primary port	Ah
		Invalid negative value	Bh
		Invalid parameter change	Ch
		Invalid move after limit condition	Dh
		Invalid move into limit	Eh

Packet structure



Description GetHostIOError returns the code for the last Host I/O error, then resets to 0 both the *error* and the Host I/O bit in the Status-Read word. Generally this command is issued only after the Host I/O error bit in the Status-read word indicates there was an I/O error.

Restrictions


see GetEventStatus

Syntax GetIntegral *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3

Returned data	Type	Range	Scaling	Units
<i>integral</i>	signed 32 bits	-2^{31} to $2^{31}-1$	$1/2^8$	count*cycles

Packet structure



Description

GetIntegral returns the current integrated position error of the servo filter for the specified *axis*. **GetIntegral** can be used to monitor loading on the axis, because changes in the axis loading can be reflected in the value of the integration limit.

Scaling example:

If a constant position error of 100 counts is present for 256 cycles then the total accumulated integral value will be 100 (100*256/256). Alternatively a returned value of 1,000 indicates a total stored value of 256,000 count*cycles (1,000*256).

Restrictions

The integrated position error is available only when the chipset is in closed-loop mode (**SetMotorMode** command).

This command is not valid on the MC2400 and MC2500.

see


GetDerivative, Set/GetIntegrationLimit

Syntax GetInterruptAxis

Arguments none

Returned data	Name	Instance	Encoding
	<i>axisMask</i>	Axis1	1
		Axis2	2
		Axis3	4
		Axis4	8

Packet structure



Description GetInterruptAxis returns a field which identifies all axes with pending interrupts. Axis numbers are assigned to the low-order four bits of the returned word; bits corresponding to interrupting axes are set to 1. If the host interrupt signal has not been set, the returned word is 0.

Restrictions

see ClearInterrupt, Set/GetInterruptMask


Syntax GetPhaseCommand *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3

Returned data	<i>phase</i>	PhaseA	0
		PhaseB	1
		PhaseC	2

	Type	Range	Scaling	Units
<i>motor command</i>	signed 16 bit	-2^{15} to $2^{15}-1$	100/ 2^{15}	% output

Packet structure



Description

GetPhaseCommand returns the value of the current motor output command for phase A, B, or C of the specified axis. These are the phase values directly output to the motor after commutation.

Scaling example:

If a value of -4,489 is retrieved (EE77h) for a given axis and phase then this corresponds to $-4,489 \times 100 / 32,768 = -13.7\%$ of full-scale output.

Restrictions


see InitializePhase, Set/GetNumberPhases

Syntax GetPositionError *axis*

Arguments	<i>Name</i>	<i>Instance</i>	<i>Encoding</i>
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3

Returned data		<i>Type</i>	<i>Range</i>	<i>Scaling</i>	<i>Units</i>
	<i>position error</i>	signed 32 bit	-2^{31} to $2^{31}-1$	unity	counts steps

Packet structure



Description **GetPositionError** returns the current position error of the specified ***axis***. The error is the difference between the actual position (encoder position) and the commanded position (instantaneous output of the trajectory generator). Refer to the User's Guide for more information on this command when it is used with the stepping motor chipsets.

Restrictions


see Set/GetPosition, Set/GetPositionErrorLimit

Syntax GetSignalStatus *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3

Returned data		Description	Bit Number
	<i>status</i>	Encoder A	0
		Encoder B	1
		Encoder Index	2
		Encoder Home	3
		Positive limit	4
		Negative limit	5
		AxisIn	6
		Hall A	7
		Hall B	8
		Hall C	9
		AxisOut	10
		<i>reserved</i>	11-15

Packet structure



Description

GetSignalStatus returns the contents of the signal status register for the specified *axis*. The signal status register contains the current value of the various hardware signals connected to each axis of the chipset. The value read is combined with the signal sense register (**SetSignalSense** command) and then returned to the user. For each bit in the Signal Sense register that is set to 1 the corresponding bit in the **GetSignalStatus** command will be inverted, so that a low signal will be read as 1 and a high signal will be read as a 0. Conversely for each bit in the signal sense register that is set to 0 the corresponding bit in the **GetSignalStatus** command is not inverted, so that a low signal will be read as 0 and a high signal will be read as a 1.

All of the bits in the **GetSignalStatus** command are inputs except for AxisOut. The value read for this bit is equal to the current value output by the axis out mechanism. See **SetAxisOutSource** command for more details.

Restrictions


see GetActivityStatus, GetEventStatus

Syntax GetTime

Arguments none

Returned data	Name	Type	Range	Scaling	Units
	<i>current</i>	unsigned 32 bit	0 to $2^{32}-1$	unity	cycles
	<i>chipset time</i>				

Packet structure



Description Returns the number of cycles that have occurred since the processor was last initialized or reset.

Restrictions


see

Syntax GetTraceCount

Arguments none

Returned data	<i>Value</i>	<i>Type</i>	<i>Range</i>	<i>Scaling</i>	<i>Units</i>
	<i>trace count</i>	unsigned 32 bit	0 to $2^{32}-1$	unity	samples

Packet structure



Description GetTraceCount returns the number of points (variable values) stored in the trace buffer since the beginning of the trace.

Restrictions


see ReadBuffer, Set/GetTraceStart, Set/GetTraceStop

Syntax GetTraceStatus

Arguments none

Returned data	Name mask	Bit	Instance	Description
		0	Mode	Set to 0 when trace is in one-time mode, 1 when in rolling mode.
		1	Activity	Set to 1 when trace is active (currently tracing) , 0 if trace not active
		2	Data wrap	Set to 1 when trace has wrapped, 0 if it has not wrapped. If 0, the buffer has not yet been filled and all recorded data are intact. If 1, the trace has wrapped to the beginning of the buffer; any previous data may have been overwritten if not explicitly retrieved by the host using the ReadBuffer command while the trace is active.

Packet structure



Description GetTraceStatus returns the current trace status.

Restrictions

see Set/GetTraceStart, Set/GetTraceMode

8Fh

Returned data	Product information	Encoding
	<i>product family</i>	Navigator
	<i>motor type</i>	Servo
		Brushless
		Microstepping
		Pulse & Direction
	<i>axes supported</i>	1, 2, or 4
	<i>special attributes</i>	0 to 15
	<i>customization code</i>	none
		other
	<i>major s/w version</i>	0 to 15
	<i>minor s/w version</i>	0 to 15

e

GetVersion

0	8Fh
15	0

First data word

read

<i>product family</i>	<i>motor type</i>	<i>number of axes</i>	<i>special attributes</i>
15	12 11	8 7	4 3 0

Second data word

read

<i>customization code</i>	<i>major s/w version</i>	<i>minor s/w version</i>
15	8 7	4 3 0


Restrictions

33

Syntax InitializePhase *axis*

Arguments	<i>Name</i>	<i>Instance</i>	<i>Encoding</i>
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3

Packet structure



Description InitializePhase initializes the phase angle for the specified axis using the mode (Hall-based or Algorithmic) specified by the SetPhaseInitializationMode command.


Restrictions Warning: If the phase initialization mode has been set to algorithmic then after this command is sent the motor can move suddenly in an uncontrolled manner.

see GetPhaseCommand, Set/GetNumberPhases

Syntax MultiUpdate *mask*

Arguments	Name	Instance	Encoding
	<i>mask</i>	None	0
		Axis1mask	1
		Axis2mask	2
		Axis3mask	4
		Axis4mask	8

Packet structure



Description

MultiUpdate causes an Update to occur on all axes whose corresponding bit is set to 1 in the mask argument. After this command is executed, and for those axes which are selected using the mask, all buffered data parameters are copied into the corresponding run-time registers.

The following instruction is buffered: **ClearPositionError**.

The following trajectory parameters are buffered: Acceleration, Deceleration, GearRatio, Jerk, Position, ProfileMode, StartVelocity, StopMode, and Velocity.

The following PID filter parameters are buffered: DerivativeTime, IntegrationLimit, Kaff, Kd, Ki, Kp, and Kvff.

The following Motor Command parameter is buffered: MotorCommand

Restrictions

see Update


NoOperation

00h

Syntax NoOperation

Arguments none

Packet structure



Description The NoOperation command has no affect on the chipset. It is useful as a “null” operation to verify communications with the Motion Processor.


Restrictions

see

Syntax ReadAnalog *portID*

Arguments	<i>Name</i>	<i>Type</i>	<i>Range</i>	<i>Scaling</i>	<i>Units</i>
	<i>portID</i>	unsigned 16 bit	0 to 7	unity	-
Returned data	<i>value</i>	unsigned 16 bit	0 to $2^{16}-1$	$1/2^{16}$	% input

Packet structure



Description ReadAnalog returns a 16-bit value representing the voltage (read by an on-chip 10 bit A/D) presented to the specified analog input. See User's Guide for more information on analog input and scaling. The value returned is the result of shifting the 10-bit value 6 bits left.


Restrictions

see

Syntax ReadBuffer *bufferID*

Arguments	Name	Type	Range	Scaling	Units
	<i>bufferID</i>	unsigned 16 bit	0 to 31	unity	-
Returned data	<i>value</i>	signed 32 bit	-2^{31} to $2^{31}-1$	unity	-

Packet structure



Description ReadBuffer returns the 32-bit contents of the current location in the specified buffer. The current location is determined by adding the base address of the buffer (set by **SetBufferStart**), to the buffer's Read Index (set by **SetBufferReadIndex**). After the contents have been read, the Read Index is incremented by 1; if the result is equal to the buffer length (set by **SetBufferLength**), the Index is reset to 0. Some commands automatically change the read index such as at the completion of a trace when in rolling mode. Refer to Section 6.4 of the User's Guide for details.


Restrictions

see Set/GetBufferReadIndex, WriteBuffer

Syntax ReadIO *address*

Arguments	<i>Name</i>	<i>Type</i>	<i>Range</i>	<i>Scaling</i>	<i>Units</i>
	<i>address</i>	unsigned 8 bit	0 to 255	unity	-
Returned data	<i>value</i>	unsigned 16 bit	0 to $2^{16}-1$	unity	-

Packet structure



Description ReadIO reads one 16-bit word of data from the device whose address is calculated by adding 1000h to **address**. (**address** is an offset from the base address, 1000h, of the MC2000's memory-mapped I/O space.)

The format and interpretation of the 16-bit data word are dependent on the user-defined device being addressed. User-defined I/O can be used to implement a number of features including additional parallel I/O, flash memory for non-volatile configuration information storage, or display devices such as LED arrays.


Restrictions

see WriteIO

Syntax Reset

Arguments none

Packet structure



Description

Reset restores the chipset to its initial condition, setting all chipset variables to their default values. These default values are shown in the following table:

Acceleration	0	MotorBias	0
ActualPosition	0	MotorCommand	0
AutoStopMode	0	MotorLimit	32767
AxisMode	1	MotorMode	1
AxisOutSource	0	NumberPhases	<i>see note 1</i>
Breakpoint 1	0	OutputMode	<i>see note 2</i>
Breakpoint 2	0	PhaseAngle	65535
BreakpointValue 1	0	PhaseCorrectionMode	1
BreakpointValue 2	0	PhaseCounts	0
BufferLength	0	PhaseInitializeMode	0
BufferReadIndex	0	PhaseInitializeTime	0
BufferStart	200h	PhaseOffset	65535
BufferWriteIndex	0	PhasePrescale	0
CaptureSource	0	Position	0
CommutationMode	0	PositionErrorLimit	32767
Deceleration	0	ProfileMode	0
DerivativeTime	1	SampleTime	<i>see note 3</i>
EncoderModulus	0	SettleTime	0
EncoderSource	0	SettleWindow	0
GearMaster	0	SignalSense	0
GearRatio	0	Stop	0
IntegrationLimit	0	TraceMode	0
InterruptMask	0	TracePeriod	1
Jerk	0	TraceStart	0
Kaff	0	TraceStop	0
Kd	0	TraceVariable 1	0
Ki	0	TraceVariable 2	0
Kout	65535	TraceVariable 3	0
Kp	0	TraceVariable 4	0
Kvff	0	TrackingWindow	0
LimitMode	1	Velocity	0
MotionCompleteMode	0		

Notes:

1. The reset value for the number of phases is dependent on the Motion Processor series, as follows:

MC2100	1
MC2300	3
MC2400	2
2. The reset value for the output mode is dependent on the Motion Processor series, as follows:

MC2100	1
MC2300	2
MC2400	1
3. The reset value for **SampleTime** depends on the number of axes and the motion processor series, as follows:

MC2100	102 x number of axes
MC2300	154 x number of axes
MC2400	154 x number of axes

All axes supported by the motion processor are enabled at reset.

Profile, servo filter, and other axis-specific parameters are reset on all axes.

External-memory buffer parameters are reset for all buffers. **BufferStart** is reset to (200h), the lowest user-accessible address.

Axis-specific conditions are reset on all axes. External-memory buffer conditions are reset on all 16 memory buffers.

Restrictions

For the MC2400/MC2500:

AutoStopMode Off


EncoderSource None

see

Syntax ResetEventStatus *axis mask*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3
	<i>mask</i>	Motion complete	0001h
		Wrap-around	0002h
		Breakpoint 1	0004h
		Capture received	0008h
		Motion error	0010h
		In positive limit	0020h
		In negative limit	0040h
		Instruction error	0080h
		Commutation error	0800h
		Breakpoint 2	4000h

Packet structure



Description ResetEventStatus clears (sets to 0) , for the specified *axis*, each bit in the Event Status Register that has a value of 0 in the *mask* sent with this command. All other Event Status register bits (bits which have a mask value of 1) are unaffected.

Restrictions

see GetEventStatus

SetAcceleration GetAcceleration


buffered

90h
4Ch

Syntax SetAcceleration *axis acceleration*
GetAcceleration *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	<i>acceleration</i>	Type unsigned 32 bit	Range 0 to $2^{31}-1$	Scaling $1/2^{16}$	Units counts/cycle ²

Packet structure



Description

SetAcceleration loads the maximum acceleration buffer register for the specified *axis*. This command is used with the Trapezoidal, Velocity Contouring, and S-curve profiling modes.

GetAcceleration reads the maximum acceleration buffer register set by the previous **SetAcceleration** command.

Scaling example: To load a value of 1.750 counts/cycle² multiply by 65,536 (giving 114,688) and load the resultant number as a 32 bit number, giving 0001 in the high word and C000h in the low word. Values returned by **GetAcceleration** must correspondingly be divided by 65,536 to convert to units of counts/cycle².

Restrictions

SetAcceleration may not be issued while an axis is in motion with the S-curve profile.

SetAcceleration is not valid in Electronic Gearing profile mode.

SetAcceleration is a buffered command. The value set using this command will not take effect until the next **Update** or **MultiUpdate** instruction.

see

Set/GetDeceleration, Set/GetJerk, Set/GetPosition, Set/GetVelocity, MultiUpdate, Update


SetActualPosition GetActualPosition

4Dh
37h

Syntax SetActualPosition *axis position*
GetActualPosition *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	<i>position</i>	Type signed 32 bits	Range -2^{31} to $2^{31}-1$	Scaling unity	Units counts steps

Packet structure



Description

SetActualPosition loads the actual position register (encoder position) for the specified *axis*. At the same time, the current commanded position is replaced by the loaded value minus the current actual position error. This prevents a servo "bump" when the new axis position is established. The destination position (see **SetPosition**) is also modified by this amount so that no trajectory motion will occur when the update instruction is issued. In effect, this instruction establishes a new reference position from which subsequent positions can be calculated. It is commonly used to set a known reference position after a homing procedure.

Note: On the MC2400 and MC2500 series, the position error is zeroed.

SetActualPosition takes effect immediately, it is not buffered.

GetActualPosition reads the contents of the encoder's actual position register. This value will be the result of the last encoder input, which will be accurate to within one cycle (as determined by **Set/GetSampleTime**).

Restrictions

see GetPositionError; GetActualVelocity, Set/GetActualPositionUnits, AdjustActualPosition

SetActualPositionUnits *(MC2400 and MC 2500 only)*


GetActualPositionUnits *(MC2400 and MC 2500 only)*

BEh
BFh

Syntax SetActualPositionUnits *axis mode*
GetActualPositionUnits *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3
	<i>mode</i>	Counts	0
		Steps	1

Packet structure



Description SetActualPositionUnits determines the units used by the Set/GetActualPosition, AdjustActualPosition and GetCaptureValue for the specified *axis*. When set to *Counts* position units are in encoder counts. When set to *Steps* GetActualPosition position units are in steps.

GetActualPositionUnits returns the mode for the specified *axis*.

Restrictions This command is only available on the MC2400 and MC2500 series.

see Set/GetActualPosition, Set/GetEncoderToStepRatio, AdjustActualPosition, GetCaptureValue

SetAutoStopMode


GetAutoStopMode

D2h
D3h

Syntax SetAutoStopMode *axis mode*
GetAutoStopMode *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3
	<i>mode</i>	Disable	0
		Enable	1

Packet structure



Description

SetAutoStopMode determines the behavior of the specified *axis* when a motion error occurs. When auto stop is enabled (**SetAutoStopMode Enable**), the axis goes into open-loop mode when a motion error occurs. When Auto-Stop is disabled (**SetAutoStopMode Disable**), the axis is not affected by a motion error.

GetAutoStopMode returns the current state of the Auto-Stop mode.

Restrictions

see GetEventStatus

SetAxisMode


GetAxisMode

87h
88h

Syntax SetAxisMode *axis mode*
GetAxisMode *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3
	<i>mode</i>	off	0
		on	1

Packet structure



Description SetAxisMode enables (On) or disables (Off) the specified *axis*. A disabled axis will not respond to profile or other motion commands.

GetAxisMode returns the current status of the specified axis.

Restrictions Disabled axes do not provide encoder feedback. If it is desired that an axis provide encoder feedback even though no profiling or servo control is to be used, that axis must be left enabled.

see

SetAxisOutSource


GetAxisOutSource

EDh
EEh

Syntax SetAxisOutSource *axis sourceAxis bit register*
GetAxisOutSource *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3
	<i>sourceAxis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3
	<i>bit</i>	<i>see below</i>	0 to 15
	<i>register</i>	(none) EventStatus ActivityStatus SignalStatus	0 1 2 3

Packet structure



Description

SetAxisOutSource maps the specified *bit* of the specified status *register* of *axisn* to the AxisOut pin for the specified *axis*. The state of the AxisOut pin will thereafter track the state of *bit*. If *register* is absent (encoding of 0), *bit* is ignored, and the specified AxisOut pin is, in effect, turned off (inactive).

GetAxisOutSource reads the mapping of the AxisOut pin of *axis*.

The table below shows the corresponding value for combinations of *bit* and *register*.

<i>encoding of "bit"</i>	<i>register = event status</i>	<i>register = activity status</i>	<i>register = signal status</i>
0	Motion Complete	Phasing Initialized	Encoder A
1	Wrap-around	At maximum velocity	Encoder B
2	Breakpoint 1	Tracking	Encoder index
3	Position capture		Home
4	Motion error		Positive limit
5	In positive limit		Negative limit
6	In negative limit		AxisIn
7	Instruction error	Axis settled	Hall sensor 1
8		Motor on/off	Hall sensor 2
9		Position capture	Hall sensor 3
0Ah		In motion	
0Bh	Commutation error	In positive limit	
0Ch		In negative limit	
0Dh			
0Eh	Breakpoint 2		
0Fh			

Restrictions

see SetSignalSense


SetBreakpoint GetBreakpoint

D4h
D5h

Syntax SetBreakpoint *axis breakpoint sourceAxis action trigger*
GetBreakpoint *axis breakpoint*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3
	<i>breakpoint</i>	Breakpoint1 Breakpoint2	0 1
	<i>sourceAxis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3
	<i>action</i>	(none) Update AbruptStop SmoothStop MotorOff	0 1 2 3 4
	<i>trigger</i>	(none) PositiveCommandedPosition NegativeCommandedPosition PositiveActualPosition NegativeActualPosition CommandedPositionCrossed ActualPositionCrossed Time EventStatus ActivityStatus Signal	0 1 2 3 4 5 6 7 8 9 Ah

Packet structure



Description

SetBreakpoint establishes a breakpoint for the specified **axis** to be triggered by a condition or event on **sourceAxis**, which may be the same as or different from **axis**. Up to two concurrent breakpoints can be set for each axis.

The six **Position** breakpoints and the **Time** breakpoint are *threshold-triggered*; the breakpoint occurs when the indicated value reaches or crosses a threshold. The **Status** breakpoints are *level-triggered*; the breakpoint occurs when a specific bit or combination of bits in the indicated status register changes state. Thresholds and bit specifications are both set by the **SetBreakpointValue** instruction.

action determines what the Navigator does when the breakpoint occurs, as follows:

Action	Resultant command sequence
none	no action
Update	Update <i>axis</i>
AbruptStop	SetStop <i>axis</i> , AbruptStop Update <i>axis</i>
SmoothStop	SetStop <i>axis</i> , SmoothStop Update <i>axis</i>
MotorOff	SetMotorMode <i>axis</i> , Off

axis is the axis for which the breakpoint has been set.

GetBreakpoint returns the condition, axis, and action for the specified breakpoint (1 or 2) of the indicated axis.

Two completely separate breakpoints are supported, each of which may have its own breakpoint type and comparison value. The **breakpoint** field specifies which breakpoint the **SetBreakpoint** and **GetBreakpoint** commands will address.

Restrictions

Before setting a new breakpoint condition (**SetBreakpoint** command) ALWAYS load the comparison value first (**SetBreakpointValue** command). This is because as soon as the breakpoint condition is set the chipset will start using the breakpoint value register, and if it is not yet defined the breakpoint will not behave as expected.

see

Set/GetBreakpointValue

SetBreakpointValue GetBreakpointValue


D6h
D7h

Syntax SetBreakpointValue *axis breakpoint value*
GetBreakpointValue *axis breakpoint*

Arguments	Name	Instance	Encoding	Type	Range	Units
	<i>axis</i>	Axis1	0			
		Axis2	1			
		Axis3	2			
		Axis4	3			
	<i>breakpoint</i>	Breakpoint1	0			
		Breakpoint2	1			
	<i>value</i>	PositiveCommandedPosition		signed 32 bit	-2^{31} to $2^{31}-1$	counts
		NegativeCommandedPosition		signed 32 bit	-2^{31} to $2^{31}-1$	counts
		PositiveActualPosition		signed 32 bit	-2^{31} to $2^{31}-1$	counts
		NegativeActualPosition		signed 32 bit	-2^{31} to $2^{31}-1$	counts
		CommandedPositionCrossed		signed 32 bit	-2^{31} to $2^{31}-1$	counts
		ActualPositionCrossed		signed 32 bit	-2^{31} to $2^{31}-1$	counts
		Time		unsigned 32 bit	0 to $2^{32}-1$	cycles
		EventStatus		2 word mask *	-	-
		ActivityStatus		2 word mask *	-	-
		SignalStatus		2 word mask *	-	-

* see description section below for more details on mask format

Packet structure



Description

SetBreakpointValue sets the breakpoint comparison value for the specified **axis**. For the position and time breakpoints this is a threshold comparison value.

For level-triggered breakpoints, the high-order part of **value** is the selection mask, and the low-order word is the sense mask. For each selection bit that is set to 1, the corresponding bit of the specified status register is conditioned to cause a breakpoint when it changes state. The sense-mask bit determines which state causes the break. If it is 1, the corresponding status-register bit will cause a break when it is set to 1. If it is 0, the status-register bit will cause a break when it is set to 0.

For example assume it is desired that the breakpoint type will be set to "EventStatus" and that a breakpoint should be recognized whenever the motion complete bit (bit 0 of event status register) is set to 1, and the commutation error bit (bit 11 of event status register) is set to 0. In this situation the high and low words for **value** would be high word: 0x801 (hex) and low word: 1.

GetBreakpointValue returns the current breakpoint value for the specified breakpoint.

Two completely separate breakpoints are supported, each of which may have its own breakpoint type and comparison value. The **breakpoint** field specifies which breakpoint the **SetBreakpointValue** and **GetBreakpointValue** commands will address.

Restrictions

Before setting a new breakpoint condition (**SetBreakpoint** command) ALWAYS load the comparison value first (**SetBreakpointValue** command). This is because as soon as the breakpoint condition is set the chipset will start using the breakpoint value register, and if it is not yet defined the breakpoint will not behave as expected.

see

Set/GetBreakpoint

SetBufferFunction


GetBufferFunction

CAh
CBh

Syntax SetBufferFunction *axis function bufferID*
 GetBufferFunction *axis function*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1	0		
		Axis2	1		
		Axis3	2		
		Axis4	3		
	<i>function</i>	Position	0		
		Velocity	1		
		Acceleration	2		
		Jerk	3		
		Time	4		
	Name	Type	Range	Scaling	Units
	<i>bufferID</i>	signed 16 bits	-1 to 31	unity	-

Packet structure



Description

SetBufferFunction sets the interpretation for data stored in a buffer when an axis is in External Profile mode. A function will have no associated buffer if the *bufferID* parameter is set to -1. This is useful for disabling a function.

GetBufferFunction returns the *bufferID* for the specified function. If a function has not been assigned a buffer, the return value is -1.

Restrictions

see Set/GetProfileMode

C2h
C3h

Arguments	<i>Name</i>	<i>Type</i>	<i>Range</i>	<i>Scaling</i>	<i>Units</i>
	<i>bufferID</i>	unsigned 16 bits	0 to 31	unity	-
	<i>length</i>	unsigned 32 bits	1 to $2^{30}-1$	unity	-

e

SetBufferLength

0 8 7 C2h 0

15 First data word

write 0 4 bufferID 0

15 Second data word

write length (high-order part) 31 16

Third data word

write length (low-order part) 15 0

GetBufferLength

0 8 7 C3h 0

15 First data word

write 0 4 3 bufferID 0

15 Second data word

read length (high-order part) 31 16

Third data word

read length (low-order part) 15 0

GetBufferLength returns the length of the specified buffer.

Note: Setting the buffer length beyond the end of physical memory could cause the chip set to unexpectedly reset during operation.

55


SetBufferReadIndex

GetBufferReadIndex

C6h
C7h

Syntax	SetBufferReadIndex <i>bufferID index</i> GetBufferReadIndex <i>bufferID</i>				
Arguments	Name	Type	Range	Scaling	Units
	<i>bufferID</i>	unsigned 16 bits	0 to 31	unity	-
	<i>index</i>	unsigned 32 bits	0 to buffer length-1	unity	double words (32 bit)

Packet structure



Description

SetBufferReadIndex sets the address of the Read Index for the specified buffer. If the read index is set to an address beyond the length of the buffer, the command will not be executed and will return an error.

GetBufferReadIndex returns the current Read Index for the specified buffer.

Restrictions


see Set/GetBufferLength, Set/GetBufferStart, Set/GetBufferWriteIndex

SetBufferStart GetBufferStart

C0h
C1h

Syntax	SetBufferStart <i>bufferID</i> <i>address</i> GetBufferStart <i>bufferID</i>				
Arguments	Name	Type	Range	Scaling	Units
	<i>bufferID</i>	unsigned 16 bit	0 to 31	unity	-
	<i>address</i>	unsigned 32 bit	2^9 to $2^{31}-1$	unity	double words (32 bit)

Packet structure



Description SetBufferStart sets the starting address for the specified buffer. **The buffer start address must be 200h or greater.**

Note: SetBufferStart resets the buffers read and write indexes to 0.

GetBufferStart returns the starting address for the specified buffer.

Restrictions If the specified length extends beyond the end of addressable memory, SetBufferStart is not executed, and returns host-I/O error code 7, *buffer bound exceeded*.

Note: Setting the buffer start beyond the end of physical memory could cause the chip set to unexpectedly reset during operation.

see Set/GetBufferLength, Set/GetReadIndex, Set/GetBufferWriteIndex

SetBufferWriteIndex


GetBufferWriteIndex

C4h
C5h

Syntax SetBufferWriteIndex *bufferID index*
GetBufferWriteIndex *bufferID*

Arguments	Name	Type	Range	Scaling	Units
	<i>bufferID</i>	unsigned 16 bit	0 to 31	unity	-
	<i>index</i>	unsigned 32 bit	0 to buffer length-1	unity	long words (32 bits)

Packet structure



Description

SetBufferWriteIndex sets the address of the write index for the specified buffer. If the write index is set to an address beyond the length of the buffer, the command will not be executed and will return an error.

GetBufferWriteIndex returns the current write index for the specified buffer.

Restrictions

see Set/GetBufferLength, Set/GetBufferReadIndex, Set/GetBufferStart


SetCaptureSource GetCaptureSource

D8h
D9h

Syntax SetCaptureSource *axis source*
 GetCaptureSource *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3
	<i>source</i>	Index	0
		Home	1

Packet structure



Description SetCaptureSource determines which of two encoder signals, Index or Home, is used to trigger the high-speed capture of the actual axis position for the specified *axis*.

GetCaptureSource returns the capture signal *source* for the selected *axis*.

Restrictions

see GetCaptureValue

SetCommutationMode (MC2300 and MC2800 only)


GetCommutationMode (MC2300 and MC2800 only)

E2h
E3h

Syntax SetCommutationMode *axis mode*
GetCommutationMode *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3
	<i>mode</i>	Sinusoidal	0
		Hall-Based	1
		Microstepping	2

Packet structure



Description

SetCommutationMode sets the phase commutation mode for the specified *axis*.

When set to **sinusoidal**, as the motor turns, the encoder input signal is used to calculate the phase angle. This angle is in turn used to generate sinusoidally varying outputs to each motor winding.

When set to **Hall-based** the hall effect sensor inputs are used to commutate the motor windings using a "six-step" or "trapezoidal" waveform method.

When set to **microstepping** the output of the trajectory generator is used to calculate the phase angle. This angle is in turn used to generate sinusoidally varying outputs to each motor phase.

GetCommutationMode returns the current commutation mode.

When operating with brushless servo motors either sinusoidal or Hall-based are typically used for motor commutation.

Microstepping is sometimes used with brushless motors to "manually" move the motor before phase initialization has occurred. Alternatively, Microstepping can be used with step motors or with AC induction motors where frequency synthesis is all that is required to rotate the motor.

Restrictions

see Set/GetCommutationPrescale, Set/GetCommutationCounts, Set/GetPhase commands

SetDeceleration GetDeceleration


buffered

91h
92h

Syntax SetDeceleration *axis deceleration*
GetDeceleration *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	<i>deceleration</i>	Type unsigned 32 bits	Range 0 to $2^{31}-1$	Scaling $1/2^{16}$	Units counts/cycle ²

Packet structure



Description SetDeceleration loads the maximum deceleration buffer register for the specified *axis*. This command sets the magnitude of the deceleration register, which always has a negative sign.

GetDeceleration reads the Maximum Deceleration buffer.

Scaling example: To load a value of 1.750 counts/cycle² multiply by 65,536 (giving 114,688) and load the resultant number as a 32 bit number, giving 0001 in the high word and C000h in the low word. Retrieved numbers (GetDeceleration) must correspondingly be divided by 65,536 to convert to units of counts/cycle²

Restrictions This is a buffered command. The new value set will not take effect until the next **Update** or **MultiUpdate** instruction is entered.

These commands are used with the Trapezoidal, S-curve, and Velocity contouring profile modes. They are not used with the electronic gearing profile mode.

Note: If deceleration is set to zero, then the value specified for acceleration (SetAcceleration) will automatically be used to set the magnitude of deceleration.

see Set/GetAcceleration, Set/GetJerk, Set/GetPosition, Set/GetVelocity, MultiUpdate, Update

SetDerivativeTime


GetDerivativeTime

9Ch
9Dh

Syntax SetDerivativeTime *axis time*
GetDerivativeTime *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	<i>time</i>	Type unsigned 16 bits	Range 0 to 2 ¹⁵ -1	Scaling unity	Units cycles

Packet structure



Description SetDerivativeTime sets the sampling time, in number of servo cycles, for the servo filter to use in calculating the derivative term for the specified **axis**.
GetDerivativeTime returns the derivative sampling time.

Restrictions This command is NOT buffered. The new sampling time value will take effect immediately after the command is sent to the chipset.
This command does not affect the overall cycle time of the chipset, only the derivative sampling time. The overall cycle time of the chipset is set using the command SetSampleTime.

see GetDerivative, GetIntegral, MultiUpdate, Update

SetDiagnosticPortMode


GetDiagnosticPortMode

89h
8Ah

Syntax SetDiagnosticPortMode *mode*
GetDiagnosticPortMode

Arguments	Name	Instance	Encoding
	<i>mode</i>	Limited	0
		Full	1

Packet structure



Description

SetDiagnosticPortMode determines the instruction set that can be executed through the diagnostic port. When set to **Limited**, only the following instructions may be executed:

- all **Get** instructions

- The **SetBufferReadIndex** instruction

When set to **Full**, all instructions may be executed.

GetDiagnosticPortMode returns the current mode of the diagnostic port.

Restrictions

see Set/GetSerialPort

SetEncoderModulus


GetEncoderModulus

8Eh
8Dh

Syntax SetEncoderModulus *axis modulus*
GetEncoderModulus *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	<i>modulus</i>	Type unsigned 16 bit	Range 1 to 2 ¹⁶ -1	Scaling unity	Units counts

Packet structure



Description

SetEncoderModulus sets the parallel word range for the specified *axis* when parallel-word feedback is used. *Modulus* determines the range of the connected device. The value provided should be one-half of the actual *modulus* of the axis. For example if the parallel-word input is used with a linear potentiometer connected to an external A/D (Analog to Digital converter) which has 12 bits of resolution, than the total range is 4,096 and a value of 2,048 should be loaded with this command.

GetEncoderModulus returns the current encoder modulus.

Restrictions

These commands are only used if parallel-word feedback is used. If incremental encoder feedback is used then these commands are not required.

see

Set/GetEncoderSource


SetEncoderSource GetEncoderSource

DAh
DBh

Syntax SetEncoderSource *axis source*
GetEncoderSource *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3
	<i>source</i>	Incremental	0
		Parallel	1
		None	2

Packet structure



Description

SetEncoderSource sets the type of feedback (incremental quadrature encoder or parallel-word) for the specified **axis**. When incremental quadrature is selected the chip set expects A and B quadrature signals to be input at the I/O chip. When parallel-word is selected the chipset expects user-defined external circuitry connected to the chip set's external bus to load a 16-bit word containing the current position value for each axis. External feedback devices with less than 16 bits may be used but the unused bits must be sign extended or 'zeroed'.

GetEncoderSource returns the code for the current type of feedback.

Restrictions

see Set/GetEncoderModulus

SetEncoderToStepRatio (MC2400 and MC2500 only)


GetEncoderToStepRatio (MC2400 and MC2500 only)

DEh
DFh

Syntax SetEncoderToStepRatio *axis counts steps*
GetEncoderToStepRatio *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	<i>counts</i>	Type signed 16 bit	Range -2^{15} to $2^{15}-1$	Scaling unity	Units encoder counts
	<i>steps</i>	signed 16 bit	-2^{15} to $2^{15}-1$	unity	steps

Packet structure



Description

SetEncoderToStepRatio sets the ratio of number of encoder counts to the number of output steps per motor rotation used by the motion processor to convert encoder counts into steps/microsteps. **Counts** is the number of encoder counts per full rotation of the motor. **Steps** is the number of steps/microsteps output by the motion processor per full rotation of the motor. Since this command sets a ratio, the parameters do not have to be for a full rotation as long as they correctly represent the encoder count to step ratio.

GetEncoderToStepRatio gets the ratio of number of encoder counts to the number of output steps per motor rotation.


Restrictions

see Set/GetActualPositionUnits

Syntax SetGearMaster *axis masterAxis source*
GetGearMaster *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3
	<i>masterAxis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3
	<i>source</i>	Actual	0
		Commanded	1

Packet structure



Description SetGearMaster establishes the slave (*axis*) and master (*masterAxis*) axes for the electronic-gearing profile, and sets the source, **Actual** or **Commanded**, of the master axis position data to be used.

The masterAxis determines what axis will drive the slave axis. Both the slave and the master axes must be enabled (**SetAxisMode** command). The source determines whether the master axis' commanded position as determined by the trajectory generator will be used to drive the slave axis, or whether the master axis' encoder position will be used to drive the slave.

GetGearMaster returns the codes for the geared axes and position source.

Restrictions For electronic gear mode to operate properly the master axis must be enabled.

see Set/GetGearRatio

SetGearRatio GetGearRatio


buffered

14h
59h

Syntax SetGearRatio *slaveAxis ratio*
GetGearRatio

Arguments	Name	Instance	Encoding		
	<i>slaveAxis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	<i>ratio</i>	Type signed 32 bits	Range -2^{31} to $2^{31}-1$	Scaling $1/2^{16}$	Units SlaveCounts/ MasterCounts

Packet structure



Description

SetGearRatio sets the ratio between the master and slave axes for the electronic gearing profile for the current **axis**. Positive ratios cause the slave to move in the same direction as the master, negative ratios in the opposite direction. The specified ratio has a unity scaling of 65,536.

GetGearRatio returns the gear ratio set for the specified slave axis.

Scaling examples:

ratio value	resultant ratio
-32,768	.5 negative slave counts for each positive master count
1,000,000	15.259 positive slave counts for each positive master count
123	.0018 positive slave counts for each positive master count

Restrictions

This is a buffered command. The new value set will not take effect until the next **Update** or **MultiUpdate** instruction is entered.

see

Set/GetGearMaster, MultiUpdate, Update

SetIntegrationLimit *(Servo products only)* GetIntegrationLimit *(Servo products only)*


buffered

95h
96h

Syntax SetIntegrationLimit *axis limit*
GetIntegrationLimit *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	<i>limit</i>	Type signed 32 bits	Range 0 to $2^{31}-1$	Scaling $1/2^8$	Units count*cycles

Packet structure



Description

SetIntegrationLimit loads the integration-limit register of the digital servo filter for the specified *axis*.

GetIntegrationLimit returns the value of the current integration limit.

Scaling example: The scaling is the same as for the GetIntegral command, namely that (for example) a constant position error of 100 counts which is present for 256 cycles will result in an integral value of 100 ($100 \times 256 / 256$), and therefore an IntegrationLimit value of 100 will limit the total accumulated integration error to 25,600 count*cycles.

Restrictions

This is a buffered command. The value set using this command will not take effect until the next Update or MultiUpdate instruction.

This command is not valid on the MC2400 and MC2500.

see

GetIntegral, GetDerivative, Set/GetDerivativeTime, MultiUpdate, Update


SetInterruptMask GetInterruptMask

2Fh
56h

Syntax SetInterruptMask *axis interruptMask*
GetInterruptMask *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3
	<i>interruptMask</i>	Motion complete Wrap-around Breakpoint 1 Capture received Motion error In positive limit In negative limit Instruction error Commutation error Breakpoint 2	0001h 0002h 0004h 0008h 0010h 0020h 0040h 0080h 0800h 4000h

Packet structure



Description

SetInterruptMask determines which bits in the Event Status register of the specified **axis** will cause a host interrupt. For each interrupt mask bit that is set to 1, the corresponding Event Status register bit will cause an interrupt when that status register bit goes active (is set to 1). Interrupt mask bits set to 0 will not generate interrupts.

GetInterruptMask returns the current mask for the specified axis.

Example: The interrupt mask value 28h will generate an interrupt when either the "in positive limit" bit or the "capture received" bit of the event status register goes active (set to 1).

Restrictions

see ClearInterrupt, GetInterruptAxis

SetJerk GetJerk


buffered

13h
58h

Syntax SetJerk *axis jerk*
GetJerk *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	<i>jerk</i>	Type unsigned 32 bits	Range 0 to $2^{31}-1$	Scaling $1/2^{32}$	Units counts/cycle ³

Packet structure



Description SetJerk loads the jerk register in the parameter buffer for the specified *axis*.
GetJerk reads the contents of the Jerk register.

Scaling example: To load a jerk value (time rate of change of acceleration) of .012345 counts/cycle³ multiply by 2^{32} or 4,294,967,296. In this example this gives a value to load of 53,021,371 (decimal) which corresponds to a high word of 0329h and a low word of 0AB Bh when loading each word in hexadecimal.

Restrictions SetJerk is a buffered command. The value set using this command will not take effect until the next **Update** or **MultiUpdate** instruction.

This command is used only with the S-curve profile mode. It is not used with the trapezoidal, velocity contouring, or electronic gear profile modes.

see Set/GetAcceleration, Set/GetDeceleration, Set/GetPosition, Set/GetVelocity, MultiUpdate, Update

SetKaff *(Servo products only)*
GetKaff *(Servo products only)*


buffered

93h
94h

Syntax SetKaff *axis Kaff*
GetKaff *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	<i>Kaff</i>	Type unsigned 16 bit	Range 0 to $2^{15}-1$	Scaling unity	Units -

Packet structure



Description SetKaff sets the acceleration feedforward gain of the digital servo filter for the specified *axis*.

GetKaff reads the current value of the acceleration feedforward gain.

Restrictions SetKaff is a buffered command. . The value set using this command will not take effect until the next Update or MultiUpdate instruction.

This command is not valid on the MC2400 and MC2500.

see Set/GetKd, Set/GetKi, Set/GetKout, Set/GetKp, Set/GetKvff, MultiUpdate, Update

SetKd (*Servo products only*)
GetKd (*Servo products only*)


buffered

27h
52h

Syntax SetKd *axis Kd*
GetKd *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	<i>Kd</i>	Type unsigned 16 bit	Range 0 to $2^{15}-1$	Scaling unity	Units -

Packet structure



Description SetKd sets the derivative gain of the digital servo filter for the specified axis.
GetKd reads the current value of the derivative gain.

Restrictions SetKd is a buffered command. The value set using this command will not take effect until the next **Update** or **MultiUpdate** instruction.

This command is not valid on the MC2400 and MC2500.

see Set/GetKaff, Set/GetKi, Set/GetKout, Set/GetKp, Set/GetKvff, MultiUpdate, Update

SetKi (*Servo products only*)
GetKi (*Servo products only*)


buffered

26h
51h

Syntax SetKi *axis Ki*
 GetKi *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	<i>Ki</i>	Type unsigned 16 bit	Range 0 to 2 ¹⁵ -1	Scaling unity	Units -

Packet structure



Description SetKi sets the integral gain of the digital servo filter for the specified *axis*.
 GetKi reads the current value of the integral gain.

Restrictions This is a buffered command. The value set using this command will not take effect until the next **Update** or **MultiUpdate** instruction.

This command is not valid on the MC2400 and MC2500.

see Set/GetKaff, Set/GetKd, Set/GetKout, Set/GetKp, Set/GetKvff, MultiUpdate, Update


SetKout *(Servo products only)*

GetKout *(Servo products only)*

9Eh
9Fh

Syntax	SetKout <i>axis</i> <i>Kout</i> GetKout <i>axis</i>				
Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	Kout	Type	Range	Scaling	Units
		unsigned 16 bit	0 to 2 ¹⁶ -1	100/2 ¹⁶	% output

Packet structure



Description SetKout sets the output scale factor of the digital servo filter for the specified axis. The default value of Kout is 65535.

GetKout reads the current value of the output scale factor.

Example:

To set the output scaling of the servo filter to half, set the Kout register to 32767.

Restrictions This command is NOT buffered. It will take affect immediately after it is sent.

This command is not valid on the MC2400 and MC2500.

see Set/GetKaff, Set/GetKd, Set/GetKi, Set/GetKp, Set/GetKvff

SetKp (*Servo products only*)
GetKp (*Servo products only*)


buffered

25h
50h

Syntax SetKp *axis Kp*
 GetKp *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	<i>Kp</i>	Type unsigned 16 bit	Range 0 to $2^{15}-1$	Scaling unity	Units -

Packet structure



Description SetKp sets the proportional gain of the digital servo filter for the specified *axis*.
 GetKp reads the current value of the proportional gain.

Restrictions SetKp is a buffered command. The value set using this command will not take effect until the next **Update** or **MultiUpdate** instruction.

This command is not valid on the MC2400 and MC2500.

see Set/GetKaff, Set/GetKd, Set/GetKi, Set/GetKout, Set/GetKvff, MultiUpdate, Update

SetKvff (*Servo products only*)
GetKvff (*Servo products only*)


buffered

2Bh
54h

Syntax SetKvff *axis Kvff*
GetKvff *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	<i>Kvff</i>	Type unsigned 16 bit	Range 0 to $2^{15}-1$	Scaling unity	Units -

Packet structure



Description SetKvff sets the velocity feedforward gain of the digital servo filter for the specified *axis*.

GetKvff reads the current value of the velocity feedforward gain.

Restrictions SetKvff is a buffered command. The value set using this command will not take effect until the next **Update** or **MultiUpdate** instruction.

This command is not valid on the MC2400 and MC2500.

see Set/GetKaff, Set/GetKd, Set/GetKi, Set/GetKout, Set/GetKp, MultiUpdate, Update

SetLimitSwitchMode


GetLimitSwitchMode

80h
81h

Syntax SetLimitSwitchMode *axis mode*
GetLimitSwitchMode *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3
	<i>mode</i>	off	0
		on	1

Packet structure



Description

SetLimitSwitchMode enables (On) or disables (Off) limit-switch sensing for the specified *axis*. When the mode is enabled, the axis will cause the corresponding limit-switch bits in the Event Status register and Activity Status register to be set when it enters either the positive or negative limit switches and the axis will be immediately stopped. When it is disabled these bits are not set, regardless of whether the axis is in a limit switch or not.

GetLimitSwitchMode returns the code for the current state of the limit-sensing mode.

Restrictions

see GetActivityStatus, GetEventStatus

SetMotionCompleteMode


GetMotionCompleteMode

EBh
ECh

Syntax SetMotionCompleteMode *axis mode*
GetMotionCompleteMode *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3
	<i>mode</i>	commanded	0
		actual	1

Packet structure



Description

SetMotionCompleteMode establishes the source for the comparison which determines the motion-complete status for the specified **axis**. When set to **commanded** mode the motion is considered complete when the profile velocity reaches zero and no further motion will occur without an additional host command. This mode is unaffected by the actual encoder location.

When set to **actual** mode the motion complete bit will be set when the above condition is true AND the actual encoder position has been within the Settle Window (**SetSettleWindow** command) for the number of servo loops specified by the **SetSettleTime** command. The settle "timer" is started at zero at the end of the trajectory profile motion so at a minimum a delay of SettleTime cycles will occur after the trajectory profile motion is complete.

GetMotionCompleteMode returns the current motion-complete mode.

Restrictions

see Set/GetSettleTime, Set/GetSettleWindow


SetMotorBias *(Servo products only)* **GetMotorBias** *(Servo products only)*

0Fh
2Dh

Syntax SetMotorBias *axis bias*
GetMotorBias *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	<i>bias</i>	Type signed 16 bit	Range -2^{15} to $2^{15}-1$	Scaling $100/2^{15}$	Units % output

Packet structure



Description SetMotorBias sets the bias voltage of the digital servo filter for the specified axis.

GetMotorBias reads the current bias voltage of the digital servo filter.

Scaling example:

If it is desired that a motor bias value of -2.5 % of full scale be placed on the servo filter output then this register should be loaded with a value of $-2.5 \times 32,768 / 100 = -819$ (decimal). This corresponds to a loaded hexadecimal value of 0FCCDh.

Restrictions This command is not valid on the MC2400 and MC2500.

see Set/GetMotorCommand, Set/GetMotorLimit

SetMotorCommand GetMotorCommand


buffered

77h
69h

Syntax SetMotorCommand *axis value*
GetMotorCommand *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	<i>value</i>	Type signed 16 bit	Range -2^{15} to $2^{15}-1$	Scaling $100/2^{15}$	Units % output

Packet structure



Description

SetMotorCommand loads the motor-command buffer register of the specified *axis*. For the MC2400 series, this command is used to control the magnitude of the output waveform.

GetMotorCommand reads the contents of the motor-command buffer register.

Scaling example:

If it is desired that a motor command value of 13.7 % of full scale be output to the motor than this register should be loaded with a value of $13.7 * 32,768 / 100 = 4,489$ (decimal). This corresponds to a hexadecimal value of 1189h.

Restrictions

SetMotorCommand is valid only when the motor is “off” for the MC2100 and MC2300 series.

SetMotorCommand is a buffered command. The value set using this command will not take effect until the next **Update** or **MultiUpdate** instruction.

This command is not available on the MC2500 series.

see

Set/GetMotorBias, Set/GetMotorLimit, Set/GetMotorMode, MultiUpdate, Update


SetMotorLimit *(Servo products only)*

GetMotorLimit *(Servo products only)*

06h
07h

Syntax	SetMotorLimit <i>axis limit</i> GetMotorLimit <i>axis limit</i>				
Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	limit	Type	Range	Scaling	Units
		unsigned 16 bit	0 to 2 ¹⁵ -1	100/2 ¹⁵	% output

Packet structure



Description

SetMotorLimit sets the maximum value for the motor output command allowed by the digital servo filter of the specified **axis**. Motor command values beyond this value will be clipped to the specified motor command limit. For example if the motor limit was set to 1,000 and the servo filter determined that the current motor output value should be 1,100 the actual output value would be 1,000. Conversely if the output value were -1,100 then it would be clipped to -1,000. This command is useful for protecting amplifiers, motors, or system mechanisms when it is known that a motor command exceeding a certain value will cause damage.

GetMotorLimit reads the current motor limit value.

Scaling example:

If it is desired that a motor limit of 75 % of full scale be established then this register should be loaded with a value of $75.0 * 32,768 / 100 = 24,576$ (decimal). This corresponds to a hexadecimal value of 06000h.

Restrictions

This command only affects the motor output when in closed loop mode. When the chipset is in open loop mode this command has no affect.

This command is not valid on the MC2400 and MC2500.

see

Set/GetMotorBias, Set/GetMotorCommand

SetMotorMode


GetMotorMode

DCh
DDh

Syntax SetMotorMode *axis mode*
GetMotorMode *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3
	<i>mode</i>	Off	0
		On	1

Packet structure



Description

SetMotorMode determines the mode of motor operation. For servo products, when set to **On**, the axis is in *closed-loop* mode, and is controlled by the output of the servo filter. On the MC2400 series and MC2500 series, the trajectory generator controls the motor output.

When set to **Off**, the axis is in *open-loop* mode, and is controlled by commands placed directly into the motor output register by the host. On the MC2400 series and MC2500 series the trajectory generator is switched off when the motor mode is set to **Off**.

GetMotorMode returns the current motor mode.

Restrictions

see GetActivityStatus, Set/GetMotorCommand

SetNumberPhases (MC2300, MC2400 and MC2800 only)


GetNumberPhases (MC2300, MC2400 and MC2800 only)

85h
86h

Syntax SetNumberPhases *axis* *phases*
GetNumberPhases *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3
	<i>phases</i>	1Phase	1
		2Phases	2
		3Phases	3

Packet structure



Description SetNumberPhases establishes the number of phases, 1, 2 or 3, for commutation of the specified *axis*.

GetNumberPhases returns the number of phases set for the *axis*.

Restrictions In PWM Sign/Magnitude output mode, the number of phases can be set to 1 or 2.
In PWM 5050 output mode, the number of phases can be set to 1,2 or 3.

see GetPhaseCommand, InitializePhase, Set/GetPhase Set/GetOutputMode commands


SetOutputMode GetOutputMode

E0h
6Eh

Syntax SetOutputMode *axis mode*
GetOutputMode *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3
	<i>mode</i>	DAC	0
		PWMSignMagnitude	1
		PWM5050Magnitude	2

Packet structure



Description SetOutputMode determines the form of the motor output signal of the specified *axis*.

GetOutputMode returns the code for the current motor output mode.

Restrictions This command is not available on the MC2500.

If the number of phases is set to 3, PWM Sign/Magnitude output mode is not available.

see


SetPhaseAngle (MC2300 and MC2800 only) GetPhaseAngle (MC2300 and MC2800 only)

84h
2Ch

Syntax SetPhaseAngle *axis angle*
GetPhaseAngle *axis*

Arguments	Name	Instance	encoding			
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3			
	<i>angle</i>	Type unsigned integer	Range 0 to 2 ¹⁵ -1	Scaling unity	Units counts	

Packet structure



Description SetPhaseAngle sets the instantaneous commutation angle for the specified *axis*. GetPhaseAngle returns the value of the current phase angle. To convert counts to an actual phase angle divide by the number of encoder counts per electrical cycle and multiply by 360.

For example if a value of 500 is retrieved using GetPhaseAngle and the counts per electrical cycle value has been set to 2,000 (SetPhaseCounts command) this corresponds to an angle of $(500/2,000) \times 360 = 90$ degrees current phase angle position.

Restrictions The specified angle must not exceed the number of counts per electrical cycle set by the SetPhaseCounts command.

see GetPhaseCommand, InitializePhase, Set/GetNumberPhases

SetPhaseCorrectionMode *(MC2300 and MC2800 only)*


GetPhaseCorrectionMode *(MC2300 and MC2800 only)*

E8h
E9h

Syntax SetPhaseCorrectionMode *axis mode*
GetPhaseCorrectionMode *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3
	<i>mode</i>	Disabled	0
		Enabled	1

Packet structure



Description

SetPhaseCorrectionMode sets the phase correction mode for the specified *axis* to either 0 (disabled) or 1(enabled). When phase correction is enabled, the encoder index signal is used to update the commutation phase angle each motor revolution. This ensures that the commutation angle will remain correct even if some encoder counts are lost due to electrical noise, or due to the number of encoder counts/electrical phase not being an integer.

GetPhaseCorrectionMode returns the current phase correction mode.

Restrictions

see GetPhaseCommand, InitializePhase, Set/GetNumberPhases, Set/GetPhaseCounts

SetPhaseCounts *(MC2300, MC2400 and MC2800 only)*


GetPhaseCounts *(MC2300, MC2400 and MC2800 only)*

75h
7Dh

Syntax SetPhaseCounts *axis counts*
GetPhaseCounts *axis*

Arguments	Name	Instance	encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
		Type	Range	Scaling	Units
	<i>counts</i>	unsigned 16 bit	0 to 2 ¹⁵ -1	unity	counts

Packet structure



Description SetPhaseCounts sets the number of encoder count per electrical phase of the motor. If this value is not an integer then the closest integer value should be used, and phase correction mode should be enabled (See SetPhaseCorrectionMode command). The number of electrical cycles is equal to 1/2 the number of motor poles.

GetPhaseCounts returns the number of counts per electrical cycle.

Restrictions

For MC2400:

The number of microsteps per full step is set using the command SetPhaseCounts. The parameter used for this command represents the number of microsteps per electrical cycle (4 times the desired number of microsteps). So for example, to set 64 microsteps per full step, the command SetPhaseCounts 256 should be used. The maximum number of microsteps that can be generated per full step is 256, giving a maximum parameter for this command of 1024.

see

GetPhaseCommand, InitializePhase, Set/GetNumberPhases

SetPhaseInitializeMode (MC2300 and MC2800 only)


GetPhaseInitializeMode (MC2300 and MC2800 only)

E4h
E5h

Syntax SetPhaseInitializeMode *axis mode*
GetPhaseInitializeMode *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3
	<i>mode</i>	Algorithmic	0
		Hall-based	1

Packet structure



Description

SetPhaseInitializeMode establishes the mode in which the specified axis is to be initialized for commutation. The options are Algorithmic and Hall-based. In algorithmic mode the chipset briefly stimulates the motor windings and sets the initial phasing based on the observed motor response. In Hall-based initialization mode the 3 Hall sensor signals are used to determine the motor phasing.

GetPhaseInitializeMode returns the current initialization mode.

Restrictions

Algorithmic mode should only be selected if it is known that the axis is free to move in both directions, and that a brief uncontrolled move can be tolerated by the motor, mechanism, and load.

see

GetPhaseCommand, InitializePhase, Set/GetNumberPhases

SetPhaseInitializeTime (MC2300 and MC2800 only)


GetPhaseInitializeTime (MC2300 and MC2800 only)

72h
7Ch

Syntax SetPhaseInitializeTime *axis time*
GetPhaseInitializeTime *axis*

Arguments	Name	Instance	encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
		Type	Range	Scaling	Units
	<i>time</i>	unsigned 16 bit	0 to 2 ¹⁵ -1	unity	cycles

Packet structure



Description

SetPhaseInitializeTime sets the time value (in cycles) to be used during the algorithmic phase initialization procedure. This value determines the duration of each of the four segments in the phase initialization algorithm. See the User's guide for more information on algorithmic initialization.

GetPhaseInitializeTime returns the current phase initialization time.

Restrictions

see GetPhaseCommand, InitializePhase, Set/GetNumberPhases


SetPhaseOffset (MC2300 and MC2800 only) GetPhaseOffset (MC2300 and MC2800 only)

76h
7Bh

Syntax SetPhaseOffset *axis offset*
GetPhaseOffset *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1	0		
		Axis2	1		
		Axis3	2		
		Axis4	3		
		Type	Range	Scaling	Units
	<i>offset</i>	unsigned 16 bit	0 to 2 ¹⁵ -1	unity	counts

Packet structure



Description

SetPhaseOffset sets the offset from the index mark of the specified axis to the maximum output value of phase A. This command will have no immediate effect on the commutation angle but will have an affect once the index pulse is encountered.

GetPhaseOffset returns the current value of the phase offset.

To convert counts to a phase angle in degrees, divide by the number of encoder counts per electrical cycles and multiply by 360. For example if a value of 500 is specified using **SetPhaseOffset** and the counts per electrical cycle value has been set to 2,000 (**SetPhaseCounts** command) this corresponds to an angle of $(500/2,000)*360 = 90$ degrees phase angle at the index mark.

Restrictions

see GetPhaseCommand, InitializePhase, Set/GetNumberPhases

SetPhasePrescale (MC2300 and MC2800 only)


GetPhasePrescale (MC2300 and MC2800 only)

E6h
E7h

Syntax SetPhasePrescale *axis scale*
GetPhasePrescale *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3
	<i>mode</i>	Off	0
		On	1

Packet structure



Description

SetPhasePrescale On causes the number of encoder counts to be scaled by a factor of $\frac{1}{64}$ before being used to calculate a commutation angle for the specified **axis**. When operated in the prescale mode the chipset can commute motors with a high number of counts per electrical cycle, such as motors with very high accuracy encoders.

SetPhasePrescale Off removes the scale factor.

GetPhasePrescale returns the current scaling mode.

Restrictions

see GetPhaseCommand, InitializePhase, Set/GetNumberPhases

SetPosition GetPosition


buffered

10h
4Ah

Syntax SetPosition *axis position*
 GetPosition *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	<i>position</i>	Type signed 32 bit	Range -2^{31} to $2^{31}-1$	Scaling unity	Units counts

Packet structure



Description SetPosition specifies the trajectory destination of the specified **axis**. It is used in the Trapezoidal and S-curve profile modes.

 GetPosition reads the contents of the buffered position register.

Restrictions SetPosition is a buffered command. The value set using this command will not take effect until the next **Update** or **MultiUpdate** instruction.

see Set/GetAcceleration, Set/GetDeceleration, Set/GetJerk, Set/GetVelocity, GetPositionError, Set/GetPositionErrorLimit, MultiUpdate, Update

SetPositionErrorLimit


GetPositionErrorLimit

97h
98h

Syntax SetPositionErrorLimit *axis limit*
 GetPositionErrorLimit *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	<i>limit</i>	Type unsigned 32 bit	Range 0 to 2 ³¹ -1	Scaling unity	Units counts

Packet structure



Description

SetPositionErrorLimit sets the absolute value of the maximum position error allowable by the chipset for the specified **axis**. If the position error exceeds this limit, a motion error occurs. Such a motion error may or may not cause the axis to stop moving depending on the value set using the **SetAutoStopMode** command.

GetPositionErrorLimit returns the current position error limit value.

Restrictions

see GetPositionError, GetActualPosition, Set/GetPosition

SetProfileMode GetProfileMode


buffered

A0h
A1h

Syntax SetProfileMode *axis profile*
GetProfileMode *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3
	<i>profile</i>	Trapezoidal	0
		Velocity contouring	1
		S-curve	2
		Electronic gear	3
		External	4

Packet structure



Description SetProfileMode sets the profile mode, selecting Trapezoidal, Velocity Contouring, S-curve, Electronic gear or External for the specified *axis*.
GetProfileMode returns the contents of the buffered profile-mode register for the specified *axis*.

Restrictions SetProfileMode is a buffered command. The value set using this command will not take effect until the next Update or MultiUpdate instruction.

see Set/GetGearMaster, Set/GetGearRatio, Set/GetBufferFunction, MultiUpdate, Update

SetSampleTime


GetSampleTime

38h
61h

Syntax SetSampleTime *time*
GetSampleTime

Arguments	Name	Type	Range	Scaling	Units
	<i>time</i>	unsigned 16 bit	1 to 2 ¹⁵ -1	unity	μsec/cycle

Packet structure



Description

SetSampleTime sets the cycle time for the chipset. This is the time between servo loop updates and trajectory calculations. The value is expressed in microseconds. Only certain values are allowed as follows:

Product	Allowed values
MC2100 series	multiples of 102 and at least 102 μsec per enabled axis
MC2300 series	multiples of 154 and at least 154 μsec per enabled axis
MC2400 series	multiples of 154 and at least 154 μsec per enabled axis

GetSampleTime returns the current sample time value.

Restrictions

This command is not available with the MC2500 series.
This command affects the cycle time for all axes.

see

SetSerialPortMode

GetSerialPortMode


8Bh
8Ch

Syntax SetSerialPort *mask*
GetSerialPort

Arguments

Name	Instance	Encoding
<i>mask</i>		see below

Packet structure



Description

SetSerialPortMode sets the configuration for the asynchronous serial port.

Note: It is recommended that two stop bits be used for baud rates greater than 19200bps.

GetSerialPortMode returns the configuration for the asynchronous serial port.

The following table shows the encoding of the data used by this command.

<i>Bit Number</i>	<i>Name</i>	<i>Instance</i>	<i>Encoding</i>
0-3	transmission rate	1200 baud 2400 9600 19200 57600 115200 250000 416667	0 1 2 3 4 5 6 7
4-5	parity	none odd even	0 1 2
6	stop bits	1 2	0 1
7-8	protocol	Point-to-point Multi-drop using address bit Multi-drop using idle-line detection	0 2 3
11-15	multi-drop address	Address 0 Address 1 ... Address 31	0 1 ... 31

Restrictions

see Set/GetDiagnosticPortMode

SetSettleTime


GetSettleTime

AAh
ABh

Syntax SetSettleTime *axis time*
GetSettleTime *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	<i>time</i>	Type unsigned 16 bit	Range 0 to $2^{15}-1$	Scaling unity	Units cycles

Packet structure



Description SetSettleTime sets the time, in number of cycles, that the specified *axis* must remain within the settle window before the axis-settled indicator (in the activity status register) is set.

GetSettleTime returns the current settle time for the specified *axis*.

Restrictions

see Set/GetMotionCompleteMode, Set/GetSettleWindow, GetActivityStatus

SetSettleWindow


GetSettleWindow

BCh
BDh

Syntax SetSettleWindow *axis window*
GetSettleWindow *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	<i>window</i>	Type unsigned 16 bit	Range 0 to 2 ¹⁵ -1	Scaling unity	Units counts

Packet structure



Description SetSettleWindow sets the position range within which the specified *axis* must remain for the duration specified by SetSettleTime before the axis-settled indicator (in the activity status register) is set.

GetSettleWindow returns the current value of the settle window.

Restrictions

see Set/GetMotionCompleteMode, Set/GetSettleTime, GetActivityStatus

SetSignalSense GetSignalSense

A2h
A3h

Syntax SetSignalSense *axis mask*
GetSignalSense *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3
		Indicator	Bit Number
	<i>mask</i>	Encoder A	0001h 0
		Encoder B	0002h 1
		Encoder Index	0004h 2
		Encoder Home	0008h 3
		Positive limit	0010h 4
		Negative limit	0020h 5
		AxisIn	0040h 6
		Hall A	0080h 7
		Hall B	0100h 8
		Hall C	0200h 9
		AxisOut	0400h 10
		StepOutput	0800h 11
		MotorOutput	1000h 12
		<i>reserved</i>	13 - 15

Packet structure



Description

SetSignalSense establishes the sense of the signals connected to the Signal Sense register by using a bitwise *mask* that corresponds to the bits of the Signal Status register, for the specified *axis*.

For each sense bit that is 0, the input is active low, or not inverted.

For each sense bit that is 1, the input is active high, or inverted.

Inverting the MotorOutput has the effect of reversing the direction of motion when a positive or negative motor command is given.

Inverting the StepOutput has the effect of reversing step signal generated by the MC2500 chipset. Refer to the User's Guide for more information.

GetSignalSense returns the current signal sense mask.

Restrictions	Inverting the encoder A,B, or index may prevent the index capture mechanism from operating correctly. Refer to the Navigator Technical Specifications for the index capture electrical requirements.
<i>see</i>	GetSignalStatus

SetStartVelocity (MC2400 and MC2500 only)
GetStartVelocity (MC2400 and MC2500 only)


buffered

6Ah
6Bh

Syntax SetStartVelocity *axis velocity*
GetStartVelocity *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1	0		
		Axis2	1		
		Axis3	2		
		Axis4	3		
		Type	Range	Scaling	Units
	<i>velocity</i>	unsigned 32 bit	0 to $2^{31}-1$	$1/2^{16}$	counts/cycle

Packet structure



Description

SetStartVelocity loads the starting velocity buffer register for the specified *axis*.

GetStartVelocity reads the starting velocity buffer register.

Scaling example: To load a starting velocity value of 1.750 counts/cycle multiply by 65,536 (giving 114,688) and load the resultant number as a 32 bit number, giving 0001 in the high word and C000h in the low word. Retrieved numbers (GetStartingVelocity) must correspondingly be divided by 65,536 to convert to units of counts/cycle.

Restrictions

SetStartVelocity has no effect when the chip is in S-curve profile mode.

SetVelocity is a buffered command. The value set using this command will not take effect until the next Update or MultiUpdate instruction.

see

Set/GetAcceleration, Set/GetDeceleration, Set/GetPosition

SetStepRange (MC 2500 only)


GetStepRange (MC 2500 only)

CFh
CEh

Syntax SetStepRange *axis frequency*
GetStepRange *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3
	<i>frequency</i>	5 MHz	1
		625 kHz	4
		156.25 kHz	6
		39.062 kHz	8

Packet structure



Description SetStepRange set the maximum pulse rate frequency for the specified *axis*. For example, if the desired maximum pulse rate is 200,000 pulses/second, the command SetStepRange 4 should be issued.

GetMaxStepRate returns the maximum pulse rate frequency for the specified *axis*.

Restrictions This command is only available on the MC2500 series.

SetStopMode GetStopMode


buffered

D0h
D1h

Syntax SetStop *axis mode*
GetStop *axis*

Arguments	Name	Instance	Encoding
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3
	<i>mode</i>	NoStop	0
		AbruptStop	1
		SmoothStop	2

Packet structure



Description

SetStopMode stops the specified **axis**. The available stop modes are AbruptStop, which instantly (without any deceleration phase) stops the axis, SmoothStop which uses the programmed deceleration value and profile shape for the current profile mode to stop the axis, or NoStop which is generally used to turn off a previously set stop command.

Note: After an **Update** a buffered stop command (SetStopMode command) will reset to the NoStop condition. In other words if the command **SetStopMode** is followed by an **Update** command and then by a **GetStopMode** command, the retrieved stop mode will be NoStop.

GetStopMode returns the stop mode set using **SetStopMode**.

Restrictions

SmoothStop mode is not available in the electronic-gearing profile.

SetStopMode is a buffered command. The value set using this command will not take effect until the next **Update** or **MultiUpdate** instruction.

see

MultiUpdate, Update


SetTraceMode GetTraceMode

B0h
B1h

Syntax SetTraceMode *mode*
 GetTraceMode

Arguments	Name	Instance	Encoding
	<i>mode</i>	OneTime	0
		RollingBuffer	1

Packet structure



Description **SetTraceMode** sets the buffer usage for the next trace. In OneTime mode, the trace continues until the buffer is filled, then stops. In Rolling mode, the trace continues from the beginning of the buffer after the end is reached. Values stored when in the rolling mode are lost if they are not read before being overwritten by the wrapped data being traced and stored.

GetTraceMode returns the code for the current buffer mode.

Restrictions

see GetTraceStatus


SetTracePeriod GetTracePeriod

B8h
B9h

Syntax SetTracePeriod *period*
GetTracePeriod

Arguments	Name	Type	Range	Scaling	Units
	<i>period</i>	unsigned 16 bit	1 to $2^{15}-1$	unity	cycles

Packet structure



Description SetTracePeriod sets the time period, expressed in number of cycles, between successive trace points.

GetTracePeriod returns the current trace period.


Restrictions

see Set/GetSampleTime, Set/GetTraceStart, Set/GetTraceStop

Syntax SetTraceStart *triggerAxis condition triggerBit triggerState*
GetTraceStart

Arguments	Name	Instance	Encoding
	<i>triggerAxis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3
		Description	
	<i>condition</i>	Immediate Next update Event Status register bit Activity Status register bit Signal Status register bit	0 1 2 3 4
	<i>triggerBit</i>	Status register bit	0 to 15
	<i>triggerState</i>	Triggering state of the bit	0 (value = 0) 1 (value = 1)

Packet structure



Description

SetTraceStart sets the condition for starting the trace. The *Immediate* condition requires no axis to be specified and the trace will begin upon execution of this instruction. The other four conditions require an axis to be specified; and when the condition for that axis is attained, the trace will begin.

When a status register bit is the trigger, the bit number and state must be included in the argument. The trace is started when the indicated bit reaches the specified state (0 or 1).

Once a trace has started, the trace-start indicator is reset and the **SetTraceStart** instruction must be reentered before another trace can be started.

GetTraceStart returns the the current trace-start condition.

Examples:

If it is desired that the trace begin on the next **Update** for axis 3, then a "1" is set for the condition, a "2" is set for the axis number, and bit number and state can be loaded with zeroes since they are not used.

If it is desired that the trace begin when bit 7 of the Activity Status register for axis 2 goes to 0 then the trace start is loaded as follows: A "3" is loaded for condition, a "1" is loaded for axis number, a "7" is loaded for bit number, and a "0" is loaded for state.

The table below shows the corresponding value for combinations of *triggerBit* and *register*.

<i>encoding of "triggerBit"</i>	<i>register = event status</i>	<i>register = activity status</i>	<i>register = signal status</i>
0	Motion Complete	Phasing Initialized	Encoder A
1	Wrap-around	At maximum velocity	Encoder B
2	Breakpoint 1	Tracking	Encoder index
3	Position capture		Home
4	Motion error		Positive limit
5	In positive limit		Negative limit
6	In negative limit		AxisIn
7	Instruction error	Axis settled	Hall sensor 1
8		Motor on/off	Hall sensor 2
9		Position capture	Hall sensor 3
0Ah		In motion	
0Bh	Commutation error	In positive limit	
0Ch		In negative limit	
0Dh			
0Eh	Breakpoint 2		
0Fh			

Restrictions

see

Set/GetBufferLength, GetTraceCount, Set/GetTraceMode, Set/GetTracePeriod, Set/GetTraceStop

SetTraceStop GetTraceStop

B4h
B5h

Syntax SetTraceStop *triggerAxis condition triggerBit triggerState*
GetTraceStop

Arguments	Name	Instance	Encoding
	<i>triggerAxis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3
		Description	
	<i>condition</i>	Immediate Next update Event Status register bit Activity Status register bit Signal register bit	0 1 2 3 4
	<i>triggerBit</i>	Status register bit	0 to 15
	<i>triggerState</i>	Triggering state of the bit	0 (value = 0) 1 (value = 1)

Packet structure



Description

SetTraceStop sets the condition for stopping the trace. The *Immediate* condition requires no axis to be specified and the trace will stop upon execution of this instruction. The other four conditions require an axis to be specified; and when the condition for that axis is attained, the trace will stop.

When a status register bit is the trigger, the bit number and state must be included in the argument. The trace stops when the indicated bit reaches the specified state (0 or 1).

Once a trace has stopped, the trace-stop indicator is reset and the **SetTraceStop** instruction must be reentered before another trace can be stopped.

GetTraceStop returns the code for the current trace-stop condition.

Examples:

If it is desired that the trace stop on the next Update for axis 3, then a "1" is set for the condition, a "2" is set for the axis number, and bit number and state can be loaded with zeroes since they are not used.

If it is desired that the trace stop when bit 7 of the Activity status for axis 2 goes to 0 then the trace stop is loaded as follows: A "3" is loaded for condition, a "1" is loaded for axis number, a "7" is loaded for bit number, and a "0" is loaded for state.

The table below shows the corresponding value for combinations of *triggerBit* and *register*.

<i>encoding of "triggerBit"</i>	<i>register = event status</i>	<i>register = activity status</i>	<i>register = signal status</i>
0	Motion Complete	Phasing Initialized	Encoder A
1	Wrap-around	At maximum velocity	Encoder B
2	Breakpoint 1	Tracking	Encoder index
3	Position capture		Home
4	Motion error		Positive limit
5	In positive limit		Negative limit
6	In negative limit		AxisIn
7	Instruction error	Axis settled	Hall sensor 1
8		Motor on/off	Hall sensor 2
9		Position capture	Hall sensor 3
0Ah		In motion	
0Bh	Commutation error	In positive limit	
0Ch		In negative limit	
0Dh			
0Eh	Breakpoint 2		
0Fh			

Restrictions

see


Set/GetTraceCount, Set/GetTraceStart, Set/GetTraceStatus

SetTraceVariable GetTraceVariable

B6h
B7h

Syntax	SetTraceVariable <i>variableNumber</i> <i>traceAxis</i> <i>variable</i> GetTraceVariable <i>variableNumber</i>		
Arguments	<i>Name</i>	<i>Instance</i>	<i>Encoding</i>
	<i>variableNumber</i>	Variable1 Variable2 Variable3 Variable4	0 1 2 3
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3
	<i>variable</i>	None (disable the variable) Position error (32 bits) Commanded position (32 bits) Commanded velocity (32 bits) Commanded acceleration (32 bits) Actual position (32 bits) Actual velocity (32 bits) Motor command (16 bits) Chipset time (32 bits) Capture register (32 bits) Integral (32 bits) Derivative (16 bits) Event Status register (16 bits) Activity Status register (16 bits) Signal Status register (16 bits) Phase angle (16 bits) Phase offset (16 bits) Phase A (16 bits) Phase B (16 bits) Phase C (16 bits) Analog input 1 (16 bits) Analog input 2 (16 bits) Analog input 3 (16 bits) Analog input 4 (16 bits) Analog input 5 (16 bits) Analog input 6 (16 bits) Analog input 7 (16 bits) Analog input 8 (16 bits) PID Servo Error	0 1 2 3 4 5 6 7 8 9 Ah Bh Ch Dh Eh Fh 10h 11h 12h 13h 14h 15h 16h 17h 18h 19h 1Ah 1Bh 1Ch

Packet structure



Description

SetTraceVariable assigns the given variable to the specified *variableNumber* location in the trace buffer. The variable will always occupy a 32-bit buffer location. 16-bit values are sign extended to 32 bits. Up to four variables may be traced at one time. All combinations of axis numbers and trace variables are supported.

All variable assignments must be contiguous starting with *variableNumber* = 0.

GetTraceVariable returns the variable and axis of the specified *variableNumber*.

Example: To set up a 3 variable trace capturing the commanded acceleration for axis 1, the actual position for axis 1, and the event status word for axis 3 the following sequence of commands would be used. First a **SetTraceVariable** command with traceId of "0", axis of "0", and variable of "4" would be sent. Then a **SetTraceVariable** command with traceId of "1", axis of "0", and variable of "5" would be sent. Finally a **SetTraceVariable** command with traceId of "2", axis of "2" and variable of "0Ch" would be sent.

Restrictions

see Set/GetTrace commands


SetTrackingWindow GetTrackingWindow

A8h
A9h

Syntax SetTrackingWindow *axis window*
 GetTrackingWindow *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	<i>window</i>	Type unsigned 16 bit	Range 0 to 2 ¹⁵ -1	Scaling unity	Units counts

Packet structure



Description SetTrackingWindow sets boundaries for the actual position of the specified axis. If the axis crosses the window boundary in either direction, the Tracking indicator (bit 2 of the activity Status register) is set to 0. When the axis returns to within the window, the tracking indicator is set to 1.

GetTrackingWindow returns the value of the current tracking window.

Restrictions

see GetActivityStatus, GetActualPosition

SetVelocity GetVelocity


buffered

11h
4Bh

Syntax SetVelocity *axis velocity*
GetVelocity *axis*

Arguments	Name	Instance	Encoding		
	<i>axis</i>	Axis1 Axis2 Axis3 Axis4	0 1 2 3		
	<i>velocity</i>	Type signed 32 bit	Range -2^{31} to $2^{31}-1$	Scaling $1/2^{16}$	Units counts/cycle

Packet structure



Description SetVelocity loads the Maximum Velocity buffer register for the specified *axis*.

GetVelocity returns the Maximum Velocity buffer register.

Scaling example: To load a velocity value of 1.750 counts/cycle multiply by 65,536 (giving 114,688) and load the resultant number as a 32 bit number, giving 0001 in the high word and C000h in the low word. Retrieved numbers (GetVelocity) must correspondingly be divided by 65,536 to convert to units of counts/cycle.

Restrictions SetVelocity may not be issued while an axis is in motion with the S-curve profile.

SetVelocity is not valid in Electronic Gearing profile mode.

The velocity must not be ≤ 0 except in the Velocity-Contouring profile mode.


SetVelocity is a buffered command. The value set using this command will not take effect until the next Update or MultiUpdate instruction.

see Set/GetAcceleration, Set/GetDeceleration, Set/GetJerk, Set/GetPosition, MultiUpdate, Update

Syntax Update *axis*

Arguments	<i>Name</i>	<i>Instance</i>	<i>Encoding</i>
	<i>axis</i>	Axis1	0
		Axis2	1
		Axis3	2
		Axis4	3

Packet structure



Description

Update causes all buffered data parameters are copied into the corresponding run-time registers on the specified **axis**.

The following instruction is buffered: **ClearPositionError**.

The following trajectory parameters are buffered: Acceleration, Deceleration, GearRatio, Jerk, Position, ProfileMode, StartVelocity, Stop, and Velocity.

The following PID filter parameters are buffered: DerivativeTime, IntegrationLimit, Kaff, Kd, Ki, Kp, and Kvff.

The following Motor Command parameters is buffered: MotorCommand.


Restrictions

see MultiUpdate

Syntax WriteBuffer *bufferID value*

Arguments	Name	Type	Range	Scaling	Units
	<i>bufferID</i>	unsigned 16 bit	0 to 15	unity	-
	<i>value</i>	signed 32 bit	-2^{31} to $2^{31}-1$	unity	-

Packet structure



Description

WriteBuffer writes the 32-bit *value* into the current location in the specified buffer. The current location is determined by adding the base address of the buffer (set by **SetBufferStart**), to the buffer's Write Index (set by **SetBufferWriteIndex**). After the contents have been read, the Write Index is incremented by 1; if the result is equal to the buffer length (set by **SetBufferLength**), the Index is reset to 0.

Some chipset operations automatically change the write index such as during a trace. See the User's Guide for more details.


Restrictions

see ReadBuffer, Set/GetBufferWriteIndex

Syntax WriteIO *address data*

Arguments	Name	Type	Range	Scaling	Units
	<i>address</i>	unsigned 8 bit	0 to 255	unity	-
	<i>data</i>	unsigned 16 bit	0 to $2^{16}-1$	unity	-

Packet structure



Description

WriteIO writes one 16-bit word of data to the device whose address is calculated by adding 1000h to *address*. (*address* is an offset from the base address, 1000h, of the Navigator's memory-mapped I/O space.)

The format and interpretation of the 16-bit data word are dependent on the user-defined device being addressed. User-defined I/O can be used to implement a variety of features such as additional parallel I/O, flash memory for non-volatile configuration information storage, or display devices such as LED arrays.

Restrictions

see ReadIO

3 Instruction Summary Tables

3.1 Descriptions by Functional Category

Breakpoints and Interrupts

ClearInterrupt	Reset interrupt line
GetBreakpoint	Get breakpoint type
GetBreakpointValue	Get breakpoint comparison value
GetInterruptAxis	Get the axes with pending interrupts
GetInterruptMask	Get interrupt mask
SetBreakpoint	Set breakpoint type
SetBreakpointValue	Set breakpoint comparison value
SetInterruptMask	Set interrupt mask

Commutation

GetCommutationMode	Get the commutation mode
GetNumberPhases	Get the number of phases
GetPhaseAngle	Get current commutation phase angle
GetPhaseCommand	Get the motor output command for a given phase A, B, or C
GetPhaseCorrectionMode	Get phase correction mode
GetPhaseCounts	Get number of encoder counts per commutation cycle
GetPhaseInitializeMode	Get phase initialization mode
GetPhaseInitializeTime	Get the time parameters for algorithmic phase initialization
GetPhaseOffset	Get phase offset value
GetPhasePrescale	Get phasing prescaler
InitializePhase	Perform phase initialization procedure
SetCommutationMode	Set the commutation mode (Hall-based, sinusoidal, or microstepping)
SetNumberPhases	Set the number of phases (1, 2, or 3)
SetPhaseAngle	Set current commutation phase angle
SetPhaseCorrectionMode	Set phase correction mode (on or off)
SetPhaseCounts	Set number of encoder counts per commutation cycle
SetPhaseInitializeMode	Set phase initialization method (hall-based or algorithmic)
SetPhaseInitializeTime	Set the time parameters for algorithmic phase initialization
SetPhaseOffset	Set phase offset value
SetPhasePrescale	Set commutation prescaler mode (enable or disable)

Digital Servo Filter

ClearPositionError	Set position error to 0
GetAutoStopMode	Get auto stop mode
GetDerivative	Get the derivative of the error signal
GetDerivativeTime	Get derivative sampling time
GetIntegral	Get integrated position error value
GetIntegrationLimit	Get integration limit
GetKaff	Get acceleration feedforward gain
GetKd	Get derivative gain
GetKi	Get integral gain
GetKout	Get servo filter output scaler
GetKp	Get proportional gain
GetKvff	Get velocity feedforward gain
GetMotorBias	Get motor output bias
GetMotorLimit	Get motor output limit

GetPositionError	Get actual position error
GetPositionErrorLimit	Get position error limit
SetAutoStopMode	Set auto stop on position error (on or off)
SetDerivativeTime	Set derivative sampling time
SetIntegrationLimit	Set integration limit
SetKaff	Set acceleration feedforward gain
SetKd	Set derivative gain
SetKi	Set integral gain
SetKout	Set servo filter output scaler
SetKp	Set proportional gain
SetKvff	Set velocity feedforward gain
SetMotorBias	Set motor output bias
SetMotorLimit	Set motor output limit
SetPositionErrorLimit	Set maximum position error limit
Encoder	
AdjustActualPosition	Sums the specified offset with the actual encoder position
GetActualPosition	Get the actual encoder position
GetActualPositionUnits	Get the unit type returned for the actual encoder position
GetActualVelocity	Get the actual encoder velocity
GetCaptureSource	Get capture source
GetCaptureValue	Get current axis position capture value and reset the capture
GetEncoderModulus	Get the full scale range of the parallel-word encoder
GetEncoderSource	Get encoder type
GetEncoderToStepRatio	Get encoder count to step ratio
SetActualPosition	Set the actual encoder position
SetActualPositionUnits	Set the unit type returned for the actual encoder position
SetCaptureSource	Set capture source (home or index)
SetEncoderModulus	Set the full scale range of the parallel-word encoder
SetEncoderSource	Set encoder type (incremental or 16-bit parallel word)
SetEncoderToStepRatio	Set encoder count to step ratio
External RAM	
GetBufferFunction	Returns the buffer ID for a specified function
GetBufferLength	Get the length of a memory buffer
GetBufferReadIndex	Get the buffer read pointer for a particular buffer
GetBufferStart	Get the start location of a memory buffer
GetBufferWriteIndex	Get the buffer write pointer for a particular buffer
ReadBuffer	Read a long word value from a buffer memory location
SetBufferFunction	Assigns a buffer to the specified function
SetBufferLength	Set the length of a memory buffer
SetBufferReadIndex	Set the buffer read pointer for a particular buffer
SetBufferStart	Set the start location of a memory buffer
SetBufferWriteIndex	Set the buffer write pointer for a particular buffer
WriteBuffer	Write a long word value to a buffer memory location
Motor Output	
GetCurrentMotorCommand	Read the current motor command value
GetMotorCommand	Read buffered motor output command
GetMotorMode	Get motor loop mode
GetOutputMode	Get output mode
SetStepRange	Sets the allowable range (in KHz) for step output generation
SetMotorCommand	Set direct value to motor output register
SetMotorMode	Set motor loop mode (on or off)
SetOutputMode	Set motor output mode (PWM sign-magnitude, PWM 50%, or DAC)

Profile generation

GetAcceleration	Get acceleration limit
GetCommandedAcceleration	Get commanded (instantaneous desired) acceleration
GetCommandedPosition	Get commanded (instantaneous desired) position
GetCommandedVelocity	Get commanded (instantaneous desired) velocity
GetDeceleration	Get deceleration limit
GetGearMaster	Get the electronic gear mode master axis and source
GetGearRatio	Get command electronic gear rate
GetJerk	Get jerk limit
GetPosition	Get destination position
GetProfileMode	Get current profile mode set using SetProfileMode
GetStartVelocity	Get start velocity
GetStop	Get stop command; abrupt, smooth, or none
GetVelocity	Get velocity limit
MultiUpdate	Multiple axis immediate parameter update
SetAcceleration	Set acceleration limit
SetDeceleration	Set deceleration limit
SetGearMaster	Set the master axis and source (actual or target-based)
SetGearRatio	Set command electronic gear ratio
SetJerk	Set jerk limit
SetPosition	Set position limit
SetProfileMode	Set profile mode (S-curve, trapezoidal, velocity-contouring, or electronic gear)
SetStartVelocity	Set start velocity
SetStop	Set stop command. (abrupt stop, smooth stop, or none)
SetVelocity	Set velocity limit
Update	Immediate parameter update

Servo loop control

GetAxisMode	Get axis mode
GetLimitSwitchMode	Get limit switch mode
GetMotionCompleteMode	Get the motion complete mode
GetSampleTime	Get servo loop sample time
GetSettleTime	Get the axis-settled time
GetSettleWindow	Get the settle-window boundary value
GetTime	Get current chip set time (number of servo loops)
GetTrackingWindow	Get the tracking window boundary value
SetAxisMode	Set axis operation mode (enabled or disabled)
SetLimitSwitchMode	Set limit switching (on or off)
SetMotionCompleteMode	Set the motion complete mode (target-based or actual)
SetSampleTime	Set servo loop sample time
SetSettleTime	Set the axis-settled time
SetSettleWindow	Set the settle-window boundary
SetTrackingWindow	Set the tracking window boundary

Status Registers and AxisOut Indicator

GetActivityStatus	Get Activity Status
GetAxisOutSource	Get axis out signal monitor source
GetEventStatus	Get event status word
GetSignalStatus	Get the current axis Signal Status register
GetSignalSense	Get the interpretation of the Signal Status bits
ResetEventStatus	Reset bits in event status word
SetAxisOutSource	Set axis out monitor signal source
SetSignalSense	Set the interpretation of the Signal Status bits

Traces

GetTraceCount	Get the number of traced data points
GetTraceMode	Get the trace mode

GetTracePeriod	Get the trace period
GetTraceStart	Get the trace start condition
GetTraceStatus	Get the trace status word
GetTraceStop	Get the trace stop condition
GetTraceVariable	Get a trace variable setting
SetTraceMode	Set the trace mode (rolling or one-time)
SetTracePeriod	Set the trace period
SetTraceStart	Start the trace
SetTraceStop	Stop the trace
SetTraceVariable	Set variable (i.e., data) to be traced
Miscellaneous	
GetChecksum	Reads the internal chip checksum
GetDiagnosticPortMode	Get the diagnostic port valid instruction mode
GetHostIOError	Get the most recent I/O error code
GetSerialPort	Read serial-port configuration data
GetVersion	Get chipset software version information
NoOperation	Perform no operation, used to verify communications
ReadIO	Read user defined I/O value
Reset	Reset chipset
SetDiagnosticPortMode	Set the diagnostic port valid instruction mode (limited or full)
SetSerialPort	Set serial-port configuration data
WriteIO	Write user-defined I/O value

3.2 Alphabetical Listing

Note: Get/Set instruction pairs are shown together on the same line of the table

Instruction	Code	Instruction	Code
AdjustActualPosition	F5		
ClearInterrupt	AC		
ClearPositionError	47		
GetAcceleration	4C	SetAcceleration	90
GetActivityStatus	A6		
GetActualPosition	37	SetActualPosition	4D
GetActualPositionUnits	BF	SetActualPositionUnits	BE
GetActualVelocity	AD		
GetAutoStopMode	D3	SetAutoStopMode	D2
GetAxisMode	88	SetAxisMode	87
GetAxisOutSource	EE	SetAxisOutSource	ED
GetBreakpoint	D5	SetBreakpoint	D4
GetBreakpointValue	D7	SetBreakpointValue	D6
GetBufferFunction	CB	SetBufferFunction	CA
GetBufferLength	C3	SetBufferLength	C2
GetBufferReadIndex	C7	SetBufferReadIndex	C6
GetBufferStart	C1	SetBufferStart	C0
GetBufferWriteIndex	C5	SetBufferWriteIndex	C4
GetCaptureSource	D9	SetCaptureSource	D8
GetChecksum	F8		
GetCaptureValue	36		
GetCommandedAcceleration	A7		
GetCommandedPosition	1D		
GetCommandedVelocity	1E		
GetCommutationMode	E3	SetCommutationMode	E2
GetCurrentMotorCommand	3A		
GetDeceleration	92	SetDeceleration	91
GetDerivative	9B		
GetDerivativeTime	9D	SetDerivativeTime	9C
GetDiagnosticPortMode	8A	SetDiagnosticPortMode	89
GetEncoderModulus	8E	SetEncoderModulus	8D
GetEncoderSource	DB	SetEncoderSource	DA
GetEncoderToStepRatio	DF	SetEncoderToStepRatio	DE
GetEventStatus	31		
GetGearMaster	AF	SetGearMaster	AE
GetGearRatio	59	SetGearRatio	14
GetHostIOError	A5		
GetIntegral	9A		
GetIntegrationLimit	96	SetIntegrationLimit	95
GetInterruptAxis	E1		
GetInterruptMask	56	SetInterruptMask	2F
GetJerk	58	SetJerk	13
GetKaff	94	SetKaff	93
GetKd	52	SetKd	27
GetKi	51	SetKi	26
GetKout	9F	SetKout	9E
GetKp	50	SetKp	25
GetKvff	54	SetKvff	2B
GetLimitSwitchMode	81	SetLimitSwitchMode	80
GetMotionCompleteMode	EC	SetMotionCompleteMode	EB
GetMotorBias	2D	SetMotorBias	0F
GetMotorCommand	69	SetMotorCommand	77
GetMotorLimit	07	SetMotorLimit	06

Instruction	Code	Instruction	Code
GetMotorMode	DD	SetMotorMode	DC
GetNumberPhases	86	SetNumberPhases	85
GetOutputMode	6E	SetOutputMode	E0
GetPhaseAngle	2C	SetPhaseAngle	84
GetPhaseCommand	EA		
GetPhaseCorrectionMode	E9	SetPhaseCorrectionMode	E8
GetPhaseCounts	7D	SetPhaseCounts	75
GetPhaseInitializeMode	E5	SetPhaseInitializeMode	E4
GetPhaseInitializeTime	7C	SetPhaseInitializeTime	72
GetPhaseOffset	7B	SetPhaseOffset	76
GetPhasePrescale	E7	SetPhasePrescale	E6
GetPosition	4A	SetPosition	10
GetPositionError	99		
GetPositionErrorLimit	98	SetPositionErrorLimit	97
GetProfileMode	A1	SetProfileMode	A0
GetSampleTime	61	SetSampleTime	38
GetSerialPort	8C	SetSerialPort	8B
GetSettleTime	AB	SetSettleTime	AA
GetSettleWindow	BD	SetSettleWindow	BC
GetSignalStatus	A4		
GetSignalSense	A3	SetSignalSense	A2
GetStartVelocity	6B	SetStartVelocity	6A
GetStop	D1	SetStop	D0
GetTime	3E		
GetTraceCount	BB		
GetTraceMode	B1	SetTraceMode	B0
GetTracePeriod	B9	SetTracePeriod	B8
GetTraceStart	B3	SetTraceStart	B2
GetTraceStatus	BA		
GetTraceStop	B5	SetTraceStop	B4
GetTraceVariable	B7	SetTraceVariable	B6
GetTrackingWindow	A9	SetTrackingWindow	A8
GetVelocity	4B	SetVelocity	11
GetVersion	8F		
InitializePhase	7A		
MultiUpdate	5B		
NoOperation	00		
ReadAnalog	EF		
ReadBuffer	C9		
ReadIO	83		
Reset	39		
ResetEventStatus	34		
Update	1A		
WriteBuffer	C8		
WriteIO	82		

3.3 Numeric Listing

Code	Instruction	Code	Instruction	Code	Instruction
00	NoOperation	80	SetLimitSwitchMode	B6	SetTraceVariable
06	SetMotorLimit	81	GetLimitSwitchMode	B7	GetTraceVariable
07	GetMotorLimit	82	WriteIO	B8	SetTracePeriod
0F	SetMotorBias	83	ReadIO	B9	GetTracePeriod
10	SetPosition	84	SetPhaseAngle	BA	GetTraceStatus
11	SetVelocity	85	SetNumberPhases	BB	GetTraceCount
13	SetJerk	86	GetNumberPhases	BC	SetSettleWindow
14	SetGearRatio	87	SetAxisMode	BD	GetSettleWindow
1A	Update	88	GetAxisMode	BE	SetActualPositionUnits
1D	GetCommandedPosition	89	SetDiagnosticPortMode	BF	GetActualPositionUnits
1E	GetCommandedVelocity	8A	GetDiagnosticPortMode	C0	SetBufferStart
25	SetKp	8B	SetSerialPort	C1	GetBufferStart
26	SetKi	8C	GetSerialPort	C2	SetBufferLength
27	SetKd	8D	SetEncoderModulus	C3	GetBufferLength
2B	SetKvff	8E	GetEncoderModulus	C4	SetBufferWriteIndex
2C	GetPhaseAngle	8F	GetVersion	C5	GetBufferWriteIndex
2D	GetMotorBias	90	SetAcceleration	C6	SetBufferReadIndex
2F	SetInterruptMask	91	SetDeceleration	C7	GetBufferReadIndex
31	GetEventStatus	92	GetDeceleration	C8	WriteBuffer
34	ResetEventStatus	93	SetKaff	C9	ReadBuffer
36	GetCaptureValue	94	GetKaff	CA	SetBufferFunction
37	GetActualPosition	95	SetIntegrationLimit	CB	GetBufferFunction
38	SetSampleTime	96	GetIntegrationLimit	D0	SetStop
39	Reset	97	SetPositionErrorLimit	D1	GetStop
3A	GetCurrentMotorCommand	98	GetPositionErrorLimit	D2	SetAutoStopMode
3E	GetTime	99	GetPositionError	D3	GetAutoStopMode
47	ClearPositionError	9A	GetIntegral	D4	SetBreakpoint
4A	GetPosition	9B	GetDerivative	D5	GetBreakpoint
4B	GetVelocity	9C	SetDerivativeTime	D6	SetBreakpointValue
4C	GetAcceleration	9D	GetDerivativeTime	D7	GetBreakpointValue
4D	SetActualPosition	9E	SetKout	D8	SetCaptureSource
50	GetKp	9F	GetKout	D9	GetCaptureSource
51	GetKi	A0	SetProfileMode	DA	SetEncoderSource
52	GetKd	A1	GetProfileMode	DB	GetEncoderSource
54	GetKvff	A2	SetSignalSense	DC	SetMotorMode
56	GetInterruptMask	A3	GetSignalSense	DD	GetMotorMode
58	GetJerk	A4	GetSignalStatus	E0	SetOutputMode
59	GetGearRatio	A5	GetHostIOError	E1	GetInterruptAxis
5B	MultiUpdate	A6	GetActivityStatus	E2	SetCommutationMode
61	GetSampleTime	A7	GetCommandedAcceleration	E3	GetCommutationMode
68	SetEncoderToStepRatio	A8	SetTrackingWindow	E4	SetPhaseInitializeMode
69	GetMotorCommand	A9	GetTrackingWindow	E5	GetPhaseInitializeMode
6A	SetStartVelocity	AA	SetSettleTime	E6	SetPhasePrescale
6B	GetStartVelocity	AB	GetSettleTime	E7	GetPhasePrescale
6E	GetOutputMode	AC	ClearInterrupt	E8	SetPhaseCorrectionMode
6F	GetEncoderToStepRatio	AD	GetActualVelocity	E9	GetPhaseCorrectionMode
72	SetPhaseInitializeTime	AE	SetGearMaster	EA	GetPhaseCommand
75	SetPhaseCounts	AF	GetGearMaster	EB	SetMotionCompleteMode
76	SetPhaseOffset	B0	SetTraceMode	EC	GetMotionCompleteMode
77	SetMotorCommand	B1	GetTraceMode	ED	SetAxisOutSource
7A	InitializePhase	B2	SetTraceStart	EE	GetAxisOutSource
7B	GetPhaseOffset	B3	GetTraceStart	EF	ReadAnalog
7C	GetPhaseInitializeTime	B4	SetTraceStop	F5	AdjustActualPosition
7D	GetPhaseCounts	B5	GetTraceStop	F8	GetChecksum