

# **SBM050C**

# **Special 9127**

## **Semi-Automatic**

## **Filling System**

**Controller**  
Operator and  
Programmer Guide

October 1993





**METTLER**

**TOLEDO**

**SPECIAL MODEL 9127  
DRUMFILLER CONTROLLER**

Program SBM050C

The Drumfiller Controller is designed to control a Toledo Scale Automatic Drumfiller Lance for filling drums, totes, or pails to a preset weight setpoint. The following documentation details the Drumfiller Controller operation, including configuration, setup, printing, and filling, from the operator's perspective, and includes Host communications protocol. The documentation is divided into sections with an overview at the beginning of each section.

This document must be read and understood by anyone who installs, operates, or maintains the Drumfiller.



# TABLE of CONTENTS

POWER UP SEQUENCE .....	1
NORMAL OPERATING SEQUENCE .....	10
SYSTEM SETUP SEQUENCE .....	16
GENERAL SETUP SEQUENCE .....	17
HOST SETUP SEQUENCE .....	35
PRINTER SETUP SEQUENCE .....	38
SETUP PARAMETER PRINTOUT SEQUENCE .....	48
SETUP PRODUCT ID'S SEQUENCE .....	49
TEST MODE SEQUENCE .....	69
SELECT PRODUCT ID SEQUENCE .....	80
CONSECUTIVE NUMBER SELECT SEQUENCE .....	87
VARIABLE ID SELECT SEQUENCE .....	88
ACCUMULATED WEIGHT SELECT SEQUENCE .....	89
AUTOMATIC DRUMFILLING SEQUENCE .....	91
ID SETUP REPORT SEQUENCE .....	108
PRODUCTION SUMMARY REPORT SEQUENCE .....	110
PRODUCT ID LIST REPORT SEQUENCE .....	114
REPORT PRINTOUT EXAMPLES .....	116
BATCH LOG REPORT EXAMPLE .....	116
SYSTEM SETUP REPORT .....	117
PRODUCT ID SETUP REPORT .....	119
PRODUCTION SUMMARY REPORT .....	120
PRODUCT ID LIST REPORT .....	121
DRUM LOG REPORT .....	121
APPENDICES .....	122
APPENDIX A - CONTROL AND SPECIAL CHARACTER ENTRY .....	122
APPENDIX B - ASCII CONTROL CODE CHART .....	125
APPENDIX C - HOST COMMUNICATIONS .....	128
About this Section .....	128
Host Glossary .....	129
Hardware Considerations .....	130
Host Communications Protocol .....	131

Establishing a Host to 9127 link .....	131
Transferring Data .....	131
HOST REQUEST CODES .....	132
9127 COMMUNICATIONS ACKNOWLEDGEMENTS .....	136
9127 RESPONSE CODES .....	137
INDIVIDUAL HOST REQUEST CODE PROTOCOL .....	139
REQUEST DRUM LOG .....	139
CLEAR DRUM LOG TABLE .....	141
PRODUCT SETUP RECORD DOWNLOAD .....	142
PRINTER REPORT FORMAT SELECTION DOWNLOAD .....	144
PRINTER REPORT FORMAT SELECTION UPLOAD .....	145
CLEAR PRODUCT SETUP RECORD .....	146
PRINTER LITERAL FORMAT DOWNLOAD .....	147
PRINTER LITERAL SELECTION UPLOAD .....	148
GLOBAL PRODUCT SETUP RECORDS UPLOAD .....	149
REQUEST RUN PRODUCT ID .....	150
SELECT RUN PRODUCT ID .....	151
REQUEST 9127 SYSTEM STATUS .....	152
REQUEST 9127 TIME & DATE .....	153
PRODUCT SETUP RECORD UPLOAD .....	154
9127 SYSTEM SETUP INFORMATION UPLOAD .....	155
9127 SYSTEM SETUP INFORMATION DOWNLOAD .....	157
SET 9127 TIME & DATE .....	158
CLEAR ALL PRODUCT ID RECORDS .....	159
ESTABLISH COMMUNICATION LINK .....	160
BREAK COMMUNICATION LINK .....	161
HOST REQUEST CODE VALIDITY TABLE .....	162
INDEX of DISPLAY PROMPTS .....	163

## **POWER UP SEQUENCE**

Statements 10 through 199

### About This Section

The following section describes the Drumfiller Controller power up sequence. Upon applying power to the controller, operation will begin from Statement number 10. It should be noted that the controller is configured with a bank of DIP switches located on the main control printed circuit board. The setting of these switches determines the type of Toledo Scale lance being controlled as well as other operational characteristics.



## **WARNING**

INCORRECT SETTING OF THE CONTROLLER CONFIGURATION

'DIP' SWITCHES (SW1) MAY RESULT IN IMPROPER AND UNSAFE

OPERATION OF THE DRUMFILLER. THESE SWITCHES MUST

BE SET AND VERIFIED BY A QUALIFIED TOLEDO SCALE

TECHNICIAN AT THE TIME OF INSTALLATION IN ACCORDANCE

WITH DETAILS PROVIDED IN THE HARDWARE TECHNICAL

DESCRIPTION MANUAL. FAILURE TO OBSERVE THIS

PRECAUTION MAY RESULT IN BODILY INJURY.





## POWER UP SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

10

-----  
[SBM050\_        YYYYYY]  
-----

The "\_" denotes the program version number, and "YYYYYY" the operating system language. This message will be displayed briefly while memory is checked. A test is performed on the program checksum and RAM memory.

If the checksum calculation is incorrect the program will advance to the next Statement.

If the RAM memory failed testing the program will advance to statement #25.

If the Controller Configuration DIP switch (SW1-8) is ON (Forced Cold Start), the program will advance to statement #30. Otherwise, the program will advance to statement #40.

20

-----  
[CPU FAILURE P    XX]  
-----

The display shows the expected value of the program checksum 'XX'. Operation will halt at this statement and the controller cannot be operated. Display of this message indicates a system hardware failure. Contact Toledo Scale Service.

25

-----  
[CPU FAILURE D       ]  
-----

The display shows that the RAM failed testing. Display of this message indicates a system hardware failure. Operation will halt at this statement and the controller cannot be operated. Contact Toledo Scale Service.

30

-----  
[FORCE COLD START? N]  
-----

The display asks if a forced cold start is to be performed. Cold start will clear all setups, variables and system passwords.

Press <Y> (yes) to force a cold start and advance to the next statement.

Press <N> (no) or <ENTER> to advance to the next statement.

## POWER UP SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

-----

40            [READING SCALE            ]

-----

There will be a 8 second delay at this time to allow the indicator's power up routine to be preformed.

The scale is read to determine the scale setup (decimal point location, etc). If a scale fault occurs the program will advance to the next statement. If the scale is read properly but the scale setup has changed, the program will advance to Statement #60.

Next, the Controller Configuration DIP setup switches (SW1-1 thru SW1-3) are checked. If they have changed, the program will advance to Statement #70.

The memory is then checked for data retention. If the data stored is not valid, or a cold start is being forced, the program will advance to statement #100.

Otherwise, the program will advance to Statement #110.

50            [SCALE FAULT            ]

-----

No data, invalid data, or checksum error was received from the indicator. Press <ENTER> to return the program to statement #40 and retry. If after several attempts the scale cannot be read check the indicator setup as detailed in the Hardware Technical Description manual or contact Toledo Scale Service.

60            [SCALE SETUP CHANGE    ]

-----

The scale setup cannot be changed without doing a cold start on the system (all variables are cleared). This is because it cannot be assumed that the programmed data for one scale setup will be valid for a different setup. Press <ENTER> to advance the program to Statement #80.

## POWER UP SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

```
-----
```

70	<p><b>[SWITCH SETUP CHANGE]</b></p> <p>-----</p> <p>The Controller Configuration DIP setup switches cannot be changed without doing a cold start on the system. This is because it cannot be assumed that programmed data for one configuration will be valid for a different configuration. Press &lt;ENTER&gt; to advance the program to the next statement.</p>
80	<p><b>[COLD START?            N]</b></p> <p>-----</p> <p>Press &lt;Y&gt; (yes) to have all the program variables cleared and the new configuration used. The program will advance to the next statement.</p> <p>Press &lt;N&gt; (no) or &lt;ENTER&gt; to have the scale read again. The program will return to Statement #40.</p>
90	<p><b>[ARE YOU SURE?        N]</b></p> <p>-----</p> <p>Press &lt;Y&gt; (yes) to have all the program variables cleared and the new configuration used. The program will advance to the next statement. It should be noted that taking this action will require the re-entry of all programmed setup data.</p> <p>Press &lt;N&gt; (no) or &lt;ENTER&gt; to have the scale read again. The program will return to Statement #40.</p>
100	<p><b>[ALL DATA CLEARED!   ]</b></p> <p>-----</p> <p>All variables are cleared. The program will advance to the next statement.</p>

## POWER UP SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

110

[SUBSURFACE] or [SURFACE]

The display indicates that the system is configured for surface or for subsurface operation, as set by SW1-1. The program will advance to the next statement.

or

If cold start, press <ENTER> to advance to the next statement.

### ! CAUTION

**DO NOT** advance until this configuration has been verified as correct. Sub-surface and Surface type lances operate differently. A sub-surface lance will raise the lance as material is delivered into the drum requiring additional limit switches for safe operation.



## WARNING

INCORRECT SETTING OF THE CONTROLLER CONFIGURATION

'DIP' SWITCHES (SW1) MAY RESULT IN IMPROPER AND UNSAFE

OPERATION OF THE DRUMFILLER. THESE SWITCHES MUST

BE SET AND VERIFIED BY A QUALIFIED TOLEDO SCALE

TECHNICIAN AT THE TIME OF INSTALLATION IN ACCORDANCE

WITH DETAILS PROVIDED IN THE HARDWARE TECHNICAL

DESCRIPTION MANUAL. FAILURE TO OBSERVE THIS

PRECAUTION MAY RESULT IN BODILY INJURY.

## POWER UP SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

120

[SINGLE DRUM ] or [MULTIPLE DRUM ]

The display indicates that the system is configured for single or multiple drums, as set by SW1-2. The program will advance to the next statement.

or

If cold start, press <ENTER> to advance to the next statement.

### **! CAUTION**

**DO NOT** advance until this configuration has been verified as correct. Single Drum and Multiple Drum lances operate differently. A single drum lance does a maximum drum empty weight check for each new drum filled (refer to statement number 1100). A multiple drum lance allows more than one drum to be placed on the scale at a time and the lance can be "swiveled" from drum to drum. A maximum drum empty test cannot be done on a multiple drum filler.



## **WARNING**

INCORRECT SETTING OF THE CONTROLLER CONFIGURATION

'DIP' SWITCHES (SW1) MAY RESULT IN IMPROPER AND UNSAFE

OPERATION OF THE DRUMFILLER. THESE SWITCHES MUST

BE SET AND VERIFIED BY A QUALIFIED TOLEDO SCALE

TECHNICIAN AT THE TIME OF INSTALLATION IN ACCORDANCE

WITH DETAILS PROVIDED IN THE HARDWARE TECHNICAL

DESCRIPTION MANUAL. FAILURE TO OBSERVE THIS

PRECAUTION MAY RESULT IN BODILY INJURY.

## POWER UP SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

130

[NORMAL ] or [INVALID SETTING ]

-----  
The display indicates the setting of Controller Configuration DIP switch SW1-3.  
The program will halt and will not advance to the next statement if the display reads "Invalid Setting".  
The program will advance to the next statement if "Normal" is displayed.

or

If cold start, press <ENTER> to advance to the next statement.

This switch has been reserved for a future alternative function selection.



## WARNING

INCORRECT SETTING OF THE CONTROLLER CONFIGURATION  
'DIP' SWITCHES (SW1) MAY RESULT IN IMPROPER AND UNSAFE  
OPERATION OF THE DRUMFILLER. THESE SWITCHES MUST  
BE SET AND VERIFIED BY A QUALIFIED TOLEDO SCALE  
TECHNICIAN AT THE TIME OF INSTALLATION IN ACCORDANCE  
WITH DETAILS PROVIDED IN THE HARDWARE TECHNICAL  
DESCRIPTION MANUAL. FAILURE TO OBSERVE THIS  
PRECAUTION MAY RESULT IN BODILY INJURY.

## POWER UP SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

-----

135

[HOST DROP ADDRESS XX]

-----

The display indicates the Controller Configuration for DIP switches SW1-4 through SW1-6. These switches set the multi-drop address for Host operation. The setting of these switches is important to successful Host Communications.

If the Force Cold Start switch is ON the program will advance to statement #140.

If "warm start" the program will advance to statement #200.

or

If cold start, press <ENTER> to advance to the next statement.

### MULTI-DROP ADDRESSING

SW1-4	SW1-5	SW1-6	DROP ADDRESS
OFF	OFF	OFF	00
ON	OFF	OFF	01
OFF	ON	OFF	02
ON	ON	OFF	03
OFF	OFF	ON	04
ON	OFF	ON	05
OFF	ON	ON	06
ON	ON	ON	07

## POWER UP SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

-----

140

[COLD START FORCED ]

-----

The display indicates the Controller Configuration Forced Cold Start DIP switch (SW1-8) is ON. The program will not advance from this step. It is necessary to remove power from the controller, turn SW1-8 OFF then reapply power to restart.



**NORMAL OPERATING SEQUENCE**  
Statements 200 through 299

About This Section

The following section describes the Drumfiller Controller Normal Operating Sequence. The controller will display the selected product ID, as shown in statement number 200, whenever conditions are normal and the filling sequence is between drums.

At this prompt the operator may start another filling sequence for the displayed product ID by pressing the START pushbutton or he may use one of the function keys.

**PROGRAM  
STATEMENT**

**APPLICATION**

200

**[RUN ID:XXXXXXXXXXXX]**

-----  
The display shows the product ID which is to be used for this run. If CONTROL POWER is off, the program will advance to the next statement. If the AUTO / MANUAL switch is in the MANUAL position, the program will advance to statement #260. If the lance is not up the program will advance to statement #270.

Press START to begin filling the product ID indicated on the display. If the ID is valid the program will advance to Statement #2000, otherwise, the program will advance to Statement #290.

The function buttons are functional to allow ID Selection, ID and system setup, report printing, and system testing. Press the proper key for the desired function as described on the next page:

Press the "Print" button on the indicator keypad to initiate a "duplicate" printout of the last filling transaction.

## NORMAL OPERATING SEQUENCE (Continued)

### FUNCTION

### MODE

F1	*	ID SETUP - allows setup of parameters, such as the drum fill setpoint, for each stored drum ID record. Program will advance to Statement #1000.
F2	*	SYSTEM SETUP - allows setup of system general parameters, features, host, and printing. Program will advance to Statement #300.
F3		ID SELECT - allows operator selection of Run ID, Order Filling, and recall of the Run ID to be filled. Program will advance to Statement #1400.
F4	*	TEST MODE - permits self test and exercise of the controller and lance to verify correct operation. Program will advance to Statement #1200.
F5		ID SETUP REPORT - allows print out of the ID Setup Report. If the printer is enabled in Statement #710 the program will advance to Statement #3000.
F6		SUMMARY REPORT - allows print out of the filling Summary Report and Drum Logs. If the printer is enabled in Statement #710 the program will advance to Statement #3100.
F7		ID LIST REPORT - allow print out of the ID List Report. If the printer is enabled in Statement #710 the program will advance to Statement #3200. If the printer is disabled the program will advance to Statement #3210.
F8		CONSECUTIVE NUMBER - allows display or editing of the Product ID Consecutive Number. Program will advance to Statement #1500.
F9		VARIABLE ID - allows display or editing of the variable ID field. Program will advance to Statement #1600.
F10	*	ACCUMULATED WEIGHT - allows display or zeroing of the Accumulated Weight register. Program will advance to Statement #1700.
	*	Indicates that these functions may be password protected. Refer to Statement number 320 for password setup.

## NORMAL OPERATING SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

-----

210

[\*\*EMERGENCY STOP\*\* ]

-----

The display indicates that there is no control power present, due to the pressing of the EMERGENCY STOP button or the loss of the REMOTE EMERGENCY STOP input.

If not presently in the middle of a fill cycle, the program will return to Statement #200, upon the restoring of the of the EMERGENCY STOP inputs. The function buttons, as described in statement #200, will be active.

If a fill cycle is in process, the program will advance to the next statement, upon the restoring of the EMERGENCY STOP inputs. The function buttons will not be active.

### **! WARNING**

**DO NOT** restore power to the controller or restart the filling cycle until the system is in a known safe condition. Failure to observe this precaution may result in bodily injury.

220

[CONT FILL CYCLE? Y]

-----

A fill cycle has been interrupted. The display is asking the operator if he wishes to restart the fill sequence or abort the fill sequence.

Press START button to advance to the appropriate statement within the run sequence and restart.

Press <Y> (yes) or <ENTER> to advance to the next statement.

Press <N> (no) to advance to statement #240 to abort the sequence.

## NORMAL OPERATING SEQUENCE (Continued)

<u>PROGRAM</u> <u>STATEMENT</u>	<u>APPLICATION</u> -----
230	<p><b>[STOPPD - PUSH START]</b> -----</p> <p>The display indicates that a fill cycle has been interrupted. The operator may restart the fill sequence or return to the previous statement to abort the sequence.</p> <p>Press START button to restart the fill cycle and advance to the appropriate statement within the run sequence.</p> <p>Press &lt;RESET&gt; or &lt;UPARROW&gt; to return to statement #220.</p>
240	<p><b>[ABORT FILL CYCLE? N]</b> -----</p> <p>The display asks if the fill cycle is to be aborted.</p> <p>Press &lt;Y&gt; (yes) to advance to the next statement.</p> <p>Press &lt;N&gt; (no), &lt;ENTER&gt;, &lt;RESET&gt;, or &lt;UPARROW&gt; to return to statement #220.</p>
250	<p><b>[ARE YOU SURE?        N]</b> -----</p> <p>The display asks if you are sure that the fill cycle is to be aborted.</p> <p>Press &lt;Y&gt; (yes) to abort the fill sequence and return to statement #200.</p> <p>Press &lt;N&gt; (no), &lt;ENTER&gt;, &lt;RESET&gt;, or &lt;UPARROW&gt; to return to statement #220.</p>
255	<p><b>[CTPZ COMM FAULT!     ]</b> -----</p> <p>The display indicates that a communications error has occurred between the 9127 Controller and the CTPZ Board.</p> <p>The ALARM output is turned on. Press the SILENCE ALARM key &lt;F11&gt; to silence the alarm. Press START to return the program to Statement #200.</p> <p>&lt;RESET&gt; returns the program to Statement #220.</p>

## NORMAL OPERATING SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

260

[MANUAL MODE            ]

-----  
The display indicates that the AUTO / MANUAL switch is in the MANUAL position, and that the system is now under manual control. The controller will turn off all outputs.

The ALARM output will be turned on. The ALARM output may be turned off by pressing the SILENCE ALARM key <F11> on the keyboard.

If a container was in process:

The container's fill data will be added to the reject totals and a transaction printout will occur (if printer is enabled). When the AUTO / MANUAL switch is restored to the AUTO position, the program will return to statement #200.

If a container is not in process:

Press the "PRINT" button on the indicator keypad to initiate a printout.

When the AUTO / MANUAL switch is restored to the AUTO position, the program will return to statement #200.

270

[LANCE NOT UP           ]

-----  
The display indicates that the lance is not up. The ALARM output will be turned on. The ALARM output may be turned off by pressing the SILENCE ALARM key <F11> on the keyboard. Press START to cause the lance to be raised. The program will advance to the next statement.

280

[RAISING LANCE           ]

-----  
The lance is raised to the fully up position. If the lance cannot be raised to the fully up position within the Lance Raise Time (see statement #370) the program will advance to the next statement.

Once the lance has been raised the program will return to Statement #200.

## NORMAL OPERATING SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

285

[LANCE FAULT ]

-----  
The ALARM output is turned on. Press the SILENCE ALARM key <F11> to silence the alarm. Press START to return the program to Statement #280 to have the system try raising the lance again.

<RESET> returns the program to Statement #220.

290

[ID NOT FOUND ]

-----  
Indicates that an invalid Id was displayed when the operator pressed the START button.

<UP ARROW> returns the program to Statement #200.

<RESET> returns the program to Statement #200.

Press <ENTER> to return the program to Statement #200.

295

[\*\*ORDER COMPLETE\*\* ]

-----  
The display indicates that Order Filling is enabled, the present Run ID order has been filled and the START button has been pressed to start filling another drum.

The ALARM output is on at this time. Press the SILENCE ALARM key <F11> to silence the alarm.

<RESET> returns the program to Statement #240.

Press <START> to return the program to Statement #200.

## **SYSTEM SETUP SEQUENCE**

Statements 300 through 499 - General Setup

Statements 600 through 699 - Host Setup

Statements 700 through 899 - Printer Setup

Statements 900 through 999 - Setup Printing

### About This Section

The following section describes the Drumfiller Controller System Setup Sequence. It is normally only necessary to enter this mode when initially installing and configuring the system.

## GENERAL SETUP SEQUENCE

Statements 300 through 499

### About This Section

The following section describes the Drumfiller Controller General Setup Sequence. It allows setup of general system parameters such as the supervisor password and system time delays. The operation may be returned to the Statement #310 prompt from within the setup sequence by pressing the F2 System Setup function key.

### PROGRAM STATEMENT

### APPLICATION

300

[PASSWORD? ]

Enter the system password and press <ENTER>.

A password character must be entered with-in 5 (five) seconds or the program will return to Statement #200. The 5 second timer must be satisfied between each additional character to be entered.

If the password entered is correct, the program will advance to Statement #310.

If the password is incorrect the program will advance to the next statement.

Default - no password setup - this step skipped

305

[INVALID PASSWORD ]

This statement will be displayed for 2 seconds. The program will return to Statement #200.

310

[GENERAL SETUP? Y]

The display asks if the general setup parameters such as the supervisor password or system time delays are to be set.

Press <Y> (yes) or <ENTER> to advance to the next statement.

Press <N> (no) to advance to statement #600.

Press <UPARROW> to return to statement #200.

Press <RESET> to advance to statement #900.



## GENERAL SETUP SEQUENCE (Continued)

PROGRAM STATEMENT	APPLICATION -----
320	<p>[NEW PASSWORD?      N] -----</p> <p>&lt;UP ARROW&gt; returns the program to Statement #310.</p> <p>&lt;RESET&gt; returns the program to Statement #310.</p> <p>Press &lt;Y&gt; (yes) to enter a new system password. The program will advance to the next statement.</p> <p>Press &lt;N&gt; (no) or &lt;ENTER&gt; to leave the system password as is. The program will advance to Statement #330.</p> <p>Default - no password.</p>
325	<p>[PASSWORD?      XXXXXX] -----</p> <p>&lt;UP ARROW&gt; returns the program to Statement #320.</p> <p>&lt;RESET&gt; returns the program to Statement #310.</p> <p>&lt;CLEAR&gt; removes current password, press &lt;ENTER&gt; to advance to the next statement, or enter new password.</p> <p>Enter the new system password and press &lt;ENTER&gt;. The program will advance to the next statement.</p> <p>The Password must be 6 alpha / numeric characters, entering less than 6 characters will lock out the General Setup Sequence. To recover from this lock out, the system must be Cold Started, there-by removing all stored data and other setups.</p> <p>Default - 865336</p>

## GENERAL SETUP SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

330

[FILLER NO?        XX]  
-----

<UP ARROW> returns the program to Statement #320.

<RESET> returns the program to Statement #310.

Enter the Filler Number for this system and press  
<ENTER> to advance the program to the next statement.

The Filler Number may be printed out on drum tickets.

The Filler Number is not to be confused with the Host  
Drop Address number, which is a hardware setup only.

Default - 01

340

[DRUM HIT WT?        XX]  
-----

<UP ARROW> returns the program to Statement #330.

<RESET> returns the program to Statement #310.

Enter the Drum Hit Detection Weight and press <ENTER>  
to advance the program to the next statement.

When the lance is being lowered into the drum, the  
controller will use this target weight in determining  
if the lance has hit the drum. If the weight (not  
including the empty drum weight) exceeds this value  
as the lance is being lowered, the lance will reverse  
and raise to the fully up position and a Drum Hit  
Fault is displayed.

A starting value equivalent to 5 lbs is recommended.

If this proves to be too sensitive, increase this  
value gradually until the lance does not reverse  
under normal operation. Test the drum hit fault  
operation by applying a weight greater than the Drum  
Hit Weight to the scale as the lance is lowering to  
verify that it reverses direction and raises.

A value greater than 25 can not be entered. A value  
of 0 is not recommended.

Default - 5

## GENERAL SETUP SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

-----

341           [CONT A MAX WT?XXXXX]  
-----  
              <UP ARROW> returns the program to Statement #340.  
  
              <RESET> returns the program to Statement #310.  
  
              Enter the Maximum Weight for Container size "A" and  
              press <ENTER>. The program will advance to the next  
              statement.

342           [CONT B MAX WT?XXXXX]  
-----  
              <UP ARROW> returns the program to Statement #341.  
  
              <RESET> returns the program to Statement #310.  
  
              Enter the Maximum Weight for Container size "B" and  
              press <ENTER>. The program will advance to the next  
              statement.

343           [CONT C MAX WT?XXXXX]  
-----  
              <UP ARROW> returns the program to Statement #342.  
  
              <RESET> returns the program to Statement #310.  
  
              Enter the Maximum Weight for Container size "C" and  
              press <ENTER>. The program will advance to the next  
              statement.

344           [FLOW FLT CNTR?   XX]  
-----  
              The "Flow Fault Counter" is the number of consecutive  
              times a "Minimum Flow Fault" can occur before an  
              error is generated. This counter is incremented once  
              every second.  
  
              <UP ARROW> returns the program to Statement #343.  
  
              <RESET> returns the program to Statement #310.  
  
              Enter the FLOW FAULT COUNTER value and press <ENTER>.  
              The program will advance to the next statement.

## GENERAL SETUP SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

-----

345

[FLOW DELAY?        XX]

-----

<UP ARROW> returns the program to Statement #344.

<RESET> returns the program to Statement #310.

Enter the Material Flow Delay Time in seconds and press <ENTER> to advance the program to the next statement.

The controller will delay for the amount of time entered prior to performing a test on the material flow rate.

This time delay is needed to allow the material flow rate to stabilize to it's normal rate on start of filling.

Following this delay the controller will calculate the material flow rate and compare it to the Minimum Flow Rate for the selected Product ID.

A MINIMUM FLOW alarm is generated if the fill rate does not exceed this value which may be indicative of a system failure.

### **! CAUTION**

Set this value as low as possible. The flow rate calculation and minimum flow rate verification are an important indication of proper and safe equipment operation.

Default - 1 second.

## GENERAL SETUP SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

-----

350

[TOL. DELAY?        XX]

-----

<UP ARROW> returns the program to Statement #345.

<RESET> returns the program to Statement #310.

Enter the Tolerance Check Delay Time in seconds and press <ENTER> to advance the program to the next statement.

The controller will delay for the amount of time entered prior to performing a full drum tolerance check.

This time delay is needed to allow the scale to settle after filling of the container and prior to doing the tolerance check.

The default value is 01 second. A value of 0 is not recommended.

370

[RAISE TIME?        XX]

-----

<UP ARROW> returns the program to Statement #350.

<RESET> returns the program to Statement #310.

Enter the Lance Raise Time in seconds and press <ENTER> to advance the program to the next statement.

A lance fault alarm will be generated if the lance does not raise to the fully up position within the amount of time entered.

The default value is 10 seconds.

A value of 5 or less than 5 is not recommended. Lance Faults will occur, and delays in the filling operation, if set for a value of 5 or less.

## GENERAL SETUP SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

372

-----  
[SLOW TIME 1? X.XX]  
-----

<UP ARROW> returns the program to Statement #370.

<RESET> returns the program to Statement #310.

Enter the Time Value, in seconds, required to allow the two speed valve to go from full closed to it's slow fill position and press <ENTER> to advance to the next statement.

A starting value of 0.35 is suggested.

A smaller time value will cause the valve to be more closed for slow fill and a larger value more open. The setting of this value will be dependent upon input air pressure and the ball valve seat pressure.

Fine tuning of this value allows for control of the material slow fill rate for the first slow fill in a Slow-Fast-Slow fill mode. This value is used for dribble re-start, when the filling operation has been halted during the second slow fill of the Slow-Fast-Slow cycle.

Default - 0.35 seconds.

374

-----  
[SLOW TIME 2? X.XX]  
-----

<UP ARROW> returns the program to Statement #372.

<RESET> returns the program to Statement #310.

Enter the Time Value, in seconds, required to allow the two speed valve to go from full open (fast fill) to it's slow fill position and press <ENTER> to advance to the next statement.

A starting value of 0.35 is suggested.

A smaller time value will cause the valve to be more open for slow fill and a larger value more closed. The setting of this value will be dependent upon input air pressure and the ball valve seat pressure.

Fine tuning of this value allows for control of the material slow fill rate at dribble.

Default - 0.35 seconds.

## GENERAL SETUP SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

400

[ENABLE ID ENTRY? N]

-----  
The display asks if the variable ID entry feature is to be used. The answer is set to the last response.

The Variable ID can be entered by the operator and is stored with each Product ID setup.

Press <Y> (yes) to enable Variable ID entry and advance to the next statement.

Press <N> (no) to disable Variable ID entry and advance to statement #430.

Press <ENTER> to branch according to the displayed answer.

Press <UPARROW> to return to the previous statement.

Press <RESET> to advance to statement #900.

Default - disabled (N)

410

[ID PROMPT XXXXXXXX]

-----  
Enter the prompt (8 characters A/N maximum) to be used to request the Variable ID when selected from the <F9> Function Key in the normal operation mode.

Press <CLEAR> to clear the entry field.

Press <ENTER> to complete field entry and advance to the next statement.

Press <UPARROW> to return to the previous statement.

Press <RESET> to advance to statement #310.

## GENERAL SETUP SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

420

[ID LENGTH            XX]

-----  
Enter the number of characters to be entered for the variable ID. Maximum allowable number is 10.

Press <CLEAR> to clear the entry field.

Press <ENTER> to complete field entry and advance to the next statement.

Press <UPARROW> to return to the previous statement.

Press <RESET> to advance to statement #310.

430

[ENABLE CONSEC #?    X]

-----  
The display asks if the Global Consecutive Number and Product Consecutive Number features are to be used. The answer is set to the last response.

Press <Y> (yes) to enable the Global Consecutive Number and Product Consecutive Number features, then advance to the next statement.

Press <N> (no) to disable the Global Consecutive Number and Product Consecutive Number features, then advance to Statement #440.

Press <ENTER> to branch according to the displayed answer.

Press <UPARROW> to return to previous statement.

Press <RESET> to advance to statement #310.

Default - disabled

The 6 digit Product Consecutive Number is accessible by the operator, with the <F8> key, and may be printed with each drum, of the selected ID filled. The Product Consecutive Number may be accessed by the Host device.



## GENERAL SETUP SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

-----

435

[GLOBL CNSEC? XXXXXX]

-----

The display shows the next Global Consecutive Number to be assigned to the next drum filled.

The 6 digit Global Consecutive Number is not accessible by the operator, but may be printed with each drum filled. The Global Consecutive Number may be accessed by the Host device.

The Global Consecutive Number is incremented, by one, for each drum filled, except if the filling process is aborted or if an out of tolerance drum is rejected.

Press <CLEAR> to change the displayed number to all zeros.

Press <UPARROW> to return to previous statement.

Press <RESET> to advance to statement #310.

Enter the starting number desired and press <ENTER> to complete the field and advance to the next statement.

## GENERAL SETUP SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

-----

440

[ENABLE SUM?           X]

-----

The display asks if the Accumulated Sum register is to be used. The answer is set to the last response.

The 10 digit Accumulated Sum can be accessed, by the key <F10>, and cleared by the operator. The Accumulated Sum may be password protected, see Program Statement #445.

The Accumulated Sum is increased, by the drum net weight, with each drum filled except; if the filling process is aborted or if an out of tolerance drum is rejected.

The Accumulated Sum is a system variable and is not specific to a particular Product ID.

The Accumulated Sum may be used to accumulate production totals for a time period such as a shift, day or week.

Press <Y> (yes) to enable the Accumulated Sum and advance to the next statement.

Press <N> (no) to disable the Accumulated Sum and advance to the statement #450.

Press <ENTER> to branch according to the displayed answer.

Press <UPARROW> to return to the previous statement.

Press <RESET> to advance to statement #310.

Default - disabled

## GENERAL SETUP SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

-----

445

[PASSWORD PROTECT? X]

-----

The display asks if clearing of the Accumulated Sum register is to be password protected. The answer is set to the last response.

Press <Y> (yes) to enable password protection of clearing of the Accumulated Sum and advance to the next statement.

Press <N> (no) to disable password protection and advance to the next statement.

Press <ENTER> to branch according to the displayed answer.

Press <UPARROW> to return to the previous statement.

Press <RESET> to advance to statement #310.

Default - No Password Protection

## GENERAL SETUP SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

-----

447

[ENBL PROD ORDERS? X]

-----

The display asks if Order Filling is to be used. The answer is set to the last response.

Press <Y> (yes) to enable Order Filling and advance to the next statement.

Press <N> (no) to disable Order Filling and advance to the program to Statement #449.

Press <ENTER> to branch according to the displayed answer.

Press <UPARROW> to return to the previous statement.

Press <RESET> to advance to statement #310.

When Order Filling is enabled, the Select Product ID sequence will include Order number entry and number of drums on the order entry. The Drumfiller Controller will then keep track of the number of drums filled against the order and will prompt the operator when the order is complete.

Default - disabled.

## GENERAL SETUP SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

-----

448

[PRINT ORDER TOTS? X]

-----

The display asks if Order Totals are to be printed after order is completed. The answer is set to the last response.

Press <Y> (yes) to enable Order Totals printing and advance to the next statement.

Press <N> (no) to disable Order Totals printing and advance to the next statement.

Press <ENTER> to branch according to the displayed answer.

Press <UPARROW> to return to the previous statement.

Press <RESET> to advance to statement #310.

If no printer is selected in during printer setup, there will be no output to the printer port.

Default - enabled.

## GENERAL SETUP SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

-----

449

[ENABLE ID SELECT? X]

-----

The display asks if the keyboard will be used to select the Run ID. The answer is set to the last response.

This feature is intended to be used with a Host device. Disable ID Select to prevent operators from selecting or changing the Run ID with the keyboard.

Press <Y> (yes) to enable Run ID selection with the keyboard.

Press <N> (no) to disable Run ID selection with the keyboard.

Press <ENTER> to branch according to the displayed answer.

Press <UPARROW> to return to the previous statement.

Press <RESET> to advance to statement #310.

Default - enabled.

## GENERAL SETUP SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

-----

450

[ENABLE DRUM LOGS? X]

-----

The display asks if a Drum Log is to be stored. The answer is set to the last response.

This feature, when enabled, will store up to 480 drum transactions. Each transaction stores:

Product ID

Consecutive Number of Product ID

Gross Weight

Tare Weight

Net weight

Drum Status, okay, off tolerance, or rejected

Time

Date

Global Consecutive Number

When the Drum Log is full, additional transactions will be lost. The Drum Log must be cleared, periodically to prevent loss of data.

The Drum Log may be printed and cleared by the operator in the Summary Report mode, key <F6>.

The Drum Log may be up loaded to the Host device, and cleared by the Host device.

Press <Y> (yes) to enable the Drum Log storage and advance the program to the next statement.

Press <N> (no) to disable the Drum Log storage and advance the program to the next statement.

Press <ENTER> to accept the displayed answer and advance the program to the next statement.

Press <UPARROW> to return to the previous statement.

Press <RESET> to advance to statement #310.

Default - enabled.

## GENERAL SETUP SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

-----

454            [ENABLE CORRECTION?X]

-----

The display asks if Manual Tolerance Correction of drums will be allowed. The answer is set to the last response.

Press <Y> (yes) to enable Manual Tolerance Correction and advance the program to the next statement.

Press <N> (no) to disable Manual Tolerance Correction and advance the program to the next statement.

Press <ENTER> to accept the displayed answer and advance the program to the next statement.

Press <UPARROW> to return to the previous statement.

Press <RESET> to return to statement #310.

458            [DATE?            MM/DD/YY]

-----

Enter the date. The date field is numerical, use <SPACE> to separate the month (MM), day (DD), and year (YY).

Press <CLEAR> to clear the entry field.

Press <ENTER> to complete field entry and advance to the next statement.

Press <UPARROW> to return to the previous statement.

Press <RESET> to return to statement #310.



GENERAL SETUP SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

-----

460           [TIME?           HH:MM:SS]

-----

Enter the time in 24 hour format. The time field is numerical, use <SPACE> to separate the hours (HH), minutes (MM), and seconds (SS).

Press <CLEAR> to clear the entry field.

Press <ENTER> to complete field entry and advance the program to Statement #600.

Press <UPARROW> to return to the previous statement.

Press <RESET> to return to statement #310.

## HOST SETUP SEQUENCE

Statements 600 through 699

### About This Section

The following section describes the Drumfiller Controller Host Setup Sequence. This allows setup of the Host port.

<b>PROGRAM STATEMENT</b> -----	<b>APPLICATION</b> -----
<b>600</b>	<b>[HOST PORT SETUP? Y]</b> ----- The display asks if the Host port setup parameters are to be set.  Press <Y> (yes) or <ENTER> to advance to the next statement.  Press <N> (no) to advance to statement #700.  Press <UPARROW> to return to statement #310.  Press <RESET> to advance to statement #900.
<b>610</b>	<b>[SELECT HOST? X]</b> ----- The display asks whether a Host device will be used or not. Answer displayed is last response.  Press <Y> (yes) to advance to the next statement.  Press <N> (no) to advance to statement #700.  Press <ENTER> to branch according to the displayed answer.  Press <UPARROW> to return to the previous statement.  Press <RESET> to return to the previous statement.  Default - no host device being used.

## HOST SETUP SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

-----

-----

625

[HOST BAUD RATE XXXX]

-----

Enter the baud rate for the Host port. Allowable settings are 300, 1200, 2400, 4800, or 9600.

Press <CLEAR> to clear the entry field.

Press <ENTER> to complete field entry and advance to the next statement.

Press <UPARROW> to return the program to Statement #610.

Press <RESET> to return the program to statement #600.

Default - 4800

## HOST SETUP SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

630

[HOST DATA BITS     X]

-----  
Enter the number of data bits for the Host port.  
Allowable settings are 7 or 8.

Press <CLEAR> to clear the entry field.

Press <ENTER> to complete field entry and advance to  
the next statement.

Press <UPARROW> to return to the previous statement.

Press <RESET> to return the program to statement  
#600.

Default - 7 data bits

640

[HOST PARITY (EON) X]

-----  
Enter the parity setting for the Host port. Answer  
displayed is the last response.  
Allowable values are <E> for even parity, <O> for odd  
parity, or <N> for no parity.

Press <E> to set to even parity and advance the  
program to Statement #700.

Press <O> to set to odd parity and advance the  
program to Statement #700.

Press <N> to set to no parity and advance the program  
to Statement #700.

Press <ENTER> to accept the displayed setting and  
advance the program to Statement #700.

Press <UPARROW> to return to the previous statement.

Press <RESET> to return the program to statement  
#600.

Default - even parity enabled

## PRINTER SETUP SEQUENCE

Statements 700 through 899

### About This Section

The following section describes the Drumfiller Controller Printer Setup Sequence. This allows setup of the printer port as well as setup of the printer output formatting. The defaults are meant to work with the Toledo Model 8855 printer.

PROGRAM STATEMENT	APPLICATION
700	<div><div>[PRINTER SETUP?    Y]</div><div>The display asks if the printer setup parameters are to be set.</div><div>Press &lt;Y&gt; (yes) or &lt;ENTER&gt; to advance to the next statement.</div><div>If a printer has been selected to be used (see statement #710), pressing &lt;N&gt; (no) will advance the program to statement #900.</div><div>If a printer has not been selected to be used (see statement #710), pressing &lt;N&gt; (no) will return the program to Statement #200.</div><div>Press &lt;UPARROW&gt; to return to statement #600.</div><div>Press &lt;RESET&gt; to advance to statement #900.</div></div>
710	<div><div>[SELECT PRINTER?    X]</div><div>The display asks whether a printer is to be used or not. Displayed answer is the last response.</div><div>Press &lt;Y&gt; (yes) to enable printer and advance to the next statement.</div><div>Press &lt;N&gt; (no) to disable printer and advance to statement #900.</div><div>Press &lt;ENTER&gt; to branch according to the displayed answer.</div><div>Press &lt;UPARROW&gt; to return to the previous statement.</div><div>Press &lt;RESET&gt; to return to previous statement.</div><div>Default - printer disabled</div></div>

## PRINTER SETUP SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

722

[PNTR BAUD RATE XXXX]

-----  
Enter the baud rate for the printer port. Allowable  
settings are 300, 1200, 2400, 4800, or 9600.

Press <CLEAR> to clear the entry field.

Press <ENTER> to complete field entry and advance to  
the next statement.

Press <UPARROW> to return to the previous statement.

Press <RESET> to return program to Statement #700.

Default - 300 baud.

## PRINTER SETUP SEQUENCE (Continued)

PROGRAM STATEMENT -----	APPLICATION -----
730	<p>[PNTR DATA BITS     X]</p> <p>-----</p> <p>Enter the number of data bits for the printer port. Allowable settings are 7 or 8.</p> <p>Press &lt;CLEAR&gt; to clear the entry field.</p> <p>Press &lt;ENTER&gt; to complete field entry and advance to the next statement.</p> <p>Press &lt;UPARROW&gt; to return to the previous statement.</p> <p>Press &lt;RESET&gt; to return program to Statement #700.</p> <p>Default - 7 data bits</p>
740	<p>[PNTR PARITY (EON) X]</p> <p>-----</p> <p>Enter the parity setting for the printer port. Answer is set to last response. Allowable values are &lt;E&gt; for even parity, &lt;O&gt; for odd parity, or &lt;N&gt; for no parity.</p> <p>Press &lt;E&gt; for even parity, program advances to the next statement.</p> <p>Press &lt;O&gt; for odd parity, program advances to the next statement.</p> <p>Press &lt;N&gt; for no parity, program advances to the next statement.</p> <p>Press &lt;ENTER&gt; to accept displayed answer and advance to the next statement.</p> <p>Press &lt;UPARROW&gt; to return to the previous statement.</p> <p>Press &lt;RESET&gt; to return the program to Statement #700.</p> <p>Default - even parity enabled</p>

## PRINTER SETUP SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

770

[PNTR NET WT POS 018]

A 250 character string buffer is provided for the printer output string transmission. This allows for full customization of the printer output string.

Parameters within this string may be freely formatted. Each parameter to be included in the string is assigned a starting string position number.

The starting position may be from 1 to 250, however, to avoid truncation, the starting position plus the parameter string length must not exceed 250.

A starting position of 0 will cause the parameter not to be printed.

The following prompts allow entry of starting positions for each parameter.

The prompts will be skipped for the features not enabled in the general setup.

Starting positions greater than the listed maximum starting position will not be allowed.

The transmission string will be initialized to spaces prior to loading so un-occupied columns will be printed as spaces. The transmission string length will be determined by the greatest ending string position set.

Parameter field overlaps will not be checked.

A block check character may be sent by setting a block check character position other than 0. The block check is a single character that is computed as the XOR of all characters beginning at a specified starting character position and up to but not including the block check character itself. The block check begin prompt will not appear if the block check character position is 0.



**PRINTER SETUP SEQUENCE (Continued)**

770	[PNTR NET WT POS 018] (Continued)		
Prompt	Field Length	Max Pos Set	Description
[PNTR NET WT POS 020]*	6	245	Net Weight w/decimal pt.
[PNTR UNIT POS 027]*	2	249	Weight Units (LB/kg)
[PNTR OT FLG POS 019]*	1	250	Off Tolerance Flag ( +, -, or R ) **
[PNTR GRS WT POS 000]	6	245	Gross Weight w/decimal pt.
[PNTR TARE W POS 000]	6	245	Tare Weight w/decimal pt.
[PNTR SETPNT POS 000]	6	245	Setpoint Weight
[PNTR ID POS 006]*	12	239	Product ID
[PNTR ID PMT POS 000]	8	243	Variable ID Prompt
[PNTR VAR ID POS 000]	1-10	241-250	Variable ID
[PNTR CNBYID POS 000]	6	245	Product Id Consecutive number
[PNTR SUM POS 000]	10	241	Sum of weights w/dp.
[PNTR ORDER# POS 000]	1-10	214-250	Production order Number
[PNTR FILLER POS 000]	2	249	Filler Number
[PNTR DUPLCT POS 058]*	9	242	*** The word "DUPLICATE"
[PNTR DATE POS 044]*	8	243	Date (MM/DD/YY)
[PNTR TIME POS 037]*	5	246	Time (HH/MM)
[PNTR BATCH# POS 000]	5	246	Batch Number
[PNTR BC CHR POS 000]	1	250	Block check character
[PNTR BC BGN POS 000]	1	250	Begin block check

## PRINTER SETUP SEQUENCE (Continued)

770                    [PNTR NET WT POS 018] (Continued)

-----

- \*     The settings shown in the prompt column are the cold start default settings. The default settings generate the printout shown in Figure 1. Figure 2 shows the setup printout for this default print setup.
- \*\*    This single character field will be printed in the designated position of the string as a "+" for accepted over tolerance drums, "-" for accepted under tolerance drums, and "R" for rejected off tolerance drums.
- \*\*\*   This 9 character field will print "DUPLICATE" in the designated position of the string if the printout is a duplicate.

Press <CLEAR> to clear the entry field.

Press <ENTER> to complete field entry and advance to the next statement.

Press <UPARROW> to return to the previous statement.

Press <RESET> to return program to Statement #700.

## PRINTER SETUP SEQUENCE (Continued)

PROGRAM  
STATEMENT  
-----

APPLICATION  
-----

780

[NEW PNTR LITERAL? N]  
-----

The display asks if the printer literal constants are to be edited.

A literal constant is a character that will be loaded into the print string at a specific location each time the string is printed. In this manner it is possible to load strings of characters, by loading contiguous character positions, or control characters may be loaded for printer control, or to emulate the format required by an existing printer or data device.

Press <Y> (yes) to advance to the next statement.

Press <N> (no) or <ENTER> to advance to statement #900.

Press <UPARROW> to return to the last prompt of the previous statement.

Press <RESET> to advance to statement #700.

## PRINTER SETUP SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

790

[CLR PRNT LITRLS? N]

The display asks if the printer literal constants are to be cleared. Default literals will not be displayed. The literals must be cleared to change the defaults.

Press <Y> (yes) to advance to the next statement.

Press <N> (no) or <ENTER> to advance to statement #810.

Press <UPARROW> to return to the previous statement.

Press <RESET> to return program to Statement #700.

Default Literals -

The character `I' (49H) in position 1.  
The character `.' (2EH) in position 2.  
The character `D' (44H) in position 3.  
The character `.' (2EH) in position 4.  
The character `N' (4EH) in position 31.  
The character `E' (45H) in position 32.  
The character `T' (54H) in position 33.  
A carriage return (0DH) in position 35.  
A line feed (0AH) in position 36.  
A carriage return (0DH) in position 68.  
A line feed (0AH) in position 69.  
A line feed (0AH) in position 70.

800

[PNTR LITERALS CLR'D ]

The display indicates that all previously entered printer literals have been cleared. After 1.5 seconds the program will advance to the next statement.

## PRINTER SETUP SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

-----

-----

810

[PNTR LITRL POS XXX]

-----

Enter the string position for the desired literal. A position entry greater than 250 will not be accepted.

Press <CLEAR> to clear the entry field.

Press <ENTER> to complete the field entry and advance to the next statement.

Press <UPARROW> to return to statement #790.

Press <ENTER> with a position entry of zero to proceed to Statement #900.

Press <RESET> to proceed to Statement #900.

820

[PNTR LITERAL CHAR X]

-----

Enter the desired literal to be inserted into the printer transmission string. See Appendix A for control and special character entry.

Press <CLEAR> to clear the entry field.

Press <ENTER> to complete the field entry. The literal string position will automatically be incremented and the program will then return to Statement #810.

Press <UPARROW> to return to the previous statement.

Press <RESET> to return to Statement #900.

There is only one (1) limit on the number of Literals that may be entered; the Printer character string buffer is limited to 250 characters. Re-read program statement #770 to determine the maximum number of Literals that may be entered for your application.

---

Statements 900 through 999

The following section describes the operator interface which allows printout of the setup parameters. The printer setups must enable a printer to get to this section.

48

## SETUP PRODUCT ID'S SEQUENCE

Statements 1000 through 1199

### About This Section

The following section describes the operator interface which allows setup of the parameters associated with each of the 100 possible Product ID's. These parameters are ID specific such as fill setpoint, fill tolerance, and minimum material flow rate. The 9127 software will preform certain checks when ever the user exits critical entries of the Product Id setup. If an invalid entry is made to a critical entry and the user tries to exit the routine with the <RESET> key, the program will display [ID SETUP ERROR!] for 2 seconds and return to Statement #1010.

#### PROGRAM STATEMENT

#### APPLICATION

1000

[PASSWORD? ]

-----  
If no system password has been entered in General Setup, the program will advance to Statement #1010, without displaying this prompt.

Enter the system password and press <ENTER>. If the password entered is correct, the program will advance to Statement #1010. If the password is incorrect the program will advance to the next statement.

A password character must be entered with-in 5 (five) seconds or the program will return to Statement #200. The 5 second timer must be satisfied between each additional character to be entered.

1005

[INVALID PASSWORD ]

-----  
This statement will be displayed for 2 seconds. The program will return to Statement #200.

## SETUP PRODUCT ID'S SEQUENCE (Continued)

PROGRAM STATEMENT -----	APPLICATION -----
1010	<p>[PRD ID?XXXXXXXXXXXX] ----- &lt;UP ARROW&gt; returns the program to Statement #200.  &lt;RESET&gt; returns the program to Statement #200.  Press &lt;CLEAR&gt; to clear the entry field.  Enter the product ID to be added or modified and press &lt;ENTER&gt;.  If the ID already exists the program will advance to Statement #1030.  If the ID entered is a new ID and 100 ID's already exist in memory the program will advance to Statement #1020.  Otherwise the program will advance to Statement #1059A.</p>
1020	<p>[ID TABLE FULL       ] ----- &lt;RESET&gt; returns the program to Statement #200.  Press &lt;ENTER&gt; to return the program to Statement #1010.  The program will only store 100 Product Id's.</p>



## SETUP PRODUCT ID'S SEQUENCE (Continued)

PROGRAM STATEMENT -----	APPLICATION -----
1030	<p><b>[(C)OPY (D)EL (E)DIT]</b> -----</p> <p>&lt;UP ARROW&gt; returns the program to Statement #1010.</p> <p>&lt;RESET&gt; returns the program to Statement #200.</p> <p>Press &lt;C&gt; to copy the information from the selected ID to a new Product ID. The program will then proceed to Statement #1031.</p> <p>Press &lt;D&gt; to delete the selected ID. If Order Filling is enabled, this is the Run ID, and the order has not been filled the program will advance to Statement #1032.</p> <p>If Order Filling is disabled and this ID has accumulated production totals, the program will advance to Statement #1040.</p> <p>The program will advance to Statement #1050 if there are no accumulated totals for this ID.</p> <p>Press &lt;E&gt; to edit the selected ID. If Order Filling is enabled and this is the Run ID, the program will advance to Statement #1056.</p> <p>If Order Filling is disabled the program will advance to Statement #1059A.</p>
1031	<p><b>[NEW ID?XXXXXXXXXXXX]</b> -----</p> <p>&lt;UP ARROW&gt; returns the program to Statement #200.</p> <p>&lt;RESET&gt; returns the program to Statement #200.</p> <p>Enter the new Product ID and press &lt;ENTER&gt;.</p> <p>If the ID entered already exists the program will display "ID ALREADY EXISTS!" for 2 seconds and then return to Statement #1031.</p> <p>If the ID entered is a new ID the program will then proceed to Statement #1059A.</p>

## SETUP PRODUCT ID'S SEQUENCE (Continued)

PROGRAM STATEMENT -----	APPLICATION -----
1032	<p><b>[ORDER NOT COMPLETE!]</b> -----</p> <p>The display indicates that the current Run ID, with order filling, has not been completed.</p> <p>&lt;UP ARROW&gt; returns the program to Statement #1030.</p> <p>&lt;RESET&gt; returns the program to Statement #200.</p> <p>&lt;ENTER&gt; returns the program to Statement #200.</p> <p>To delete this ID, the operator must return to the ID Select mode. Then change the order quantity to the number of drums filled, this way the order will be complete.</p>
1040	<p><b>[TOTALS EXIST           ]</b> -----</p> <p>&lt;UP ARROW&gt; returns the program to Statement #1030.</p> <p>&lt;RESET&gt; returns the program to Statement #200.</p> <p>Press &lt;ENTER&gt; to advance to the next Statement.</p> <p>NOTE: If this ID is deleted, the production totals will also be deleted.</p>
1050	<p><b>[ARE YOU SURE?       N]</b> -----</p> <p>&lt;UP ARROW&gt; returns the program to Statement #1030.</p> <p>&lt;RESET&gt; returns the program to Statement #200.</p> <p>Press &lt;Y&gt; (yes) to have this ID deleted from memory. The program will advance to the next statement.</p> <p>Press &lt;N&gt; (no) or &lt;ENTER&gt; to leave this ID in memory. The program will advance to Statement #1056.</p>
1055	<p><b>[ID DELETED           ]</b> -----</p> <p>This prompt is displayed for 2 seconds and the program will then return to Statement #1010.</p>

## SETUP PRODUCT ID'S SEQUENCE (Continued)

PROGRAM STATEMENT	APPLICATION
1056	<p>-----</p> <p>[CONTAINER:           X]</p> <p>-----</p> <p>&lt;UP ARROW&gt; returns the program to Statement #1010.</p> <p>&lt;RESET&gt; returns the program to Statement #200.</p>
1059	<p>Press &lt;ENTER&gt; to advance to the next Statement.</p> <p>[SETPOINT           XXXXXX]</p> <p>-----</p> <p>The display shows the setpoint value for the current Run ID, Order Filling is enabled, and the ID has been used to start an order. The Setpoint value can not be changed, only the other values associated with this ID can be changed. If the scale is calibrated with a decimal point position (Exmpl: XXXX.X), one of the six displayed characters will be the decimal point.</p> <p>&lt;RESET&gt; returns the program to Statement #1010.</p> <p>&lt;UP ARROW&gt; returns the program to Statement #1010.</p> <p>Press &lt;ENTER&gt; to advance the program to Statement #1070.</p>
1059A	<p>[CONTAINER?           X]</p> <p>-----</p> <p>&lt;UP ARROW&gt; returns the program to Statement #1010.</p> <p>&lt;RESET&gt; returns the program to Statement #200.</p> <p>Enter the Container Size (A, B or C) and press &lt;ENTER&gt;. The program will advance to the next Statement.</p>
1060	<p>[CALC SETPOINT?       N]</p> <p>-----</p> <p>The display asks if the Setpoint is to be calculated using density times the volume filled.</p> <p>Press &lt;ENTER&gt; or &lt;N&gt; to advance the program to statement #1068.</p> <p>Press &lt;Y&gt; (yes) to advance the program to the next statement.</p> <p>&lt;UP ARROW&gt; returns the program to Statement #1010.</p> <p>&lt;RESET&gt; returns the program to Statement #1010.</p>

## SETUP PRODUCT ID'S SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

1061

[DENSITY        X.XXXX]

-----  
Enter the material density, units are grams per milliliter. The specific gravity of the material may also be used.

<UP ARROW> returns the program to the previous Statement.

<RESET> returns the program to Statement #1010.

Press <CLEAR> to clear the field entry.

If the scale has been calibrated in the pounds mode, pressing <ENTER> will advance the program to the next statement.

If the scale has been calibrated in the kilograms mode, pressing <ENTER> will advance the program to Statement #1063.

1062

[GALLONS        XXX.X]

-----  
Enter the number of gallons (U.S.) to be filled into the container.

<UP ARROW> returns the program to the previous Statement.

<RESET> returns the program to Statement #1010.

Press <CLEAR> to clear the field entry.

Press <ENTER> to complete the entry and advance the program to Statement #1068.

The Setpoint will be calculated by the following formula:

$$(\text{Density} \times \text{Volume}) \times 8.328 = \text{Setpoint}$$

The figure, 8.328, is equal to the weight of one gallon of pure water at 60 degrees F..

## SETUP PRODUCT ID'S SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

1063

[LITERS            XXX.X]

Enter the number of liters to be filled into the container.

<UP ARROW> returns the program to the previous Statement.

<RESET> returns the program to Statement #1010.  
Press <CLEAR> to clear the field entry.

Press <ENTER> to complete the entry and advance the program to Statement #1068.

The Setpoint will be calculated by the following formula:

Density X Volume = Setpoint

## SETUP PRODUCT ID'S SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

1068

[SETPOINT?      XXXXXX]

-----  
If Calc Setpoint was used, the display will show the calculated value. The user may change the displayed value or pressing <ENTER> will advance the program to Statement #1070.

If Calc Setpoint was not used, enter the Setpoint weight (target weight) for this product ID. Pressing <ENTER> will advance the program to Statement #1070.

**Note: If the Setpoint entered exceeds the Maximum Weight for the Container selected (A,B or C) the program will proceed to the next statement.**

<UP ARROW> returns the program to Statement #1060.  
<RESET> returns the program to Statement #1010.  
Press <CLEAR> to clear the field entry.

### **! WARNING**

The setpoint weight is determined by the desired net weight of product in the container, however, care must be taken that the entered value does not exceed the capacity of the container. Failure to observe this precaution could result in overfilling the container and spillage of the material. Failure to observe this precaution may result in bodily injury.

If the scale is calibrated with a decimal point position (Exmpl: XXXX.X), one of the six displayed characters will be the decimal point.

1069

[OVER MAX WEIGHT!      ]

-----  
This prompt is displayed for 2 seconds and the program will then return to Statement #1068.

## SETUP PRODUCT ID'S SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

1070

[DRIBBLE?        XXXXX]

-----  
<UP ARROW> returns the program to the statement that preceded.

<RESET> returns the program to Statement #1010.

Press <CLEAR> to clear the field entry.

Enter the Dribble value and press <ENTER> to advance the program to the next statement.

The Dribble value is used to switch from fast fill to slow fill.

The fast fill output stays on until the scale reaches a value of SETPOINT minus PREACT minus DRIBBLE, at which time the fast fill is turned off. The dribble value should be optimized to give repeatable cutoff and minimum total fill cycle time.

If the scale is calibrated with a decimal point position (Exmpl: XXXX.X), one of the five displayed characters will be the decimal point.

## SETUP PRODUCT ID'S SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

1080

[PREACT?        XXXXX]

<UP ARROW> returns the program to Statement #1070.

<RESET> returns the program to Statement #1010.

Press <CLEAR> to clear the field entry.

Enter the Preact value and press <ENTER> to advance the program to the next statement.

The preact is the allocation for material flow after fill valves have been closed.

Fill valves close at SETPOINT minus PREACT.

The PREACT value plus the DRIBBLE value must be less than the SETPOINT value.

NOTE: The accuracy of weighment is further refined by automatic adjustment of the preact value based on previous weighments if the Auto Preact Adjust feature has been selected IN (refer to statement number 1085). The dribble point is relative to the preact point to allow repeatable cutoff.

Example of SETPOINT, DRIBBLE, and PREACT relationship.

If Setpoint = 100.0, Dribble = 20.0, and Preact = 2.0 the control would switch from fast to slow fill at 78.0 and final cutoff would be at 98.0.

If the scale is calibrated with a decimal point position (Exmpl: XXXX.X), one of the five displayed characters will be the decimal point.



## SETUP PRODUCT ID'S SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

1085

[AUTO PREACT FAC? XX]

-----  
Enter Auto Preact Adjust factor in percent of error correction. Error equals Setpoint, plus or minus Actual weight delivered. The result, times the entered adjustment factor, will be added to or subtracted from the current Preact value.

<UP ARROW> returns the program to Statement #1080.

<RESET> returns the program to Statement #1010.

Press <CLEAR> to clear the field entry.

Enter the Auto Preact Adjust Factor value and press <ENTER> to advance the program to the next statement.

An entry of 00 will disable the Auto Preact Adjust.

Example of Auto Preact Adjust Factor:

If Setpoint = 100.0 , Preact = 2.00 and Auto Preact Factor = 30.

If actual weight delivered = 98.0 , therefore Error = 2.0. Auto Preact Adjust will change the Preact value by subtracting 30% of 2.0 from the current Preact value. In this example the correction factor result will be 0.6 and the Preact value will be changed from 2.0 to 1.4 .

**NOTE:** The Auto Preact Adjust Factor may calculate a negative preact value to compensate for a system setup error condition. This negative preact value is limited to a maximum of 1 percent of the Setpoint. If the preact value is ever a negative value, the Drumfilling System should be modified to correct for this error condition. This condition would occur if the Drum weight reached the Setpoint but the final weight after the tolerance check is less than the setpoint.

## SETUP PRODUCT ID'S SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

1090

[MIN EMPTY WT? XXXXX]

<UP ARROW> returns the program to Statement #1085.

<RESET> returns the program to Statement #1010.

Press <CLEAR> to clear the field entry.

Enter the Minimum Weight of an empty drum and press  
<ENTER>. A value of 1 or less will not be accepted.

If the Controller is configured for single drum  
filling the program will advance to the next  
statement (refer to statement number 120).

If the Controller is configured for multiple drum  
filling the program will advance to Statement #1110  
(refer to statement number 120).

### **! CAUTION**

This value is used as a check prior to starting  
to fill a drum. It is important to enter a value  
that is just under the actual empty drum weight  
to inhibit filling without a drum on the scale.  
An alarm is generated if the scale weight is less  
than this value at zero tolerance check. Refer to  
statement #2020.

If the scale is calibrated with a decimal point  
position (Exmpl: XXXX.X), one of the five displayed  
characters will be the decimal point.

## SETUP PRODUCT ID'S SEQUENCE (Continued)

PROGRAM  
STATEMENT  
-----

APPLICATION  
-----

1100

**[MAX EMPTY WT? XXXXX] (Single drums only)**  
-----

<UP ARROW> returns the program to Statement #1090.

<RESET> returns the program to Statement #1010.

Press <CLEAR> to clear the field entry.

Enter the Maximum Weight of an empty drum and press <ENTER> to advance the program to the next statement. A value less than the Minimum Drum Weight will not be accepted.

### **! CAUTION**

This value is used as a check prior to starting to fill a drum. It is important to enter a value that is just above the actual empty drum weight to inhibit filling a drum that is partially filled. An alarm is generated if the scale weight is greater than this value at zero tolerance check. Refer to statement #2020.

If the scale is calibrated with a decimal point position (Exmpl: XXXX.X), one of the four displayed characters will be the decimal point.

1110

**[FULL TOLRANCE? XXXX]**  
-----

<UP ARROW> returns the program to Statement # 1090 or #1100 dependent upon the controller configuration as single or multiple drum.

<RESET> returns the program to Statement #1010.

Press <CLEAR> to clear the field entry.

Enter the Full Tolerance value, in weight units, and press <ENTER> to advance the program to the next statement. A value of 0 will disable Tolerance checking.

The Full Tolerance value is the amount of weight less than or greater than SETPOINT that is allowable on a filled drum before an OFF TOLERANCE alarm is generated.

If the scale is calibrated with a decimal point position (Exmpl: XXXX.X), one of the four displayed characters will be the decimal point.

## SETUP PRODUCT ID'S SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

1120

[CYCLE TIME?      XXX]

<UP ARROW> returns the program to Statement #1110.

<RESET> returns the program to Statement #1010.

Press <CLEAR> to clear the field entry.

Enter the Cycle Time in seconds and press <ENTER>.

**NOTE: A value of Zero will disable this feature.**

If the Controller is configured for Sub-Surface filling the program will advance to Statement #1130.

If the Controller is configured Surface filling the program will advance to Statement #1140.

### **! CAUTION**

This value is used to determine that the total drum filling cycle time is shorter than a maximum expected cycle time. It is important to enter a value that is just longer than the theoretical maximum time calculated from the container volume and the material flow rate. A CYCLE SLOW alarm is generated if the fill cycle exceeds this value which may be indicative of a system failure.

## SETUP PRODUCT ID'S SEQUENCE (Continued)

PROGRAM STATEMENT -----	APPLICATION -----
1130	<p>[SLOW/FAST/SLOW?    Y] -----</p> <p>&lt;UP ARROW&gt; returns the program to Statement #1120.</p> <p>&lt;RESET&gt; returns the program to Statement #1010.</p> <p>Press &lt;Y&gt; (yes) or &lt;ENTER&gt; if the fill cycle should be SLOW-FAST-SLOW. The program will advance to Statement #1150.</p> <p>Press &lt;N&gt; (no) if the fill cycle should be FAST-SLOW. The program will advance to the next statement.</p> <p>A SLOW-FAST-SLOW cycle is often used with sub-surface drumfillers to delay fast fill to minimize foaming until the material covers the lance.</p>
1140	<p>[FAST/SLOW?            Y] -----</p> <p>&lt;UP ARROW&gt; returns the program to Statement #1120.</p> <p>&lt;RESET&gt; returns the program to Statement #1010.</p> <p>Press &lt;Y&gt; (yes) or &lt;ENTER&gt; if the fill cycle should be FAST-SLOW. The program will advance statement #1160.</p> <p>Press &lt;N&gt; (no) if the fill cycle should be SLOW-FAST-SLOW. The program will return to Statement #1130.</p>

## SETUP PRODUCT ID'S SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

-----

-----

1150

[SLW FILL WT? XXXXXX]

-----

<UP ARROW> returns the program to Statement #1130.

<RESET> returns the program to Statement #1010.

Press <CLEAR> to clear the field entry.

Enter the Slow Fill Weight and press <ENTER> to advance the program to the next statement.

The Drumfiller controller will switch from Slow Fill to Fast Fill when the scale reaches the Slow Fill Weight.

A value greater than setpoint is not allowed.

If the scale is calibrated with a decimal point position (Exmpl: XXXX.X), one of the six displayed characters will be the decimal point.

## SETUP PRODUCT ID'S SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

1160

[MIN FLW RATE? XXXXX]

The "Minimum Flow Rate" is entered in scale units per minute. The software in the 9127 Controller divides this value by 60 and the Flow Rate is then checked every second.

<UP ARROW> returns the program to Statement #1150 if fill is slow - fast - slow, if fill is fast - slow program will return to Statement #1140.

<RESET> returns the program to Statement #1010.

Press <CLEAR> to clear the field entry.

Enter the Minimum Flow Rate in scale units per minute and press <ENTER>.

If the Controller configuration is set for surface fill, and single drum the program will return to Statement #1010 (refer to statement #110).

If the Controller configuration is set for surface fill, and multiple drum the program will advance to Statement #1170 (refer to statements #110 and #120).

If the Controller configuration is set for sub-surface fill the program will advance to the next statement (refer to statement #110).

### **! CAUTION**

This value is used to check that the rate of change of weight is greater than the anticipated minimum flow rate of the material. It is important to enter a value that is approximately 10% less than the normal minimum material slow fill flow rate. The controller will check the weight at 1 second intervals. A MINIMUM FLOW alarm is generated if the fill rate does not exceed this value which may be indicative of a system failure.



## SETUP PRODUCT ID'S SEQUENCE (Continued)

PROGRAM STATEMENT -----	APPLICATION -----
-------------------------------	----------------------

1160	(Continued)
------	-------------

### NOTES:

1. To disable positive "Minimum Flow Rate" checking, enter a value of "0". The 9127 will still check for negative flow rate which may occur when a container is leaking.
2. To disable positive and negative "Minimum Flow Rate" checking, enter a value of "-1". This will totally disable the "Minimum Flow Rate" feature.

CAUTION!: If the "Minimum Flow Rate" feature is totally disabled, the 9127 controller will not be able to detect container leakage.

Example of calculation of Minimum Flow Rate value:  
The product being filled is water and the normal slow fill flow rate of the water is demonstrated to be 20 gallons per minute. Multiply 20 GPM x 8.34 lbs (weight per gallon of water) to calculate the flow rate to be 166.8 lbs per minute.  $166.8 \times .9 = 150.12$  pounds per minute should be used for the minimum flow rate. Any rate less than that will cause feed valves to close and an alarm to appear.

If the scale is calibrated with a decimal point position (Exmpl: XXXX.X), one of the six displayed characters will be the decimal point.

## SETUP PRODUCT ID'S SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

1165 [RAISE DUTY CYCL? XX] (Sub-Surface only)

-----  
During fast fill, the lance will rise, this variable will help control how fast the lance will rise.

The entered value is the percentage of ON time during one (1) second. A value entered of 60 means, the raise output will be on for .6 seconds and off for .4 seconds. The longer the raise lance output is on, the faster the rise rate. The larger the entered value the faster the lance will rise.

<UP ARROW> returns the program to Statement #1160.

<RESET> returns the program to Statement #1010.

Press <CLEAR> to clear the field entry.

Enter the ON time duty cycle percentage for the raise output and press <ENTER>. A value of 0 will disable raising the lance during a slow-fast-slow fill cycle.

If the Controller configuration is set for multiple drum the program will advance to the next statement (refer to statement #120).

If the Controller configuration is set for single drum the program will return to Statement #1010 (refer to statement #120).

Default value is 50.

1170 [MAX NO. OF DRUMS?XX]

-----  
Enter the Maximum number of drums per pallet and press <ENTER> to return the program to Statement #1010.

A number greater than this value will not be allowed to be entered during Select Product ID.

<UP ARROW> returns the program to Statement #1165.

<RESET> returns the program to Statement #1010.

A number greater than 25 will not be accepted. The default value is 1.

## SETUP PRODUCT ID'S SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

-----

-----

1180        [ID SETUP ERROR!        ]

-----

Display indicates an error was found with an entry and the <RESET> key was used to exit the Product Id setup routine. This display will last for 2 seconds, then the program will return to Statement #1010.

Errors are:

Dribble greater than Setpoint.

Minimum Empty Drum Weight is equal or less than 1.

Maximum Empty Drum Weight is less than Minimum Empty Drum Weight.

Slow Cycle Time is less than 20.

Slow Fill Weight is greater than Setpoint.

Maximum Drums is equal or less than 0.

## TEST MODE SEQUENCE

Statements 1200 through 1399

### About This Section

The following section describes the operator interface which allows initiation of system self test and for exercising the equipment in test mode.

PROGRAM STATEMENT -----	APPLICATION -----
1200	<p>[TEST MODE                    ]</p> <p>-----</p> <p>&lt;UP ARROW&gt; returns the program to Statement #200.</p> <p>&lt;RESET&gt; returns the program to Statement #200.</p> <p>Press &lt;ENTER&gt; to advance the program.</p> <p>If a system password is enabled the program will advance to the next statement.</p> <p>If there is no system password the program will advance to Statement #1230.</p>
1210	<p>[PASSWORD?                    ]</p> <p>-----</p> <p>&lt;UP ARROW&gt; returns the program to Statement #1200.</p> <p>&lt;Reset&gt; returns the program to Statement #200.</p> <p>A password character must be entered with-in 5 (five) seconds or the program will return to Statement #200. The 5 second timer must be satisfied between each additional character to be entered.</p> <p>Enter the system password and press &lt;ENTER&gt;. If the password entered is correct, the program will advance to Statement #1230. If the password is incorrect the program will advance to the next statement.</p>

## TEST MODE SEQUENCE (Continued)

PROGRAM STATEMENT -----	APPLICATION -----
1220	<p>[INVALID PASSWORD ]</p> <p>-----</p> <p>This statement will be displayed for 2 seconds. The program will return to Statement #1210.</p>
1230	<p>[ROM TEST? Y]</p> <p>-----</p> <p>&lt;UP ARROW&gt; returns the program to Statement #1200.</p> <p>&lt;Reset&gt; returns the program to Statement #200.</p> <p>Press &lt;Y&gt; (yes) or &lt;ENTER&gt; to have the controller perform the ROM checksum test. The program will advance to the next statement.</p> <p>Press &lt;NO&gt; to skip this test. The program will advance to Statement #1250.</p>
1235	<p>[TESTING ]</p> <p>-----</p> <p>A ROM checksum is calculated and compared to a known value. If the calculation is correct the program will advance to Statement #1245. If the calculation is not correct the program will advance to the next Statement.</p>
1240	<p>[TEST FAILED XX]</p> <p>-----</p> <p>The display shows the expected value of the checksum 'XX'. Display of this message indicates a system hardware failure. Operation will halt at this statement and the controller cannot be operated. Contact Toledo Scale Service.</p>

## TEST MODE SEQUENCE (Continued)

PROGRAM STATEMENT -----	APPLICATION -----
1245	<p>[TEST PASSED           ]</p> <p>-----</p> <p>&lt;UP ARROW&gt; returns the program to Statement #1230.</p> <p>&lt;Reset&gt; returns the program to Statement #200.</p> <p>Press &lt;ENTER&gt; to advance the program to the next statement.</p>
1250	<p>[RAM TEST?           Y]</p> <p>-----</p> <p>&lt;UP ARROW&gt; returns the program to Statement #1230.</p> <p>&lt;Reset&gt; returns the program to Statement #200.</p> <p>Press &lt;Y&gt; (yes) or &lt;ENTER&gt; to have the controller perform the RAM test. The program will advance to the next statement.</p> <p>Press &lt;N&gt; (no) to skip this test. The program will advance to Statement #1270.</p>
1255	<p>[TESTING            ]</p> <p>-----</p> <p>A RAM test is preformed, where every byte of RAM is checked. If the RAM is good the program will advance to Statement #1265. If a bad RAM location is found the program will advance to the next statement.</p>
1260	<p>[TEST FAILED         ]</p> <p>-----</p> <p>Display of this message indicates a system hardware failure. Operation will halt at this statement and the controller cannot be operated. Contact Toledo Scale Service.</p>

## TEST MODE SEQUENCE (Continued)

PROGRAM STATEMENT -----	APPLICATION -----
1265	<p>[TEST PASSED           ]</p> <p>-----</p> <p>&lt;UP ARROW&gt; returns the program to Statement #1250.</p> <p>&lt;Reset&gt; returns the program to Statement #200.</p> <p>Press &lt;ENTER&gt; to advance the program to the next statement.</p>
1270	<p>[SCALE TEST?           Y]</p> <p>-----</p> <p>&lt;UP ARROW&gt; returns the program to Statement #1250.</p> <p>&lt;Reset&gt; returns the program to Statement #200.</p> <p>Press &lt;Y&gt; (yes) or &lt;ENTER&gt; to have the scale test performed. If a scale fault occurs the program will advance to the next statement. If the scale is read properly the program will advance to statement #1280.</p> <p>Press &lt;N&gt; (no) or &lt;ENTER&gt; to skip this test. The program will advance to Statement #1290.</p>
1275	<p>[SCALE FAULT           ]</p> <p>-----</p> <p>No data, invalid data, or checksum error was received from the indicator. If after several attempts the scale cannot be read, contact Toledo Scale Service.</p> <p>&lt;UP ARROW&gt; returns the program to Statement #1270.</p> <p>&lt;Reset&gt; returns the program to Statement #200.</p> <p>Press &lt;ENTER&gt; to advance the program to Statement #1286.</p>

## TEST MODE SEQUENCE (Continued)

PROGRAM STATEMENT -----	APPLICATION -----
1280	<p>[SCALE WT.        XXXXXX] -----</p> <p>&lt;UP ARROW&gt; returns the program to Statement #1270.</p> <p>&lt;Reset&gt; returns the program to Statement #200.</p> <p>The display will show the scale weight. It is updated if the weight changes.</p> <p>Press &lt;ENTER&gt; to advance the program to the Statement #1286. If the scale goes over capacity, the program will advance to the next statement.</p>
1285	<p>[SCALE OVER CAP        ] -----</p> <p>&lt;UP ARROW&gt; returns the program to Statement #1270.</p> <p>&lt;Reset&gt; returns the program to Statement #200.</p> <p>Press &lt;ENTER&gt; to advance the program to the next statement.</p>
1286	<p>[PRINTER TEST?        Y] -----</p> <p>&lt;UP ARROW&gt; returns the program to Statement #1270.</p> <p>&lt;Reset&gt; returns the program to Statement #200.</p> <p>Press &lt;Y&gt; (yes) or &lt;ENTER&gt; to have the controller perform the printer test. The program will advance to the next statement.</p> <p>Press &lt;N&gt; (no) to skip this test. The program will advance to Statement #1290.</p>



## TEST MODE SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

-----

-----

1287

[PRINTING                   ]

-----

This message will be displayed for a short period of time while the controller outputs the print string programmed in setup statements #770 through #830. The system will then advance to the next statement.

1290

[TEST INPUTS?           Y]

-----

<UP ARROW> returns the program to Statement #1286 if the printer is enabled or to #1270.

<Reset> returns the program to Statement #200.

Press <Y> (yes) or <ENTER> to test the inputs. The program will advance to the next statement.

Press <N> (no) to skip this test. The program will advance to Statement #1310.

## TEST MODE SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

1295

[INPUT NUMBER?    XX]

<UP ARROW> returns the program to Statement #1290.

<Reset> returns the program to Statement #200.

Enter the corresponding input number, as listed below, for the input to be tested and press <ENTER>. The program will advance to the next statement.

To exit this test press <CLEAR> then <ENTER>. The program will advance to Statement #1310.

Input test number assignments.

### NUMBER

### INPUT

01	CONTROL POWER ON
02	AUTO/MANUAL
03	START
04	STOP
05	LANCE UP
06	LANCE DOWN
07	LANCE IN DRUM (Subsurface Only)
08	LANCE OUT OF DRUM (Subsurface Only)

Note that the control power must be turned on for the controller to read these inputs.

## TEST MODE SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

-----  
1300

-----  
[INPUT XX            ON]  
-----

or

[INPUT XX            OFF]  
-----

<UP ARROW> returns the program to Statement #1290.

<Reset> returns the program to Statement #200.

The display will show which state the input entered  
'XX' is in (ON or OFF).

Press <ENTER> to return the program to Statement  
#1295.

## TEST MODE SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

1310

[TEST OUTPUTS?      Y]

<UP ARROW> returns the program to Statement #1290.

<Reset> returns the program to Statement #200.

Press <Y> (yes) or <ENTER> to test the outputs. ALL  
OUTPUTS WILL BE TURNED OFF and the program will  
advance to the next statement.

Press <N> (no) to skip this test. The program will  
proceed to Statement #1330.



## DANGER

EXECUTION OF THE OUTPUT TEST WILL CAUSE THE STATE  
OF OUTPUTS TO CHANGE, WHICH IN TURN WILL CAUSE  
MACHINE OPERATION. IT IS EXTREMELY IMPORTANT TO  
FULLY UNDERSTAND THE CONSEQUENCE OF TURNING 'ON'  
OR 'OFF' A PARTICULAR OUTPUT. YOU MUST TAKE PROPER  
SAFETY PRECAUTIONS TO MAKE SURE THAT THIS ACTION  
WILL NOT RESULT IN AN UNSAFE CONDITION SUCH AS AN  
OPEN MATERIAL VALVE OR LOWERING THE LANCE. IN  
SOME SYSTEMS THE DRUMFILLER CONTROLLER OUTPUTS  
MAY BE WIRED TO OTHER CONTROLLERS FOR THE PURPOSE  
OF CONTROLLING MACHINERY OTHER THAN THE DRUMFILLER  
LANCE. FAILURE TO OBSERVE THIS PRECAUTION MAY  
RESULT IN BODILY INJURY.

## TEST MODE SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

1315

[OUTPUT NUMBER?   XX]

<UP ARROW> returns the program to Statement #1310.

<Reset> returns the program to Statement #200.

Enter the corresponding output number (given on the next page) for the output to be tested and press <ENTER>. The program will advance to the next statement.

To exit this test press <CLEAR> then <ENTER>. The program will return to Statement #1200.

### NUMBER

### OUTPUT

### WARNING - MAY CAUSE THIS ACTION

01	ALARM	URNS ON THE ALARM LIGHT/HORN
02	FOOT VALVE	OPENS LANCE FOOT VALVE
03	FILL FAST	OPENS MATERIAL DELIVERY VALVE
04	FILL SLOW	ACTIVATES SLOW FILL SOLENOID
05	LOWER LANCE	CAUSES LANCE MOVEMENT - DOWN
06	RAISE LANCE SLOW	CAUSES LANCE MOVEMENT - UP
07	RAISE LANCE FAST	CAUSES LANCE MOVEMENT - UP
08	DRUM COMPLETE	URNS ON DRUM COMPLETE OUTPUT

1320

[OUTPUT XX       ON]

<Reset> returns the program to Statement #200.

Press and hold the START pushbutton to have this output turned ON and release the START pushbutton to turn this output OFF.

<Enter> returns the program to Statement #1315.

Note that the control power must be turned on and applied to the outputs and the "AUTO/MANUAL" switch must be in the "AUTO" position to turn on outputs.

## TEST MODE SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

1330

[TEST CTPZ BOARD? X]

<UP ARROW> returns the program to Statement #1310.

<Reset> returns the program to Statement #200.

Press <Y> (yes) or <ENTER> to test the CTPZ Board.  
The program will proceed to the next statement.

Press <N> (no) to skip this test. The program will  
return to Statement #1200.

1340

[I/O 1:x 2:x 3:x 4:x]

(x = 0 for Off      x = 1 for On)

<UP ARROW> returns the program to Statement #1310.

<Reset> returns the program to Statement #200.

<u>NUMBER</u>	<u>CTPZ BOARD INPUTS</u>
1	Container Size Selection
2	Ground Fault Detector
3	Container Size Selection
4	(Not Used)

CONTAINER	INPUT 1	INPUT 3
A	OFF	OFF
B	ON	OFF
C	ON	ON

**SELECT PRODUCT ID SEQUENCE**  
Statements 1400 through 1499

About This Section

The following section describes the operator interface which allows the operator to select and recall the setup record for a particular Product ID record, selection of the number of drums on a pallet for multiple drum lances, and also allows for Order Number and quantity, if Order Filling is enabled.

If the ID Select has been disabled in General Setup, this section will not be accessible to the operator.

<b>PROGRAM STATEMENT</b> -----	<b>APPLICATION</b> -----
1400	<b>[SELECT RUN ID       ]</b> ----- <UP ARROW> returns the program to Statement #200.  <Reset> returns the program to Statement #200.  Press <ENTER> to advance the program to the next statement.
1410	<b>[ID?       XXXXXXXXXXXX]</b> ----- <UP ARROW> returns the program to Statement #1400.  <Reset> returns the program to Statement #200.  Press <CLEAR> to clear the field entry.  Enter the product ID to be used in the next automatic fill operation and press <ENTER>. The program will proceed to the next statement.

PROGRAM  
STATEMENT  
-----

APPLICATION  
-----

1415

[BATCH NUMBER? XXXXX]  
-----

<UP ARROW> returns the program to Statement #1410.

<Reset> returns the program to Statement #200.

Press <CLEAR> to clear the field entry.

Enter the Batch Number to be used in the next  
automatic fill operation and press <ENTER>.

- If the Run ID is changed from an ID that had not finished filling an Order the program will advance to Statement #1480.
- If the ID entered is not stored in memory the program will advance to the next statement.
- If setup for single drums and Order Filling is enabled, the program will advance to Statement #1440.
- If setup for single drums and Order Filling is disabled, the program will return to Statement #200.
- If setup for multiple drums the program will advance to Statement #1430.



## SELECT PRODUCT ID SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

-----

-----

1420

[ID NOT FOUND         ]

-----

<UP ARROW> returns the program to Statement #1410.

<Reset> returns the program to Statement #200.

Press <ENTER> to return the program to Statement #1410.

1430

[NUMBER OF DRUMS? XX]

-----

This prompt will appear if the system is setup for multiple drums.

Press <CLEAR> to clear the field entry.

Enter the number of drums on the pallet, and press <ENTER> or just press <ENTER> to leave the number as is. The number will default to the MAX NUMBER OF DRUMS entered in the I.D. setup.

If Order Filling is enabled the program will advance to the next statement.

If Order Filling is disabled the program will return to Statement #200.

<UP ARROW> returns the program to Statement #1415.

<Reset> returns the program to Statement #200.

## SELECT PRODUCT ID SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

-----  
1440

-----  
[ORDER NO. XXXXXXXXXX]  
-----

This prompt will appear if Production Order Filling  
was enabled in General Setup.

Press <CLEAR> to clear the field entry.

Enter the order number to be used with the Run ID,  
and press <ENTER> or just press <ENTER> to leave the  
order number as is.

If this is a new Order Number or an incomplete Order  
Number the program will advance to the next  
statement.

If the Order Number entered is complete the program  
will advance to Statement #1475.

<UP ARROW> returns the program to Statement #1430,  
for multiple drum setup or no effect for single drum  
setup.

<Reset> returns the program to Statement #200.

## SELECT PRODUCT ID SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

1450

[# DRUMS ORDERED XXX]  
-----

Enter the number of drums to be filled on this Order, used with the Run ID, and press <ENTER> or just press <ENTER> to leave the number of drums as is.

Press <CLEAR> to clear the field entry.

The entry of zero (0) drums to fill will disable order filling for the current Run ID, and the program will return to Statement #200.

If this is a new Order Number or the same Order Number that has not been started, the program will advance to the next statement.

If the same Order Number that has been started, and the number of drums ordered was increased, the program will advance to the next statement.

If this is the same Order Number that has been started, and the number of drums ordered has been changed to equal to the number of drums filled the program will advance to Statement #1480.

<UP ARROW> returns the program to Statement #1440.

<Reset> returns the program to Statement #200.

The program will not allow the number of drums to equal less than the number of drums filled on an order that has been started.

1460

[#DRUMS COMPLETE XXX]  
-----

The display shows the number of drums completed, for the entered Order Number.

<UP ARROW> returns the program to Statement #1450.

<Reset> returns the program to Statement #200.

Press <ENTER> to advance program to the next statement.

SELECT PRODUCT ID SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

1470

[ORDER TOT       XXXXXX]  
-----

The display shows the total net weight filled, for the entered Order Number.

<UP ARROW> returns the program to Statement #1460.

<Reset> returns the program to Statement #200.

Press <ENTER> to return the program to Statement #200.

1475

[ADD TO ORDER?       ]  
-----

The display asks if the Order Number is to have the number of drums increased or not.

Press <Y> (yes) or <ENTER> to increase the number of drums to be filled. The program will return to Statement #1450.

Press <N> to have the drum quantity, drum count and filled net weight cleared for this order. The program will advance to Statement #1450.

<UP ARROW> returns the program to Statement #1440.

<Reset> returns the program to Statement #200.

Default answer is yes.

1480

[END ORD? XXXXXXXXXXXX]  
-----

The display asks if the current order is to be ended.

<UP ARROW> returns the program to Statement #1415.

<Reset> returns the program to Statement #200.

Press <N> (no) or <ENTER> to not end the current Order, the program will return to Statement #1400.

Press <Y> (yes) to end the current Order. The program will advance to the next statement.

SELECT PRODUCT ID SEQUENCE (Continued)

PROGRAM  
STATEMENT

APPLICATION

-----

-----

1485

[ARE YOU SURE?        N]

-----

Press <N> (no) or <ENTER> to not end the current  
Order, the program will return to Statement #1400.

Press <Y> (yes) to end the current Order. Order  
Totals will print if enabled. The program will  
advance to the next statement.

<UP ARROW> returns the program to Statement #1415.

<Reset> returns the program to Statement #200.

## CONSECUTIVE NUMBER SELECT SEQUENCE

Statements 1500 through 1599

### About This Section

The following section describes the operator interface which allows the operator to recall and edit the consecutive number for the selected Product ID. Consecutive numbering must be enabled in system setup (refer to statement #430). The consecutive number may be printed and is typically used as a drum serial number in a lot of material.

This section uses the current Run ID, if no ID is selected the display will show **[ID NOT FOUND]**, then the program will return to Statement #200.

#### **PROGRAM STATEMENT**

#### **APPLICATION**

1500

**[CONSEC NO?   XXXXXX]**

-----  
If the consecutive number has not been enabled, the prompt will not be displayed and the program will return to Statement #200.

<UP ARROW> returns the program to Statement #200.

<Reset> returns the program to Statement #200.

Press <CLEAR> to clear the entry field.

Enter a new consecutive number for this product ID and press <ENTER> or just press <ENTER> to leave the consecutive number as is. The program will return to Statement #200.

This field will always default to 1 (one) if an entry of 0 (zero) is ever entered.

**VARIABLE ID SELECT SEQUENCE**  
Statements 1600 through 1699

About This Section

The following section describes the operator interface which allows the operator to recall and edit the Variable ID for the selected Product ID. Variable ID must be enabled in system setup (refer to statement #400). The Variable ID may be printed and is typically used as a lot number.

This section uses the current Run ID, if no ID is selected the display will show **[ID NOT FOUND]**, then the program will return to Statement #200.

**PROGRAM  
STATEMENT**  
-----

**APPLICATION**  
-----

1600

**[PPPPPPPP XXXXXXXXXXXX]**  
-----

If the variable ID has not been enabled, the prompt will not be displayed and the program will return to Statement #200.

The display prompts the operator to enter the variable ID. The prompt and the length of the ID is set in Setup mode.

Press <CLEAR> to clear the entry field.

Enter a new variable ID and press <ENTER> or just press <ENTER> to leave the variable ID as is. The program will return to Statement #200.

<UP ARROW> returns the program to Statement #200.

<Reset> returns the program to Statement #200.

PPPPPPPP = prompt entered in General Setup.

## ACCUMULATED WEIGHT SELECT SEQUENCE

Statements 1700 through 1799

### About This Section

The following section describes the operator interface which allows the operator to recall and edit the Accumulated Sum for the selected Product ID. Sum operation must be enabled in system setup (refer to statement #440). The Sum may be printed and is typically used as an accumulator for a lot, shift, day, week, or a pallet of drums. The accumulator may be cleared to zero and this action can be protected by the password if additional security is required.

#### PROGRAM STATEMENT

#### APPLICATION

1700

[SUM           XXXXXXXXXX]  
-----

The display indicates the sum of the product weights processed since the value was last cleared. If the sum feature has not been enabled, the prompt will not be displayed and the program will return to Statement #200.

<UP ARROW> returns the program to Statement #200.

<Reset> returns the program to Statement #200.

<Clear> will clear the accumulator to zero or advance to the next statement if password protection of the clear was enabled in statement #445.

1710

[PASSWORD?           ]  
-----

<UP ARROW> returns the program to Statement #1700.

<Reset> returns the program to Statement #200.

Enter the system password and press <ENTER>. If the password entered is correct, the program will clear the accumulator and return to statement #1700. If the password is incorrect the program will advance to the next statement.



ACCUMULATED WEIGHT SELECT SEQUENCE (Continued)

PROGRAM STATEMENT -----	APPLICATION -----
1720	[INVALID PASSWORD ] ----- This statement will be displayed for 2 seconds. The program will return to Statement #1700.

## AUTOMATIC DRUMFILLING SEQUENCE

Statements 2000 through 2999

### About This Section

The following section describes the operator interface which allows the operator to control the automatic drumfilling sequence.

Normal Automatic Drumfilling sequence: (assuming no errors)

Press the START button to accept the displayed ID as the Run ID. (program advances from Statement #200 to #2000)

1. Press the START button
2. The Drum Complete output is turned off.
3. The weight on the scale is checked for a container.
4. The lance is lowered into the container.
5. The indicator is tared, to Net Zero indication.
6. The fill valve on the lance activates, material flows into the container.
7. The container becomes filled to the desired level, the fill valve closes.
8. Container data is stored, internally, and optionally by a printer.
9. The Drum Complete output is turned on.
10. The lance is raised from out of the drum.

Repeat the above sequence for the next container.

## **AUTOMATIC DRUMFILLING SEQUENCE (Continued)**

Operation Common Throughout the Auto Cycle:

If at the first press of the START button, the program does not find the selected ID or that no ID has been selected, the program will return to Statement #290. If the program finds the selected ID the program will advance to Statement #2000.

Pressing the STOP AUTO FILL Pushbutton will halt the filling operation. The program will return to Statement #230, [STOPPD- PUSH START]. To resume operation press START. To exit automatic run operation press <Reset>.

If the EMERGENCY STOP input is seen at any time during the filling operation the program will return to Statement #210.

If the AUTO ON input shuts off (AUTO - MANUAL switch placed in MANUAL position) during the filling operation the program will return to Statement #260.

If a scale fault occurs the program will advance to Statement #2300.

If the scale goes over capacity, the program will advance to Statement #2310.

If the fill cycle time exceeds the cycle time entered in Statement #1120, the program will advance to Statement #2320. The cycle timer starts when the operator pushes the START pushbutton to lower the lance and runs until after the tolerance check (if enabled) at the end of the fill cycle.

If the material flow rate drops below the Minimum Flow Rate for the selected Product ID the fill outputs will turn OFF and the program will advance to Statement #2350. The minimum flow rate calculation starts when the lance valves are opened and following the Flow Delay programmed in statement #345.

## AUTOMATIC DRUMFILLING SEQUENCE (Continued)

Operation Common Throughout the Auto Cycle: (Continued)

If the tare weight changes at any time during the filling operation, the program will advance to Statement #2330.

If for surface type lances the LANCE DOWN input is removed or for sub-surface lances the LANCE OUT OF DRUM input is not seen at any time during the filling operation, the program will advance to Statement #2340. If the lance cannot be re-positioned the program will advance to Statement #2360.

## AUTOMATIC DRUMFILLING SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

2000

[XXXXXXXXXX] - for Single Drum Lances

or

[XXXXXXXXXX NN OF TT] - for Multiple Drum Lances and  
Order Filling

<UP ARROW> returns the program to Statement #200.

<Reset> returns the program to Statement #200.

The display shows the Product ID (XXXXXXXXXX) that is used for this run, the number of the next drum to be filled (NN) on this pallet, and the total number of drums (TT) selected for this pallet.

Press the "Print" button on the indicator keypad to initiate a "duplicate" printout of the last filling transaction.

Press START to advance to the next statement.

2020

[TOLERANCE CHECK]

The scale is read and a container tolerance check is performed once there is no motion on the scale.

If the scale weight is less than the minimum drum weight the program will advance to the next statement. If the controller is configured as a single drum controller, and the scale weight is greater than the maximum drum weight the program will advance to Statement #2040. If the drum weight is ok the scale will then be tared, the LOWER LANCE output is turned on, and the program will advance to Statement #2050.

The DRUM COMPLETE output is also turned off.

## AUTOMATIC DRUMFILLING SEQUENCE (Continued)

PROGRAM STATEMENT -----	APPLICATION -----
2030	<p>[UNDER MINIMUM WT     ] ----- The ALARM output is turned on.</p> <p>Press the SILENCE ALARM key &lt;F11&gt;, to silence the alarm.</p> <p>The operator must now take the necessary steps to place an empty drum on the scale that exceeds the Minimum Weight value setup in statement #1090. Press START to return the program to Statement #2020.</p> <p>&lt;Reset&gt; returns the program to Statement #240.</p>
2040	<p>[OVER MAXIMUM WT     ] ----- Not used in multiple drum applications.</p> <p>The ALARM output is turned on.</p> <p>Press the SILENCE ALARM key &lt;F11&gt;, to silence the alarm.</p> <p>The operator must now take the necessary steps to place an empty drum on the scale that is less than the Maximum Weight value setup in statement #1100. Press START to return the program to Statement #2020.</p> <p>&lt;Reset&gt; returns the program to Statement #240.</p>
2050	<p>[LOWERING LANCE     ] ----- The lance is lowered into the drum. If the scale weight increase is greater than the Drum Hit Detection Weight the lance is raised to the fully up position. The program will advance to the next statement.</p> <p>If the LANCE DOWN input is not seen within 30 seconds the program will advance to Statement #2070.</p> <p>When the LANCE DOWN input is seen the program will advance to Statement #2075.</p>

## AUTOMATIC DRUMFILLING SEQUENCE (Continued)

PROGRAM STATEMENT	APPLICATION
2060	<p>[DRUM HIT FAULT       ]</p> <p>-----</p> <p>The ALARM output is turned on.</p> <p>Press the SILENCE ALARM key &lt;F11&gt;, to silence the alarm.</p> <p>The drum should be repositioned.</p> <p>After re-positioning the drum bung hole to align it with the lance, press START to return the program to Statement #2050 to have the lance lowered again.</p> <p>&lt;Reset&gt; returns the program to Statement #200.</p>
2070	<p>[LANCE FAULT           ]</p> <p>-----</p> <p>The ALARM output is turned on.</p> <p>Press the SILENCE ALARM key &lt;F11&gt;, to silence the alarm.</p> <p>Press START to return the program to Statement #2050 to have the lance lowered again.</p> <p>&lt;Reset&gt; returns the program to Statement #240.</p>
2075	<p>[SETTLING               ]</p> <p>-----</p> <p>The program is waiting for no scale motion before sending a Tare Command to the indicator. At No Motion, the program will attempt to Tare the indicator, then will double check that the indicator is in the Net Mode. If after three un-successful attempts to Tare the scale, the program will advance to Statement #2330.</p> <p>After successfully Taring the scale, the program will advance to Statement #2085 if FAST-SLOW fill has been selected or to Statement #2080 if SLOW-FAST-SLOW fill has been selected (refer to statements #1130 and #1140).</p> <p>This step of the container filling cycle may occur so fast that the user may only see the display blink. The user need only be concerned if the program advances to Statement #2330.</p>

## AUTOMATIC DRUMFILLING SEQUENCE (Continued)

PROGRAM STATEMENT -----	APPLICATION -----
2080	<p>[SLOW FILL                    ] -----</p> <p>The proper valve sequencing is done to achieve slow fill until the scale weight reaches the SLOW FILL WEIGHT. The program will advance to the next statement.</p> <p>For SubSurface filling operation, the Out of Drum input is checked after the Lance Down input is seen. If the Out of Drum input is not <u>ON</u> the program will advance to Statement #2360.</p>
2085	<p>[SLOW FILL/PRIME LNC] -----</p> <p>The Raise and Raise Fast outputs to the lance has been turned on, the fill sequence is still slow fill. When the LANCE DOWN input goes off, the program advances to the next statement.</p>
2090	<p>[FAST FILL                    ] -----</p> <p>The proper valve sequencing is done to achieve fast fill until the scale weight reaches SETPOINT minus PREACT minus DRIBBLE. The program will advance to the next statement.</p> <p>If the system is setup for subsurface fill the Raise Lance output will remain turned on, the Raise Fast output will be turned off. The Raise Lance output will be turned off when the LANCE IN DRUM input (on) is seen.</p>
2100	<p>[SLOW FILL                    ] -----</p> <p>The proper valve sequencing is done to achieve slow fill until the scale weight reaches SETPOINT minus PREACT. The program will advance to the next statement.</p>



## AUTOMATIC DRUMFILLING SEQUENCE (Continued)

PROGRAM STATEMENT -----	APPLICATION -----
2140	<p>[TOLERANCE DELAY      ] -----</p> <p>The drumfiller controller will delay for the Tolerance Check Delay Time. The program will then advance to the next Statement.</p>
2150	<p>[TOLERANCE CHECK      ] -----</p> <p>A fill tolerance check is performed. If the drum weight is within tolerance the program will advance to Statement #2240. If the drum weight is out of tolerance high the program will advance to Statement #2200. If the drum weight is out of tolerance low the program will advance to Statement #2210.</p> <p>If the scale is in motion for 5 seconds the program will advance to the next statement.</p>
2160	<p>[SCALE MOTION          ] -----</p> <p>The ALARM output is turned on.</p> <p>Press SILENCE ALARM key &lt;F11&gt;, to silence the alarm.</p> <p>Press START or &lt;Enter&gt; to return the program to the previous statement.</p> <p>&lt;Reset&gt; returns the program to Statement #240.</p>

## AUTOMATIC DRUMFILLING SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

2200

[OFF HIGH        XXXXXX]  
-----

The ALARM output is turned on. The display shows how much over setpoint the fill weight is.

Press SILENCE ALARM key <F11>, to silence the alarm.

Press START or <Enter> to advance the program to Statement #2220.

Press ACCEPT OFF TOLERANCE (key <F12>) to accept the off tolerance and advance to statement #2240.

If Manual Tolerance Correction has been enabled (see Statement #454 in General Setup), the user may place the AUTO / MANUAL switch in the MANUAL position. While in the Manual position, the user can remove product from the container. The user should observe the indicator display and get the reading to the desired weight. After removing product, the user then places the AUTO / MANUAL switch back to the AUTO position. The user should next press the START push button, the program will return to Statement #2150, tolerance will be checked again. The ACCEPT OFF TOLERANCE (key <F12>) will not function.

#### Manual Tolerance Correction CAUTION:

Pressing the <RESET> key or the START push button while the AUTO / MANUAL switch is in the MANUAL position will abort the container, data on the container will be added to the reject totals and a transaction printout will occur ( if the printer is enabled). After pressing the <RESET> key or the START push button, returning the AUTO / MANUAL switch to the AUTO position will return the program to Statement #200.

## AUTOMATIC DRUMFILLING SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

2210

[OFF LOW        XXXXXX]

-----  
The ALARM output is turned on. The display shows how much under setpoint the fill weight is.

Press SILENCE ALARM key <F11>, to silence the alarm.

Press START or <Enter> to advance the program to the next statement.

Press ACCEPT OFF TOLERANCE (key <F12>) to accept the off tolerance and advance to statement #2240.

If Manual Tolerance Correction has been enabled (see Statement #454 in General Setup), the user may place the AUTO / MANUAL switch in the MANUAL position. While in the Manual position, the user can add product using the MANUAL FILL push button. The user should observe the indicator display and get the reading to the desired weight. After adding product, the user then returns the AUTO / MANUAL switch back to the AUTO position. The user should next press the START push button, the program will return to Statement #2150, tolerance will be checked again. The ACCEPT OFF TOLERANCE (key <F12>) will not function.

#### Manual Tolerance Correction CAUTION:

Pressing the <RESET> key or the START push button while the AUTO / MANUAL switch is in the MANUAL position will abort the container, data on the container will be added to the reject totals and a transaction printout will occur ( if the printer is enabled). After pressing the <RESET> key or the START push button, returning the AUTO / MANUAL switch to the AUTO position will return the program to Statement #200.

## AUTOMATIC DRUMFILLING SEQUENCE (Continued)

PROGRAM STATEMENT	APPLICATION
-----	-----
2220	[ACCEPT?                      Y] ----- <p>&lt;Reset&gt; returns the program to Statement #200. Press &lt;Y&gt; (yes) or &lt;ENTER&gt; to accept the drum. An asterisk is printed next to the net weight on the batch log and the drum data will be recorded as a good drum. The program will advance to Statement #2240. Press &lt;N&gt; (no) to advance the program to the next statement.</p> <p>Press ACCEPT OFF TOLERANCE (key &lt;F12&gt;) to accept the off tolerance and advance to statement #2240.</p>
2230	[REJECT?                      Y] ----- <p>&lt;Reset&gt; returns the program to Statement #200. Press &lt;Y&gt; (yes) or &lt;ENTER&gt; to reject the drum. The letter &lt;R&gt; is printed next to the net weight on the batch log and the drum data will be recorded as a rejected drum. The program will advance to Statement #2240. Press &lt;N&gt; (no) to return the program to Statement #2220.</p>
2240	[STORING DATA                ] ----- <p>The DRUM COMPLETE output is turned on. The production, order totals, and Drum Log Tables are updated. If the printer has been selected in (statement #710 yes in setup), a batch log is printed.</p> <p>If the Drum Log Table is not full, and the printer has been selected in, the program will advance to Statement #2242.</p> <p>If the Drum Log Table is not full, and the printer has been selected out, the program will advance to Statement #2243.</p> <p>If the Drum Log Table is full the program will advance to the next Statement.</p>

## AUTOMATIC DRUMFILLING SEQUENCE (Continued)

PROGRAM STATEMENT -----	APPLICATION -----
2241	<p><b>[DRUM LOG TABLE FULL]</b> -----</p> <p>The display indicates to the operator that the Drum Log table is full. There will be about a 2 second delay before the program advances.</p> <p>If the printer has been selected in, the program will advance to the next Statement.</p> <p>If the printer has been selected out, the program will advance to Statement #2243.</p> <p>The Drum Log is user enabled and is normally used in conjunction with Host operations. The table will hold 480 drum transactions, once the table is full no more drums will be stored and all new drum data will be lost.</p>
2242	<p><b>[WAITING FOR PRINTER]</b> -----</p> <p>The display indicates that data is being sent to the printer. After all data has been transmitted out the printer port the program will advance to the next Statement.</p>
2243	<p><b>[RAISING LANCE       ]</b> -----</p> <p>The RAISE FAST output is turned on. If the LANCE UP input is not seen within the RAISE LANCE TIME the program will advance to the next statement. When the LANCE UP input is seen the program will advance to Statement #2250.</p>

## AUTOMATIC DRUMFILLING SEQUENCE (Continued)

PROGRAM STATEMENT -----	APPLICATION -----
2245	<p>[ LANCE FAULT ] ----- The ALARM output is turned on.</p> <p>Press the SILENCE ALARM key &lt;F11&gt;, to silence the alarm.</p> <p>Press START to return the program to Statement #2243 to have the lance raised again.</p> <p>&lt;Reset&gt; returns the program to Statement #240.</p>
2250	<p>[ DRUM READY ] ----- This statement is displayed for 2 seconds.</p> <p>If multiple drum filling is on, and the pallet is not complete the program will advance to Statement #2260.</p> <p>If single drum filling the program will return to Statement #200.</p> <p>If order filling is enabled, and order is not complete the program will advance to Statement #2270.</p> <p>If order filling is enabled, and order is complete the program will advance to Statement #2280.</p>
2260	<p>[ COMPLETE    XX OF XX ] ----- This statement is displayed for 2 seconds.</p> <p>If this is not the last drum, on the pallet, to be filled the program will then return to statement #2000.</p> <p>If the last drum has been filled the program will return to Statement #200.</p>

## AUTOMATIC DRUMFILLING SEQUENCE (Continued)

PROGRAM STATEMENT -----	APPLICATION -----
2270	<p>[# XxXxXxXxNNN/TTT] ----- This statement is displayed for 1 second.</p> <p>XxXxXxXxXx = Order Number NNN = number of drums filled on order TTT = total number of drums to be filled to satisfy the order.</p> <p>The program will return to statement #2000.</p>
2280	<p>[**ORDER COMPLETE** ] ----- This statement is displayed for 1 second. The display indicates that the Order has been filled. The program will return to statement #200.</p>
2300	<p>[SCALE FAULT            ] ----- No data, invalid data, or checksum error was received from the indicator. The ALARM output is turned on.</p> <p>Press SILENCE ALARM key &lt;F11&gt;, to silence the alarm.</p> <p>Press START to have the system retry reading the scale.</p> <p>&lt;Reset&gt; returns the program to Statement #240.</p>
2310	<p>[SCALE OVER CAP        ] ----- The ALARM output is turned on.</p> <p>Press SILENCE ALARM key &lt;F11&gt;, to silence the alarm.</p> <p>Press START to have the system retry reading the scale.</p> <p>&lt;Reset&gt; returns the program to Statement #240.</p>

## AUTOMATIC DRUMFILLING SEQUENCE (Continued)

PROGRAM STATEMENT -----	APPLICATION -----
2320	<p>[CYCLE SLOW            ] ----- The ALARM output is turned on.</p> <p>Press SILENCE ALARM key &lt;F11&gt;, to silence the alarm.</p> <p>Press START to resume the run operation.</p> <p>&lt;Reset&gt; returns the program to Statement #240.</p>
2330	<p>[SCALE TARE FAULT     ] ----- This is a fatal fault condition. The ALARM output is turned on. If fill was started, data on container is stored as a rejected drum.</p> <p>Press SILENCE ALARM key &lt;F11&gt;, to silence the alarm.</p> <p>Press START to resume operation. The program will return to Statement #200.</p>
2340	<p>[LANCE NOT DOWN       ] ----- The ALARM output is turned on.</p> <p>Press SILENCE ALARM key &lt;F11&gt;, to silence the alarm.</p> <p>Press START to resume the run operation. The program will advance to the next statement.</p> <p>&lt;Reset&gt; returns the program to Statement #240.</p>



## AUTOMATIC DRUMFILLING SEQUENCE (Continued)

PROGRAM STATEMENT -----	APPLICATION -----
2342	<p>[LOWERING LANCE       ]</p> <p>-----</p> <p>The lance is lowered until the Out of Drum input comes back on. If the Out of Drum input comes back on the program returns to statement #2100.</p> <p>If the Out of Drum input does not turn on and the Lance Down input does come on the program advances to statement #2360.</p> <p>After 30 seconds if none of the above conditions occur the program will advance to the next statement.</p>
2344	<p>[LANCE FAULT           ]</p> <p>-----</p> <p>The ALARM output is turned on.</p> <p>Press the SILENCE ALARM key &lt;F11&gt;, to silence the alarm.</p> <p>Press START to return the program to the previous statement.</p> <p>&lt;Reset&gt; returns the program to Statement #240.</p>
2350	<p>[MIN FLOW FAULT       ]</p> <p>-----</p> <p>The ALARM output is turned on.</p> <p>Press SILENCE ALARM key &lt;F11&gt;, to silence the alarm.</p> <p>Press START to resume the run operation.</p> <p>&lt;Reset&gt; returns the program to Statement #240.</p>

## AUTOMATIC DRUMFILLING SEQUENCE (Continued)

### PROGRAM STATEMENT

### APPLICATION

2360

[POSITION FAULT       ]

-----  
This is a fatal fault condition.

If this message is displayed there may be a hardware problem within the Drumfiller system. Position Faults are typically caused by the Drum in Position input being removed. Another cause may be the Lance Out of Drum limit switch is defective. Contact Toledo Scale Service for assistance.

The ALARM output is turned on.

Press SILENCE ALARM key <F11>, to silence the alarm.

Press START to return the program to statement #200.

2370

[TOO MANY DRUMS SLCT]

-----  
This display indicates there is an error between the number of drums, per pallet, setup in the Product ID and the number of drums entered in the Selected ID. This error can only occur by setting up the ID with a maximum number of drums per pallet. Selecting the Run ID with a number of drums per pallet, then going back to the ID setup and changing the maximum number of drums to less than entered for the Run ID selected.

Press <RESET>, then change the Run ID to reflect the change made to the ID setup.

## ID SETUP REPORT SEQUENCE

Statements 3000 through 3099

### About This Section

The following section describes the operator interface which allows the operator to initiate a printout of the setup report for any stored Product ID. This section will not be accessible unless the printer has been enabled in statement #710.

#### PROGRAM STATEMENT

#### APPLICATION

3000

[ID SETUP REPORT ]

-----  
If no printer has been selected in statement #710 the program will skip this section and return to statement #200.

<UP ARROW> returns the program to Statement #200.

<Reset> returns the program to Statement #200.

Press <ENTER> to advance the program to the next statement.

3010

[ID?           XXXXXXXXXX]

-----  
<UP ARROW> returns the program to Statement #3000.

<Reset> returns the program to Statement #200.

Enter the product ID of which a setup report is desired and press <ENTER>.

If the ID is found in memory the program will advance to Statement #3030.

If the ID is not found the program will advance to the next statement.

## ID SETUP REPORT SEQUENCE (Continued)

PROGRAM STATEMENT -----	APPLICATION -----
3020	<p>[ID NOT FOUND           ]</p> <p>-----</p> <p>&lt;UP ARROW&gt; returns the program to Statement #3010.</p> <p>&lt;Reset&gt; returns the program to Statement #200.</p> <p>Press &lt;ENTER&gt; to return the program to Statement #3010.</p>
3030	<p>[PRTING XXXXXXXXXXXXX]</p> <p>-----</p> <p>The product ID setup report is printed for the ID entered (figure 3). Upon completion of printing the program will return to Statement #3010.</p> <p>&lt;Reset&gt; will stop the printout and return the program to Statement #200.</p>

## PRODUCTION SUMMARY REPORT SEQUENCE

Statements 3100 through 3199

### About This Section

The following section describes the operator interface which allows the operator to initiate a printout of the Production Summary report, for any stored Product ID or for all Product IDs with non-zero totals. Also allows the operator to initiate a printout of the Drum Log, if enabled. This section will not be accessible unless the printer has been enabled in statement #710.

#### PROGRAM STATEMENT

#### APPLICATION

3100

[PROD SUMMARY REP? Y]

If no printer has been selected in statement #710 the program will skip this section and return to statement #200.

<UP ARROW> returns the program to Statement #200.

<Reset> returns the program to Statement #200.

Press <Y> (yes) or <ENTER> to advance the program to the next statement.

Press <N> (no) to advance the program to Statement #3160.

3110

[ID?           XXXXXXXXXX]

<UP ARROW> returns the program to Statement #3100.

<Reset> will advance the program to Statement #3160.

Press <CLEAR> to clear the entry field.

Enter the product ID of which a production summary report is desired and press <ENTER>.

If the ID is found in memory the program will advance to Statement #3130.

If the ID is not found the program will advance to the next statement.

If an ID is not entered the report will include all IDs and the program will advance to Statement #3130.

## PRODUCTION SUMMARY REPORT SEQUENCE (Continued)

PROGRAM STATEMENT -----	APPLICATION -----
3120	<p>[ID NOT FOUND         ]</p> <p>-----</p> <p>&lt;UP ARROW&gt; returns the program to Statement #3110.</p> <p>&lt;Reset&gt; will advance the program to Statement #3160.</p> <p>Press &lt;ENTER&gt; to return the program to Statement #3110.</p>
3130	<p>[PRTING XXXXXXXXXXXXX]</p> <p>-----</p> <p>The product ID summary report is printed for the ID entered or for all of the IDs (figure 4). Upon completion of printing the program will advance to the next statement.</p> <p>&lt;Reset&gt; will advance the program to Statement #3160.</p>

PRODUCTION SUMMARY REPORT SEQUENCE (Continued)

PROGRAM STATEMENT -----	APPLICATION -----
3140	<p>[CLR SUMMARY RPT? N] -----</p> <p>&lt;Reset&gt; will advance the program to Statement #3160.</p> <p>Press &lt;Y&gt; (yes) to have the production summary report for the selected ID(s) cleared. The program will advance to the next statement.</p> <p>If all product IDs were selected pressing &lt;N&gt; (no) or &lt;ENTER&gt; will advance the program to Statement #3160.</p> <p>If a single product ID was selected pressing &lt;N&gt; (no) or &lt;ENTER&gt; will return the program to Statement #3100.</p>
3150	<p>[ARE YOU SURE? N] -----</p> <p>&lt;Reset&gt; will advance the program to Statement #3160.</p> <p>Press &lt;Y&gt; (yes) to have the production summary report for the selected IDs cleared. The program will return to Statement #3100 after clearing the production report for a single ID or to Statement #3160 after all ID's production reports are cleared.</p> <p>If all product IDs were selected, pressing &lt;N&gt; (no) or &lt;ENTER&gt; will advance the program to Statement #3160 without clearing the production summary reports.</p> <p>If a single product ID was selected, pressing &lt;N&gt; (no) or &lt;ENTER&gt; will return the program to Statement #3100 without clearing the production summary report.</p>

## PRODUCTION SUMMARY REPORT SEQUENCE (Continued)

PROGRAM STATEMENT	APPLICATION
3160	<p>[DRUM LOG REPORT? Y]</p> <p>-----</p> <p>&lt;UP ARROW&gt; will return the program to Statement #3100.</p> <p>&lt;RESET&gt; will return the program to Statement #200.</p> <p>Press &lt;NO&gt; to return the program to Statement #200.</p> <p>Press &lt;Y&gt; (yes) or &lt;ENTER&gt; to have the Drum Log Report printed. The program will advance to the next statement.</p>
3170	<p>[PRINTING XXX OF YYY]</p> <p>-----</p> <p>The display shows the total number of drums in the log (YYY) and the current drum number being down loaded to the printer (XXX).</p> <p>&lt;RESET&gt; will stop the Drum Log report and advance the program to the next statement.</p>
3180	<p>[CLEAR DRUM LOGS? N]</p> <p>-----</p> <p>&lt;UPARROW&gt; will return the program to Statement #3160.</p> <p>&lt;RESET&gt; will return the program to Statement #200.</p> <p>&lt;N&gt; (no) or &lt;ENTER&gt; will return the program Statement #200.</p> <p>Press &lt;Y&gt; (yes) to have the Drum Log cleared. The program will advance to the next statement.</p>
3190	<p>[ARE YOU SURE? N]</p> <p>-----</p> <p>&lt;UPARROW&gt; will return the program to the previous statement.</p> <p>&lt;RESET&gt; will return the program to Statement #200.</p> <p>&lt;N&gt; (no) or &lt;ENTER&gt; will return the program Statement #200.</p> <p>Press &lt;Y&gt; (yes) to clear the Drum Log. The program will return to Statement #200.</p>



## PRODUCT ID LIST REPORT SEQUENCE

Statements 3200 through 3299

### About This Section

The following section describes the operator interface which allows the operator to initiate a printout of the Product ID List report.

If the printer has been enabled (Statement #710), the program will advance to Statement #3200.

If the printer is disabled (Statement #710), the program will advance to Statement #3210.

### PROGRAM STATEMENT

### APPLICATION

3200

[PRINTING ID LIST ]

-----  
The names of all product ID's stored in memory is printed (figure 5). Upon completion of printout the program will return to Statement #200.

Press <RESET> to stop printout and return program to Statement #200.

3210

[ID'S ENTERED XXX ]

-----  
The number of product ID's stored in memory is displayed.

Press <RESET> to return program to Statement #200.  
Press <UPARROW> to return program to Statement #200.  
Press <ENTER> to advance the program to the next statement.

3220

[I.D. XXXXXXXXXXXX ]

-----  
The display is showing the name of the first product ID stored in memory. Repeat pressing of the <ENTER> key will cycle through all ID's stored in memory. Pressing the <ENTER> when the last ID is displayed will return the program to Statement #200.

Press <RESET> to return program to Statement #200.

Press <UPARROW> to return program to Statement #200.

## REPORT PRINTOUT EXAMPLES

FIGURE 1 - BATCH LOG REPORT EXAMPLE (USER PROGRAMMABLE)

I.D. XXXXXXXXXXXXXXXX    XXXX.X LB NET        : for in tolerance drums  
XX:XX   XX/XX/XX

I.D. XXXXXXXXXXXXXXXX \* XXXX.X LB NET        : for out of tolerance drums  
XX:XX   XX/XX/XX

I.D. XXXXXXXXXXXXXXXX    XXXX.X LB NET        : for "duplicate" prints  
XX:XX   XX/XX/XX        DUPLICATE

                         XXXX.X LB NET        : for "manual" prints  
XX.XX   XX/XX/XX        MANUAL

## REPORT PRINTOUT EXAMPLES (Continued)

**FIGURE 2 - SYSTEM SETUP REPORT**

TIME	XX:XX
DATE	XX/XX/XX

### GENERAL PARAMETER SETUP

HOST DROP ADDRESS	XX
FILLER NUMBER	XX
DRUM HIT WEIGHT	XX
CONTAINER A MAXIMUM WEIGHT	XXXXXX
CONTAINER B MAXIMUM WEIGHT	XXXXXX
CONTAINER C MAXIMUM WEIGHT	XXXXXX
FLOW CHECK DELAY	XX
TOLERANCE CHECK DELAY	XX
RAISE LANCE TIME	XX
SLOW TIME 1	X.XX
SLOW TIME 2	X.XX
LANCE TYPE	SWIVEL SUBSURFACE
VARIABLE ID ENTRY	ENABLED
ID PROMPT	BATCH NO
ID LENGTH	10
CONSECUTIVE NUMBERING	ENABLED
SUMMATION	ENABLED
SUMMATION PASSWORD PROTECT	DISABLED
SUPERVISOR PASSWORD USED	NO
ID SELECT	ENABLED
DRUM LOGS	ENABLED
CORRECTION	ENABLED

### HOST PARAMETER SETUP

HOST	ENABLED
BAUD RATE	4800
CHARACTER DATA BITS	7
CHARACTER PARITY	EVEN

## REPORT PRINTOUT EXAMPLES (Continued)

**FIGURE 2 - SYSTEM SETUP REPORT - cont.**

### PRINTER PARAMETER SETUP

```
-----
BAUD RATE                                300
CHARACTER DATA BITS                     7
CHARACTER PARITY                         EVEN
NET WEIGHT POSITION                       018
WEIGHT UNIT POSITION                      025
OUT OF TOLERANCE FLAG POSITION            017
GROSS WEIGHT POSITION                     000
TARE WEIGHT POSITION                      000
SETPOINT POSITION                        000
ID POSITION                              006
VARIABLE ID PROMPT POSITION               000
VARIABLE ID POSITION                      000
CONSECUTIVE NUMBER POSITION               000
ORDER NUMBER POSITION                     000
FILLER NUMBER POSITION                    000
SUM POSITION                             000
DUPLICATE PRINT LABEL POSITION            056
DATE POSITION                             042
TIME POSITION                             035
BATCH NUMBER POSITION                     000
BLOCK CHECK CHARACTER POSITION            000
BLOCK CHECK CHARACTER START POSITION      000
LITERAL CHARACTER I POSITION              001
LITERAL CHARACTER . POSITION              002
LITERAL CHARACTER D POSITION              003
LITERAL CHARACTER . POSITION              004
LITERAL CHARACTER N POSITION              029
LITERAL CHARACTER E POSITION              030
LITERAL CHARACTER T POSITION              031
LITERAL CHARACTER 0DH POSITION             033
LITERAL CHARACTER 0AH POSITION             034
LITERAL CHARACTER 0DH POSITION             066
LITERAL CHARACTER 0AH POSITION             067
LITERAL CHARACTER 0AH POSITION             068
TOTAL STRING LENGTH                      068
```

REPORT PRINTOUT EXAMPLES (Continued)

FIGURE 3 - PRODUCT ID SETUP REPORT

```

                                PRODUCT ID SETUP

TIME                           XX:XX
DATE                           XX/XX/XX

I.D.                           XXXXXXXXXXXXX
CONTAINER                      X
GRAMS/ML                       X.XXXX
GALLONS                        XXX.X (LITERS for Kg)
SETPOINT                       XXXXXX
DRIBBLE                        XXXXXX
PREACT                         XXXXXX
AUTO PRACT FACTOR              XX
MAX. EMPTY WT.                 XXXX
MIN. EMPTY WT.                 XXXX
FULL TOLERANCE                 XXXX
CYCLE TIME                     XXX
FILL SEQUENCE                   SLOW/FAST/SLOW
SLOW FILL WEIGHT                XXXXXX
MIN. FLOW RATE                  XXXXXX
RAISE LANCE DUTY CYCLE         XX
MAX. NUMBER OF DRUMS           XX
```

## REPORT PRINTOUT EXAMPLES (Continued)

FIGURE 4 - PRODUCTION SUMMARY REPORT

```

      PRODUCTION SUMMARY REPORT

FILLER:  XX
FROM:    XX:XX      XX/XX/XX
TO:      XX:XX      XX/XX/XX


      I.D.          NO OF   TOTAL   NO OF   TOTAL
                   GOOD     ACCEPT  REJ.    REJ.
                   DRUMS   NET WT  DRUMS   NET WT

XXXXXXXXXXXXXXXX XXXXX XXXXXXXX XXXXX XXXXXX
XXXXXXXXXXXXXXXX XXXXX XXXXXXXX XXXXX XXXXXX
XXXXXXXXXXXXXXXX XXXXX XXXXXXXX XXXXX XXXXXX
XXXXXXXXXXXXXXXX XXXXX XXXXXXXX XXXXX XXXXXX
XXXXXXXXXXXXXXXX XXXXX XXXXXXXX XXXXX XXXXXX
TOTAL          XXXXX XXXXXXXX XXXXX XXXXXX
```

## REPORT PRINTOUT EXAMPLES (Continued)

### FIGURE 5 - PRODUCT ID LIST REPORT

PRODUCT ID LIST

XXXXXXXXXXXXX  
XXXXXXXXXXXXX  
XXXXXXXXXXXXX  
XXXXXXXXXXXXX  
XXXXXXXXXXXXX  
XXXXXXXXXXXXX

TIME        XX:XX  
DATE      XX/XX/XX

### FIGURE 6 - DRUM LOG REPORT

The printed Drum Log report is intended to be printed out on an 40 column printer. A block of data as shown below is printed for each drum stored in the log.

ORDER xxxxxxxxxxx  
BATCH # NNNNN  
PRODUCT xxxxxxxxxxxxxx  
CNSEC# NNNNNN  
HH:MM:SS MM/DD/YY  
GROSS WWW.W  
TARE WWW.W  
NET WWW.W T

(T = weight in tolerance, blank = out of tolerance)

### FIGURE 7 - PRODUCTION ORDER TOTAL REPORT

TOTALS FOR ORDER XXXXXXXXXX

NNN OUT OF NNN DRUMS COMPLETED

XXXXX.X LB

TIME        HH:MM  
DATE      MM/DD/YY

## APPENDICES

---

### APPENDIX A - CONTROL AND SPECIAL CHARACTER ENTRY

When setting up string literals it is sometimes necessary to use control characters and other characters not available on the Controller keyboard.

The following is a chart on how to enter control characters.

**Note:** The Controller's local display, will display ASCII Control Characters using the CTRL with a bar over the character entered. All other characters will be displayed as shown in the ASCII Control Character column.



# APPENDICES

## APPENDIX A - CONTROL AND SPECIAL CHARACTER ENTRY (Continued)

ASCII CONTROL CHARACTER	HEX EQUIV.	ENTRY
-----	-----	-----
SOH	01H	Press CTRL then A
STX	02H	Press CTRL then B
ETX	03H	Press CTRL then C
EOT	04H	Press CTRL then D
ENQ	05H	Press CTRL then E
ACK	06H	Press CTRL then F
BEL	07H	Press CTRL then G
BS	08H	Press CTRL then H
HT	09H	Press CTRL then I
LF	0AH	Press CTRL then J
VT	0BH	Press CTRL then K
FF	0CH	Press CTRL then L
CR	0DH	Press CTRL then M
SO	0EH	Press CTRL then N
SI	0FH	Press CTRL then O
DLE	10H	Press CTRL then P
DC1	11H	Press CTRL then Q
DC2	12H	Press CTRL then R
DC3	13H	Press CTRL then S
DC4	14H	Press CTRL then T
NAK	15H	Press CTRL then U
SYN	16H	Press CTRL then V
ETB	17H	Press CTRL then W
CAN	18H	Press CTRL then X
EM	19H	Press CTRL then Y
SUB	1AH	Press CTRL then Z
ESC	1BH	Press CTRL then [
FS	1CH	Press CTRL then \
GS	1DH	Press CTRL then ]
RS	1EH	Press CTRL then ~
US	1FH	Press CTRL then ?
DEL	7FH	Press CTRL then _

## APPENDICES

### APPENDIX A - CONTROL AND SPECIAL CHARACTER ENTRY (Continued)

Special characters are entered on the Controller keyboard by pressing SHIFT, ALT, or CTRL followed by a function key. The following is a chart of these special characters.

CHARACTER	HEX EQUIV.	ENTRY
* (asterisk)	2AH	Press SHIFT then F1
/ (slash)	2FH	Press SHIFT then F2
= (equal sign)	3DH	Press SHIFT then F3
<> (not equal)	n/a	Press SHIFT then F4
<= (less than or equal to)	n/a	Press SHIFT then F5
>= (greater than or equal to)	n/a	Press SHIFT then F6
! (exclamation mark)	21H	Press SHIFT then F7
" (double quotation mark)	22H	Press SHIFT then F8
# (number sign)	23H	Press SHIFT then F9
\$ (dollar sign)	24H	Press SHIFT then F10
% (percent sign)	25H	Press SHIFT then F11
& (ampersand)	26H	Press SHIFT then F12
` (single quotation mark)	60H	Press ALT then F1
' (apostrophe)	27H	Press ALT then F2
^	5EH	Press ALT then F3
@ (at sign)	40H	Press ALT then F4
( (opening parentheses)	28H	Press ALT then F5
) (closing parentheses)	29H	Press ALT then F6
[ (opening bracket)	5BH	Press ALT then F7
\ (backslash)	5CH	Press ALT then F8
] (closing bracket)	5DH	Press ALT then F9
~	7EH	Press ALT then F10
? (question mark)	3FH	Press ALT then F11
_ (underscore)	5FH	Press ALT then F12
{	7BH	Press CTRL then F5
}	7DH	Press CTRL then F6
	7CH	Press CTRL then ;

# APPENDICES

## APPENDIX B - ASCII CONTROL CODE CHART

ASCII CHARACTER	DEC. EQUIV.	OCTAL EQUIV.	HEX EQUIV.
NUL	0	000	00
SOH	1	001	01
STX	2	002	02
ETX	3	003	03
EOT	4	004	04
ENQ	5	005	05
ACK	6	006	06
BEL	7	007	07
BS	8	010	08
HT	9	011	09
LF	10	012	0A
VT	11	013	0B
FF	12	014	0C
CR	13	015	0D
SO	14	016	0E
SI	15	017	0F
DLE	16	020	10
DC1	17	021	11
DC2	18	022	12
DC3	19	023	13
DC4	20	024	14
NAK	21	025	15
SYN	22	026	16
ETB	23	027	17
CAN	24	030	18
EM	25	031	19
SUB	26	032	1A
ESC	27	033	1B
FS	28	034	1C
GS	29	035	1D
RS	30	036	1E
US	31	037	1F
SP	32	040	20

# APPENDICES

## APPENDIX B - ASCII CODE CHART (Continued)

ASCII CHAR.	DEC. EQUIV.	OCTAL EQUIV.	HEX EQUIV.	ASCII CHAR.	DEC. EQUIV.	OCTAL EQUIV.	HEX EQUIV.
!	33	041	21	I	73	111	49
"	34	042	22	J	74	112	4A
#	35	043	23	K	75	113	4B
\$	36	044	24	L	76	114	4C
%	37	045	25	M	77	115	4D
&	38	046	26	N	78	116	4E
'	39	047	27	O	79	117	4F
(	40	050	28	P	80	120	50
)	41	051	29	Q	81	121	51
*	42	052	2A	R	82	122	52
+	43	053	2B	S	83	123	53
,	44	054	2C	T	84	124	54
-	45	055	2D	U	85	125	55
.	46	056	2E	V	86	126	56
/	47	057	2F	W	87	127	57
0	48	060	30	X	88	130	58
1	49	061	31	Y	89	131	59
2	50	062	32	Z	90	132	5A
3	51	063	33	[	91	133	5B
4	52	064	34	\	92	134	5C
5	53	065	35	]	93	135	5D
6	54	066	36	^	94	136	5E
7	55	067	37	_	95	137	5F
8	56	070	38	`	96	140	60
9	57	071	39	a	97	141	61
:	58	072	3A	b	98	142	62
;	59	073	3B	c	99	143	63
<	60	074	3C	d	100	144	64
=	61	075	3D	e	101	145	65
>	62	076	3E	f	102	146	66
?	63	077	3F	g	103	147	67
@	64	100	40	h	104	150	68
A	65	101	41	i	105	151	69
B	66	102	42	j	106	152	6A
C	67	103	43	k	107	153	6B
D	68	104	44	l	108	154	6C
E	69	105	45	m	109	155	6D
F	70	106	46	n	110	156	6E
G	71	107	47	o	111	157	6F
H	72	110	48	p	112	160	70

# APPENDICES

## APPENDIX B - ASCII CODE CHART (Continued)

ASCII CHAR.	DEC. EQUIV.	OCTAL EQUIV.	HEX EQUIV.		ASCII CHAR.	DEC. EQUIV.	OCTAL EQUIV.	HEX EQUIV.
q	113	161	71		y	121	171	79
r	114	162	72		z	122	172	7A
s	115	163	73		{	123	173	7B
t	116	164	74			124	174	7C
u	117	165	75		}	125	175	7D
v	118	166	76		~	126	176	7E
w	119	167	77		DEL	127	177	7F
x	120	170	78					

## APPENDIX C - HOST COMMUNICATIONS

### About this Section

The following describes the Bi-Directional Host Communications Protocol of the 9127 Drumfiller Controller. The Host Glossary defines some terms used. The Hardware Considerations section discusses the interfaces available. The Host Communications Protocol section describes the communication commands briefly. The Individual Host Request Code Protocol section shows the exact protocol required for each Host command and the data transferred. The Host Request Code Validity Table tells which commands are valid when the 9127 is in it's different modes of operation.

There is no Host test routine built into the 9127 program. Toledo Scale can offer, to users and service personnel, a Host ToolBox program that is IBM personal computer compatible. The Host ToolBox performs all operations described in this section of the documentation, and offers many features that take advantage of the host computer. This program is used by Toledo Scale test personnel to assure the operation of the 9127 Host port at the factory. The Host ToolBox also includes over 80 pages of documentation on its usage.

## Host Glossary

<STX>	Start of TeXt character (02H).
<ETX>	End of TeXt character (03H).
<BCC>	Block Check Character, the Exclusive OR of all characters in the message block, starting with the character after the <STX>, up to and including the <ETX>.
<EOT>	End Of Transmission Character (04H), breaks off communication link between any/all 9127's and the host computer.
<ENQ>	ENQuiry character (05H), when it is preceded by a 9127 <Drop Address> it establishes a communication link between the host computer and the associated 9127.
<ACK>	ACKnowledge character (06H), character sent by the receiving device to inform the transmitting device that the message was received without error.
<NAK>	Negative AcKnowledgement character (15H), character sent by the receiving device to inform the transmitting device that an error was detected in the message received.
<Drop Address>	Specific Address of a 9127 (set by dip switches on TSM300 PCB) in a multidrop link that an individual unit will respond to.
Alpha/Numeric	Field type definition indicating the characters can be numbers or any character A-Z.
Date Format	Field type definition indicating a format for date "mm/dd/yy"; where mm is the month, dd is the day, and yy is the year.
Numeric	Field type definition indicating all of the character must be numbers.
Time Format	Field type definition indicating a format for time "hh:mm:ss"; where hh is the hour(24 hour format), mm is minutes, and ss is seconds.
Wt Format	Field type definition indicating it is numeric with a decimal point at the calibrated location for the scale.

## **Hardware Considerations**

The 9127 uses a multidrop protocol which supports up to 7 9127's serviced by a single host computer. Two hardware standards are available to the designer, RS232 and RS422/485. See system drawings provided for connection details.

RS232 is a point-to-point connection between a host computer and one 9127 no greater than 50 feet away. RS232 has a medium amount of noise immunity, and successful communications is highly dependent on the electrical environment. Most often it is used in simple installations with one 9127 or to service individual 9127's taken offline from a multidrop configuration.

RS422/485 supports a multidrop connection between a host computer and 9127 batchers. Distances as great as 4000 ft can be supported with a medium amount of noise immunity. Performance of the RS422/RS485 communication link can be improved by not bundling the cables with other wiring and routing the cable away from devices which produce electrical noise.



## Host Communications Protocol

The following briefly discusses establishing communication with a 9127 and the available commands and 9127 responses. See the section on Individual Code Protocol for more detail of each code.

The GENERAL SETUP SEQUENCE section in the main portion of the manual explains how to configure the Host Port of the Drumfiller Controller before communication can be initiated.

### **Establishing a Host to 9127 link**

The 9127 acts as a slave station in the multidrop/point-to-point bidirectional communications link. It only responds when it receives a proper enquiry (<EOT><Drop Address><ENQ>) from the host computer and a link is established.

#### Typical protocol

```
Host : <EOT>                                ' break all links
Host : <EOT><drop address><ENQ>              ' request link to 9127
9127 :                                     <ACK> ' link established

                                Or

9127 :                                     <NAK><Z> ' 9127 busy
```

NOTE: Only the 9127 with the same drop address as the one transmitted will respond to the host computer.

### **Transferring Data between a host computer and the 9127**

Once the link between a 9127 and the host computer has been established, all communication occurs only between these two devices with data flow controlled by the host computer. The host computer will then be able to request an upload of information stored in the 9127's memory or download information to the 9127's memory without interference with any other 9127's in the multidrop link. The transfer of information to and from the 9127 requires the host computer to send special "Host Request Codes" to the 9127 to select the action required. Following are the typical protocols required.

#### **Host Computer Download**

<STX><HOST REQUEST CODE><DATA><ETX><BCC>

OR

#### **Host Computer Upload**

<STX><HOST REQUEST CODE><ETX><BCC>

## HOST COMMUNICATIONS PROTOCOL (Continued)

### HOST REQUEST CODES

These are the single character codes. See the Individual Host Request Code Protocol section for more detail of each code.

<u>CODE</u>	<u>HEX VALUE</u>	<u>MEANING</u>
<B>	42	The 9127 is to upload Drum Log information to the Host Device.
<C>	43	The 9127 is to clear Drum Log information.
<D>	44	The 9127 is to receive a download of Product ID and Product ID setups. This request must be followed by the Product ID and Product ID setup data. See the Setup Product ID's Sequence section for more information on Product ID's and Product ID setup.
<F>	46	The 9127 is to receive a download of Printer Report Setup data. This request must be followed by the Printer Report Setup data this data does not include Literal data for the Printer Report Setup. See <L> for Printer Literal Setup. See Program Statement 770, in the Printer Setup Sequence section for more information on setting up a Printer Report.
<G>	47	The 9127 is to upload, to the Host, the Printer Report Setup data stored in the 9127.
<K>	4B	The 9127 is to receive a Product ID and clear it's Setup data stored in the 9127. The Product ID must follow this request.

## HOST COMMUNICATIONS PROTOCOL (Continued)

### HOST REQUEST CODES (Continued)

These are the single character codes. See the Individual Host Request Code Protocol section for more detail of each code.

<u>CODE</u>	<u>HEX VALUE</u>	<u>MEANING</u>
<L>	4C	The 9127 is to receive a download of Printer Report Literal Setup data. This request must be followed by the Printer Report Literal Setup data, this data does not include data for the Printer Report Setup. This command replaces all Printer Report Literals currently in the 9127. See Program Statements 810 and 820, in the Printer Setup Sequence section for more information on setting up Printer Report Literals. Understanding Program Statement 770 in the Printer Setup Sequence will be an aid with Printer Report Literals.
<M>	4D	The 9127 is to upload, to the Host, the Printer Report Literal Setup data stored in the 9127.
<P>	50	The 9127 is to upload, to the Host, the Setup data for all stored Product ID's in the 9127.
<Q>	51	The 9127 is to upload, to the Host, the selected Product ID, also called the Run Product ID. See Select Product ID Sequence section for more information.

## HOST COMMUNICATIONS PROTOCOL (Continued)

### HOST REQUEST CODES (Continued)

These are the single character codes. See the Individual Host Request Code Protocol section for more detail of each code.

<u>CODE</u>	<u>HEX VALUE</u>	<u>MEANING</u>
<R>	52	The 9127 is to receive a download of (Run) Product ID and Run Product ID setups. This request must be followed by the Product ID and Run Product ID setup data. See the Select Product ID Sequence section for more information on Run Product ID and Run Product ID setup.
<S>	53	The 9127 is to upload, to the Host, the status of the Drumfiller Controller.
<T>	54	The 9127 is to upload, to the Host, the current time and date being used by the Drumfiller Controller.
<U>	55	The 9127 is to receive a Product ID and upload, to the Host, that Product's ID Setup data stored in the 9127. The Product ID must follow this request.
<V>	56	The 9127 is to upload, to the Host, the General (System) Setup data. This data will not include the current time and date being used by the Drumfiller Controller. See <T> for time and date up load. See the General Setup Sequence section for more information on General Setup.

## HOST COMMUNICATIONS PROTOCOL (Continued)

### HOST REQUEST CODES (Continued)

These are the single character codes. See the Individual Host Request Code Protocol section for more detail of each code.

<u>CODE</u>	<u>HEX VALUE</u>	<u>MEANING</u>
<W>	57	The 9127 is to receive a download of General (System) Setup data. This request must be followed by the General Setup data, this data does not include data for time and date Setup. See the General Setup Sequence section for more information on setting up the General Setup's. See <X> for setting time and date.
<X>	58	The 9127 is to receive a download of Time and Date Setup data. This request must be followed by the Time and Date Setup data. See the General Setup Sequence section, Program Statements 450 and 460, for more information on setting the time and date within the Drumfiller Controller.
<Z>	5A	The 9127 is to clear all Product Id Setups and accumulated data, associated with each Id, stored in the 9127.

## HOST COMMUNICATIONS PROTOCOL (Continued)

### 9127 COMMUNICATIONS ACKNOWLEDGEMENTS

The following <ACK/NAK> responses are sent by the 9127 to the Host after a Host Request code message has been sent.

9127 -	<Nak><D>	- Didn't Understand Request
	<Nak><E>	- first Character of Request was NOT in the list of Request Codes.
	<Nak><H>	- Partial Data Received
	<Nak><I>	- Too Many Characters Received
	<Nak><J>	- Invalid Block Check Character
	<Nak><W>	- Something Wrong with Request
	<Nak><X>	- Something Wrong with Request
	<Nak><Z>	- System busy
	<Ack>	- Received Request, (No Transmission Errors).
or	<Ack>	- Received Request, (No Transmission Errors).
	<Nak><*>	- first Character of Request was in the list of Request Codes, But the Data within the Request was of the wrong Length.

Followed by...

## HOST COMMUNICATIONS PROTOCOL (Continued)

### **9127 RESPONSE CODES**

These are single character codes. The Drumfiller Controller transmits back the Host Request Code before the Response Code. See the Individual Host Request Code Protocol section for more detail.

<u>CODE</u>	<u>HEX VALUE</u>	<u>MEANING</u>
<A>	41	The 9127 is in an Alarm condition.
<B>	42	The 9127 is unable to comply with the Host request. This will be the usual response, from the 9127, when the Drumfiller is in the Run Mode or Filling Mode, and means the request, from the Host, will effect the accurate and safe filling of drums at the time of the request.
<D>	44	Host Request Code <X>. This code means the Date field data received had an invalid value.
<E>	45	Host Request code <S>. Indicates the 9127 is at Emergency Stop.
<F>	46	This code means the Product ID table is full or if Host Request Code <S> the system is Filling a drum.
<I>	49	This code means the 9127 received invalid data or if Host Request Code <S> the system is Idle.
<K>	4B	Host Request code <S>. Indicates the 9127 is in Keyboard Setup mode.
<L>	4C	This code means this is the last record in the table.
<M>	4D	This code means there are more records to be sent following this one or if Host Request Code <S> the system is in Manual mode.
<N>	4E	This code means there are no records stored in the table or if Host Request Code <U> the product was not found.
<P>	50	The 9127 is in it's power up sequence.

## HOST COMMUNICATIONS PROTOCOL (Continued)

### 9127 RESPONSE CODES (Continued)

<u>CODE</u>	<u>HEX VALUE</u>	<u>MEANING</u>
<R>	52	This code means data in a field was out of range or if Host Request Code <S> the system is in Run mode.
<S>	53	Host Request code <S>. Indicates the 9127 is in Stop mode.
<T>	54	For Host Request Code <T> this code means data in a Time field was invalid or if Host Request Code <S> the system is in Test mode.



## INDIVIDUAL HOST REQUEST CODE PROTOCOL

The following section shows each Host Request Code and the possible resulting interactions between the host and 9127.

### **REQUEST DRUM LOG**

Host - <Stx><B><Etx><Bcc> - to Upload Drum Log

#### **Successful 9127 Request**

9127 - <Ack> - to Acknowledge Request

Followed By...

<Stx><B><M><B\_Data><Etx><Bcc> - Drum log record (More to Follow)

Host - <Ack> - an Ack is expected from the host

.  
.  
.

9127 - <Stx><B><L><B\_Data><Etx><Bcc> - Drum Log Record (Last Record)

Host - <Ack> - An Ack is Expected from the Host

9127 - <Ack> - An Ack is Sent Back by the 9127 to Signal the End of the Request.

#### **Unsuccessful 9127 Request**

9127 - <Ack> - to Acknowledge Request

<Stx><B><N><Etx><Bcc> - No Drum Log Records Stored

Host - <Ack> - An Ack is Expected from the Host

9127 - <Ack> - An Ack is Sent Back by the 9127 to Signal the End of the Request.

#### **NOTE:**

After each record is received and the host transmits an <Ack> the next record will be sent.

After the last record has been sent and the <Ack> is received from the host, the drum log table will be cleared.

## Record/Field Definitions

Field	Length	Type	Description
<B_Data>			Drum Log Information Record
<Pid>	12	Alpha/Numeric	Product Id
<CnById>	6	Numeric	Consecutive Drum number (By Product)
<OrderNumber>	10	Alpha/Numeric	If Order Filling
<GrossWt>	6	Wt Format	
<TareWt>	5	Wt Format	
<NetWt>	6	Wt Format	
<WtFlag>	1	Wt Flag	(R-Rejected, *-Off Tolerance, <Space>-Okay)
<WtTime>	8	Time Format	Time of Filling
<WtDate>	8	Date Format	Date of Filling
<BatNo>	5	Numeric	Batch Number
EndRecord	—		
Total	67	Bytes	

## INDIVIDUAL HOST REQUEST CODE PROTOCOL (CONTINUED)

### **CLEAR DRUM LOG TABLE**

Host -           <Stx><C><Etx><Bcc>           - to Clear Drum Log

#### **Successful 9127 Request**

9127 -           <Ack>                       - to Acknowledge Request

9127 -           <Ack>                       - to Acknowledge Product has  
  Been Deleted

#### **Unsuccessful 9127 Request**

9127 -           <Ack>                       - to Acknowledge Request

                  <Stx><C><B><Etx><Bcc> - System is Busy

#### **Then**

Host -           <Ack>                       - An Ack is Expected from the  
  Host

9127 -           <Ack>                       - An Ack is Sent Back by the  
  9127 to Signal the End of  
  the Request.

## INDIVIDUAL HOST REQUEST CODE PROTOCOL (CONTINUED)

### PRODUCT SETUP RECORD DOWNLOAD

Host - <Stx><D><Pid><D\_Data><Etx><Bcc> - to download  
Product Setup  
information

#### Successful 9127 data transfer

9127 - <Ack> - to Acknowledge Request  
9127 - <Ack> - Setup Data was Accepted

#### Unsuccessful 9127 data transfer

9127 - <Ack> - to Acknowledge Request  
<Stx><D><F><Etx><Bcc>- Product Id Table is Full  
**Or**  
9127 - <Ack> - to Acknowledge request  
<Stx><D><I><Etx><Bcc>- Non-Numeric Data in a Numeric  
**Or** Field  
9127 - <Ack> - to Acknowledge request  
<Stx><D><R><Etx><Bcc>- Data in a Field Out of Range.

#### Then

Host - <Ack> - An Ack is Expected from the Host  
9127 - <Ack> - and an Ack is Sent Back by the  
9127 to Signal the End of the  
Request.

### Record/Field Definitions

Field	Length	Type	Description
<Pid>	12	Alpha/Numeric	Product Id
<D_Data>			Product Setup Information Record
<SetPoint>	6	Wt Format	
<Dribble>	5	Wt Format	
<Preact>	5	Wt Format	
<A_Preact_Adj>	2	Numeric	Auto Preact Factor
<Max_Empt_Wt>	5	Wt Format	Maximum empty weight
<Min_Empt_Wt>	5	Wt Format	Minimum empty weight
<Full_Tol>	4	Wt Format	Full Tolerance
<Cycle_Time>	3	Numeric	Seconds
<Slow_Start>	1	Yes/No	<Y>=Slow_Fast_Slow, <N>=Fast_Slow
<Slow_Fill_Wt>	6	Wt Format	
<Min_Flow_Rate>	5	Wt Format	Scale Units Per Minute
<RDtyCycle>	2	Numeric	Raise Lance Duty Cycle
<Max_Drums>	2	Numeric	No Drums Per Pallet
<Variable_Id>	10	Alpha/Numeric	
<CnById>	6	Numeric	Consecutive No By Product Id
<Density>	6	Numeric	Format must be X.XXXX
<Volume>	5	Numeric	Format must be XXX.X
<Container>	1	Alpha/Numeric	Container A,B or C
EndRecord			
Total	81	Bytes	

**INDIVIDUAL HOST REQUEST CODE PROTOCOL (CONTINUED)**  
**PRINTER REPORT FORMAT SELECTION DOWNLOAD**

Host - <Stx><F><F\_Data><Etx><Bcc> - to Download Report Format

...and the Response will be...

9127 - <Ack> - to Acknowledge Request

Followed By...

<Ack> - Report Format Accepted

or <Stx><F><B><Etx><Bcc> - Bad Time to Change Report Format

or <Stx><F><I><Etx><Bcc> - Non-Numeric Data in a Numeric Field

or <Stx><F><R><Etx><Bcc> - Data in a Field Out of Range.

After an Error Code.....

Host - <Ack> - An Ack is Expected from the Host

9127 - <Ack> - ... and an Ack is Sent Back by the  
9127 to Signal the End of the Request.

**Record/Field Definitions**

Field	Length	Type	Description
<F_Data>			Download Report Format Information Record
<PWtPos>	3	Numeric Max 245	Net Weight
<PUtPos>	3	Numeric Max 249	Wt Units (LB/kg)
<POTPos>	3	Numeric Max 250	Off Tolerance Flag
<PGWPos>	3	Numeric Max 245	Gross Weight
<PTWPos>	3	Numeric Max 245	Tare Weight
<PSPPos>	3	Numeric Max 245	SetPoint Weight
<PIDPos>	3	Numeric Max 241	Product Id
<PVPPos>	3	Numeric Max 243	Variable ID Prompt
<PVIPos>	3	Numeric Max 241-250	Variable Id Pos
<PCNPos>	3	Numeric Max 245	Consecutive number (By Product)
<PSmPos>	3	Numeric Max 241	Sum of Weights
<PONPos>	3	Numeric Max 249	Order Number
<PFlPos>	3	Numeric Max 249	Filler Number
<PDuPos>	3	Numeric Max 242	"DUPLICATE"
<PDtPos>	3	Numeric Max 243	Date Position
<PTmPos>	3	Numeric Max 246	Time Position
<PBPos>	3	Numeric Max 246	Batch Number
<PBcPos>	3	Numeric Max 250	Block Check Char
<PBsPos>	3	Numeric Max 250	Block Check Start
EndRecord			
Total	57	Bytes	

## INDIVIDUAL HOST REQUEST CODE PROTOCOL (CONTINUED)

### PRINTER REPORT FORMAT SELECTION UPLOAD

Host -       <Stx><G><Etx><Bcc>                       - to UpLoad Report Format  
    ...and the Response will be...

9127 -       <Ack>                                       - to Acknowledge Request  
            Followed By...

9127 -       <Stx><G><F\_Data><Etx><Bcc> - Report Format Data

Host -       <Ack>                                       - An Ack is Expected from the  
  Host

9127 -       <Ack>                                       - ... and an Ack is Sent Back by  
  the 9127 to Signal the End  
  of the Request.

See Code <F> for <F\_Data> record structure.

## INDIVIDUAL HOST REQUEST CODE PROTOCOL (CONTINUED)

### **CLEAR PRODUCT SETUP RECORD**

Host - <Stx><K><Pid><Etx><Bcc> - to Clear Product Setup  
Information

#### **Successful 9127 Request**

9127 - <Ack> - to Acknowledge Request Followed  
By...  
9127 - <Ack> - to Acknowledge Product has  
Been Deleted

#### **Unsuccessful 9127 Request**

9127 - <Ack> - to Acknowledge Request  
<Stx><K><N><Etx><Bcc> - Error, Product Not Found  
**Or**  
9127 - <Ack> - to Acknowledge Request  
<Stx><K><B><Etx><Bcc> - Product In Use, Bad Time

to Delete

#### **After an Error Code.....**

Host - <Ack> - An Ack is Expected from the  
Host  
9127 - <Ack> - An Ack is Sent Back by the 9127 to  
Signal the End of the  
Request.

### **Record/Field Definitions**

Field	Length	Type	Description
<Pid>	10	Alpha/Numeric	Product Id

INDIVIDUAL HOST REQUEST CODE PROTOCOL (CONTINUED)

PRINTER LITERAL FORMAT DOWNLOAD

Host - <Stx><L><L\_Data><Etx><Bcc> - to Download Printer  
Literal

...and the Response will be...

9127 -       <Ack>                               - to Acknowledge Request  
              Followed By...

```
<Ack> - Literal Accepted
```

```
or      <Stx><L><B><Etx><Bcc>      - Bad Time to Change Printer
                                     Literal
```

## After an Error Code.....

```
Host -      <Ack>          - An Ack is Expected from the Host
9127 -      <Ack>          - ... and an Ack is Sent Back by the
                           9127 to Signal the End of the
                           Request.
```

## Record/Field Definitions

Field	Length	Type	Description
<L_Data>	Download	Printer Literal	Record
<PLitSt>	250	Alpha/Numeric	Printer Literal
EndRecord			



## INDIVIDUAL HOST REQUEST CODE PROTOCOL (CONTINUED)

### PRINTER LITERAL SELECTION UPLOAD

Host -       <Stx><M><Etx><Bcc>               - to UpLoad Printer Literal

    ...and the Response will be...

9127 -       <Ack>                               - to Acknowledge Request  
    Followed By...

9127 -       <Stx><M><L\_Data><Etx><Bcc> - Printer Literal

Host -       <Ack>                               - An Ack is Expected from the Host

9127 -       <Ack>                               - ... and an Ack is Sent Back by the  
  9127 to Signal the End of the  
  Request.

See Code <L> for <L\_Data> record structure.

## INDIVIDUAL HOST REQUEST CODE PROTOCOL (CONTINUED)

### GLOBAL PRODUCT SETUP RECORDS UPLOAD

Host - <Stx><P><Etx><Bcc> - to Upload All Product Setup Information

#### **Successful 9127 data request**

9127 - <Ack> - to Acknowledge Request  
<Stx><P><M><Pid><U\_Data><Etx><Bcc> - Product Setup (More to Follow)

Host - <Ack> - An ACK is expected from the host after each record

.  
. .

9127 - <Stx><P><L><Pid><U\_Data><Etx><Bcc> - Product Setup (Last Record)

#### **Unsuccessful 9127 data request**

<Ack> - to Acknowledge request  
<Stx><P><N><Etx><Bcc> - No Product setup records

#### **Then**

Host - <Ack> - An Ack is Expected from the Host

9127 - <Ack> - An Ack is Sent Back  
by the 9127 to Signal the end of transmission

See Code <U> for <U\_Data> Record structure.

## INDIVIDUAL HOST REQUEST CODE PROTOCOL (CONTINUED)

### REQUEST RUN PRODUCT ID

Host - <Stx><Q><Etx><Bcc> - to Upload Run Product

Information

#### Successful 9127 Request

9127 - <Ack> - to Acknowledge Request Followed  
By...

<Stx><Q><PID><Q\_Data><Etx><Bcc> - Run Product

Information

#### Then

Host - <Ack> - An Ack is Expected from the

Host  
9127 - <Ack> - An Ack is Sent Back by the

9127 to Signal the End of

the Request.

### Record/Field Definitions

Field	Length	Type	Description
<PID>	12	Alpha/Numeric	Product Id
<Q_Data>			Run Product Information Record
<No_of_Drums>	2	Numeric	Number of Drums per Pallet(Swivel Lance)
<OrderNumber>	10	Alpha/Numeric	If Order Filling
<No_DrumsOrdered>	3	Numeric	Non-Zero if Order Filling
<BatNo>	5	Numeric	Batch Number
<DrumCount>	3	Numeric	Number of Drums Completed if Order Filling
<TotOrdNtWt>	10	Wt Format	Total Order Net Weight of Completed Drums
EndRecord	—		
Total	35	Bytes	

## INDIVIDUAL HOST REQUEST CODE PROTOCOL (CONTINUED)

### SELECT RUN PRODUCT ID

Host - <Stx><R><Pid><R\_Data><Etx><Bcc> - to Download Run  
Product Selection

#### Successful 9127 Request

9127 - <Ack> - to Acknowledge Request

Followed By...

9127 - <Ack> - to Acknowledge Product has  
Been Deleted

#### Unsuccessful 9127 Request

9127 - <Ack> - to Acknowledge Request  
<Stx><R><B><Etx><Bcc> - Cannot Change Run Product  
Selection

#### Or

9127 - <Ack> - to Acknowledge Request  
<Stx><R><I><Etx><Bcc> - InValid Data Number of Drums  
Field

#### After an Error Code.....

Host - <Ack> - An Ack is Expected from the  
Host

9127 - <Ack> - An Ack is Sent Back by the  
9127 to Signal the End of  
the Request.

### Record/Field Definitions

Field	Length	Type	Description
<Pid>	12	Alpha/Numeric	Product Id
<R_Data>			DownLoad Run Product Information Record
<No_of_Drums>	2	Numeric	Number of Drums per Pallet(Swivel Lance)
<OrderNumber>	10	Alpha/Numeric	If Order Filling
<No_DrumsOrdered>	3	Numeric	Non-Zero if Order Filling
<BatNo>	5	Numeric	Batch Number
EndRecord	—		
Total	22	Bytes	

## INDIVIDUAL HOST REQUEST CODE PROTOCOL (CONTINUED)

### REQUEST 9127 SYSTEM STATUS

Host - <Stx><S><Etx><Bcc> - to Upload System Status

#### 9127 Response

9127 - <Ack> - to Acknowledge Request  
<Stx><S><X><S\_Data><Etx><Bcc> - 9127 Reply

#### Then

Host - <Ack> - An Ack is Expected from the Host

9127 - <Ack> - An Ack is Sent Back by the 9127 to Signal the End of the Request.

<X>	Definition	<S_Data>	type	# bytes
P	Power Up Mode	# of IDs	Numeric	3 bytes
I	Idle Mode	# Drum log	Numeric	3 bytes
K	Keyboard Setup	Scale mode	Gr/Net	1 byte
R	Ready to fill drums	Display Wt	Numeric	6 bytes
F	Filling a drum	Tare Wt	Numeric	6 bytes
T	Test Mode	Units	LB/KG	2 bytes
M	Manual Mode			
E	Emergency Stop Mode			
A	Alarm Mode			
S	Stopped			

## INDIVIDUAL HOST REQUEST CODE PROTOCOL (CONTINUED)

### REQUEST 9127 TIME & DATE

Host -       <Stx><T><Etx><Bcc>               - to UpLoad System Time & Date

9127 -       <Ack>                               - to Acknowledge Request  
             <Stx><T><T\_Data><Etx><Bcc> - System Time & Date

**Then**

Host -       <Ack>                               - An Ack is Expected from

             the Host

9127 -       <Ack>                               - An Ack is Sent Back by       the  
  9127 to Signal the    End  
  of the Request.

<T_Data>	# Bytes	Definition
<SystemTime>	8	Time Format HH:MM:SS (Military Time)
<SystemDate>	8	Date Format MM/DD/YY

## INDIVIDUAL HOST REQUEST CODE PROTOCOL (CONTINUED)

### PRODUCT SETUP RECORD UPLOAD

Host - <Stx><U><Pid><Etx><Bcc> - to UpLoad Product Setup Information

**Successful 9127 data request**

9127 - <Ack> - to Acknowledge Request  
<Stx><U><L><Pid><U\_Data><Etx><Bcc> - Product Setup Information

**Unsuccessful 9127 data request**

<Ack> - to Acknowledge request  
<Stx><U><N><Etx><Bcc> - Product Not Found in Table

**Then**

Host - <Ack> - An Ack is Expected from the Host

9127 - <Ack> - An Ack is Sent Back by the 9127 to Signal the End of the Request.

### Record/Field Definitions

Field	Length	Type	Description
<Pid>	12	Alpha/Numeric	Product Id
<U_Data>			Product Setup UpLoad Information Record
<SetPoint>	6	Wt Format	
<Dribble>	5	Wt Format	
<Preact>	5	Wt Format	
<A_Preact_Adj>	2	Numeric	Auto Preact Adjustment
<Max_Empt_Wt>	5	Wt Format	Maximum Empty Weight
<Min_Empt_Wt>	5	Wt Format	Minimum Empty Weight
<Full_Tol>	4	Wt Format	Full Tolerance
<Cycle_Time>	3	Numeric	Seconds
<Slow_Start>	1	Yes/No	<Y>=Slow_Fast_Slow, <N>=Fast_Slow
<Slow_Fill_Wt>	6	Wt Format	
<Min_Flow_Rate>	5	Wt Format	Scale Units Per Minute
<RDtyCycle>	2	Numeric	Raise Lance Duty Cycle
<Max_Drums>	2	Numeric	No Drums Per Pallet
<Variable_Id>	10	Alpha/Numeric	
<CnById>	6	Numeric	Consecutive No By Product Id
<Density>	6	Numeric	Format will be X.XXXX
<Volume>	5	Numeric	Format will be XXX.X
<Container>	1	Alpha/Numeric	Container A,B or C
<GoodDrums>	5	Numeric	Number of Good Drums
<GoodWt>	11	Wt Format	Total Wt of Good Drums
<BadDrums>	5	Numeric	Number of Bad Drums
<BadWt>	10	Wt Format	Total Wt of Bad Drums
EndRecord			
Total	112	Bytes	

## INDIVIDUAL HOST REQUEST CODE PROTOCOL (CONTINUED)

### 9127 SYSTEM SETUP INFORMATION UPLOAD

Host - <Stx><V><Etx><Bcc> - to UpLoad System Setup

#### 9127 Response

9127 - <Ack> - to Acknowledge Request  
<Stx><V><V\_Data><Etx><Bcc> - System Setup

#### Then

Host - <Ack> - An Ack is Expected from the Host  
9127 - <Ack> - An Ack is Sent Back by the 9127 to Signal the End of the Request.

### Record/Field Definitions

Field	Length	Type	Description
<V_Data>	System Setup Information Record		
<SuprPw>	6	Alpha/Numeric	Supervisor Password
<FillerNo>	2	Numeric	Filler No
<DHwt>	2	Wt Format	Drum Hit Wt
<Flw_Delay>	2	Numeric Sec.	Flow Delay
<Tol_Delay>	2	Numeric Sec.	Tolerance Delay
<LRaise_Time>	2	Numeric Sec.	Lance Raise Time
<STim1>	4	Numeric X.XX Sec.	Slow Time 1
<STim2>	4	Numeric X.XX Sec.	Slow Time 2
<IDEnb>	1	Yes/No	Enable Id Entry
<IDPrmpt>	8	Alpha/Numeric	Variable ID Prompt
<IDLngth>	2	Numeric	Variable ID Length
<CnEnb>	1	Yes/No	Enable Consecutive Numbering
<CnGlbl>	6	Numeric	Consecutive Drum number (By Machine)
<SumEnb>	1	Yes/No	Enable Summing
<SumPrtct>	1	Yes/No	Protect Summing
<PrdEnb>	1	Yes/No	Enable Production Orders
<POTEnb>	1	Yes/No	Print Order Totals
<SlctEnb>	1	Yes/No	Select ID Key Enable
<DLogEnb>	1	Yes/No	Enable Drum Log Table
<M_Corr>	1	Yes/No	Enable Manual Tolerance Correction
<DpSw1>	1	Surface <S> / SubSurface <B>	Filling Lance
<DpSw2>	1	Single <S> / Multiple <M>	Drum (Swivel Lance)
<DpSw3>	1	<0> = Normal Mode, <1> = Illegal	
<DpSw4>	1	Bit 1 of Host Drop Address	
<DpSw5>	1	Bit 2 of Host Drop Address	
<DpSw6>	1	Bit 4 of Host Drop Address	
<DpSw7>	1	Unused Switch <1> = On, <0> = Off	
<DpSw8>	1	Force Cold Start	



# **RECORD/FIELD DEFINITIONS (CONTINUED)**

<u>Field</u>	<u>Length</u>	<u>Type</u>	<u>Description</u>
V_Data(continued)			
<ScaleGraduations>	4	Numeric	(.00X, .0X0, .X00, X.00, or X0.0; where X=1, 2, or 5)
<ScaleUnits>	2	Alpha	(LB or KG)
EndRecord	—		
Total	63	Bytes	

Field Type Yes/No: <Y> = yes, <N> = no

## INDIVIDUAL HOST REQUEST CODE PROTOCOL (CONTINUED)

### 9127 SYSTEM SETUP INFORMATION DOWNLOAD

Host -       <Stx><W><W\_Data><Etx><Bcc> - Download setup

9127 -       <Ack>                       - to Acknowledge Request  
          <Ack>                       - to Signal Setup Information  
                                      was valid

**Unsuccessful 9127 Request**

9127 -       <Ack>                       - to Acknowledge request  
          <Stx><W><B><Etx><Bcc> - System Busy

9127 -       <Ack>                       - to Acknowledge request  
          <Stx><W><I><Etx><Bcc> - Non-Numeric Data in a  
                                      Numeric Field

9127 -       <Ack>                       - to Acknowledge request  
          <Stx><W><R><Etx><Bcc> - Data in a Field Out of  
                                      Range

**After an Error Code.....**

Host -       <Ack>                       - An Ack is Expected from the  
                                      Host

9127 -       <Ack>                       - An Ack is Sent Back by the  
                                      9127 to Signal the End of  
                                      the Request.

### Record/Field Definitions

Field	Length	Type	Description
<W_Data>			System Setup Information Record
<SuprPw>	6	Alpha/Numeric	Supervisor Password
<FillerNo>	2Numeric		Filler No
<DHwt>	2	Wt Format	Drum Hit Wt
<Flw_Delay>	2	Numeric Sec.	Flow Delay
<Tol_Delay>	2	Numeric Sec.	Tolerance Delay
<LRaise_Time>	2	Numeric Sec.	Lance Raise Time
<STim1>	4	Numeric X.XX Sec.	Slow Time 1
<STim2>	4	Numeric X.XX Sec.	Slow Time 2
<IDEnb>	1	Yes/No	Enable Id Entry
<IDPrmpt>	8	Alpha/Numeric	Variable ID Prompt
<IDLngth>	2	Numeric	Variable ID Length
<CnEnb>	1	Yes/No	Enable Consecutive Numbering
<SumEnb>	1	Yes/No	Enable Summing
<SumPrtct>	1Yes/No		Protect Summing
<PrdEnb>	1	Yes/No	Enable Production Orders
<POTEnb>	1	Yes/No	Print Order Totals
<SlctEnb>	1	Yes/No	Select ID Key Enable
<DLogEnb>	1	Yes/No	Enable Drum Log Table
<M_Corr>	1Yes/No		Enable Manual Tolerance Correction
EndRecord	—		
Total	43	Bytes	

## INDIVIDUAL HOST REQUEST CODE PROTOCOL (CONTINUED)

### SET 9127 TIME & DATE

Host - <Stx><X><T\_Data><Etx><Bcc> - to DownLoad System Time  
& Date

9127 - <Ack> - to Acknowledge Request  
<Ack> - to say that the command was

Accepted

### Unsuccessful 9127 data transfer

9127 - <Ack> - to Acknowledge Request  
<Stx><X><B><Etx><Bcc> - Bad Time to Change Time &

Date

Or

9127 - <Ack> - to Acknowledge request  
<Stx><X><D><Etx><Bcc> - Date Field has an InValid

Value

Or

9127 - <Ack> - to Acknowledge request  
<Stx><X><T><Etx><Bcc> - Time Field has an InValid

Value

### After an Error Code.....

Host - <Ack> - An Ack is Expected from the

Host

9127 - <Ack> - An Ack is Sent Back by the  
9127 to Signal the End of  
the Request.

See Code <T> for <T\_Code> record structure.

## INDIVIDUAL HOST REQUEST CODE PROTOCOL (CONTINUED)

### CLEAR ALL PRODUCT ID RECORDS

Host -        <Stx><Z><Etx><Bcc>                      - to Clear All Product Setup  
Information

#### Successful 9127 Request

9127 -        <Ack>                                      - to Acknowledge Request                      Followed  
By...  
9127 -        <Ack>                                      - to Acknowledge All Product                      Ids  
    Have Been Deleted

#### Unsuccessful 9127 Request

9127 -        <Ack>                                      - to Acknowledge Request  
    <Stx><Z><B><Etx><Bcc> - 9127 In Use, Bad Time

to Delete

#### After an Error Code.....

Host -        <Ack>                                      - An Ack is Expected from the  
Host  
9127 -        <Ack>                                      - An Ack is Sent Back by the                      9127 to  
    Signal the End of                      the  
    Request.

INDIVIDUAL HOST REQUEST CODE PROTOCOL (CONTINUED)

**ESTABLISH COMMUNICATION LINK**

Host - <EOT><drop address><ENQ> - request link to 9127  
9127 - <ACK> - link established  
Or  
9127 - <NAK><Z> - 9127 busy

INDIVIDUAL HOST REQUEST CODE PROTOCOL (CONTINUED)

**BREAK COMMUNICATION LINK**

Host -	<EOT>	- to Break the Link with any 9127's
9127 -	<EOT>	- to Mimic the Host

# HOST REQUEST CODE VALIDITY TABLE

The following Table shows which Host Request Codes(rows) are available While 9127 is in certain modes(columns). Asterisks(\*) indicate the Code is valid and blanks( ) indicate they are not.

<I> - Idle  
     <S> - Stop Mode  
         <R> - Run Mode  
             <F> - Fill Mode  
                 <T> - Test Mode  
                     <M> - Manual Mode  
                         <E> - Emergency Stop  
                             <A> - Alarm Mode  
                                 <K> - Keyboard Mode

*	*	*		*	*	*	*	*	<B>	- UpLoad Drum
										Logs
*			*	*	*				<C>	- Clear Drum
										Logs
*	*	*	*	*	*	*	*	*	<D>	- DownLoad
										Product Setup
*	*			*	*	*	*	*	<F>	- DownLoad
										Report Format
*	*	*	*	*	*	*	*	*	<G>	- UpLoad
										Report Format
*	*	*	*	*	*	*	*		<K>	- Clear Product
										Setup
*	*			*	*	*	*	*	<L>	- DownLoad
										Printer Literal
*	*	*	*	*	*	*	*	*	<M>	- UpLoad
										Printer Literal
*	*	*		*	*	*	*	*	<P>	- UpLoad All
										Product Setup
*	*	*	*	*	*	*	*	*	<Q>	- UpLoad
										Run Product
*				*	*				<R>	- DownLoad Run
										Product Selection
*	*	*	*	*	*	*	*	*	<S>	- Upload
										System Status
*	*	*	*	*	*	*	*	*	<T>	- UpLoad System
										Time and Date
*	*	*	*	*	*	*	*	*	<U>	- UpLoad
										Product Setup
*	*	*	*	*	*	*	*	*	<V>	- UpLoad System
										Setup
*					*				<W>	- DownLoad
										System Setup
*				*	*			*	<X>	- DownLoad
										System Time & Date
*				*	*				<Z>	- Clear All Product
										Ids



# INDEX of DISPLAY PROMPTS

(C)OPY (D)EL (E)DIT .....	51
**EMERGENCY STOP** .....	12
**ORDER COMPLETE** .....	15, 104
# XxXxXxXxXxNNN/TTT .....	104
#DRUMS COMPLETED XX .....	84
ABORT FILL CYCLE? Y .....	13
ACCEPT? Y .....	101
ADD TO ORDER? .....	85
ALL DATA CLEARED! .....	4
ARE YOU SURE? N .....	4, 13, 52, 86, 112, 113
AUTO PREACT FAC? XX .....	59
BATCH NUMBER? XXXXX .....	81
CALC SETPOINT? .....	53
CLEAR DRUM LOGS? N .....	113
CLR PRNT LITRLS? N .....	46
CLR SUMMARY RPT? N .....	112
COLD START FORCED .....	9
COLD START? N .....	4
COMPLETE X OF X .....	103
CONSEC NO? XXXXXX .....	87
CONT A MAX WT?XXXXX .....	20
CONT B MAX WT?XXXXX .....	20
CONT C MAX WT?XXXXX .....	20
CONT FILL CYCLE? Y .....	12
CONTAINER: X .....	53
CONTAINER? X .....	53
CPU FAILURE D .....	2
CPU FAILURE P XX .....	2
CTPZ COMM FAULT! .....	13
CYCLE SLOW .....	105
CYCLE TIME? XXXX .....	62
DATE? MM/DD/YY .....	33
DENSITY X.XXXX .....	54
DRIBBLE? XXXXX .....	57
DRUM HIT FAULT .....	96
DRUM HIT WT? XX .....	19
DRUM LOG REPORT? Y .....	113
DRUM LOG TABLE FULL .....	102
DRUM READY .....	103
ENABLE CONSEC #? X .....	25
ENABLE CORRECTION?X .....	33
ENABLE DRUM LOGS? X .....	32
ENABLE ID ENTRY? N .....	24
ENABLE ID SELECT? X .....	31
ENABLE SUM? X .....	27
ENBL PROD ORDERS? X .....	29
END ORD? XXXXXXXXXXXX .....	85
FAST FILL 97 .....	
FAST/SLOW? Y .....	63
FILLER NO? XX .....	19

FLOW DELAY?	XX	21
FLOW FLT CNTR?	XX	20
FORCE COLD START?	N	2
FULL TOLRANCE?	XXXX	61
GALLONS	XXX.X	54
GENERAL SETUP?	Y	17
GLOBL CNSEC?	XXXXXX	26
HOST BAUD RATE	XXXX	36
HOST DATA BITS	X	37
HOST DROP ADDRES	XX	8
HOST PARITY (EON)	X	37
HOST PORT SETUP?	Y	35
I.D. XXXXXXXXXXXX		114
I/O 1:x 2:x 3:x 4:x		79
ID DELETED		52
ID LENGTH	XX	25
ID NOT FOUND		15, 82, 87, 88, 109, 111
ID PROMPT	XXXXXXXXX	24
ID SETUP ERROR!		68
ID SETUP REPORT		108
ID TABLE FULL		50
ID?	XXXXXXXXXXXX	108, 110
ID?	XXXXXXXXXXXXXXXX	80
ID'S ENTERED	XXX	114
INPUT NUMBER?	XX	75
INPUT XX	ON	76
INPUT XX	OFF	76
INVALID PASSWORD		17, 49, 70, 90
INVALID SETTING		7
LANCE FAULT		15, 96, 103, 106
LANCE NOT DOWN		105
LANCE NOT UP		14
LITERS	XXX.X	55
LOWERING LANCE		95, 106
MANUAL MODE		14
MAX EMPTY WT?	XXXX	
	SURFACE ONLY	61
MAX NO. OF DRUMS?	X	67
MIN EMPTY WT?	XXXX	60
MIN FLOW FAULT		106
MIN FLW RATE?	XXXXX	65, 66
MULTIPLE DRUM		6
NEW ID?XXXXXXXXXXXX		51
NEW PASSWORD?	N	18
NEW PNTR LITERAL?	N	45
NO. DRUMS ORDERED	XX	84
NORMAL	7	
NUMBER OF DRUMS?	X	82
OFF HIGH	XXXXXX	99
OFF LOW	XXXXXX	100
ORDER NO.	XXXXXXXXXX	83
ORDER NOT COMPLETE!		52
ORDER TOL	XXXXXX	85

OUTPUT NUMBER? XX .....	78
OUTPUT XX ON .....	78
OVER MAX WEIGHT! .....	56
OVER MAXIMUM WT .....	95
PASSWORD PROTECT? X .....	28
PASSWORD? 17, 49, 69, 89	
PASSWORD? XXXXXX .....	18
PNTR BATCH# POS 000 .....	43
PNTR BAUD RATE XXXX .....	40
PNTR BC BGN POS 000 .....	43
PNTR BC CHR POS 000 .....	43
PNTR CNBYID POS 000 .....	43
PNTR DATA BITS X .....	41
PNTR DATE POS 044 .....	43
PNTR DUPLCT POS 058 .....	43
PNTR FILLER POS 000 .....	43
PNTR GRS WT POS 000 .....	43
PNTR ID PMT POS 000 .....	43
PNTR ID POS 006 .....	43
PNTR LITERAL CHAR X .....	47
PNTR LITERALS CLRD .....	46
PNTR LITRL POS XXX .....	47
PNTR NET WT POS 018 .....	42
PNTR NET WT POS 020 .....	43
PNTR ORDER# POS 000 .....	43
PNTR OT FLG POS 019 .....	43
PNTR PARITY (EON) X .....	41
PNTR SETPNT POS 000 .....	43
PNTR SUM POS 000 .....	43
PNTR TARE W POS 000 .....	43
PNTR TIME POS 037 .....	43
PNTR UNIT POS 027 .....	43
PNTR VAR ID POS 000 .....	43
POSITION FAULT .....	107
PPPPPPPP XXXXXXXXXXXX .....	88
PRD ID?XXXXXXXXXXXX .....	50
PReact? XXXXX .....	58
PRINT ORDER TOTS? X .....	30
PRINT SETTINGS? Y .....	48
PRINTER SETUP? Y .....	38
PRINTER TEST? Y .....	73
PRINTING 48, 74	
PRINTING ID LIST .....	114
PRINTING XXX OF YYY .....	113
PROD SUMMARY REP? Y .....	110
PRTING XXXXXXXXXXXX .....	109, 111
RAISE DUTY CYCL? XX	
SUB-SURFACE ONLY .....	67
RAISE TIME? XX .....	22
RAISING LANCE .....	14, 102
RAM TEST? Y .....	71
READING SCALE .....	3
REJECT? Y .....	101

ROM TEST?	Y	70
RUN ID:XXXXXXXXXX		10
SBM050_	YYYYYY	2
SCALE FAULT		3, 72, 104
SCALE MOTION		98
SCALE OVER CAP		73, 104
SCALE SETUP CHANGE		3
SCALE TARE FAULT		105
SCALE TEST?	Y	72
SCALE WT.	XXXXXX	73
SELECT HOST?	X	35
SELECT PRINTER?	X	38
SELECT RUN ID		80
SETPOINT	XXXXXX	53
SETPOINT?	XXXXXX	56
SETTLING	96	
SINGLE DRUM		6
SLOW FILL	97	
SLOW FILL/PRIME LNC		97
SLOW TIME 1?	X.XX	23
SLOW TIME 2?	X.XX	23
SLOW/FAST/SLOW?	Y	63
SLW FILL WT?	XXXXXX	64
STOPPD - PUSH START		13
STORING DATA		101
SUBSURFACE		5
SUM	XXXXXXXXXX	89
SURFACE	5	
SWITCH SETUP CHANGE		4
TEST CTPZ BOARD?	X	79
TEST FAILED		71
TEST FAILED	XX	70
TEST INPUTS?	Y	74
TEST MODE	69	
TEST OUTPUTS?	Y	77
TEST PASSED		71, 72
TESTING	70, 71	
TIME?	HH:MM:SS	34
TOL. DELAY?	XX	22
TOLERANCE CHECK		94, 98
TOLERANCE DELAY		98
TOO MANY DRUMS SLCT		107
TOTALS EXIST		52
UNDER MINIMUM WT		95
WAITING FOR PRINTER		102
XXXXXXXXXXXX		94
XXXXXXXXXXXX	N OF T	94



FOR YOUR NOTES:

