


702 Standalone RAM 0003 Addendum

Setup: Plug the RS422 serial interface cable into the labeler port on the scale controller. Set the Peripheral Configuration in the scale controller unit setup to 606. Set the Security Setpoints in the scale controller unit setup.

Operation: With the Convey\Apply switch in the Apply position, the scale controller sends an apply or a do not apply command to the 702 control board. If the interface cable is not connected, the 702 will operate in the continuous operation mode.

Note: The 702 RAM 0003 must use the A rev PCB. The A rev PCB has 8 dip switches as opposed to the 4 dip switches on the original PCB. The switch assignments are the same. Positions 5 - 8 are not used.



Wiring Diagram