

PS

Shipping Scales

PS60G

PS60U

PS6L

PS30

PS3L

Technical/Operator Manual

For PS units with **GEOCAL™**

©Mettler-Toledo, Inc. 2003


No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose without the express written permission of Mettler-Toledo, Inc.

U.S. Government Restricted Rights: This documentation is furnished with Restricted Rights.

**FOLD THIS FLAP
FIRST**



NO POSTAGE
NECESSARY
IF MAILED IN
THE UNITED



**BUSINESS REPLY
MAIL**

POSTAGE WILL BE PAID BY ADDRESSEE

Mettler-Toledo, Inc.
Retail Quality Manager - MTWR
P.O. Box 1705
Columbus, OH 43216
USA



Please seal with tape.

INTRODUCTION

This publication is provided as a guide for individuals in the operation, use, and care of this METTLER TOLEDO product.

Further information or assistance regarding this product may be obtained by writing to:

METTLER TOLEDO
1900 Polaris Parkway
Columbus, OH 43240-2020
(614) 438-4400

WARNING!

This equipment generates, uses, and can radiate radio frequency energy and if not installed and used properly, i.e., in accordance with the instructions manual, may cause harmful interference to radio communications. It has been tested and found to comply with the limits for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area may cause interference, in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.

**METTLER TOLEDO RESERVES THE RIGHT TO MAKE REFINEMENTS OR
CHANGES WITHOUT NOTICE.**

PRECAUTIONS

READ this manual BEFORE operating or servicing this equipment.

FOLLOW these instructions carefully.

SAVE this manual for future reference.


DO NOT allow untrained personnel to operate, clean, inspect, maintain, service, or tamper with this equipment.

ALWAYS DISCONNECT this equipment from the power source before cleaning or performing maintenance.


CALL METTLER TOLEDO for parts, information, and service.



Note: If the unit has been stored or transported in below freezing temperatures, allow the unit to warm up to room temperature before turning on AC power.

	 WARNING
	DISCONNECT ALL POWER TO THIS UNIT BEFORE INSTALLING, SERVICING, CLEANING, OR REMOVING THE FUSE. FAILURE TO DO SO COULD RESULT IN BODILY HARM AND/OR PROPERTY DAMAGE.

	 CAUTION
	OBSERVE PRECAUTIONS FOR HANDLING ELECTROSTATIC SENSITIVE DEVICES.

	 WARNING
	ONLY PERMIT QUALIFIED PERSONNEL TO SERVICE THIS EQUIPMENT. EXERCISE CARE WHEN MAKING CHECKS, TESTS AND ADJUSTMENTS THAT MUST BE MADE WITH POWER ON. FAILING TO OBSERVE THESE PRECAUTIONS CAN RESULT IN BODILY HARM.

	 WARNING
	FOR CONTINUED PROTECTION AGAINST SHOCK HAZARD, CONNECT TO PROPERLY GROUNDED OUTLET ONLY. DO NOT REMOVE THE GROUND PRONG.

 CAUTION
BEFORE CONNECTING OR DISCONNECTING ANY INTERNAL ELECTRONIC COMPONENTS OR INTERCONNECTING WIRING BETWEEN ELECTRONIC EQUIPMENT, ALWAYS REMOVE POWER AND WAIT AT LEAST THIRTY (30) SECONDS BEFORE ANY CONNECTIONS OR DISCONNECTION'S ARE MADE. FAILURE TO OBSERVE THESE PRECAUTIONS COULD RESULT IN DAMAGE TO OR DESTRUCTION OF THE EQUIPMENT, OR BODILY HARM.

CONTENTS

1	Introduction.....	1-1
	Standard Features.....	1-2
	Optional Accessories.....	1-2
	Specifications.....	1-3
	Physical Dimensions	1-4
	Power Requirements	1-5
	Environmental Requirements.....	1-5
	Standards Compliance	1-5
	AC Power Line voltage Variation.....	1-5
	RFI Susceptibility	1-6
	Electrical Interfaces	1-6
2	Installation and Calibration	2-1
	Unpacking and Setup	2-1
	Installation.....	2-1
	Basic Information	2-4
	The Display	2-4
	Keys and Navigation.....	2-4
	Initial Calibration using GEOCAL™.....	2-6
	Power up Sequence	2-8
	Full Calibration.....	2-8
	Metrological Seal Installation.....	2-12
	USB Installation.....	2-12
	Windows 98	2-12
	Windows 2000 / XP	2-13
3	Configuring the Setup Parameters.....	3-1
	Basic Information	3-1
	Program Block Access	3-1
	Exit Setup.....	3-1
	Configuring Setup Parameters	3-2
	Push Button Zero Program Block.....	3-2
	Zero Cursor Program Block.....	3-3
	Power-up Unit Program Block.....	3-3
	Build Program Block	3-3
	Alternate Units Program Block.....	3-4
	Mode Program Block	3-4
	Filter Program Block.....	3-5
	Baud Program Block.....	3-5
	ASCII Program Block	3-5
	Parity Program Block.....	3-6
	Stop Program Block	3-6
	Protocol Program Block.....	3-6
	Sleep Program Block	3-7
	GEOCAL™ Program Block	3-7
	Calibration Program Block	3-7
	End Program Block.....	3-8

4	Operating Instructions	4-1
	Keypad and Display.....	4-1
	Operator Functions	4-1
	Parcel Weighing	4-1
	Unit Switching	4-2
	Zeroing the Scale with an Empty Container	4-2
	Repowering from Sleep.....	4-3
5	Service and Maintenance	5-1
	Cleaning and Regular Maintenance	5-1
	Troubleshooting.....	5-1
	Error Code Section.....	5-2
	Wall Transformer.....	5-2
	Main PCB.....	5-3
	Blank or Half Display	5-3
	No Keypad Interaction	5-3
	Indicator Locked	5-4
	Load Cell Replacement	5-4
	Installing the Battery Kit	5-4
	Installing the Base Mount Display	5-8
	Installing the Ball Top Transfer Platter	5-8
6	Parts and Accessories	6-1
	PS60/PS6L/PS60U Scale Parts.....	6-2
	PS6L Parts List	6-3
	PS30/PS3L Scale Parts	6-4
	PS30 Parts List.....	6-5
	Weight Display Parts.....	6-6
	Appendix A: Host Interface	1
	Communication Parameters	1
	Protocols	1
	ASCII Characters and Conversions.....	2
	Toledo Protocol Host Commands	4
	Scale Status Byte Format	5
	Scale Confidence Byte Format	5
	Calibrate Using Host Interface.....	6
	Configure Scale Parameters Using Host Interface	7
	Appendix B: USB Host Interface.....	1
	References.....	1
	Hardware.....	1
	Electical Connections	1
	Power	2
	Protocol.....	2

1

Introduction

Thank you for purchasing a PS shipping scale from METTLER TOLEDO. The legal-for-trade model of the PS60 shipping scale is a low-profile, 150 × 0.05 lb (60 × 0.02 kg) capacity scale designed to meet the needs of the legal-for-trade parcel/manifest markets. The PS60 also features an auto-ranging capacity of 0 - 60 lb × .02 lb / 60 - 150 lb × .05 lb, as well as a weight classifying model with the same capacity as the auto-ranging model. Both are NTEP approved. (See Chapter 3 for a complete list of builds.)

The legal-for-trade model of the PS6L shipping scale is very much like the PS60. It has an auto ranging capacity of 0-7 lb x 0.1oz / 7-70 lb x 0.2 oz / 70-149 lb x 0.5 oz.

The model PS30 is a general purpose shipping scale with builds of 0-70 lb x 0.05 lb (1400d) / 0-30 x 0.02 kg (1500d) for the US and 0-30 x 0.01 kg for Canada. The PS30 is capable of communicating in several protocols for major shipping carriers and competitors in addition to having a Mettler-Toledo protocol.

The model PS3L is a letter and parcel version to the PS30. It has much higher resolution at lower weights and is a multi-interval and weight classifier scale. This Product is intended for the US, and Canadian markets with agency approval.

The PS60U are capable of communication either RS232 or USB. For USB, the PS scale uses the POS HID scale protocol.

The PS, like all METTLER TOLEDO products is designed for maximum durability and reliability in even the most demanding application environments. The PS is manufactured in one of METTLER TOLEDO's ten ISO 9000 certified facilities so you are assured to receive a high-quality product.

The scale is designed for use in parcel shipping and other light industrial environments. This unit is not intended for washdown or hazardous area operation, nor for operation in environments of extreme dust, heat, cold, or humidity.

In the unlikely event you experience difficulties operating your scale, please contact your local distributor or METTLER TOLEDO representative from whom you purchased the scale.

Standard Features

The following are standard features built into each PS shipping scale.

- 100 kg (PS6) or 45 kg (PS3) capacity “Eagle+” load cell
 - Die-cast aluminum base and sub-platter
 - Stainless steel or Plastic platter
 - RS-232 serial interface to the scale base
 - USB interface (PSXXU only)
 - Sleep mode for energy conservation (PSXXG only)
-

Optional Accessories

- 12 VDC, 60 mA power supply unit (wall-mount transformer)
- D-cell alkaline battery KOP (for some models)
- Car lighter jack
- Ball transfer top platter
- 0270, 2-key weight indicator base mount display with 12 in. cable
- Tower display with 14 ft cable
- Wall mount display with 14 ft cable
- Dual Wall mount displays with 6 ft cable

Specifications

The PS shipping scale conforms to and operates best within the specifications described in this section.

Physical Dimensions

- Base dimensions: 290 mm × 335 mm (11.42 in. × 13.19 in.)
- Platter dimensions: 300 mm × 350 mm (11.81 in. × 13.78 in.)
- Max. dimensions w/indicator: 358 mm × 350 mm (14.09 in. × 13.78 in.)
- Height with platter: 80 mm (3.15 in.)
- Height with platter and battery: 90 mm (3.54 in.)
- Weight with display: 6.65 kg
- Weight with display and battery: 7.75 kg
- Shipping weight: 10 kg




Figure 1-a: PS60 / PS6L Dimensions

- Base dimensions: 290 mm × 335 mm (11.42 in. × 13.19 in.)
- Platter dimensions: 300 mm × 350mm (11.81 in. × 13.78 in.)
- Maximum dimensions w/indicator: 358mm x 350mm (14.09in. x 13.71.in.)
- Height with platter: 80 mm (3.15 in.)
- Height with platter and battery: 90 mm (3.54 in.)
- Weight (w/display, non-battery): 6.65 kg
- Weight (w/display, w/battery): 7.75 kg
- Shipping weight: 10 kg




Figure 1-b: PS30/PS3L Dimensions

Power Requirements

The PS operates over an input voltage range of 7.5 to 12 VDC (at 60 mA).

- An external 9 VDC voltage converter supplies power to the PS.
- An optional D-cell battery KOP can be used to power the scale continuously for a minimum of 40 hours. Battery life is extended with the on/off switch in the “off” position.
- An optional 12 VDC Car Lighter Jack Cable can power the PS.
- The PSXXU scale can be powered by the PC through the USB port.

Environmental Requirements

The PS60 operating range is -10° to $+40^{\circ}\text{C}$ ($+14^{\circ}\text{F}$ to $+104^{\circ}\text{F}$) at 10 to 90% relative humidity, non-condensing. The PS30 and PS3L operating range is 0° to 40°C ($+32^{\circ}\text{F}$ to $+104^{\circ}\text{F}$) at 10 to 90% relative humidity, non-condensing. The PS6L operation range is $+10^{\circ}$ to $+40^{\circ}\text{C}$ at 10 to 90% relative humidity, non-condensing. The shipping and storage temperature range is -20° to $+60^{\circ}\text{C}$ (-4°F to $+140^{\circ}\text{F}$) at 0 to 95% relative humidity, non-condensing.

The scale is designed for use in parcel shipping and other light industrial environments. This unit is not intended for washdown or hazardous area operation, nor for operation in environments of extreme dust, heat, cold, or humidity.

Standards Compliance

The PS60 meets or exceeds USA NIST HB-44, Australian NSC, Canadian MC, and international OIML requirements for a 3000 division, Class III parcel scale.

The PS30 meets or exceeds USA NIST HB-44 for a 1400 division Class III parcel scale, and Canadian MC requirements for a 3000 division Class III parcel scale.

The PS6L meets or exceeds USA NIST HB-44 requirements for a 4800 division, Class III parcel scale.

The PS3L meets or exceeds USA NIST HB-44 requirements for a 0-71b / 7-70lb (1120d/5600d) Class III multi-interval scale and Canadian MC requirements for a 0-15kg / 15-30kg (3000d / 3000d) Class III multi-interval scale.

AC Power Line Voltage Variation

The PS meets USA NIST HB-44, Australian NSC, and Canadian MC line voltage variation specifications as listed in the following table:

Line Voltage Variation Specification	AC Line Voltage			Line Frequency in Hz		
	Minimum	Nominal	Maximum	Minimum	Nominal	Maximum
NIST HB-44	100	120	130	59.5	60	60.5
Australian NSC	102	120	132	58.8	60	61.2
Canadian MC	108	120	132	58.8	60	61.2

RFI Susceptibility

The PS60 meets the requirements of the European Norm. 45501 for RFI susceptibility as listed below with a maximum of one display increment of change when calibrated for recommended builds.

Radio Interference Frequency	Field Strength
26-1000 MHz	3 volts/meter

Electrical Interfaces

The PS scale's single board construction has a load cell connector (10 position ZIF), display connector (8 position phone jack), RS-232 interface (9-Pin DSUB), and an input power jack. The following interconnection diagram describes wiring connections for the PS shipping scale.

The PS can function as a peripheral device to a host through the RS-232 serial port. Calibration and setup can be done using the Host Interface command set. For detailed instructions describing calibration and setup using the Host Interface, please refer to the Appendix at the end of this manual.




Figure 1-c: PS60G/PS30 Electronic Interface Diagram




Figure 1-d: PS6L Electronic Interface Diagram




Figure 1-e: PS60U Electronic Interface Diagram



FOR YOUR NOTES

2

Installation and Calibration

This chapter gives detailed instructions and important information you will need to install the PS successfully. Please read this chapter thoroughly before you begin installation. This information is also covered in the PS Operator Instructions.

Unpacking and Setup

If you choose to dispose of the package, please recycle the materials.
The packaging is recyclable natural fiber with biodegradable adhesives.

Please inspect the package as the carrier delivers it.

- If the shipping container is damaged, check for internal damage and file a freight claim with the carrier if necessary.
- If the container is undamaged, open the box, remove the scale, and place it on a solid, flat surface.

Please keep the packing material and shipping insert in case the scale needs to be returned to METTLER TOLEDO. The PS is a precision instrument and may be permanently damaged if not shipped in factory-approved packaging.

Typical package contents for the PS include:

- PS Shipping Scale
- Installation Instructions
- Product Documentation CD
- Power Supply
- Optional Accessories
- USB Cable (PSXXU)
- RS232 Cable

Installation

The proper environment enhances the operation and longevity of the scale.

The PS shipping scale is fully assembled at the factory, and you should not have to assemble the unit. To install components other than those installed at the factory, please refer to Chapter 5 Service and Maintenance.

1. Locate a suitable environment for the scale. Refer to Chapter 1 for environmental specifications.
2. Remove the packaging material from each side of the scale. Remove the scale by grasping the bottom sides of the scale. **Do not** lift the scale by grasping the sub-platter.
3. Place the scale on a sturdy, level surface and remove any protective shipping materials under the platter.

- Level the scale by turning the adjustable feet on the bottom of the unit. When the bubble in the bubble indicator is within the circle, the PS is level (see Figures 2-a, 2-b,). The feet must be adjusted so the scale does not rock.






Figure 2-a: PS,Leveling Feet



Incorrect
Bubble is not
within circle



Correct
Bubble is
within circle

Figure 2-b: Level Indicator

- Unpack the power supply and plug it into the power jack in the scale base. The jack is recessed on the bottom of the base toward the center front. Plug the line cord into a **properly grounded** AC power outlet. Figure 2-c illustrates proper power supply connection. Figure 2-d illustrates proper power supply connection for USB models.

	WARNING!
	AC power sources must have proper short circuit and over current protection in accordance with local and national electrical regulations. Failure to provide this may result in bodily injury and/or property damage.

NOTE: Inside of barrel is positive.




Figure 2-c: Power Cable Connection




Figure 2-d: USB Connections


Basic Information

The following sections describe some basic information that you will need to know as you install, calibrate, and use the PS in normal operating mode.


The Display

The PS's display consists of six digits and five cursor positions. Each digit is composed of seven segments and is 12 mm high. The PS's cursor can appear above one or more of the legends printed on the display to indicate the current unit, stable conditions, zero, or options in setup mode.

The display area also indicates over-capacity and under-capacity conditions. Over- and under-capacity are indicated on the display as follows:



Over Capacity



Under Capacity

Figure 2-e: Over/Under Capacity Display

Keys and Navigation

The PS keypad contains a UNITS key and a ZERO key:




Figure 2-f: UNITS and ZERO Key

The functions for each key **in normal operating mode** are as follows:

- **UNITS**—Press UNITS to switch between the selected main units and alternate units.
- **ZERO**—Press ZERO to zero an empty scale. The reading must be within 2% of the calibrated zero.


If the scale is in Sleep mode (as defined in the Sleep program block), press ZERO to “awaken” the scale. The scale then goes through its normal power-up sequence and returns to normal operating mode.

The functions for each key **in setup mode** are as follows:

- **UNITS**—Press and hold UNITS for up to 8 seconds to enter setup mode. When a program block option is displayed for selection, press UNITS to confirm the selection.
- **ZERO**—Press ZERO to scroll through a list of parameter options.

Initial Calibration using GEOCAL™

The PS shipping scale must be calibrated when the unit is initially installed to correct for local gravity variations thereby ensuring accurate weighing results. If the GEOCAL™ capabilities of your PS unit have been activated, the unit has been pre-calibrated from the factory. If this is the case, the first time the PS is powered up from the factory it should display the **Geo in** prompt as follows:




This indicates that you must select the code for your location. The latitude and altitude of your location both effect gravity and the calibration of your scale. Therefore, it is important to select the proper code. Refer to the table below in order to determine the code for your area. If your location is not listed select closest one.


GEOCAL™ Location Codes					
State	Code	State	Code	State	Code
Alabama		Kansas	14	North Dakota	18
Birmingham & North	13	Kentucky	14	Ohio	
South of Birmingham	12	Louisiana	12	Akron & North	16
Alaska	See map	Maine	18	South of Akron	15
Arizona		Maryland	15	Oklahoma	13
Phoenix & North	12	Massachusetts	17	Oregon	
South of Phoenix	11	Michigan		Salem & North	18
Arkansas	13	Northwest of Lake Michigan	18	Between Oakridge & Salem	17
California	See map	Southeast of Lake Michigan	17	South of Oakridge	16
Colorado		Minnesota	18	Pennsylvania	16
Denver & North	13	Mississippi		Rhode Island	16
South of Denver	12	Kosciusko & North	13	South Carolina	13
Connecticut	16	South of Kosciusko	12	South Dakota	17
Delaware	15	Missouri		Tennessee	13
Florida		North of Springfield	15	Texas	
West Palm Beach & North	11	Springfield & South	14	Northeast of Colorado River	12
South of West Palm Beach	10	Montana		Southwest of Colorado River	11
Georgia	12	Helena & North	18	Utah	13
Hawaii	9	South of Helena	17	Vermont	17
Idaho		Nebraska	15	Virginia	14
North of Salmon River Mtns	17	Nevada	13	Washington, DC	15
South of Salmon River Mtns	16	New Hampshire	17	Washington State	18
Illinois		New Jersey	16	West Virginia	15
Bloomington & North	16	New Mexico	11	Wisconsin	
South of Bloomington	15	New York		Green Bay & North	18
Indiana		Albany & North	17	South of Green Bay	17
North of Indianapolis	16	South of Albany	16	Wyoming	
Indianapolis & South	15	North Carolina		North of Casper	15
Iowa		Raliegh & North	14	Casper & South	14
North of Des Moines	17	South of Raliegh	13		
Des Moines & South	16				

Alaska

Maps provided for residents of
Alaska and California only.



California



Locations near a
boundary may enter
either code.

The sequence for selecting your GEOCAL™ code is as follows:

1. Press the ZERO key to display the first code option and continue pressing it to scroll through all of the available codes.
2. Press the UNITS key to select the code for your location. The display will then prompt **done**. Press the UNITS key again to restart the scale.


Power-up Sequence

The PS goes through a power-up sequence each time power is applied or the scale is brought from its power-down ("sleep") state. The scale performs a diagnostic test on its ROM and RAM, then proceeds to normal operating mode. The power-up sequence is as follows:

1. All segments of the display characters are activated. This verifies operation of all segments.
2. The scale displays the software part number followed by the software revision status.
3. The scale then captures zero (if the zero reading is within $\pm 10\%$ calibrated capacity on power-up) and is ready for normal operation.

To "awaken" the PS whenever it is in sleep mode, press the ZERO key.

Full Calibration



You can calibrate the PS scale using the UNITS and ZERO keys, or you can calibrate the unit remotely from a computer terminal through its Host interface. Details on calibration using a Host Interface are given in the Appendix at the end of this manual.

To calibrate the PS at the scale:

1. Disconnect the power from the scale.
2. Remove the platter, break the legal-for-trade seal (if present), and remove the PCB cover plate to give access to the PCB.
3. Remove the calibration jumper (W1 in Figure 2-g / 2-h).

Note: PCB of PS6L looks slightly different but still has a Mlock jumper, W3.




Figure 2-g: CAL Jumper on Main PSXXG PCB




Figure 2-h: CAL Jumper on Main PSXXU PCB

This prompt only appears if the calibration jumper is removed.

4. Connect the power to the scale.
5. Enter the setup mode by pressing and holding the UNITS key for up to eight seconds until the message **Setup** is displayed. Release the UNITS key.
6. Press the UNITS key several times until the **Cal** prompt appears, then press ZERO to display YES or NO. Select Yes to calibrate or select No to abort calibration. If Yes, press UNITS to begin the calibration process.
7. Press UNITS to select the displayed approval option.
8. Press UNITS until the **Alt** prompt appears, then press ZERO to display the desired primary and secondary units. Select from the following options: (Not an option on PS6L)
 - kg/kg
 - lb/lb
 - lb/kg
 - kg/lb

Calibration units are selected according to the scale build. For example, if a scale has a kilogram build, select **kg** as the primary unit. Alternately, if the scale has a pound build, select **lb** as the primary unit.

9. Press UNITS to select the displayed units option.

If a different capacity/increment option is selected, the Cal prompt automatically appears.

10. Press UNITS until the **Build** prompt appears, then press ZERO to display the desired capacity/increment option. Capacity/increment options include:

	PS60/PS60U
Display Prompt	Build
60-01	60 x 0.01 kg
150-02	150 x 0.02 lb
60-02	60 x 0.02 kg
150-05	150 x 0.05 lb
100-05	100 x 0.05 kg
250-1	250 x 0.1 lb
50-01	50 x 0.01 kg
100-02	100 x 0.02 lb
60-Mi	60 x 0.01 / 0.02 kg Multi-Interval
150-Mi	150 x 0.02 / 0.05 lb Multi-Interval
70-Mi	70 x 0.02 / 0.05 kg Multi-Interval

PS6L

Note: The PS6L has only one Capacity/Increment build: 0-10 lb x 0.1 oz, 10-70 x 0.2 oz, 70-150 lb x 0.5 oz.

PS30/PS3L

Display Prompt	Build
30-02	30 x 0.02 kg
70-05	70 x 0.05 lb
30-01	30 x 0.01 kg
30-Mi	0-15 / 15-30 kg Multi-Interval
70-Mi	0-7 / 7-70 lb Multi-Interval
70-Mo	0-7 / 7-70lb/oz. Multi-Interval

11. Press UNITS to select the displayed capacity/increment option.
12. Press UNITS until the **CAL** prompt appears, then press ZERO to display Y or N. Select Y(es) to calibrate or select N(o) to abort calibration. If Y(es), press UNITS to begin the calibration process.
13. At the **Empty** prompt, set the empty platter on the sub-platter, then press UNITS.
14. At the 50 lb, 20 kg, 125 lb, or 50 kg prompt, place on the platter a test weight equaling **one-third of the scale's capacity** (50 lb or 20 kg), or **half of the scale's capacity** (125 lb or 50 kg) then press UNITS. The scale automatically determines a span factor then indicates **Done** while the calibration values are saved.
15. Disconnect the power from the scale. At the **Empty** prompt, insure that the empty platter is on the sub-platter, then press UNITS.
16. Replace the calibration jumper (W1), then reassemble the scale.

The PS is now calibrated and ready to configure to your needs. Chapter 2 of this manual gives setup and configuration details.

You can change the build from straight weighing to weight classifying as follows:

1. Enter setup mode by pressing and holding the UNITS key for up to eight seconds.
2. Press the UNITS key to display the Mode menu.
3. Press ZERO to display **Classifr**.
4. Press UNITS to display the End menu.
5. Press ZERO to display **Save**.
6. Press UNITS to return to normal operating mode.

Metrological Seal Installation

If a wire seal is required for W & M requirements, the PS can be sealed after calibration and setup by installing a wire seal on the Main PCB access cover, as shown in Figure 2-i.




Figure 2-i: Wire Seal Installation

USB Installation

USB scale connection is very automatic. When you connect the scale to your PC's USB port, the PC will automatically sense the scale. Different versions of Microsoft's operating systems will vary the set-up slightly.

*** When using USB, the power adapter is not necessary. The scale will be powered through the USB cable.***

Windows 98

The set-up for the USB drivers for Windows 98 is fairly automatic but MAY require some interaction with dialog boxes to complete. You may be prompted to insert your original Windows 98 CD in order to find the proper drivers. Most Windows 98 systems will react just like Windows 2000 / XP. Here are the messages you may see using Windows 98.

A dialog box stating “New Hardware Found” will appear. Immediately, the PC will begin to “Build Driver Information Database”.

1. Once this is complete, a “Add New Hardware” Wizard will appear. Select the bottom choice of “Display a list of all the drivers in a specific location, so you can select the driver you want”.
2. If the drivers are not immediately found, insert your Windows 98 CD and locate the proper directory.
3. The “USB Human Interface Device” will appear as the default driver.
4. Click on “OK” and then “Finish”

Windows 2000 / XP

This is more automatic. There are no choices to make. The PC will automatically recognize the scale and install the appropriate driver. With no human interaction required



FOR YOUR NOTES

3

Configuring the Setup Parameters

This chapter discusses basic information related to PS configuration and specific instructions on configuring each program block and operating parameter.

Basic Setup Information

The following sections describe some basic information that you will need to know as you configure the setup parameters for the PS.

Program Block Access

The PS's operational parameters are configured in setup mode through a series of program blocks. The program blocks are accessed as follows:

1. Press and hold the UNITS key for up to eight seconds until the message **Setup?** is displayed. Release the UNITS key. When released, the PS displays either the **Pb 0** or **Alt** prompt indicating the first program block.

Exit Setup

Exit setup mode as follows:

1. Press UNITS to display the **End** prompt.
2. Press ZERO to display the desired exit option. Exit options include:
 - No—Do not exit setup mode at this time.
 - Save—Save all changes program block parameters then exit setup mode.
 - Abort—Exit setup mode but do not save any changes made in this session.
 - Various Defaults—Reset all program block parameters to a pre-specified set of values, then exit setup mode. For details, refer to the End Program Block section.
3. Press UNITS to carry out the displayed option. The PS automatically exits setup mode and returns to normal operating mode unless No is selected.

There are two alternate ways to exit the setup mode:

- The scale automatically leaves the setup mode after it has been calibrated.

- Disconnect the power from the scale. Changes **will not** be saved.

Configuring Setup Parameters

This section describes the program blocks that govern normal operation including:

- Push Button Zero *
- Zero Cursor *
- Power-up Units *
- Build *
- Alternate Units
- Mode *
- Filter
- Baud
- ASCII
- Parity
- Stop Bits
- Protocol
- Sleep
- GEOCAL™*
- Calibration *
- End

This is the order that they appear in the prompts.

* The Push Button Zero, Zero Cursor, Power-up Units, Capacity/Increment (Build), Display Mode, GEOCAL™ Activation, and Calibrate program blocks are hidden in setup mode when the Metrology PCB jumper (W1) is in place. These program blocks are used only when the jumper is removed and the scale is being calibrated. Please refer to Chapter 2 for calibration details.

The PS can also be configured remotely through the METTLER TOLEDO Host Interface. Details for configuring the scale using the Host Interface are given in the Appendix at the end of this manual.

To configure the PS at the scale, enter the setup mode by pressing and holding the UNITS key for up to eight seconds until the message **Setup** is displayed. Release the UNITS key, then configure the PS program block parameters.

Push Button Zero Program Block

The Push Button Zero program block lets you configure the range within which the PS can capture zero. The only push button zero capture range currently supported is $\pm 2\%$. (Metrology PCB jumper must be removed.)

To configure the program block:

1. Press UNITS to display the **Pb 0** prompt, then press ZERO.
2. Press UNITS again to accept the 2 pct option. The PS continues to the Zero Cursor program block.

Zero Cursor Program Block

The Zero Cursor program block lets you enable or disable the center of zero indicator on the PS. (Metrology PCB jumper must be removed.)

To configure the program block:

1. Press UNITS to display the **0 CurS** prompt, then press ZERO.
2. Press ZERO to display the desired approval setting, enable or disable.
3. Press UNITS to accept the displayed option. The PS continues to the Power-up Unit program block.

Power-up Unit Program Block

The Power up Unit program block lets you select which units will be active on the PS upon startup. This program block will effect the build options that are seen in the Build program block.

To configure the program block:

1. Press UNITS to display the **units** prompt, then press ZERO.
2. Press ZERO to display the desired approval setting, pounds or metric.
3. Press UNITS to accept the displayed option. The PS continues to the Build / Alternate Units program block.

Build Program Block

The build program block lets you chose a capacity and increment size setting for the product based on the model you have purchased and the power-up units selection. (Metrology PCB jumper must be removed.)

To configure the program block:

1. Press UNITS to display the **buiLd** prompt, then press ZERO.
2. Press ZERO to display the desired approval setting. Option may vary as follows:

Standard PS60, 3000d

<u>Power-up units = Pounds</u>		<u>Power-up units = Metric</u>	
150-02	150 x 0.02 lb.	60-01	60 x 0.01 kg
150-05	150 x 0.05 lb. *	60-02	60 x 0.02 kg
100-02	100 x 0.02 lb.	50-01	50 x 0.01 kg
		70-ni	0-50 x 0.01 kg, 50-70 x 0.05 kg

Multi-interval PS60, 2x3000d

<u>Power-up units = Pounds</u>		<u>Power-up units = Metric</u>	
150-02	150 x 0.02 lb.	60-01	60 x 0.01 kg
150-05	150 x 0.05 lb.	60-02	60 x 0.02 kg
100-02	100 x 0.02 lb.	50-01	50 x 0.01 kg
150-ni	0-60 x 0.02 lb., 60-150 x 0.05 lb. *	60-ni	0-30 x 0.01 kg, 30-60 x 0.02 kg
		70-ni	0-50 x 0.01 kg, 50-70 x 0.05 kg

PS6L

<u>Power-up units = Pounds</u>	
149-ni	0-10 lb. x 0.1 oz, 10-70 lb. x 0.2 oz, 70-150 lb. x 0.5 oz *
150-n5	0-5 x 0.005 lb., 5-25 x 0.05, 25-150 x 0.1 lb.

Multi-interval PS30/PS3L

<u>Power-up units = Pounds</u>		<u>Power-up units = Metric</u>	
70-05	70 x 0.05 lb.	30-01	30 x 0.01 kg
70-Mi	0-7 / 7-70 lb Multi-Interval	30-02	30 x 0.02 kg
70-Mo	0-7 / 7-70 lb/oz. Multi-Interval.	30-Mi	0-15 / 15-30 kg Multi-Interval

* Default for that model.

‘ni’ on the display represents Multi-Interval

‘n5’ on the display represents Multi-Interval with 0.005 lb. increment size

3. Press UNITS to accept the displayed option. The PS continues to the Alternate Units program block.

Note: the scale can only be sealed in the build that is listed on the data label.

Alternate Units Program Block

This program block lets you enable or disable unit switching during normal operation.

To configure the program block:

1. Press UNITS to display the **ALt** prompt, then press ZERO.
2. Press ZERO to display the desired approval setting, enable or disable.
3. Press UNITS to accept the displayed option. The PS continues to the Mode / Filter program block.

Mode Program Block

The Mode program block lets you configure which mode is used to display weight. (Metrology PCB jumper must be removed.)

To configure the program block:

1. Press UNITS to display the **nodE** prompt, then press ZERO.

2. Press ZERO to display the desired mode. Options include:
 - Normal
 - Expanded – typically x10
 - Classifier – weight classifier rounding
3. Press UNITS to accept the displayed mode option. The PS continues to the Filter program block.

Filter Program Block

The Filter program block lets you configure the noise filter that is used in determining weight stability on the scale. The PS disregards environmental noise such as vibrations that affect the weighing accuracy according to the filter setting.

To configure the program block:

1. Press UNITS to display the **FiLteR** prompt, then press ZERO.
2. Press ZERO to display the desired noise filter. Options include:
 - Light
 - Heavy
 - Medium
3. Press UNITS to accept the displayed filter option. The PS continues to the Baud program block.

Settling time increases with heavier filter setting.

Baud Program Block

This program block lets you set the baud rate (the speed at which data is transmitted in bits-per-second).

To configure the program block:

1. Press UNITS to display the **bAud** prompt, then press ZERO.
2. Press ZERO to display the desired baud rate. Options include:
 - 300
 - 1200
 - 2400
 - 4800
 - 9600
 - 19200
3. Press UNITS to accept the displayed baud rate option. The PS continues to the ASCII program block.

ASCII Program Block

The ASCII program block lets you select the number of bits that make up an ASCII character. Most METTLER TOLEDO equipment communicates using seven data bits.

To configure the program block:

1. Press UNITS to display the **AScii** prompt, then press ZERO.
2. Press ZERO to display the desired bit selection. Options include:
 - Seven (7)
 - Eight (8)
3. Press UNITS to accept the displayed option. The PS continues to the Parity program block.

Parity Program Block

The Parity program block lets you select the parity option for data transmission. Parity is an error checking mechanism. To configure the program block:

1. Press UNITS to display the **PAr** prompt, then press ZERO.
2. Press ZERO to display the desired parity option. Options include:
 - Space
 - Mark
 - Odd
 - Even
 - None
3. Press UNITS to accept the parity option. The PS continues to the Stop program block.

Note: options will depend on the ASCII bits selection.

Stop Program Block

The Stop program block lets you select the number of stop bits to be transmitted for each ASCII character. Most METTLER TOLEDO products will work with either 1 or 2 stop bits.

To configure the program block:

1. Press UNITS to display the **StoP** prompt, then press ZERO.
2. Press ZERO to display 1 or 2 stop bits, then press UNITS to accept the displayed selection. The PS continues to the Protocol program block.

Protocol Program Block

Toledo protocol contained in the PS is identical to the Toledo protocol within the industrial builds of the 8213. The PS replaces the industrial versions of the 8213.

The Protocol program block lets you select a pre-configured set of scale commands. Protocols are configured in the factory according to your ordering information. This section gives instructions on how to select a protocol only.

To select a protocol:

1. Press UNITS to display the **Proto** prompt, then press ZERO.
2. Press ZERO to display the desired protocol. Options include:
 - Toledo (MT command set)
 - Proto 1 (Fed Ex command set)
 - Proto 4 (UPS command set)
 - Proto 5 (Purolator command set)

- Proto 2 (Weightronix SC-320 com. set) command set)
- Proto 3 (Weightronix 3870 com. set)
- Proto 6 (Airborne)
- Disable(turns off communications)

3. Press UNITS to accept the protocol option. The PS continues to the Sleep program block.

Note: Protocols 1-6 are not available on the PS6L.

Sleep Program Block

Power is saved if RS-232 interface is not used.

In normal operating mode the scale is powered-up by pressing the ZERO (ON/OFF) key.

The Sleep program block lets you configure the sleep timer. Power consumption is reduced by approximately 60% while in Sleep mode.

IMPORTANT: For battery powered units, it is important to turn battery power off (using the rocker switch underneath the scale) when the scale is not in use.

To configure the Sleep program block:

1. Press UNITS to display the **SLEEP** prompt, then press ZERO.
2. Press ZERO to display the desired sleep timer option. Options include:
 - **Disable**—the PS will not power-down regardless of time between transactions (inactivity)
 - **5 min**—the PS will enter Sleep mode after 5 minutes with no activity
3. Press UNITS to accept the sleep timer option. The PS continues to the GEOCAL™ / End program block.

GEOCAL™ Program Block

This program block lets you enable the GEOCAL™ prompt at power-up. If this setting is enabled, the unit will prompt for the entry of a GEOCAL™ code after setup is exited.

To configure the program block:

1. Press UNITS to display the **GEo in** prompt, then press ZERO.
2. Press ZERO to display the desired approval setting, enable or disable.
3. Press UNITS to accept the displayed option. The PS continues to the Cal program block.

Calibration Program Block

See Chapter 2 for detailed information about activating GEOCAL™ and calibrating the PS. (Metrology PCB jumper must be removed.)

End Program Block

The End program block lets you save the configuration and exit setup mode. This program block does not have parameters to configure.

To use the End program block:

1. Press UNITS to display the **End** prompt.
2. Press ZERO to display the desired exit option. Exit options include:
 - **Default**—Reset all program block parameters to standard MT values, then exit setup mode.
 - **Abort**—Exit setup mode but do not save any changes made in this session.
 - **Save**—Do not exit setup mode at this time. PS returns to the first program block.
 - **Def x**—Company specific.

If you are using software from one of the following carriers your PS scale can be completely configured for use by selecting one of the options below (not available on PS6L):

<u>Carrier</u>	<u>End prompt selection</u>
• RPS	Default
• DHL	Default
• Fed Ex	Def 1
• UPS	Def 4
• Purolator	Def 5
• Airborne	Def 6

Choosing a default, rather than selecting SAVE, will automatically set the following program blocks:

- | | |
|--------------------|----------------|
| • Zero Cursor | • PARITY |
| • Power-up Units | • STOP BITS |
| • Units Switching | • Sleep Mode |
| • Filter | • Protocol |
| • BAUD | • Display Mode |
| • ASCII BIT String | |

The PS6L only has the Default option. This is the standard MT communications parameters and command set.

If your carrier is not listed try the default option, otherwise contact your carrier.

3. Press UNITS to carry out the displayed option.



FOR YOUR NOTES



FOR YOUR NOTES

4

Operating Instructions

This chapter gives information that an operator will need to become familiar with the scale and perform its functions in normal operating mode. The scale operates based on the current program block configuration. Please refer to Chapter 3 for more information on configuring the PS.

Keypad and Display

The PS has a simple LCD weight display with two keys that are used to perform scale functions. Weight is displayed using up to six 7-digit numeric characters with decimal point and comma. Cursors (horizontal bars) at the bottom of the display indicate current weight units and zero condition when zero is captured.




Figure 4-a: PS Keypad




Figure 4-b: PS Display

Operator Functions

The PS supports one primary function: parcel weighing. Other operator functions described in this chapter include:

- Unit switching
- Zero the scale
- Repower from Sleep mode

Parcel Weighing

Before weighing parcels on the PS, please be sure the scale is configured as desired (Chapter 3) and power is applied as instructed in Chapter 2 of this manual. To weigh a package:

You may wish to recapture zero periodically when the scale is in continuous use. It is not necessary to press ZERO before each transaction.

1. Press ZERO to capture zero. The display reads **0.00** and a cursor appears above the zero indicator in the legend.
2. Place the parcel to be weighed on the platter. The display reads the parcel weight with a cursor above the current weight units legend.
3. Record the parcel weight, then remove the parcel from the platter.

Unit Switching

If primary and alternate units are the same (as configured in the Alternate Units program block), unit switching is effectively disabled. The UNITS key displays the same weight and unit when the UNITS key is pressed.

The PS lets you view the displayed scale weight in primary and secondary units. Alternate units must be configured (in setup mode) to convert and display in alternate units.

To switch units:

1. With scale weight displayed, press the UNITS key. The PS automatically converts the displayed weight to weight in the alternate unit as indicated by the cursor.
2. Press UNITS again to reconvert alternate units back to primary units and return weight display to the primary unit.

Zeroing the Scale

If zero change exceeds the 2% limit, the scale will not capture zero. In this case, cycle power or recalibrate.

Periodically the PS scale may need to be re-zeroed. Press ZERO to capture zero. The scale will re-zero provided the weight is within 2% of the scale capacity. The PS display will read 0.00

Repowering from Sleep

If the PS display is blank after a period of inactivity, the ZERO key “awakens” the unit from its power-saving (sleep) mode.

When the ZERO key is pressed, the PS goes through its power-up sequence and returns to normal operating mode.

5

Service and Maintenance

This chapter gives information on servicing, upgrading, and maintaining the PS including cleaning and regular maintenance, troubleshooting, and installing optional equipment kits.

Cleaning and Regular Maintenance

You may need to wipe the keypad and platter with a clean, soft cloth that has been dampened with a mild cleaner. Do not use any type of industrial solvent such as toluene or isopropanol (IPA). These may damage the display finish. Do not spray cleaner directly onto the terminal.

Troubleshooting

The PS shipping scale is designed to be virtually error free and reliable. If problems do occur, do not attempt to repair the scale before you have determined the source of the problem. Record as much information as possible about what has happened including any messages and physical responses. The following troubleshooting information may help to determine the cause of the problem.

	 WARNING
	DISCONNECT ALL POWER TO THIS UNIT BEFORE INSTALLING, SERVICING, CLEANING, OR REMOVING THE FUSE. FAILURE TO DO SO COULD RESULT IN BODILY HARM AND/OR PROPERTY DAMAGE.

	 CAUTION
	OBSERVE PRECAUTIONS FOR HANDLING ELECTROSTATIC SENSITIVE DEVICES.

Error Code Section

Error codes are displayed on the weight indicator with a leading “E” to distinguish themselves from weight data.

Code	Meaning	Action
E1	ROM (checksum) error	Replace the circuit board to clear this error (call Mettler Toledo Service)
E2	RAM error	Replace the circuit board to clear this error (call Mettler Toledo Service)
E3	EEPROM error	<p>Setup and /or calibration information has been lost. Press any display button and the scale will enter setup mode or calibration mode depending on what information is lost.</p> <p>If both setup and calibration information has been lost, the scale will enter setup mode first when a display button is pressed. After completing the setup, the scale will display E3 again until a button is pressed to enter calibration mode and calibration is completed.</p> <p>Reset the setup parameters and/or recalibrate to clear this error. If the scale continues to display E3 after the setup and/or calibration has been completed, the load cell is unable to save the information and will need to be replaced (call Mettler Toledo Service)</p>
E4	TC error	Replace the load cell to clear this error (call Mettler Toledo Service)
E5	Serial Communications (Data) error	The scale has received a character from the host with an invalid parity. The scale will display E5 until either a display button is pressed or another character is received. This error could be caused by an incorrect Baud Rate or Data Bits selection in the scale setup.

Wall Transformer

The wall transformer (when connected to the proper AC input and disconnected from the scale) may read as high as 18.3 VDC. The wall transformer should read from 7 VDC, up to 17 VDC when connected to the scale. If the voltage measured is not within this range, replace the wall transformer. The center conductor of the wall transformer is positive.

Main PCB

From PC - DB25-F RS232 SERIAL PORT		To PS - DB9-M (Male)	
2	TRANSMIT	3	RECEIVE
3	RECEIVE	2	TRANSMIT
7	SIG GROUND	1 or 5	SIG GROUND

Table 1 Standard PC RS232 DB-25 To PS

From PC - DB9-F RS232 SERIAL PORT		To PS - DB9-M (Male)	
2	RECEIVE	2	TRANSMIT
3	TRANSMIT	3	RECEIVE
5	SIG GROUND	1 or 5	SIG GROUND

Table 2 Standard PC RS232 DB9 To PS

To test the Main PCB: (Unit must be setup for standard MT communications (Default)):

1. Start your communications software such as ComTool (Part Number KN000000K64).
2. Setup your software for:
 - 7 data bits
 - Even parity
 - 1 stop bit
 - Baud rate that matches the computer's baud rate

Blank or Half Display

Remove power then check the display interface harness from the scale to the display. Apply power the unit. If the blank display continues, replace the 0270 Display.

No Keypad Interaction

To test operation of the keypad, remove power, then reapply. With power to the unit, and the W1 (W3 on PS6L) calibration jumper installed, attempt to enter setup mode by pressing and holding the UNITS key. If the display does not indicate setup mode, replace the 0270 Display.

Indicator Locked

To test operation of the indicator, remove power, then reapply. With power to the unit, add weight. If no motion is displayed, replace either the load cell or the Logic PCB.

Load Cell Replacement

For load cell replacement, please use current revision of 15302300A for PS60 (3000d) and PS6L, use 15828000A for PS60 multi-interval versions (2x3000d), and use 15354000A for PS30 and PS3L.

Loadcell replacement will require a model number to be installed. Once the model is set, it cannot be changed without replacing the cell.

At power-up the PS6 checks for a valid Scale Model Number in EEPROM. If the Scale Model field is corrupted (or has not been programmed) the scale displays an EEPROM error (E3). Once either key is pressed, the scale will enter Scale Model selection mode and display:

"nOdEL?"

By pressing either key and the first model selection is displayed:

"PS6O " (Model PS-60, standard version)

"PS6OEP" (Model PS-60, 2x3000 version)

"PS6L " (Model PS-6L)

Each time the Zero Key is pressed the next model selection is displayed. Pressing the Units Key will store the displayed scale model as the new Scale Model number. The default setup selections for the model selected are then stored into EEPROM and the scale then reboots.

Installing the Battery Kit


The following instructions describe battery installation (alkaline cell) for the PS shipping scale (PS60 model only). Under normal operation, battery life is approximately 40 hours. Sleep mode reduces power consumption by 60% and extends battery life. For prolonged battery life, turn the scale off when not in use. Rechargeable Ni-Cad batteries can also be used.

NOTE:


BATTERY KIT WILL NOT WORK ON USB MODELS (PSXXU)

	WARNING!
	Always remove all power before operating on any equipment. Mettler-Toledo recommends that only qualified technicians open the unit up for maintenance and repair. If you must open the PS, read this section carefully to avoid damage to the internal components.

1. Remove the power and turn the PS over on the on the platter side. Be extremely careful not to damage the display.
2. Install the plastic D-cell battery holder P/N 13257500A. Attach with four M3-0.5X8 Pan HD screws and washers. Note the polarity of the battery holder and terminal positions.




3. Attach the harness assembly (P/N 14544600A) to the battery holder.




4. Insert the on/off rocker switch (P/N 14262400A) into the switch hole of the battery cover (P/N 14545200A) noting the orientation of the switch.

Six alkaline 1.5 VDC, D-size batteries (P/N 13293700A) are required for operation.




5. Insert the two fasteners (P/N 12051300A) into the battery cover.
6. Install the terminal spade lugs on the terminals of the switch that is installed into the battery cover.
7. Connect the plug into the receptacle on the Logic PCB as shown below and install the six 1.5 VDC, D-size batteries.

Chapter 5: Service and Maintenance
Installing the Battery Kit




8. Carefully attach the battery cover paying close attention to the routing of the cable to the Main PCB. Close the battery cover fasteners.




Installing the Base Mount Display

A base mount display unit (0270, 2-key indicator) can be installed if one was not ordered initially for the PS shipping scale (PS60 and PS6L models only). To install the base mount display:

1. Attach the display unit to the bottom of the PS with the two M4 10mm screws (P/N R0550100A) as shown below:



2. Install the display interface harness from the display as shown. Insert the display interface harness into the PCB as shown. Make sure to route the cable as shown to prevent damage to the cable.



Installing the Ball Top Transfer Platter

A ball top transfer platter is available for the PS. To install the ball transfer platter:

1. Remove the platter supplied with the PS.
2. Place the ball top transfer platter on the PS.
3. Ensure that the ball top transfer platter drops into place without mechanical interference.

Note: If the unit fails to capture zero after power-up, re-calibration will be required.



FOR YOUR NOTES

6

Parts and Accessories

Please refer to the following diagrams and parts lists when ordering parts and accessories for the PS shipping scale.

PS60/PS6L/PS60U Scale Parts




Figure 6-a

PS6 Parts List

PARTS LIST MAJOR (REF)		
SYM	QTY	PART NO. DESCRIPTION
1A	4	*14100500A FOOT
	4	*14629400A FOOT,ADJUSTABLE, USB ONLY
1B	1	*15302300A L/C ASSY,QUAL,PS60,300,PLUS MULTIPURPOSE
	1	*15828000A L/C ASSY,QUAL.,PS60,2X3000,PLUS GEO
1C	1	*15439900D BASE PS60,RTS
	1	*15439900A BASE PS60,PS6L
1D	1	*15954000A STANDOFF,HEX,M4,M/F,19mm
1E	1	*14544000A COVER PLATE,8270 PCB
1F	1	*15809000A ASSY SPIDER,PS60
1G	1	R0514600A SCREW,M4 X 8 HEX DRILLED
1H	1	*14082800A LABEL,GRAY, VERTICAL
1J	4	R0517600A SCR,CAP M8X30 SOC
1K	1	*16567100A KOP ASSY,MAIN,PS60
	1	*16617700A PCB ASSY,MAIN,PS60
	1	*15683100A PCB ASSY,MAIN,PS60
	1	*15553700A PCB ASSY,MAIN,PS6L,UNITED POSTAL
1P	1	*14616100A INSULATOR, LOGIC,HI RES
1R	1	*10268900A LEVEL W/O ADHESIVE
1S	SUFF	*146052R SPEC,ADHESIVE,409
1W	0.4	*142128R TAPE, ACRYLIC FOAM
1Y	1	*15963500A LABEL, EC 1-STEP VER.,SMALL
1Z	1	*15963300A LABEL, SEALING, EC 1 STEP VERIFY
**	1	*13786200A POLYBAG 18"X18"
**	1	*15637300A CABLE ASSY,PS60 TO COMPUTER,3M
**	1	*16317400A CABLE ASSY,6 PIN/RJ12
**	1	*16630200A CABLE ASSY,USB
1L	1	*14543000A ASSY INDICATOR BASE MTG.,8270
	1	*14824700A ASSY,INDICATOR REMOTE SINGLE
	1	*14824800A ASSY,INDICATOR DUAL REMOTE
1M	1	*14543200A ASSY PLATTER S.S.,8270
	1	*14543200B ASSY PLATTER S.S.,8270
	1	*15802800A PLATTER,PLASTIC,DHL
	1	*14819500B PLATTER,PLASTIC,COOL GRAY
	1	*15083400A ASSY,PLATTER,SS,PS60,OPEN CORNER
	1	*15083400B ASSY,PLATTER,SS,PS60,OPEN CORNER
	1	*15644800A ASSY,PLATTER,ROLL TRANSFER
	1	*15528600A PLASTIC PLATTER, W/CUT OUT
1N	1	*16077300A ASSY DCELL BATTERY,GEO
1T	1	*14488900A OVERLAY,0270
	1	*14806600A OVERLAY,KEYPAD,PS60,NO LOGO
	1	*16532700A OVERLAY,KEYPAD,0270
	1	*16532600A OVERLAY,KEYPAD,NO LOGO
1U	1	*14489000A LENS,0270
	1	*14912300A LENS,PS60,MULTI INTERVAL
	1	*14912200A LENS,DISPLAY,PS60,60KG OIML
	1	*14912400A LENS,DISPLAY,PS60,WT CLASSIFIER
	1	*14912500A LENS,DISPLAY,PS60,NTEP,MULTI INT
	1	*15849700A LENS,DISPLAY,PS6L,LB ONLY
	1	*15362500A LENS,DISPLAY,REMOTE,WGT,CLASSIFIER
	1	*16566500A LENS,DISPLAY,0270
	1	*16566000A LENS,DISPLAY,MULTI INTERVAL
	1	*16565900A LENS,DISPLAY,PS60,60KG OIML
	1	*16566100A LENS,DISPLAY,PS60,WT CLASSIFIER
	1	*16566200A LENS,DISPLAY,PS60,NTEP MULTI INT
1V	1	*14917300A ASSY,DISPLAY TOWER MT.
	1	*15479700A ASSY INDICATOR BRACKET, PS60,UPS
**	1	*13956800A ENVELOPE,PADDED SHIPPING

(*) Some part numbers may have a revision letter in front of them.


(**) Indicates not shown if Figure 6-a.

PS3 Parts List

PARTS LIST MAJOR			
SYM	QTY	PART NO.	DESCRIPTION
1A	4	*14100500A	FOOT
1B	1	*15354000A	L/C ASSY QUALIFIED, 45KG
1C	1	*15439900D	BASE PS60,RTS
1D	1	*15954000A	STANDOFF,HEX,M4,M/F,19MM
1E	1	*14544000A	COVER PLATE,8270 PCB
1F	1	*15809000A	ASSY SPIDER,PS60
1G	1	R0514600A	SCREW,M4 X 8 HEX DRILLED
1H	1	*14082800A	LABEL,GRAY, VERTICAL
1J	4	R0517600A	SCR,CAP M8X30 SOC
1K	1	*16567200A	KOP, PCB ASSY,MAIN,PS SERVICE
1L	1	*14543000A	ASSY INDICATOR BASE MTG.,8270
1M	1	*14819500D	PLATTER,PLASTIC,COOL GRAY
1P	1	*14616100A	INSULATOR, LOGIC,HI RES
1R	1	*10268900A	LEVEL, BUBBLE
1T	1	*16509600A	LENS,DISPLAY,PS30 USA,LB/KG
	1	*16509700A	LENS,DISPLAY,PS30 30X0.01 KG
	1	*16510400A	LENS,DISPLAY,PS30 OIML
	1	*16577400A	LENS,DISPLAY,PS30, USPS
	1	*16521000A	LENS,DISPLAY,PS3L
	1	*16521100A	LENS,DISPLAY,PS3L, LB/OZ.
	1	*16522300A	LENS,DISPLAY,PS3L, KG
1U	1	*16532700A	OVERLAYS,KYPAD,PS60/PS30 W/LOGO
1V	1	*14275100A	LABEL, FCC, P.B. DOMESTIC
1Z	1	*15963300A	LABEL,SEALING, EC 1 STEP VERIFY
**	SUFF	*146052R	SPEC,409 ADHESIVE

- (*) Some part numbers may have a revision letter in front of them.
 (**) Indicates not shown in Figure 6-b.

Weight Display Parts



Parts List—Weight Display			
Ref #	Part Number	Description	Qty
1A	*15705300B	Display PCB Assembly W/Cable	1
1B	*15640800A	Display Base	1
1C	R0550100A	Screw, M4X10, PH, THD, w/Washer	2

(*) Some part numbers may have a revision letter in front of them.

Appendix A: Host Interface

The METTLER TOLEDO PS shipping scale can function as a peripheral device to a host computer. In host mode you can:

- Calibrate the scale
- Configure setup parameters
- Request and receive weight data when the scale is in a stable state
- Request and receive the scale's status when the scale is in an unstable or invalid state
- Zero the scale and/or switch units (depending on setup)

The scale does not reply to host weight commands if it is in calibration mode or if the scale cannot capture zero on power-up.

This section presents information and instructions on how to use the PS in host mode.

Communication Parameters

Data is transmitted and received by the scale through an RS-232 serial port connection. The following communication parameters are supported:

- Baud Rate (300, 1200, 2400, 4800, 9600, 19200)
 - Parity (no, even, odd, mark, space)
 - ASCII bit string (7 or 8)
 - Stop bits (1, 2)
 - The scale only responds to commands, continuous data output is not available.
-

Protocols

The scale can be programmed to respond to a selected "menu" of defined protocols. The host sends requests to the scale in the form of ASCII data and control characters as determined by the selected protocol. The scale responds to the host with a string of ASCII characters. ASCII characters and their binary conversions are listed in the following table:

ASCII Characters and Conversions

ASCII CHAR.	DEC	HEX	76543210	ASCII CHAR.	DEC	HEX	76543210
NULL	0	00	00000000	SPACE	32	20	00100000
SOH	1	01	00000001	!	33	21	00100001
STX	2	02	00000010	"	34	22	00100010
ETX	3	03	00000011	#	35	23	00100011
EOT	4	04	00000100	\$	36	24	00100100
ENQ	5	05	00000101	%	37	25	00100101
ACK	6	06	00000110	&	38	26	00100110
BELL	7	07	00000111	'	39	27	00100111
Backspace	8	08	00001000	(40	28	00101000
TAB	9	09	00001001)	41	29	00101001
Line Feed	10	0A	00001010	*	42	2A	00101010
Vert. Tab	11	0B	00001011	+	43	2B	00101011
Form Feed	12	0C	00001100	,	44	2C	00101100
Carr. Return	13	0D	00001101	-	45	2D	00101101
Shift Out	14	0E	00001110	.	46	2E	00101110
Shift In	15	0F	00001111	/	47	2F	00101111
Data Link Esc	16	10	00010000	0	48	30	00110000
DC1	17	11	00010001	1	49	31	00110001
DC2	18	12	00010010	2	50	32	00110010
DC3	19	13	00010011	3	51	33	00110011
DC4	20	14	00010100	4	52	34	00110100
NAK	21	15	00010101	5	53	35	00110101
SYNCH IDLE	22	16	00010110	6	54	36	00110110
End Trans.	23	17	00010111	7	55	37	00110111
CANCEL	24	18	00011000	8	56	38	00111000
End Of Medium	25	19	00011001	9	57	39	00111001
Substitute	26	1A	00011010	:	58	3A	00111010
ESCAPE	27	1B	00011011	;	59	3B	00111011
FS (Cur. Right)	28	1C	00011100	<	60	3C	00111100
GS (Cur. Left)	29	1D	00011101	=	61	3D	00111101
RS (Cursor Up)	30	1E	00011110	>	62	3E	00111110
US (Cur. Down)	31	1F	00011111	?	63	3F	00111111

Appendix A: Host Interface
Scale Status Byte Format

ASCII CHAR.	DEC	HEX	76543210	ASCII CHAR.	DEC	HEX	76543210
@	64	40	01000000	`	96	60	01100000
A	65	41	01000001	a	97	61	01100001
B	66	42	01000010	b	98	62	01100010
C	67	43	01000011	c	99	63	01100011
D	68	44	01000100	d	100	64	01100100
E	69	45	01000101	e	101	65	01100101
F	70	46	01000110	f	102	66	01100110
G	71	47	01000111	g	103	67	01100111
H	72	48	01001000	h	104	68	01101000
I	73	49	01001001	i	105	69	01101001
J	74	4A	01001010	j	106	6A	01101010
K	75	4B	01001011	k	107	6B	01101011
L	76	4C	01001100	l	108	6C	01101100
M	77	4D	01001101	m	109	6D	01101101
N	78	4E	01001110	n	110	6E	01101110
O	79	4F	01001111	o	111	6F	01101111
P	80	50	01010000	p	112	70	01110000
Q	81	51	01010001	q	113	71	01110001
R	82	52	01010010	r	114	72	01110010
S	83	53	01010011	s	115	73	01110011
T	84	54	01010100	t	116	74	01110100
U	85	55	01010101	u	117	75	01110101
V	86	56	01010110	v	118	76	01110110
W	87	57	01010111	w	119	77	01110111
X	88	58	01011000	x	120	78	01111000
Y	89	59	01011001	y	121	79	01111001
Z	90	5A	01011010	z	122	7A	01111010
[91	5B	01011011	{	123	7B	01111011
\	92	5C	01011100		124	7C	01111100
]	93	5D	01011101	}	125	7D	01111101
^	94	5E	01011110	~	126	7E	01111110
_	95	5F	01011111		127	7F	01111111

Toledo Protocol Host Commands

Following is a listing of host commands and scale responses. Brackets “<>” are used to indicate that the characters within are a description of the transmitted data and are not part of the transmitted data string. <STX> indicates an ASCII Start Of Text character (HEX 02). <CR> indicates an ASCII Carriage Return (HEX 0D).

Host Command	Description	Scale Response
W*	Send normal resolution weight data.	<STX>XXX.XX<CR> (for PS60 lb builds) or <STX>XXXlbXX.Xoz<CR> (for PS6L 150 lb-oz build) <u>For PS6L 150 x 0.005 lb Multi-Range build</u> <STX>XX.XXX<CR> (x 0.005 lb increment) <STX>XXX.XX<CR> (x 0.05 lb increment) <STX>XXXX.X<CR> (x 0.1 lb increment) <STX>?<StatusByte><CR> (if current weight is invalid)
H	Send high resolution weight data.	<STX>XXX.XXX<CR> (for PS-60 lb builds) or <STX>XXXXXX<CR> (for PS6L 150 lb-oz build) or <STX>XXX.XXX<CR> (for PS6L 150 x 0.005 lb build) <STX>?<StatusByte><CR> (if current weight is invalid)
Z	Zero scale unless in motion or out of range under or over capacity.	<STX>?<status byte><CR> Scale status byte.
A	Perform a confidence test of RAM, ROM, and EEPROM. Store results of tests in confidence status byte for later retrieval.	<STX><CR> The scale echoes back a <STX><CR> indicating the command was received.
B	Send results of confidence test.	<STX>?<confidence byte><CR> Confidence test status byte.
C	Initiate host interface scale configuration.	<STX>CALIBRATE?<CR>, See below
S	Initiate host interface setup.	<STX>SETUP?<CR>, See below
E	Enter “echo” serial port test mode. All characters sent to the scale will be echoed back to the host. “F” terminates the test.	<STX>E<CR> The scale echoes back the letter E indicating the command was received.
F	Exit “echo” serial port test mode.	<STX>F<CR> The scale echoes back the letter F indicating the command was received.
L	Switch to and send standard weight.	Same as for W above.
K	Switch to and send metric weight.	Same as for W above.

Table Note:* A status byte message <STX>?<status byte><CR> is sent in place of the requested weight data field if the scale is in motion, under zero, or over capacity when the weight data request is sent. The question mark “?” indicates that the following data is a non-ASCII status byte rather than weight data. See below for status byte definitions.

Scale Status Byte Format

When communicating in host mode using the standard Toledo protocol, the PS may send status bytes containing information such as motion and over/under-capacity conditions. The message **<STX>?<status byte><CR>** indicates transmission of a status byte. The status byte sent is an ASCII character that must be converted to binary form for decoding the bits. The ASCII character table with binary conversion (given in the previous section) can be used to convert status bytes. The bits of the status byte in the standard Toledo protocol are defined as follows:

Status Byte	
Bit No.	Bit Description
6	Always 1
5	Always 1
4	1 = Center of zero 0 = Not at center of zero
3	1 = Outside zero capture range 0 = Within range
2	1 = Under zero 0 = Within weighing range
1	1 = Over capacity 0 = Within weighing range
0	1 = Scale in motion 0 = Stable weight data

Scale Confidence Byte Format

When communicating in host mode using the standard Toledo protocol, the host may ask the PS to store and send confidence bytes containing information about RAM, ROM, and EEPROM testing. The message **<STX>?<confidence byte><CR>** indicates transmission of a confidence byte. The confidence byte sent is an ASCII character that must be converted to binary form for decoding the bits. The ASCII character table with binary conversion (given in the previous section) can be used to convert status bytes. The bits of the confidence byte in the standard Toledo protocol are defined as follows:

Status Byte	
Bit No.	Bit Description
6	1 = New status data available. 0 = Host has read data.
5	Bit is always a 0.
4	1 = ROM test failed. 0 = ROM test passed.
3	1 = RAM test failed. 0 = RAM test passed.
2	Bit is always a 0.
1	1 = Calibration Required. 0 = Calibration Data OK
0	1 = EEPROM test failed 0 = EEPROM test passed.

Calibrate Using Host Interface

The PS shipping scale can be calibrated using the host interface. The command to initiate the calibration sequence is available in the METTLER TOLEDO command set. Calibration is based on the current scale configuration for units and capacity/increment. These can be changed (through the keypad or the host interface) before calibrating the scale through the host interface.

To calibrate using the host interface:

1. Remove the platter, break the legal-for-trade seal (if present), and remove the sub-platter to give access to the PCB.
2. Remove the calibration jumper (W1). Refer to the calibration diagram in Chapter 2 of this manual. **DO NOT ENTER SETUP MODE.** The PS does not respond to host commands in calibration mode.
3. Send the command **C** to initiate calibration sequence. The scale responds **<STX>CALIBRATE?<CR><LF>**.
4. Send the command **Y** to continue with the calibration sequence, or send the command **N** to abort the sequence. The scale responds **<STX>UNLOAD SCALE- Y?<CR><LF>**.
5. Remove any weight on the platter and send the command **Y** to continue. A stable zero reading is taken, then the scale responds **<STX> ADD 50 LB- Y? <CR><LF>** or **<STX> ADD 20 KG- Y? <CR><LF>** or **<STX> ADD 125 LB- Y? <CR><LF>** or **<STX> ADD 50 KG- ? <CR><LF>**.

6. Add the requested calibration weight to the scale, then send the command **Y** to continue. The scale responds **<STX> CAL DONE <CR><LF>** or **<STX> INCORRECT AMOUNT OF WEIGHT <CR><LF>**.

Configure Scale Parameters Using Host Interface

Configuration parameters can also be sent using the host interface. A command to send a new scale configuration over the host interface is available in the METTLER TOLEDO command set.

To configure using the host interface:

1. From the host computer, send the host command **S** to initiate the configuration setup sequence. The scale responds with the current set bytes:

<STX>X₁X₂X₃X₄X₅X₆X₇X₈X₉X₁₀X₁₁X₁₂X₁₃X₁₄X₁₅X₁₆X₁₇X₁₈X₁₉X₂₀<CR>

2. Determine the command string representing the configuration parameters that are desired. The command string consists of 22 characters beginning with an ASCII **<STX>** and terminated with an ASCII **<CR>**. The command string represents a 10-byte bit-mapped setup array stored in EEPROM. The 10-byte array is expanded for serial transmission so that the high-order four bits of each byte are zeroes and the low-order four bits are numbers representing the desired option for each program block. See the table below for definitions of each byte.

The table below lists the programming options available in each program block as they are used in Host Interface Setup. When downloading the scale setup it is strongly recommended that you modify only the selections that you need to change in the current setup bytes sent by the scale. Leave the values of all other setup bytes as they were when sent from the scale (including the selections that are currently not used). Then send the modified setup bytes string back to the scale.

X ₁ = Not Used, Set to 0x00.	X ₁₂ = Data Bits:
X ₂ = Not Used, Set to 0x00.	0x01 = 7 Data Bits
X ₃ = Not Used, Set to 0x00.	0x02 = 8 Data Bits
X ₄ = GEO Entry Required:	X ₁₃ = Baud Rate:
0x01 = GEO Entry Required OFF	0x01 = 300 Baud
0x02 = GEO Entry Required ON	0x02 = 1200 Baud
X ₅ = Units Switching:	0x03 = 2400 Baud
0x01 = Units Switching OFF	0x04 = 4800 Baud
0x02 = Units Switching ON	0x05 = 9600 Baud
X ₆ = Zero Cursor:	0x06 = 19200 Baud
0x01 = Zero Cursor OFF	X ₁₄ = Weight Filter:
0x02 = Zero Cursor ON	0x01 = Light Filter
X ₇ = Not Used, Set to 0x00.	0x02 = Medium Filter
X ₈ = Sleep Mode:	0x03 = Heavy Filter
0x01 = Sleep Mode OFF	X ₁₅ = Weight Display Mode:
0x02 = Sleep Mode ON	0x01 = DLC Echo Test Mode
X ₉ = Serial Port Protocol:	0x02 = Expanded (X10) Weight Display
0x01 = Disabled	0x03 = Normal Weight Display
0x02 = Mettler Toledo	0x04 = Weight Classifier Display
0x03 = FedEx	X ₁₆ = Power up Units:
0x04 = Weightronix WT320	0x01 = Metric (kg)
0x05 = Weightronix WT3870	0x02 = Pounds (lb)
0x06 = UPS	X ₁₇ = PS6 Scale Build:
0x07 = Purolator	0x01 = 60 x 0.01 kg / 150 x 0.02 lb
0x08 = Airborne	0x02 = 60 x 0.02 kg / 150 x 0.05 lb
X ₁₀ = Stop Bit:	0x03 = 100 x 0.05 kg / 250 x 0.1 lb
0x01 = One Stop Bit	0x04 = 50 x 0.01 kg / 100 x 0.02 lb
0x02 = Two Stop Bits	0x05 = 60 x 0.02 kg / 150 x 0.05 lb Multi-Range
X ₁₁ = Parity Bit:	0x06 = 70 x 0.05 kg / 149 lb x 0.1 oz Multi-Range
0x01 = Space Parity Bit	0x07 = 150 x 0.005 lb Multi-Range
0x02 = Mark Parity Bit	X ₁₇ = PS3 Scale Build
0x03 = Odd Parity Bit	0x01 = 30 x 0.02 kg / 70 x 0.05 lb
0x04 = Even Parity Bit	0x02 = 30 x 0.01 kg / 70 x 0.02 lb
0x05 = No Parity Bit	0x03 = 0-15 x 0.005 kg, 15-30 x 0.01 kg / 0-7 x 0.01 lb, 7-70 x 0.02 lb
	0x04 = 0-15 x 0.005 kg, 15-30 x 0.01 kg / 0-7 lb x 0.1 oz., 7-70 lb x 0.2 oz.
	X ₁₈ = Not Used, Set to 0x00.
	X ₁₉ = Pushbutton Zero Capture Range:
	0x01 = +/- 2% of scale capacity
	X ₂₀ = Not Used, Set to 0x00.

You can obtain the current configuration by sending the S command. Then you can abort without changing by sending the A command to abort.

Before sending the **DONE** reply, the configuration file is analyzed just as if it had been constructed using the keyboard.

3. Send the command desired new set of bytes to the scale:
<STX>Y₁Y₂ ... Y₁₉Y₂₀<CR>
4. The scale will check to make sure the requested bytes are valid, then will echo the request: **<STX>Y₁Y₂ ... Y₁₉Y₂₀<CR>**. Or, if there were problems with the request, the scale returns the original, **unmodified** setup bytes to let the host know there was a problem:
<STX>X₁X₂ ... X₁₉X₂₀<CR>
5. Send the command **Y** to continue and store the new setup bytes and the scale will respond with **<STX>DONE<CR>** when configuration is complete or **<STX>ABORT<CR>** if the modified bytes had problems.

NOTE: At any time the Host can send an **N** command to abort the Setup Download mode.



FOR YOUR NOTES

Appendix B: USB Host Interface

The USB 1.1 full speed (12Mbps) interface on this scale is used in applications where a USB interface, which conforms to the Microsoft™ USB POS HID, is required.

References

The following documents can be found on the official USB Web page.

<http://www.usb.org/developers/docs.html>

- Universal Serial Bus Specifications, Revision 2.0

<http://www.usb.org/developers/hidpage.html>

- Universal Serial Bus Device Class Definition for Human Interface Devices (HID), Version 1.11
- Universal Serial Bus HID Usage tables, Version 1.11
- Universal Serial Bus HID Point of Sale Usage Tables, Version 1.02

Hardware

The contents to the host via a standard full speed (12Mbps) USB interface cable. This cable will connect to a Series B type receptacle on the scale.

Electrical Connection

The scale supports one USB 1.1 full speed interface (12Mbps). Refer to Universal Serial Bus Specification Revision 2.0 for details on signal termination, signal levels and other electrical specifications for the USB interface.

Power

The PS scale can be considered bus powered as a low power device because it consumes less than 1 unit load of power (<100ma) with up to two non-backlit displays or one backlit display connected. It does not fully comply with the USB specifications because it does not support the “suspend state”.

Protocol

This interface supports the standard Universal Serial Bus HID Point of Sale Usage Tables for scales. Refer to the Universal Serial Bus HID Point of Sale Usage Tables document for details on this protocol.



FOR YOUR NOTES



METTLER TOLEDO
1900 Polaris Parkway
Columbus, Ohio 43240-2020

P/N: C15402600A

(03/03)

METTLER TOLEDO® is a Trademark of Mettler-Toledo, Inc.
© 2003 Mettler-Toledo, Inc.
Printed in U.S.A.



C15402600A