


Operating instructions and installation information

METTLER TOLEDO MultiRange ID7-Base weighing terminal

METTLER TOLEDO



The weighing terminal 22001373A consists of:

ID7-Desk

BasePac-ID7

IDNet-ID7

RS232-ID7

Contents

| | Page |
|--|-----------|
| 1 Introduction and commissioning | 3 |
| 1.1 Safety precautions | 3 |
| 1.2 Applications | 3 |
| 1.3 ID7-Base weighing terminal | 4 |
| 1.4 Commissioning | 6 |
| 1.5 Cleaning | 7 |
| 2 Basic functions | 8 |
| 2.1 Switching on and off | 8 |
| 2.2 Setting to zero | 8 |
| 2.3 Taring | 9 |
| 2.4 Weighing | 10 |
| 2.5 Switch over weighing platform | 10 |
| 3 Additional functions | 11 |
| 3.1 Weighing with the DeltaTrac | 11 |
| 3.2 Dynamic weighing | 14 |
| 3.3 Change weight unit | 14 |
| 3.4 Working in a higher resolution | 15 |
| 3.5 Display gross weight | 15 |
| 3.6 Multiplicative tare function | 15 |
| 3.7 Additive tare function | 15 |
| 3.8 Sandwich tare | 16 |
| 3.9 Display ID code and test weighing platform | 16 |
| 3.10 Identifications | 16 |
| 3.11 Recall information | 18 |
| 3.12 Print or transfer data | 19 |
| 3.13 Enter values with barcode reader | 19 |
| 3.14 Working with external keypad | 20 |
| 3.15 Working with a second display | 21 |
| 4 Settings in the master mode | 22 |
| 4.1 Overview of the master mode | 22 |
| 4.2 Operating the master mode | 23 |
| 4.3 TERMINAL master mode block | 24 |
| 4.4 SCALE master mode block | 28 |
| 4.5 INTERFACE master mode block | 31 |
| 5 Interface description | 40 |
| 5.1 MMR command set | 40 |
| 5.2 METTLER TOLEDO continuous mode | 52 |

| | | |
|-----------|---|-----------|
| 6 | Application blocks | 54 |
| 6.1 | Syntax and formats..... | 54 |
| 6.2 | TERMINAL, SCALE application blocks..... | 56 |
| 6.3 | INTERFACE application blocks..... | 59 |
| 7 | What to do if ...?..... | 61 |
| 8 | Technical data and accessories..... | 64 |
| 8.1 | Technical data | 64 |
| 8.2 | Accessories | 68 |
| 9 | Appendix | 72 |
| 9.1 | Fix-tare..... | 72 |
| 9.2 | Delta-fix | 73 |
| 9.3 | Fixed texts | 74 |
| 9.4 | Table of representable characters | 75 |
| 9.5 | Opening/closing ID7-Base weighing terminal..... | 76 |
| 9.6 | Configuring Pin 5 on RS232-ID7 interface..... | 76 |
| 10 | Index..... | 77 |

1 Introduction and commissioning


1.1 Safety precautions



- ▲ Never operate the ID7-Base weighing terminal in hazardous areas; there are special scales in our product line for this purpose.
- ▲ Make sure that the electrical outlet for the ID7-Base weighing terminal is grounded and easily accessible so that it can be isolated quickly in emergencies.
- ▲ Make sure that the mains voltage at the installation location is within the range from 100 V to 240 V.
- ▲ The safety of the unit is endangered if it is not operated in accordance with these operating instructions.
- ▲ Only authorized personnel may open the ID7-Base weighing terminal.

1.2 Applications


With the ID7-Base weighing terminal the following applications are possible:



- Multi-scale operation with up to 3 weighing platforms, including a weighing platform with an analog signal output.
- Up to 6 data interfaces
 - for printing,
 - for data exchange with a computer,
 - for connecting a barcode reader,
 - for control, e.g. of valves or flaps.
- Comfortable alphanumeric entry via an external keypad.


1.3 ID7-Base weighing terminal

1.3.1 Display




- 1 Weight display BIG WEIGHT DISPLAY with sign and decimal point
- 2 Stability monitor: lights up until the weighing platform has levelled out, then the weight unit appears here
- 3 Number of the weighing platform: shows the weighing platform just selected
- 4 NET symbol for marking net weight values
- 5 Assignment of the function keys

1.3.2 Keypad



- 1 CODE A ... CODE D keys – enter identification data
- 2 ON/OFF – On/Off key
- 3 FUNCTION CHANGE key – display additional functions when entering weight values: switch over unit
- 4 INFO key – recall memory contents and system information
- 5 Function keys F1 ... F6 – the current assignment is shown in the display above the key
- 6 SCALE key – select scale
- 7 ZERO-SET key – set scale to zero, test scale
- 8 TARA key – tare scale
- 9 TARE SPECIFICATION key – enter known tare values numerically
- 10 CLEAR key – clear entries and values
- 11 ENTER key – accept and transfer data
- 12 Numeric keypad with decimal point and signs

1.3.3 Connections



- 1 Connection for the external MFII keypad
- 2 Connection for weighing platform 1
- 3 Optional connections for weighing platform 2 and 3
- 4 5 optional interface connections
- 5 Standard RS232 interface
- 6 Power supply

Possible assignments for serial interfaces

| Interface | COM1 | COM2 | COM3 | COM4 | COM5 | COM6 |
|--------------------------------|------|------|------|------|------|------|
| CL20mA-ID7 | — | X | X | X | X | X |
| RS232-ID7 | X | X | X | X | X | X |
| RS422-ID7 | — | — | — | — | X | X |
| RS485-ID7 | — | — | — | — | X | X |
| RS485-ID7 with relay box 8-ID7 | — | — | — | — | — | X |
| 4 I/O-ID7 | — | — | — | — | X | X |
| Analog Output-ID7 | — | — | — | — | X | X |
| Alibi Memory-ID7 | — | X | X | X | X | X |

Notes

- COM1 is permanently equipped with the serial interface RS232-ID7 as standard.
- Only one Alibi Memory ID7 can be installed. It has no additional external connection, and internally it occupies the space of a data port COM2 ... COM6. Alibi Memory ID7 is installed as COM4 at the factory.

CAUTION

- Cover unused connection sockets with protective caps to protect the socket contacts from moisture and dirt.



1.4 Commissioning

1.4.1 Connect weighing platforms of the series D, F, K, N, Spider ID and AWU3/6

1. Set up weighing platform, see installation instructions of weighing platform.
2. Route weighing platform cable to weighing terminal.
3. Plug in weighing platform connector on weighing terminal.

1.4.2 Connect scales of the series B, G, R and DigiTOL

Precision scales of the **series B, G and R** can be connected to the ID7-Base weighing terminal with the LC-IDNet B or LC-IDNet R/G connection set.

To connect **DigiTOL** scales, the GD17 connection set is required.

1. Set up scale, see operating instructions of scale.
2. Connect appropriate connection set to scale.
3. Route cable of connection set to weighing terminal and plug in.

1.4.3 Commissioning with several weighing platforms

→ To start up the ID7-Base weighing terminal with several weighing platforms, please contact METTLER TOLEDO Service.

1.4.4 Connect ID7-Base to network



CAUTION

The ID7-Base weighing terminal only functions properly with mains voltages of 100 V to 240 V.

- Make sure that the mains voltage at the installation location lies within this range.
- Make sure that the mains outlet is grounded and easily accessible.

Connecting

- Plug mains plug of ID7-Base into a mains outlet.
In the factory setting the display briefly shows METTLER TOLEDO ID7 and the versions of the installed components; then the weight display appears.

1.4.5 Marking and sealing of certified weighing platforms

ID code With the ID code it can be checked whether certified weighing platforms have been tampered with since the last calibration. The ID code can be displayed on the terminal at any time, see section 3.9.


During calibration the currently displayed ID code is recorded and sealed.

During each change to the configuration the displayed ID code increases. It then no longer matches the sealed ID code; the calibration is not longer valid.

Certification To mark and certify your weighing system, please contact METTLER TOLEDO Service or your local board of weights and measures.

Check certification

1. Display ID code, see section 3.9; press ZERO-SET key until IDENTCODE = ... is displayed.
No value is shown for noncertified weighing platforms, but instead:
IDENTCODE ==.
2. Compare ID code displayed with sealed ID code on ID card.
The certification of the weighing system is only valid when both values are identical.



3. Press ZERO-SET key again.
The connected weighing platform is checked. The display shows CHECK SCALE and after the test is completed SCALE IS OK.
Then the ID7-Base automatically returns to normal operation.

1.5 Cleaning



DANGER OF SHOCK

- Do not open ID7-Base weighing terminal to clean.

CAUTION

- Make sure that unused connection sockets are covered with protective caps to protect the socket contacts from moisture and dirt.
- Do not use high-pressure cleaners.

Cleaning

- Wipe of ID7-Base weighing terminal with a commercially available glass or plastic cleaner.

2 Basic functions

2.1 Switching on and off

Switch on from the standby mode

→ Press ON/OFF key.

The display shows a weight value based on the last tare value and zero point.

Switch on with restart

1. Relieve weighing platform.
2. Press ON/OFF key and hold down until METTLER TOLEDO ID7 (factory setting) or text you have specified appears in display.
Then weight value 0.000 kg appears.

The weighing platform is restarted.

Note

The text which appears during switch-on with a restart is saved in the text memory 20, see section 4.3.2.

Switch off

→ Press ON/OFF key.

The display goes out and the ID7-Base weighing terminal is in the standby mode. The zero point and tare value remain saved.

2.2 Setting to zero

Setting to zero corrects the influence of minor dirt on the load plate.

In the case of excessive dirt which cannot be compensated by setting to zero, the display shows OUT OF RANGE.

Manual zero set

1. Relieve weighing platform.
2. Press ZERO-SET key.
The display shows 0.000 kg.

Automatic zero set

On certified weighing platforms the zero point of the weighing platform is automatically corrected when the weighing platform is relieved.

The automatic zero set can be switched off in the master mode on noncertified weighing platforms.

2.3 Taring

2.3.1 Manual taring

1. Place empty container on scale.
2. Press TARE key.
The tare weight is saved and the weight display set to zero.
The display shows the NET symbol.

Notes

- When the weighing platform is relieved, the saved tare weight is displayed with a negative sign.
- The weighing platform only saves **one** tare value.

2.3.2 Automatic taring

Prerequisite

AUTOTARA ON must be set in the master mode, see section 4.4.

- Place empty container on scale.
The container weight is automatically saved and the weight display set to zero.
The display shows the NET symbol.

Note

When the weighing platform is relieved, the saved tare weight is cleared.

2.3.3 Specify tare weight

Enter numerically

1. Press TARE SPECIFICATION key.
2. Enter tare weight (container weight) and confirm with ENTER.
When weighing platform is relieved, the entered tare weight is displayed with a negative sign.

Note

With the FUNCTION CHANGE key you can select the weight unit for entering the tare weight.

Correct entry

- Clear the entry character by character with the CLEAR key and repeat correctly.

Copy tare constant

The ID7-Base has 25 Tara memories for frequently used tare weights programmed in the master mode. The programmed tare constants are listed in the table in the Annex.

1. Enter memory number: 1 ... 25.
2. Press TARE SPECIFICATION key.
The display shows the NET symbol and the net weight based on the recalled tare weight.

2.3.4 Recall currently saved tare weight

The saved tare weight can be recalled at any time.

- Enter INFO, TARE SPECIFICATION key sequence.
The saved tare weight is displayed.

2.3.5 Clear tare weight

- Relieve weighing platform and tare.

– or –

- Specify tare weight 0.

– or –

- Enter TARE SPECIFICATION, CLEAR key sequence.

2.4 Weighing

Weighing without taring

- Lay weighing sample on weighing platform.
Gross weight (total weight) is displayed.

Weighing with taring

1. Place the empty container on the weighing platform and tare.
2. Pour in weighing sample.
The display shows the net weight and the NET symbol.

Weighing with tare specification

1. Place filled container on weighing platform.
The display shows the gross weight (total weight).
2. Specify tare weight or recall tare memory.
The display shows the net weight (container content) and the NET symbol.

2.5 Switch over weighing platform

Up to 3 weighing platforms can be connected to the ID7-Base.
The weighing platform currently selected is shown on the terminal.

- Press SCALE key.
The next weighing platform is selected.

– or –

- Enter number of weighing platform and press SCALE key.
The desired weighing platform is selected.

3 Additional functions

The assignment of the 6 function keys of the ID7-Base weighing terminal differs depending on the weighing task. The current assignment is shown above the function keys.

With the FUNCTION CHANGE key it is possible to switch over to other function key assignments.

Independent of the application software, the ID7-Base has the following additional functions:

| DELT | DYN | UNIT | X 10 | GROSS | MODE |
|--------------------------------------|---------------------------|-----------------------------|--|-------------------------------|-------------------------------------|
| Weighing with the DeltaTrac, see 3.1 | Dynamic weighing, see 3.2 | Change weight unit, see 3.3 | Increase resolution, see 3.4. This key is not assigned when the control mode is continually switched on. | Display gross weight, see 3.5 | Activate master mode, see Chapter 4 |

| MULT-TARE | ADD-TARE | SANDWICH-T |
|---------------------------------------|---------------------------------|------------------------|
| Multiplicative tare function, see 3.6 | Additive tare function, see 3.7 | Sandwich tare, see 3.8 |

3.1 Weighing with the DeltaTrac

The DeltaTrac is an analog display which makes it easier to read the weighing results.

In the master mode you can select how the DeltaTrac is displayed for the various weighing tasks FILLING, CLASSIFYING or CHECKWEIGHING.

Notes

- With the DeltaTrac signals you can also control lamps, flaps or valves, see section 4.5.4.
- With the Analog Output-ID7 interface the net value can be output as an analogue current or voltage signal.

**Application
FILLING**


For weighing-in to a target weight with tolerance monitoring.

Example: Target weight = 1.000 kg, tolerance = 1 %

**Application
CLASSIFYING**


To evaluate test samples as OKAY, TOO LIGHT or TOO HEAVY, based on a target weight and specified +/- tolerances.

Example: Target weight = 1.000 kg, tolerance = 1 %

**Application
CHECKWEIGHING**

For determining the difference between the target and actual weight.

Example: Target weight = 1.000 kg, tolerance = 1 %



3.1.1 Preset DeltaTrac target values

- Enter numerically**
1. Press DELT key.
 2. Enter target weight and confirm with ENTER.
 3. Enter tolerance in % of target weight and confirm with ENTER.

Note

With the FUNCTION CHANGE key you can select the weight unit for entering the DeltaTrac target values.

- Correct entry** → With the CLEAR key the entry is corrected character by character.

- Copy constants** The ID7-Base weighing terminal has 25 DeltaTrac memories for frequently used target values and tolerances, which are programmed in the master mode. The programmed DeltaTrac constants are specified in the list in the Annex.

1. Enter number of DeltaTrac memory: 1 ... 25.
2. Press DELT key.

- Reference sample**
1. Press DELT key.
 2. Lay sample on weighing platform and confirm with SCALE key.
 3. Only for FILLING and CLASSIFYING: Enter tolerance and confirm with ENTER.
 4. Remove sample from weighing platform.

| | | |
|---------------|----------------------|--|
| Limits | Minimum target value | 40 Digit |
| | Maximum target value | configured maximum load |
| | Minimum tolerance | 1 Digit |
| | Maximum tolerance | 10 % for the applications FILLING, CHECKWEIGHING 50 % for the application CLASSIFYING |

Note

If the limits are not observed, a message appears in the display, e.g. MIN-DEL = ..., for too small a target value.

- Clear DeltaTrac target value** → Press DELT CLEAR key sequence.
DELTA CLEARED appears briefly in the display, then the weight is shown.

3.2 Dynamic weighing

With the dynamic weighing function you can weigh restless weighing samples, e.g. live animals. To do this, specify the number of weighing cycles for which the mean weight value is to be taken.

1. Set container on the weighing platform.
2. Tare weighing platform.
3. Place weighing sample in container.
4. Press DYN key and enter number of weighing cycles.
Possible values: 1 ... 255.
5. Start dynamic weighing with ENTER key.
6. After cycle time has expired, center line of display shows:
RESULT x.xxxx kg.
This display is retained until the next weighing is started or until it is cleared.

Delete result → Press CLEAR key.

Notes

- Dynamic weighing results are automatically printed when AUTO PRINT is set in the master mode, see section 4.3.2.
- During dynamic weighing it is not possible to display the weight value BIG WEIGHT DISPLAY, which fills the entire display.
- Dynamic weighing can also be started with the interface command AW016..., see section 6.2.

3.3 Change weight unit

If an additional, second weight unit is configured in the master mode, it is possible to switch back and forth between the two weight units.

- Press UNIT key.
The weight value is shown in the second unit.

Note

Possible second weight units are: g, kg, lb, oz, ozt, dwt.

3.4 Working in a higher resolution

Depending on the setting in the mastermode (see page 27), the weight value can be displayed in a higher resolution continuously or when called.

Weight values in a higher resolution are marked with a *.

Displaying weight values in higher resolution

→ Press X 10 key.

The weight value is displayed in at least a 10x higher resolution.

The higher resolution is displayed until the X 10 key is pressed again.

Note

With certified weighing platforms, the weight value only appears in a higher resolution as long as the X 10 key is pressed.


3.5 Display gross weight

The gross weight can only be displayed when a tare weight has been saved.

→ Press GROSS key and hold down.

The gross weight is displayed.

3.6 Multiplicative tare function



The multiplicative tare function is particularly suitable when pallets with identical containers are filled. If the number of containers and tare of the individual container are known, the ID7-Base weighing terminal calculates the total tare.


1. Press MULT TARE key.
2. Enter known tare weight of individual container and confirm with ENTER.
3. Enter number of containers and confirm with ENTER.

When the weighing platform is relieved, the total tare value is shown in the display with a negative sign.

Note

With the FUNCTION CHANGE key you can select the weight unit for entering the tare weight.

3.7 Additive tare function




With the additive tare function you can subtract the tare of additional containers with a known tare weight for related weighings, e.g. if containers with different weights are filled on one pallet.

1. Place container on scale and press ADD TARE key.
 2. Enter known tare weight and confirm with ENTER.
- The total net weight appears in the weight display.

Note

With the FUNCTION CHANGE key you can select the weight unit for entering the tare weight.

3.8 Sandwich tare



With the sandwich tare function you can detect additional tare weights for related weighings without losing the total gross and total net.

Example

In production or shipping boxes are laid between individual layers in the transport container. The weight of these boxes can be subtracted with this function.

1. Press SANDWICH-T key.
2. Place sandwich tare, e.g. box, on scale and confirm with ENTER.
The net weight is retained.

3.9 Display ID code and test weighing platform

Each time the weighing platform configuration is changed the ID code counter is increased by 1. On certified weighing platforms the displayed ID code must match the ID code on the ID code sticker, otherwise the calibration is no longer valid.

Display ID code

→ Press ZERO-SET key and hold until IDENTCODE = ... appears in the display.

Test weighing platform

→ Press ZERO-SET key again.

The connected weighing platform is checked. The display shows CHECK SCALE and then SCALE IS OK after completing the test.

Note

If weighing platform is defective, display shows SCALE ERROR.

3.10 Identifications

The ID7-Base weighing terminal is equipped with 4 identification data memories for storing identification data Code A ... Code D.

The memories have a name, e.g. Article No., and a content which identifies the current weighing, e.g. 1234567.

The memories are named in the mastermode, and the names can be noted on the keyboard. When the CODE keys are pressed, the name appears in the display.

Identification data Code A ... Code D can be entered or recalled for each weighing and are printed immediately.

3.10.1 Enter identification

An identification may contain a maximum of 20 characters.

Enter numerical identification

1. Press one of the keys CODE A ... CODE D.
2. Enter identification data Code A ... Code D via the numeric keypad and confirm with ENTER.

Enter alphanumeric identification

1. Press one of the keys CODE A ... CODE D.
The functions keys are given the following assignment:

| ABCDE | FGHIJ | KLMNO | PQRST | UVWXY | Z/(-) |
|-----------------------------|-----------------------------|-----------------------------|-----------------------------|-----------------------------|---|
| Selection of letters A to E | Selection of letters F to J | Selection of letters K to O | Selection of letters P to T | Selection of letters U to Y | Selection of letters Z and special characters |

2. Select desired group of letters, e.g. press KLMNO key.
3. Select desired letter.
The display changes again to the above selection.
4. Repeat entry in steps 2 and 3 for additional characters.

Note

Letters and numbers can be combined as desired.

Recall fixed text memory

The ID7-Base weighing terminal is equipped with 20 memories for fixed texts which can be programmed in the master mode and used as identifications. The programmed fixed texts are specified in the list in the Annex.

1. Enter memory number.
2. Press a key CODE A ... CODE D.
The saved fixed text is now assigned to the selected identification Code A ... Code D.

Other entry possibilities

Identifications can also be entered with a barcode reader, see section 3.13, or with an external keypad, see section 3.14.

3.10.2 Clear identifications

- Press desired key CODE A ... CODE D and clear memory content with CLEAR key.

3.11 Recall information

On the ID7-Base weighing terminal memory contents and system information can be recalled.

1. Press INFO key.

Then the following function key assignment appears:

| DELT | TARE | TEXT | ALIBI | DATE | VERS |
|--------------------------|---------------------|--|--|-----------------------|---|
| Display DeltaTrac values | Display tare weight | Display fixed texts and name of keys CODE A ... CODE D | Recall content of alibi memory. This selection only appears when Alibi Memory-ID7 is installed. | Display date and time | Display version numbers of installed software modules |

2. Select desired information.

The information is displayed for approx. 5 seconds, then the ID7-Base changes to the weighing mode again.

Notes

- When several values are displayed, the ID7-Base automatically changes to the next value after approx. 5 seconds.
- With the CLEAR key it is possible to switch to the next value or back to the weighing mode.
- When the GA46 printer is connected, the version numbers of the installed software modules are automatically printed.

3.11.1 Recall memory

1. Press INFO key.
2. Enter number of memory and press DELT, TARA or TEXT key depending on desired memory.

Recall name of CODE A ... CODE D keys

1. Press INFO key.
2. Press one of the keys CODE A ... CODE D.
The display shows the current Code.

3.12 Print or transfer data

If a printer or computer is connected, weighing results can be printed out or transferred to the computer. In the master mode you can set the following for this purpose:

- Data to be printed or transferred,
- Manual or automatic data transfer,
- Key which triggers printing or data transfer.

Factory setting

- Manual triggering with the ENTER key.
- The content of the display is transferred or printed.

3.13 Enter values with barcode reader

If you have connected a barcode reader to the ID7-Base weighing terminal, you can make all required entries, such as identifications or target specifications, easily with the barcode reader.

3.13.1 Read in any desired entries with the barcode reader

Example Read in identification Code A

1. Press CODE A key; the ID7-Base expects the entry of Code A.
2. Enter identification Code A with the barcode reader.
3. Confirm barcode entry with ENTER.

3.13.2 Read in a frequently used entry directly with the barcode reader

If your working procedure repeatedly requires the same entry, you can configure the barcode reader in the master mode (see section 4.5.3) so that no additional keys need to be pressed on the ID7-Base terminal for barcode entry.

Example Barcodes are automatically read in as Code A

If the working procedure requires the entry of Code A:

→ Enter identification Code A with barcode reader.

The read-in information is automatically processed by ID7-Base as Code A.

3.14 Working with external keypad

In addition to the alpha and numerical keys, the following additional scale functions can also be operated with the external AK-MFII keypad.

| Function for ID7-Base | External keypad | Function for ID7-Base | External keypad |
|------------------------|-----------------|------------------------|-----------------|
| Function key F1 | F1 | CODE A key | Shift F1 |
| Function key F2 | F2 | CODE A key | Shift F2 |
| Function key F3 | F3 | CODE A key | Shift F3 |
| Function key F4 | F4 | CODE A key | Shift F4 |
| Function key F5 | F5 | | |
| Function key F6 | F6 | | |
| FUNCTION CHANGE key | F7 | | |
| INFO key | F8 | | |
| SCALE key | F9 | SCALE key | Shift F9 |
| ZERO-SET key | F10 | ZERO-SET key | Shift F10 |
| TARE key | F11 | TARE key | Shift F11 |
| TARE SPECIFICATION key | F12 | TARE SPECIFICATION key | Shift F12 |

Note

The language of your external keyboard can be set in the mastermode block LAYOUT EXT. KEYBOARD, see page 26.

3.15 Working with a second display

An ID1 Plus, ID3s or another ID7-... weighing terminal can be connected to the ID7-Base as a second display.

Conditions

- Interface CL 20mA-ID7 installed in passive operating mode (factory setting).
- AUTO-DIR setting selected in mastermode (see page 33).
- Weighing terminal is connected as second display with cable 00 504 511.

Operation possibilities on second display

The following functions are also possible on the second display:

- Set to zero
- Taring


ID7-... as second display

With ID7-... as a second display, the weight value fills the entire display (BIG WEIGHT DISPLAY ON).

4 Settings in the master mode

4.1 Overview of the master mode

In the master mode you adapt the ID7-Base weighing terminal to meet your needs. Depending on the configuration, the master mode is divided into 4 or 5 master mode blocks, which are in turn divided into further blocks.



TERMINAL For system settings, such as entering the date and time or loading permanent texts, see section 4.3.2.

PAC To set application-specific parameters.
This block does not appear with ID7-Base.

SCALE To select one of the connected weighing platforms. For each selected weighing platform the parameters are then set which concern the weight value, e. g. stability detector, unit, etc., see section 4.4.

INTERFACES To select an interface. The communication parameters are then set for each interface, see section 4.5.

SERVICE For configuring the weighing platform(s). On IDNet weighing platforms only for METTLER TOLEDO service technicians.

4.2 Operating the master mode

4.2.1 Enter the master mode

1. Press MODE key.
If the current function key assignment does not contain MODE, change to the assignment with MODE by repeatedly pressing the FUNCTION CHANGE key.
2. Enter personal code if configured.
The display shows the first master mode block **TERMINAL**.

4.2.2 Assignment of function keys in the master mode

In the master mode the function keys are assigned as follows:

| | | | | | |
|---|-------------------------------------|--|---|--|---|
| ← | → | | ↑ | END | OK |
| Change to previous block within a level | Change to next block within a level | | Exit level and return to higher-level block | Exit the master mode and return to normal mode | Recall lower-level block or confirm selection |

→ Select the function by pressing the function key.

Example → Press the **END** key to exit the master mode and return to the normal mode.


When the function keys are otherwise allocated

→ Press the key **FUNCTION CHANGE** until the function keys allocation displayed above appears.

4.2.3 Orientation in the master mode

For improved orientation the display shows the last steps in the path of the current master mode block.

Example The upper 3 lines of the display show the following path for selecting the DeltaTrac application **FILLING**:



4.2.4 Entries in the master mode

The following basic rules apply to entries made in the master mode:

- Confirm (alpha)numeric entries with **ENTER**.
- Alphanumeric entries with the ID7-Base: see section 3.10.
- To accept the displayed value: Press **ENTER** key.

4.2.5 Emergency entrance into the master mode


If a personal code has been assigned for entering the master mode and you have forgotten your code, you can still enter the master mode:

→ Enter the character sequence C, L, E, A, R as your personal code.

4.3 TERMINAL master mode block

4.3.1 Overview of the TERMINAL master mode block

In the TERMINAL master mode block you enter the following system settings:



Legend

- Blocks highlighted in **grey** are described in detail in the following.
- Factory settings are printed in **bold print**.

4.3.2 Settings in the TERMINAL master mode block

| RESET TERMINAL | Reset all terminal functions to the factory setting |
|----------------|--|
| | DELTA TRAC Filling BIG WEIGHT DISPLAY On DYNAMIC WEIGHING No printout CONTROL MODE X 10 key |
| Comment | The memories are not affected by this. |

| FIX-TARE | Save tare values protected against power failure to tare memories |
|-----------------|--|
| CLEAR ALL TARES | Delete all tare memories. |
| LOAD FIX-TARE | <ol style="list-style-type: none"> 1. Enter memory number of FIX-TARE No.: 1 ... 25. 2. Enter tare weight for the selected memory in the displayed unit. 3. To load additional fixed tare values, repeat the first two steps. 4. End entry: Confirm FIX-TARE NO. without entry with ENTER. |
| Comment | A list for entering fixed values is contained in section 9.1. |

| FIXED TEXT | Save texts protected against power failure to text memories |
|-----------------|---|
| | These texts can be assigned, for example as identifications, or also output during printing. |
| CLEAR ALL TEXTS | Delete all text memories. |
| LOAD FIXED TEXT | <ol style="list-style-type: none"> 1. Enter memory number of FIXED TEXT No.: 1 ... 20. 2. Enter text for the selected memory: max. of 20 characters. 3. To load additional fixed texts, repeat the first two steps. 4. End entry: Confirm memory number without entry with ENTER. |
| Comments | <ul style="list-style-type: none"> • Fixed Text No. 20 is displayed during switch-on with a restart, see section 2.1. • A list for entering fixed values is contained in section 9.3. |

| DELTA-FIX | Save target weight/tolerance combinations in DeltaTrac memory |
|------------------|--|
| CLEAR ALL DELTA | Delete all DeltaTrac memories. |
| LOAD DELTA-FIX | <ol style="list-style-type: none"> 1. Enter memory number of DELTA-FIX No.: 1 ... 25. 2. Enter target weight TARG in the displayed unit. 3. Enter tolerance TOL in %. 4. To enter additional Delta-Fix, repeat the first three steps. 5. End entry: Confirm memory number without entry with ENTER. |
| Comment | A list for entering fixed values is contained in section 9.2. |

| DELTATRAC | Select DeltaTrac application |
|------------------|---|
| FILLING | Weigh in target weight within a tolerance range (factory setting). |
| CLASSIFYING | Evaluate the test samples as good, too light or too heavy based on the target weight and tolerance. |
| CHECKWEIGHING | Determine difference between target and actual weight. |

| LANGUAGE | Select dialog language |
|-----------------|---|
| | Possible settings: German, English, French, Dutch, Italian, Spanish |

| LAYOUT EXT. KEYBOARD | Select keyboard layout of connected external keyboard |
|-----------------------------|--|
| | Possible setting: Germany, England, France, Holland, Italy, Spain, Scandinavia, Russia, Poland, Belgium, Switzerland, Slovakia, Czech Republic, Latin America, Canada, ... |

| TEXT FOR A B C D | Name identification keys CODE A ... CODE D |
|-------------------------|---|
| KEY A | Factory setting: ARTICLE NO. |
| KEY B | Factory setting: ORDER NO. |
| KEY C | Factory setting: CODE NO. |
| KEY D | Factory setting: DOCUMENT NO. |

| DATE / TIME | Enter date and time |
|--------------------|---|
| EUROPE DATE | <ul style="list-style-type: none"> • Enter DATE in European notation: Day.Month.Year. • Enter TIME in European notation: (24) Hours.Minutes.Seconds. |
| US DATE | <ul style="list-style-type: none"> • Enter DATE in American notation: Month.Day.Year. • Enter TIME in American notation: (12) Hours.Minutes.Seconds. AM/PM, Change over between AM and PM: Press FUNCTION CHANGE key. |
| Comments | <ul style="list-style-type: none"> • Enter single-place numbers with a preceding zero. • Date and time can be printed out. • The clock continues to run after the terminal is switched off. |

| PERSONAL CODE | Load or delete code for entering the master mode |
|----------------------|---|
| CODE | Enter code with a maximum of 8 alphanumeric characters. |
| Comment | If no code is entered, access to the master mode is unrestricted. |

| SCREEN SAVER | Switch screen saver on or off |
|---------------------|---|
| WAITING TIME | Enter time until screen saver is activated. Possible values: 1 ... 99 minutes |
| Comment | To hold all display elements at the same luminosity, we recommend not switching off the screen saver. |

| BIG WEIGHT DISPLAY | Switch full-display indication of the weight on or off |
|---------------------------|---|
| | Factory setting: BIG WEIGHT DISPLAY ON |

| CONTROL MODE | Adjust control mode |
|---------------------|---|
| X 10 KEY | Activation of control mode with X 10 key (factory setting) |
| CONTROL MODE ON | This setting is only possible with non-certified scales. The weighing terminal always operates with the higher resolution. |


| DYNAMIC WEIGHING | Set printing during dynamic weighing |
|-------------------------|---|
| NO PRINT | Results during dynamic weighing are not automatically printed out (factory setting). |
| AUTO PRINT | Each result during dynamic weighing is automatically printed. Dynamic weights are marked with "Result:" on the printout. |

4.4 SCALE master mode block

In the first block the weighing platform is selected: SCALE 1 ... SCALE 3.
The other setting possibilities are the same for all connected weighing platforms.

4.4.1 Overview of the SCALE master mode block

In the SCALE master mode block the following settings for the weight can be carried out:



- Legend**
- Blocks highlighted in **grey** are described in detail in the following.
 - Factory settings are printed in **bold print**.
 - Blocks which only appear under certain conditions have a **dotted outline**.

4.4.2 Settings in the SCALE master mode block

| RESET SCALE | Reset weighing platform to factory setting | |
|--------------------|---|--------------------|
| | WEIGHING-PROC ADAPT | universal weighing |
| | VIBRATION ADAPTER | average conditions |
| | STABILITY DETECTOR | ASD = 2 |
| | AUTOZERO | on |
| | AUTOTARA | off |
| | RESTART | off |

| WEIGHING-PROC ADAPT | Adapt weighing platform to weighing sample |
|----------------------------|--|
| UNIVERSAL WEIGHING | For solid bodies, coarse filling or checkweighing (factory setting). |
| STATIC WEIGHING | For solid bodies and weighing under extreme conditions, e. g. strong vibrations or weighing animals. |
| FINE FILLING | For liquid or powdered weighing samples. |

| VIBRATION ADAPTER | Adapt weighing platform to the vibration influences of the environment |
|--------------------------|---|
| AVERAGE CONDITIONS | Factory setting. |
| EXTREME CONDITIONS | The weighing platform operates more slowly, however is less sensitive, e. g. suitable with building vibrations and vibrations at the weighing location. |
| IDEAL CONDITIONS | The weighing platform operates very quickly, however is very sensitive, e. g. suitable with very calm and stabile weighing location. |

| STABILITY DETECTOR | Adapt automatic stability detector |
|---------------------------|---|
| | Possible settings: |
| | ASD = 0 Stability detector switched off (only possible with non-certified weighing platforms) |
| | ASD = 1 fast display good reproducibility |
| | ASD = 2 ▲ ▼ (factory setting) |
| | ASD = 3 ▲ ▼ |
| | ASD = 4 slow display very good reproducibility |

| AUTOZERO | Switch automatic zero-point correction on or off |
|-----------------|--|
| | The automatic zero-point correction corrects the weight of minor dirt with the weighing platform unloaded. Factory setting: AUTOZERO ON |
| Comment | On certified weighing platforms the zero-point correction is always switched on. |

| AUTOTARA | Switch automatic taring on or off |
|-----------------|--|
| | Factory setting: AUTOTARA OFF |

| RESTART | Switch restart function on or off |
|----------------|--|
| | When RESTART ON is set, the zero point and tare value remain stored after the power supply is interrupted. When the weighing platform is switched on again, the terminal shows the current weight. Factory setting: RESTART OFF |


| SECOND UNIT | Select second weight unit | | | | | | | | | | | | | | | | | | | | | |
|-------------|--|------------------|--------------|-----------------|----------|----|----------|-------|----|---------------|-------|----|------------------|------------|-----|----------------|-------------|-----|-----------------|------|---|-------|
| | <div>Possible units: g, kg, lb, oz, ozt, dwt</div> <table><tr><th>Unit</th><th>Abbreviation</th><th>Conversion to g</th></tr><tr><td>Kilogram</td><td>kg</td><td>= 1000 g</td></tr><tr><td>Pound</td><td>lb</td><td>≈ 453.59237 g</td></tr><tr><td>Ounce</td><td>oz</td><td>≈ 28.349523125 g</td></tr><tr><td>Troy Ounce</td><td>ozt</td><td>≈ 31.1034768 g</td></tr><tr><td>Pennyweight</td><td>dwt</td><td>≈ 1.555173843 g</td></tr><tr><td>Gram</td><td>g</td><td>= 1 g</td></tr></table> | Unit | Abbreviation | Conversion to g | Kilogram | kg | = 1000 g | Pound | lb | ≈ 453.59237 g | Ounce | oz | ≈ 28.349523125 g | Troy Ounce | ozt | ≈ 31.1034768 g | Pennyweight | dwt | ≈ 1.555173843 g | Gram | g | = 1 g |
| Unit | Abbreviation | Conversion to g | | | | | | | | | | | | | | | | | | | | |
| Kilogram | kg | = 1000 g | | | | | | | | | | | | | | | | | | | | |
| Pound | lb | ≈ 453.59237 g | | | | | | | | | | | | | | | | | | | | |
| Ounce | oz | ≈ 28.349523125 g | | | | | | | | | | | | | | | | | | | | |
| Troy Ounce | ozt | ≈ 31.1034768 g | | | | | | | | | | | | | | | | | | | | |
| Pennyweight | dwt | ≈ 1.555173843 g | | | | | | | | | | | | | | | | | | | | |
| Gram | g | = 1 g | | | | | | | | | | | | | | | | | | | | |
| Comment | On certified weighing platforms only the units permitted by certification appear. | | | | | | | | | | | | | | | | | | | | | |

| DISPLAY UPDATE | Set display speed of the weight display |
|-----------------------|--|
| | Select number of updates per second (UPS). Possible values: 6, 10, 15, 20 UPS |
| Comments | <ul style="list-style-type: none"> This block only appears when the DISPLAY UPDATE function is supported by the connected weighing platform. The possible settings are dependent on the connected weighing platform. |

4.5 INTERFACE master mode block

| | |
|--|--|
| Select the interface connection | → Select the interface connection in the first block: COM1, COM2, COM3, COM4, COM5 or COM6. |
| Select interface type | → Specify the interface type for the selected interface connection COM1 ... COM6. |
| Possible interface types | <ul style="list-style-type: none"> • NOT ASSIGNED When the selected interface connection is not assigned. • GA46 For connection of the GA46/GA46-W printer. An RS232-ID7 interface must be installed on the selected interface connection for this purpose. The other setting possibilities are described in the operating and installation instructions GA46. This selection no longer appears when a GA46 printer is already configured. • BARCODE For connection of a barcode reader. An RS232-ID7 interface must be installed on the selected interface connection for this purpose. For other settings see 4.5.3. • RS232 An RS232-ID7 interface must be installed on the selected interface connection for this purpose. For other settings see 4.5.2. • ALIBI MEMORY Only for COM2 ... COM6. An Alibi Memory-ID7 must be installed on the selected interface connection for this purpose. No further settings are required in the master mode. This selection no longer appears when an Alibi Memory-ID7 is already configured. • CL20mA Only for COM2 ... COM6. A CL20mA-ID7 interface must be installed on the interface connection for this purpose. For other settings see 4.5.2. • RS422 Only for COM5/COM6. An RS422-ID7 interface must be installed on the interface connection for this purpose. For other settings see 4.5.2. • RS485 Only for COM5/COM6. An RS485-ID7 interface must be installed on the interface connection for this purpose. For other settings see 4.5.2. • 4 I/O Only for COM5/COM6. A 4 I/O-ID7 interface with relay box 4-ID7 must be installed on the interface connection for this purpose. For other settings see 4.5.4. • RELAY BOX 8 Only for COM6. An RS485-ID7 interface with relay box 8-ID7 must be installed on the interface connection for this purpose. For other settings see 4.5.4. • ANALOG OUTPUT Only for COM5/COM6 with installed analog output ID7 interface. |

4.5.1 Overview of the master mode blocks RS232, RS422, RS485, CL20mA



- Legend**
- Blocks highlighted in **grey** are described in detail in the following.
 - Factory settings are printed in **bold print**.
 - Blocks which only appear under certain conditions have a **dotted outline**.

4.5.2 Settings in the master mode blocks RS232, RS422, RS485, CL20mA

| RS232, RS422, RS485, CL20MA | |
|-----------------------------|---|
| OPERATING MODE | This selection only appears with the RS485 master mode block. |
| 1:1 CONNECTION | ID7-Base weighing terminal and peripheral are directly connected. |
| BUS SLAVE | For operating the ID7-Base weighing terminal in a bus system. The following parameters are set automatically for the dialog: No handshake, no continuous transmission, no transfer string, fixed string framing C_{RL-F} . The PC is the master, the terminals act as slaves and only transmit when requested to do so by the master. The master must also wait until after sending out a command until the slave's answer is received. Each terminal must be assigned a unique address. Additional setting: ENTER TERMINAL ADDRESS. Possible addresses: 1 ... 31 |
| COMMUNICATION | Set communications parameters. |
| STANDARD SETTING | Set communications parameters to factory setting: 7 bits, 2 stop bits, parity even, 2400 baud |
| BITS PER CHARACTER | Possible settings: 7 bits, 8 bits |
| STOPBITS | Possible settings: 1 stop bit, 2 stop bits |
| PARITY | Possible settings: Parity even, parity odd, parity space, parity mark, no parity |
| BAUDRATE | Possible settings: 150, 300, 600, 1200, 2400, 4800, 9600, 19200 baud |

| RS232, RS422, RS485, CL20MA | |
|------------------------------------|---|
| MODE | Set operating mode. This selection does not appear when interface RS485-ID7 is operated in the BUS SLAVE operating mode. |
| STANDARD SETTING | Set operating mode to factory setting: CL handshake: no auto transmission (no continuous transmission), transfer string: Standard, string framing: C_{RL_F} |
| DIALOG MODE | For dialog between ID7-Base weighing terminal and computer. For other settings see next section. |
| PRINT MODE | To print weighing data, e. g. on a form printer. Up to two interfaces can be operated in the print mode. This selection does not appear when two interfaces are already configured in the print mode. For other settings see page 35. |

Set dialog mode

| DIALOG MODE | Set dialog between ID7-Base weighing terminal and computer |
|-----------------------------------|--|
| MMR | For information on dialog mode with the MMR command set, see section 5.1. |
| HANDSHAKE | Possible settings: <ul style="list-style-type: none"> • CL HANDSHAKE – for additional information on the CL handshake, see page 34. • XON-XOFF PROTOCOL. |
| AUTOMATIC CONTINUOUS TRANSMISSION | This block does not appear with the RS485-ID7 interface. Possible settings: <ul style="list-style-type: none"> • NO AUTO TRANSMISSION. • AUTO SIR – after each measuring cycle a stabilized or dynamic weight is transmitted. • AUTO DIR – weight values are transmitted as with AUTO SIR and the special characters in the display are transmitted for a second display . Fixed communications parameters: 9600 baud, 7 data bits, 2 stop bits, parity even |
| TRANSFER STRING | This block does not appear with the RS485-ID7 interface. Possible settings: <ul style="list-style-type: none"> • STANDARD – gross, net, tare • USER-DEFINED – enter numbers of the application blocks which are to be transmitted or printed out. |

| DIALOG MODE | Set dialog between ID7-Base weighing terminal and computer |
|-------------------------|--|
| STRING FRAMING | <p>Possible settings:</p> <ul style="list-style-type: none"> • ---<CR><LF> (Factory setting) • <STX>---<ETX> • BLOCK CHECK CHAR • ---<CR> |
| TOLEDO CONTINUOUS | <p>For the continuous transmission of net and tare values to METTLER TOLEDO devices, e. g. to a second display. For a description, see section 5.2. This block does not appear with the RS485-ID7 interface.</p> |
| TOLEDO SHORT CONTINUOUS | <p>For the continuous transmission of net values to METTLER TOLEDO devices, e. g. to a second display. For a description, see section 5.2. This block does not appear with the RS485-ID7 interface.</p> |
| PE SEND CONTINUOUS | <p>For connecting a PE balance as a reference balance, only with ID7 Count.</p> |

CL handshake

With the CL handshake 3 types of interface control are possible:

Handshake in receiving direction, in transmitting direction and in both directions.

After switch-on and after each interruption, the ID7-Base attempts to establish the handshake in both directions.

CL handshake in receiving direction

This type of CL handshake is suitable for data transmission from the ID7-Base to the computer.

1. The ID7-Base transmits SYN after switch-on.
2. The computer transmits the character ACK after switch-on or after receiving SYN.
3. ID7-Base then sends the response to a command or to a key actuation after each ACK.

CL handshake in transmission direction

This type of CL handshake is suitable for data transmission from the computer to the ID7-Base.

1. The ID7-Base transmits SYN after switch-on.
2. The computer transmits the character SYN after switch-on or after receiving SYN.
3. ID7-Base acknowledges the receipt of SYN again with SYN and signals its readiness to receive with ACK.
4. Then the computer can transmit a command after each ACK.

CL handshake in both directions

1. The ID7-Base transmits SYN after switch-on.
2. The computer transmits the character SYN after switch-on or after receiving SYN.
3. ID7-Base acknowledges the receipt of SYN again with SYN and signals its readiness to receive with ACK.
4. The computer signals its readiness to receive with ACK.
5. During operation the ID7-Base receives data and transmits ACK when it is ready to receive data again.
The computer receives data and transmits ACK when it is ready to receive data again.

Set print mode

| PRINT MODE | Configure printout on an external printer |
|---|--|
| HANDSHAKE | Possible settings: <ul style="list-style-type: none"> • NO HANDSHAKE • CL HANDSHAKE • XON-XOFF PROTOCOL |
| LINE LENGTH | Enter number of characters per line. Possible settings: 1 ... 80 characters Factory setting: 40 characters |
| LINE FRAMING | Enter ASCII character for line framing. Possible settings: ASCII 0 ... 255 Factory setting: ASCII 013 010 (C _R L _F) |
| CONFIGURATION PRINTOUTS TRANSFER KEY CODE A KEY ... CODE D KEY DYNAMIC KEY Pac keys | Configuration of printouts assigned to the individual keys. The current configuration for each offered key can be printed out with CHANGE CONFIGURATION, EDIT, PRINT. For each selected key the printout can be configured as follows: <ul style="list-style-type: none"> • DELETE ALL • STANDARD SETTING key-specific • CHANGE CONFIGURATION see below |
| AUTOMATIC PRINT-OUT | When AUTOMAT. PRINT-OUT ON is selected, the key configuration of the transfer key (ENTER key) is automatically printed out for each weight change > 10 d. To activate this function in the weighing mode, press the ENTER key once, then a print-out takes place automatically each time the weight changes. |

Change configuration

If CHANGE CONFIGURATION is selected for a key, the function keys change to the following assignment with which the data string can be displayed and edited:

| << | < | EDIT | ↑ | > | >> |
|------------------------------------|---------------------------------------|--|--|-----------------------------------|-----------------------------------|
| Display first block in data string | Display previous block in data string | Edit data string, trigger test printout, see page 37 | Exit level and return to higher-level block; end configuration | Display next block in data string | Display last block in data string |


Example → To display the next block in the data string, press the > key.

Display data string

After selecting **CHANGE CONFIGURATION** the first block of the configured data string appears.

Possible displays

- | | |
|----------------------------------|---|
| • BLOCK XXX | Application block |
| • SPECIAL FUNCTION ----- | Separator line - - - - - |
| • SPECIAL FUNCTION ***** | Separator line * * * * * |
| • SPECIAL FUNCTION +++++ | Separator line + + + + + |
| • SPECIAL FUNCTION BLANK LINE | Blank line |
| • SPECIAL FUNCTION ADVANCE | Paper advance |
| • SPECIAL CHARACTERS NN x XXX | ASCII characters; NN = Number of characters; XXX = Decimal representation of the ASCII character |
| • BUFFER END | appears for last block of the configured data string |



The position of the displayed block in the total data string is shown in the lower left corner of the display.

- 1 the displayed block is the first block of the data string
- 2 the displayed block is approximately in the middle of the data string
- 3 the displayed block is the last block of the data string

Edit data string

If EDIT is selected, the function keys change to the following assignment with which the data string can be edited:

| DEL | PRINT | INS | ↑ | | |
|---|-----------------------|--|---|---|---|
| Remove displayed block from the data string | Trigger test printout | Insert block in the data string, see page 37 | Exit level and return to the higher-level block | — | — |

Insert block

After pressing INS the function keys are assigned the normal assignment for the master mode again.

| INS | Insert block in the data string before the last position shown |
|---|--|
| BLANK LINE | Insert a blank line in the data string. |
| SEPARATOR LINE | Insert separator line in the data string. Possible separator lines: -----, * * * * * , + + + + + + + |
| APPLICATION BLOCKS BLOCK 000/00 WITH TEXT WITH LEADING BLANK SPACES EXTRABLANK SPACES | Insert application block in the data string. Enter block no. and sub-block no. If all sub-blocks are to be inserted, enter sub-block no. 0. Print out designation of application block. Print weights with leading blank spaces. Enter number of additional blank spaces between designation and value. |
| SPECIAL CHARACTERS CHARACTER 000 NUMBER 00 | Insert ASCII characters in the data string. Enter ASCII character in decimal representation. Enter number of characters. |

End configuration

→ Press ↑ key, several times if necessary, until the Yes/No inquiry PAPER ADVANCE and/or SAVE CHANGES appears or until the configured key is displayed again.

Notes

- The PAPER ADVANCE inquiry only appears when no advance has been defined yet.
- The SAVE CHANGES inquiry only appears when the configuration has actually been changed.

4.5.3 Set barcode reader

| BARCODE | Set barcode reader |
|---|---|
| TYPE DL900 LS3603 ... OTHER | <p>Select barcode reader.</p> <p>When one of the barcode readers is selected, the communications and mode parameters for the selected barcode reader are automatically set.</p> <p>For other barcode readers: Settings in the sub-blocks COMMUNICATION and MODE as for the blocks RS232/RS422/RS485/CL, see section 4.5.2. The PRINT MODE setting is not possible when using barcode readers!</p> |
| DESTINATION BLOCK 000/00 | <p>Enter the number of the application block and of the subsequent block with which the barcode entry is to be described.</p> <p>When a target block is selected, barcode information can be read directly into this block without having to press a key beforehand, see section 3.13.2.</p> |

4.5.4 Configure inputs/outputs

| 4 I/O / RELAY BOX 8 | |
|---------------------|---|
| INPUT | Operate inputs internally or externally. |
| INTERNALLY | Factory setting. |
| EXTERNALLY | Inputs are independent of the weighing functions. Read status of the inputs with the AR707 command, see section 6.3.2. |
| OUTPUT | Operate outputs internally or externally. |
| INTERNALLY | Factory setting. |
| EXTERNALLY | Outputs are independent of the weighing functions. Set the outputs via the AW706... command, see section 6.3.2. |

Assignment of inputs/outputs by ID7-Base

Output signals

| | |
|----------|---|
| Output 1 | TOO LITTLE for DeltaTrac application FILLING, CHECKWEIGHING CLASS 1 for DeltaTrac application CLASSIFYING |
| Output 2 | OKAY for DeltaTrac application FILLING, CHECKWEIGHING CLASS 2 for DeltaTrac application CLASSIFYING |
| Output 3 | TOO MUCH for DeltaTrac application FILLING, CHECKWEIGHING CLASS 3 for DeltaTrac application CLASSIFYING |
| Output 4 | Stability of weighing platform |

Input signals

| | |
|---------|-------------------------------|
| Input 1 | ON/OFF key |
| Input 2 | Set weighing platform to zero |
| Input 3 | Tare weighing platform |
| Input 4 | ENTER key |

5 Interface description

To exchange data with a computer, the ID7-Base weighing terminal is equipped with an RS232 interface. Up to 5 additional interfaces are available as an option.

The interfaces operate independently of each other, can be used simultaneously and can be adjusted individually, see section 4.5.

To operate the serial interfaces in the **dialog mode**, one of the following METTLER TOLEDO command sets must be selected in the master mode:

- MMR command set, see section 5.1.
- METTLER TOLEDO Continuous mode, see section 5.2.

5.1 MMR command set

5.1.1 Syntax and formats of communication

Commands and responses for transmitting weights have the following formats:

Command format

| Identification | _ | Weight value | _ | Unit | Framing |
|--|---|---|---|---|--|
| Character sequence for specification of command (1 ... 4 characters) | | 1 ... 8 digits, number of digits variable | | 1 ... 3 characters, number of characters variable | Definable in master mode, factory setting: C _R L _F |

Response format

| Identification | _ | Weight value | _ | Unit | Framing |
|---|---|--|---|--|--|
| Character sequence for specification of response (2 ... 3 characters) | | 10 digits, right-justified, filled out with blank spaces | | 3 characters, left-justified, filled out with blank spaces | definable in master mode, factory setting: C _R L _F |

Example Command Tare specification
Response Tare specification

T _ 1 3 . 2 9 5 _ k g

T B H _ _ _ _ _ 1 3 . 2 9 5 _ k g _

- Data formats
- The following symbols are used in the following command description:

Weight value

Unit

Text_n

10 characters with sign and decimal point, right-justified (with preceding blank spaces)
3 characters, left-justified (with following blank spaces)
maximum of n characters, left-justified
 - The string framing is mandatory, however it is **not** contained in the following command description!
 - Enter commands as ASCII characters. The following ASCII characters are available: 20 hex/32 deci ... 7F hex/127 deci, see section 9.4.

BUS SLAVE
operating mode
(RS485)

In the BUS SLAVE operating mode each command and each response begins with a code for the terminal address.

Terminal address 1 ... 9 Code "1" ... "9" (31H ... 39H)
Terminal address 10 ... 31 Code "a" ... "v" (61H ... 76H)

Example

Command to terminal 3: 3S

Response from terminal 3: 3S_ _ _ _ _ 1 2 . 7 6 5 _ k g _

5.1.2 Command overview

| Command | Meaning | Page |
|-----------|---|-------|
| RO / R1 | Switch keypad on/off | 43 |
| Z | Set weight display to zero after weighing platform stabilization | 43 |
| U_... | Change over terminal to a different weight unit | 43 |
| T | Tare | 44 |
| T_... | Specify tare weight | 44 |
| DY_... | Specify DeltaTrac target value | 45 |
| S | Transmit in case of weighing platform stabilization | 45 |
| SI | Transmit independent of weighing platform stabilization | 45 |
| SIR | Transmit repeatedly independent of weighing platform stabilization | 46 |
| SR | Transmit stabilized weight values repeatedly depending on a weight change | 46 |
| SR_... | Transmit repeatedly depending on weighing platform stabilization with specification of an excursion value | 46 |
| SX | Transmit data record after weighing platform stabilization | 47 |
| SXI | Transmit data record independent of weighing platform stabilization | 47 |
| SXIR | Transmit data record repeatedly independent of weighing platform stabilization | 47 |
| ARNo. | Read information of application block | 48 |
| AWNo._... | Write to application block | 48 |
| D_... | Write to display | 48 |
| P_... | Print alphanumeric characters or barcodes on the GA46 | 48,49 |
| DS | Trigger acoustic signal | 49 |
| ID | Interrogate terminal identification | 49 |
| W_... | Actuating digital outputs | 50 |

5.1.3 Command description

Switch keypad on or off

| | |
|----------|--|
| Command | <input type="text" value="R_0"/> Switch on keypad <input type="text" value="R_1"/> Switch off keypad |
| Response | <input type="text" value="R_B"/> Keypad switched on or off |
| Comments | <ul style="list-style-type: none"> • Factory setting: Keypad switched on. • When the keypad is switched off, the terminal cannot be operated manually. |

Set zero

| | |
|----------|--|
| Command | <input type="text" value="Z"/> Set gross weight display to zero after weighing platform stabilization, effect as when ZERO-SET key is pressed. |
| Response | <input type="text" value="Z_B"/> Weighing platform set to zero <input type="text" value="Z_-"/> Command cannot be executed: Zero-set range dropped below <input type="text" value="Z_+"/> Command cannot be executed: Zero-set range exceeded |
| Comments | <ul style="list-style-type: none"> • Setting to zero is not possible when the weighing platform stabilizes in the zero-set range. • With some weighing platform types setting to zero deletes a saved tare weight. This is indicated with the message TA, see section 5.1.4. |

Changing over to different weight unit

| | |
|----------|--|
| Command | <input type="text" value="U_ _ Unit"/> Change over weight display to different weight unit <input type="text" value="U"/> Change over weight display to first weight unit |
| Response | <input type="text" value="U_B"/> Weight display changed over to different weight unit |
| Comment | Possible units: g, kg, ozt, oz, dwt |

Tare

| | |
|----------|--|
| Command | <p><input type="text" value="T"/></p> <p>Tare weighing platform: After the weighing platform stabilizes, the current weight value is saved as the tare weight and the weight display is set to zero with the weight placed on the platform. Effect as when TARE key is pressed.</p> <p><input type="text" value="T"/> <input type="text" value="_"/> Tare weight (weight value) <input type="text" value="_"/> Unit</p> <p>Specify tare weight: The content of the tare memory is overwritten with the specified tare weight and the net weight is displayed. Effect as when TARE ENTRY, 0 ... 9, ENTER key sequence is pressed.</p> <p><input type="text" value="T"/> <input type="text" value="_"/></p> <p>Delete tare weight.</p> |
| Response | <p><input type="text" value="T"/> <input type="text" value="B"/> <input type="text" value="_"/> <input type="text" value="_"/> Tare weight (weight value) <input type="text" value="_"/> Unit Weighing platform is tared</p> <p><input type="text" value="T"/> <input type="text" value="B"/> <input type="text" value="H"/> <input type="text" value="_"/> Tare weight (weight value) <input type="text" value="_"/> Unit Weighing platform is tared with specified weight</p> <p><input type="text" value="T"/> <input type="text" value="-"/> Command cannot be executed: Tare range dropped below</p> <p><input type="text" value="T"/> <input type="text" value="+"/> Command cannot be executed: Tare range exceeded</p> |
| Comments | <ul style="list-style-type: none"> • Taring is only possible when the weighing platform stabilizes within the tare range. • The tare weight is always transmitted in the first weight unit. • Each taring command overwrites the content of the tare memory with the new tare weight. • Taring with an unloaded weighing platform deletes the tare memory. On some weighing platform types a zero set is carried out in the unloaded state. This is displayed with the message ZA, see section 5.1.4. • On not certified weighing systems the tare weight is automatically rounded to the current increment. • On certified weighing systems: Tare range for MultiRange only in first increment range. |
| Example | <p>Command: <input type="text" value="T"/></p> <p>Response: <input type="text" value="T"/> <input type="text" value="B"/> <input type="text" value="_"/> <input type="text" value="_"/> <input type="text" value="_"/> <input type="text" value="_"/> <input type="text" value="1"/> <input type="text" value="2"/> <input type="text" value="."/> <input type="text" value="6"/> <input type="text" value="5"/> <input type="text" value="0"/> <input type="text" value="_"/> <input type="text" value="k"/> <input type="text" value="g"/> <input type="text" value="_"/></p> |

Specify DeltaTrac target value

| | |
|----------|---|
| Command | <div> <div>D</div><div>Y</div><div>_</div> </div> Target weight (weight value) <div>_</div> Unit <div>_</div> Tolerance <div>_</div> % Specify DeltaTrac target value <div> <div>D</div><div>Y</div> </div> Delete DeltaTrac target value |
| Response | <div> <div>D</div><div>B</div> </div> DeltaTrac target value loaded/deleted |
| Comment | Watch limits, see section 3.1.1 |
| Example | Command: <div> <div>D</div><div>Y</div><div>_</div> <div>4</div><div>.</div><div>5</div><div>_</div> <div>k</div><div>g</div><div>_</div> <div>5</div><div>_</div> <div>%</div> </div> Response: <div> <div>D</div><div>B</div> </div> |

Transmit content of display

| | |
|----------|--|
| Command | <div>S</div> Transmit a stabilized weight when weighing platform is stabilized. <div>S</div> <div>I</div> Transmit a stabilized or dynamic weight independent of weighing platform stabilization. |
| Response | <div>S</div> <div>_</div> <div>_</div> Weight value <div>_</div> Unit Stabilized weight value transmitted <div>S</div> <div>D</div> <div>_</div> Weight value <div>_</div> Unit Dynamic weight value transmitted <div>S</div> <div>I</div> Invalid weight <div>S</div> <div>I</div> <div>_</div> Weighing platform in underload range <div>S</div> <div>I</div> <div>+</div> Weighing platform in overload range |

Transmit content of display repeatedly

| | |
|----------|--|
| Command | <div>S I R</div> Transmit stabilized or dynamic weight values after each measuring cycle independent of weighing platform stabilization. |
| | <div>S R</div> Transmit the next stabilized weight value after a weight change (e. g. different item) and one dynamic and the next stabilized weight value after each deflection > 30 d. |
| | <div>S R _ Deflection weight (weight value) _ Unit</div> Transmit the next stabilized weight value and, depending on the specified deflection, a dynamic weight value after a weight change greater than the specified deflection value. |
| Response | <div>S _ _ Weight value _ Unit</div> Transmit stabilized weight value repeatedly <div>S D _ Weight value _ Unit</div> Transmit dynamic weight value repeatedly |
| Comment | Stop command with <div>S</div> , <div>S I</div> command or by interrupting the interface |
| Example | Command: <div>S R _ 1 4 0 _ k g</div> Responses: <div>S _ _ _ _ _ 2 0 0 . 0 0 _ k g</div> 1st item <div>S D _ _ _ _ _ 3 4 5 . 8 5 _ k g</div> <div>S _ _ _ _ _ 4 1 0 . 5 0 _ k g</div> 2nd item |

Transmit data record

| | |
|----------|--|
| Command | <p><code>S,X</code> Transmit a data record with stabilized weight values after weighing platform stabilization. Effect as if ENTER key is pressed.</p> <p><code>S,X,I</code> Transmit a data record with stabilized or dynamic weight values independent of weighing platform stabilization.</p> <p><code>S,X,I,R</code> Transmit data records with stabilized or dynamic weight values repeatedly independent of weighing platform stabilization.</p> |
| Response | <p><code>S,X,_,_ Application block _,_ Application block ...</code> <code>A No. _ Data record</code> Data record with stabilized weight values transmitted</p> <p><code>S,X,D,_ Application block _,_ Application block ...</code> <code>A No. _ Data record</code> Data record with dynamic weight values transmitted</p> <p><code>S,X,I</code> Invalid value <code>S,X,I,-</code> Weighing platform in underload range <code>S,X,I,+</code> Weighing platform in overload range</p> |
| Comments | <ul style="list-style-type: none"> Number of application block: three-digit with leading zeros. The content of the corresponding application block is contained in data record, see chapter 6. Standard data record consists of 3 blocks: <p> <code>S,X,_,_ A,0,1,1 _ Gross weight (weight value) _ Unit _ _</code> <code>A,0,1,2 _ Net weight (weight value) _ Unit _ _</code> <code>A,0,1,3 _ Tare weight (weight value) _ Unit</code> </p> The continuous transmission of data records started with the <code>S,X,I,R</code> command can be stopped with the <code>S,X</code> or <code>S,X,I</code> command. |
| Example | <p>Command: <code>S,X,I</code></p> <p>Response: Standard data record</p> <p> <code>S,X,D,_ A,0,1,1 _ _ _ _ _ 2,3 . 6,5,0 _ k,g _ _</code> <code>_ _ A,0,1,2 _ _ _ _ _ 2,1 . 6,5,0 _ k,g _ _</code> <code>_ _ A,0,1,3 _ _ _ _ _ 2 . 0,0,0 _ k,g _ _</code> </p> |

Read application block

| | | |
|----------|--|--|
| Command | <input type="text" value="A"/> <input type="text" value="R"/> <input type="text" value="No."/> | Read content of application block |
| Response | <input type="text" value="A"/> <input type="text" value="B"/> <input type="text" value="Information"/> | Content of application block transmitted |
| Comments | <ul style="list-style-type: none"> • Transmitted information is dependent on application block, see chapter 6. • Number of application block must be entered as 3 digits with preceding zeros. | |

Write to application block

| | | |
|----------|--|------------------------------|
| Command | <input type="text" value="A"/> <input type="text" value="W"/> <input type="text" value="No."/> <input type="text" value="Information"/> | Written to application block |
| | <input type="text" value="A"/> <input type="text" value="W"/> <input type="text" value="No."/> | Reset application block |
| | <input type="text" value="A"/> <input type="text" value="W"/> <input type="text" value="No."/> <input type="text" value="Information"/> | Delete application block |
| Response | <input type="text" value="A"/> <input type="text" value="B"/> | Written to application block |
| Comments | <ul style="list-style-type: none"> • Information to be entered is dependent on target block, see chapter 6. • Deleting and resetting have same effect. | |

Write to display

| | | |
|----------|---|------------------------------|
| Command | <input type="text" value="D"/> <input type="text" value="Text_20"/> | Write to display |
| | <input type="text" value="D"/> <input type="text" value="Information"/> | Switch display to dark |
| | <input type="text" value="D"/> | Set display to normal status |
| Response | <input type="text" value="D"/> <input type="text" value="B"/> | Written to display |
| Comments | <ul style="list-style-type: none"> • Character stock: ASCII characters 20 hex/32 deci ... 7F hex/127 deci, see section 9.4. • Watch capitalization. | |

Alphanumeric printout on GA46 printer

| | | |
|----------|--|---------------------------------|
| Command | <input type="text" value="P"/> <input type="text" value="Text_20"/> | Print text as per setting |
| | <input type="text" value="P"/> <input type="text" value="\$"/> <input type="text" value="1"/> <input type="text" value="Text_20"/> | Print text in small type |
| | <input type="text" value="P"/> <input type="text" value="\$"/> <input type="text" value="2"/> <input type="text" value="Text_20"/> | Print text in normal type |
| | <input type="text" value="P"/> <input type="text" value="\$"/> <input type="text" value="3"/> <input type="text" value="Text_20"/> | Print text in large type |
| | <input type="text" value="P"/> <input type="text" value="Information"/> | Print blank line |
| Response | <input type="text" value="P"/> <input type="text" value="B"/> | Alphanumeric characters printed |
| Comments | <ul style="list-style-type: none"> • Character stock: ASCII characters 20 hex/32 deci ... 7F hex/127 deci, see section 9.4. • Test is printed in last selected type size. • Watch capitalization. | |

Barcode printout on GA46 printer

| | | |
|----------|---|---|
| Command | <div>P _ \$ # 1 Text_20, barcode-specific</div> <div>P _ \$ # 2 Text_8, barcode-specific</div> <div>P _ \$ # 3 Text_13, barcode-specific</div> <div>P _ \$ # 4 Text_20, barcode-specific</div> <div>P _ \$ # 5 Text_20, barcode-specific</div> <div>P _ \$ # 6 Text_20, barcode-specific</div> <div>P _</div> | Print Code 39 Print EAN 8 Print EAN 13 Print EAN 128 Print Code 2 of 5 Print Code 2 of 5 interleaved Print blank line |
| Response | <div>P _ B</div> | Barcode printed |
| Comments | <ul style="list-style-type: none"> • Character stock: ASCII characters 20 hex/32 deci ... 7F hex/127 deci, see section 9.4. • With Code 39, 3 barcodes can be printed next to each other. Separating characters: \$\$ or H_T (ASCII character 09 hex/9 deci). Arrangement of barcodes: Barcode 2, Barcode 1, Barcode 3. | |

Acoustic signal

| | | |
|----------|------------------|--|
| Command | <div>D _ S</div> | Generate short acoustic signal (beep tone) in terminal |
| Response | <div>D _ B</div> | Acoustic signal generated in terminal |

Identification

| | | |
|----------|--|--|
| Command | <div>I _ D</div> | Interrogate identification of terminal |
| Response | <div>I _ D _ 7 _ Program number of Pac</div> | |

Actuating digital outputs

| | | | | | | | | | | | | | | | | | | | | | |
|--------------------|--|------------------|---|------------------|---|------------------|---|------------------|---|------------------|----|------------------|----|------------------|----|------------------|-----|------------------|---|--------------------|-----|
| Command | <div><div>W _ Status</div><div>W _ Status 1 _ Time 1 _ Status 2 _ Time 2 _ ... Status 4 _ Time 4 _ Status 5</div><div>W , W _</div><div>Status:<div>Each output is assigned a value. The total of the values of those outputs which are to be closed is indicated as the "Status".<table><tr><td>Digital output 1</td><td>1</td></tr><tr><td>Digital output 2</td><td>2</td></tr><tr><td>Digital output 3</td><td>4</td></tr><tr><td>Digital output 4</td><td>8</td></tr><tr><td>Digital output 5</td><td>16</td></tr><tr><td>Digital output 6</td><td>32</td></tr><tr><td>Digital output 7</td><td>64</td></tr><tr><td>Digital output 8</td><td>128</td></tr><tr><td>All outputs open</td><td>0</td></tr><tr><td>All outputs closed</td><td>255</td></tr></table></div><div>Time<div>1 ... 99999 ms</div></div></div></div> | Digital output 1 | 1 | Digital output 2 | 2 | Digital output 3 | 4 | Digital output 4 | 8 | Digital output 5 | 16 | Digital output 6 | 32 | Digital output 7 | 64 | Digital output 8 | 128 | All outputs open | 0 | All outputs closed | 255 |
| Digital output 1 | 1 | | | | | | | | | | | | | | | | | | | | |
| Digital output 2 | 2 | | | | | | | | | | | | | | | | | | | | |
| Digital output 3 | 4 | | | | | | | | | | | | | | | | | | | | |
| Digital output 4 | 8 | | | | | | | | | | | | | | | | | | | | |
| Digital output 5 | 16 | | | | | | | | | | | | | | | | | | | | |
| Digital output 6 | 32 | | | | | | | | | | | | | | | | | | | | |
| Digital output 7 | 64 | | | | | | | | | | | | | | | | | | | | |
| Digital output 8 | 128 | | | | | | | | | | | | | | | | | | | | |
| All outputs open | 0 | | | | | | | | | | | | | | | | | | | | |
| All outputs closed | 255 | | | | | | | | | | | | | | | | | | | | |
| Response | <div><div>W B</div><div>Digital outputs set</div></div> | | | | | | | | | | | | | | | | | | | | |
| Comments | <div><ul style="list-style-type: none">• Max. 5 statuses "Status" and 4 intervals "Time" are possible. After sequence has been run, digital outputs freeze in last status "Status".• A break in the port has no effect on the outputs.• If terminal receives a new W command before time sequence has been run, ongoing sequence will be aborted immediately.• If limits for "Status" and "Time" are not adhered to, error message EL appears.</div> | | | | | | | | | | | | | | | | | | | | |
| Example | <div><div>Command: <div>W _ 5</div><div>Digital outputs 1 and 3 are closed, all others opened</div></div><div>Command: <div>W _ 1 _ 1,0,0,0 _ 3,2 _ 5,0,0,0 _ 3,3 _ 5,0,0 _ 0</div><div>triggers following sequence:</div><div><div><div><div>1 s</div><div>0.5 s</div></div><div><div>Output 1</div><div>Output 6</div></div><div><div>5 s</div></div></div></div></div></div> | | | | | | | | | | | | | | | | | | | | |

5.1.4 Terminal messages – only with RS232, RS422 or CL

In the dialog mode the ID7-Base weighing terminal transmits an acknowledgement to the computer each time a key is pressed.

When this pressing of a key is replaced with an interface command, the acknowledgement only differs in the second character in the response format which is part of the command:

| Function | Key | Acknowledgement |
|---|-----------|--|
| Set zero | | <code>Z A</code> |
| Tare | | <code>T A</code> |
| Specify tare weight | | <code>T A H</code> ... (see command T_ ...) |
| Change over unit | | <code>U A</code> |
| Transmit data record in case of weighing platform stabilization | | <code>S T _ _</code> ... (see command SX) |
| Switch over weighing platform | | <code>S A _ n</code> n = weighing platform 1 ... 3 |
| Dynamic weighing | | <code>A A 0 1 6 _</code> Weight value _ Unit |
| Identification A ... D | A ... D | <code>K x _ Identification</code> x = A, B, C, D 20 characters, right-justified |
| Function keys | F1 ... F6 | <code>K F _ x</code> x = I, J, K, L, M, N |

5.1.5 Fault messages

Fault messages always consist of 2 characters and a string frame.

The string frame can be defined in the master mode (section 4.5.2).

`E T`

Transmission error

The terminal transmits a transmission error for errors in the received bit sequence, e. g. parity errors, missing stop bit.

`E S`

Syntax error

The terminal transmits a syntax error when the received characters cannot be processed, e. g. command does not exist.

`E L`

Logic error

The terminal transmits a logic error when a command cannot be executed, e. g. when an attempt is made to write to a write-protected application block.

5.2 METTLER TOLEDO continuous mode

These operating modes are suitable for continuous data transmission in real time to METTLER TOLEDO devices, e. g. to a second display.

The data are even transmitted when the weighing platform is moving or the gross weight = 0.

There are 2 different continuous modes:

- Continuous mode – net and tare values are continuously transmitted.
- Short continuous mode – only net values are continuously transmitted.

Output format Weight values are always transmitted in the following format:

| | | | | | | | |
|-----|-----|-----|-----|-----|-----|----|-----|
| STX | SB1 | SB2 | SB3 | DF1 | DF2 | CR | CHK |
|-----|-----|-----|-----|-----|-----|----|-----|

| | |
|-------|---|
| STX | ASCII characters 02 hex/2 deci, character for "start of text" is required by some printers |
| SB... | For status bytes, see below |
| DF1 | Data field with 6 digits for the weight value transmitted without a decimal point and unit |
| DF2 | Data field with 6 digits for the tare weight; is not transmitted in the short continuous mode |
| CR | Carriage return (ASCII character 0D hex/13 deci) |
| CHK | Checksum (2-part complement of binary sum of 7 lower bits of all previously transmitted characters, including STX and CR) |

Status byte SB1

| Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|-------|-------|----------------------|-------|------------------|-------|-------|
| 0 | 1 | Rounding / Increment | | Decimal position | | |

| Bit 4 | Bit 3 | Rounding/ Increment |
|-------|-------|------------------------|
| 0 | 1 | 1 |
| 1 | 0 | 2 |
| 1 | 1 | 5 |

| Bit 2 | Bit 1 | Bit 0 | Decimal position |
|-------|-------|-------|---------------------|
| 0 | 0 | 0 | XXXX00 |
| 0 | 0 | 1 | XXXXX0 |
| 0 | 1 | 0 | XXXXXX |
| 0 | 1 | 1 | XXXXX.X |
| 1 | 0 | 0 | XXXX.XX |
| 1 | 0 | 1 | XXX.XXX |
| 1 | 1 | 0 | XX.XXXX |
| 1 | 1 | 1 | X.XXXXX |

Status byte SB2

| Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|-------|-------|-------|----------------------|--------------------------|--------------------|------------------|
| 0 | 1 | 0 lb | 0 Stabiliza- tion | 0 Normal status | 0 Positive sign | 0 Gross value |
| | | 1 kg | 1 Movement | 1 Underload/ overload | 1 Negative sign | 1 Net value |

Status byte SB3

| Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|-------|-------|-------|----------------------------------|--------------|-------|-------|
| 0 | 1 | 0 | 0 Basic state 1 Print request | Weight value | | |

| Bit 2 | Bit 1 | Bit 0 | Weight value |
|-------|-------|-------|---------------------|
| 0 | 0 | 0 | kg / lb (SB2 Bit 4) |
| 0 | 0 | 1 | g |
| 0 | 1 | 0 | t |
| 0 | 1 | 1 | oz |
| 1 | 0 | 0 | ozt |
| 1 | 0 | 1 | dwt |
| 1 | 1 | 0 | ton |
| 1 | 1 | 1 | free unit |

6 Application blocks

Application blocks are internal information memories in which weighing data, calculated quantities, configuration data or character sequences entered with the keypad are stored. The content of the application blocks can be read out or written to with a computer.

When the GA46 printer is connected, the assignment of the application blocks can be printed out, see operating instructions for the GA46 printer.

6.1 Syntax and formats

6.1.1 Read application block

Read

| | | |
|---|---|-----|
| A | R | No. |
|---|---|-----|

The weighing terminal receives the command from the computer to read out the content of the "No." application block. This command is **not** contained in the following description of the application blocks.

Response

| | | | |
|---|---|---|-------------|
| A | B | — | Information |
|---|---|---|-------------|

As a response the weighing terminal transmits the content of the "No." application block to the computer. This response is contained in the following description of the application blocks.

Example Command
Response

| | | | | |
|---|---|---|---|---|
| A | R | 0 | 2 | 1 |
|---|---|---|---|---|

 Read out tare memory 1.

| | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| A | B | — | — | — | — | — | — | — | — | 1 | 0 | . | 5 | — | k | g | — |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|

Note

If an application block is not in use, the weighing terminal transmits the corresponding number of blank spaces in place of the data.

For example, when Tare Memory 1 is not in use, the weighing terminal transmits the following response:

| | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| A | B | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|

6.1.2 Write to application block

Write

| | | | | |
|---|---|-----|---|-------------|
| A | W | No. | — | Information |
|---|---|-----|---|-------------|

The weighing terminal receives the command from the computer to write to the "No." application block. This command is contained in the following description of the application blocks.

Response

| | |
|---|---|
| A | B |
|---|---|

The weighing terminal transmits a confirmation to the computer. This response is **not** contained in the following description of the application blocks.

Example Write

| | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| A | W | 0 | 2 | 1 | — | 1 | 2 | . | 0 | — | k | g | — |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|

Write to tare memory 1.

Response

| | |
|---|---|
| A | B |
|---|---|

Notes

- Only those application blocks can be written to for which the corresponding AW command is listed in the following description.
- An application block can consist of one or more sub-blocks, and the numbering of the sub-blocks begins with 1.
- The sub-blocks of an application block can each contain a maximum of 20 characters.
- The sub-blocks are separated with \$\$ or H_T (ASCII character 09 hex/9 deci):

| | | | | | | | | | | | |
|---|---|-----|---|-------------|----|----|-------------|----|----|-----|-------------|
| A | W | NO. | _ | Sub-block 1 | \$ | \$ | Sub-block 2 | \$ | \$ | ... | Sub-block n |
|---|---|-----|---|-------------|----|----|-------------|----|----|-----|-------------|

- Extensive application blocks are displayed so that each sub-block begins in a new line.
- To write to individual sub-blocks, enter the corresponding number of \$ characters. If only sub-block 1 is written to, the \$ characters are eliminated,
e. g. sub-block 3 written to:

| | | | | | | | | |
|---|---|-----|---|----|----|----|----|-------------|
| A | W | NO. | _ | \$ | \$ | \$ | \$ | Sub-block 3 |
|---|---|-----|---|----|----|----|----|-------------|

6.1.3 Data formats

- In the following description of the application blocks the following data formats are used:

| | |
|---------------------|--|
| <u>Weight value</u> | 10 digits with sign and decimal point, right-justified (with preceding blank space) |
| <u>Unit</u> | 3 characters, left-justified (with following blank spaces) |
| <u>Number_n</u> | Number, n digits, right-justified (with preceding blank spaces) |
| <u>Text_n</u> | maximum of n characters |

- Conclude commands and responses with the string frame C_RL_F (ASCII characters C_R = 0D hex/13 deci, L_F = 0A hex/10 deci). The string frame is **not** contained in the following description.

6.2 TERMINAL, SCALE application blocks

| No. | Content | Format |
|-----|---|--|
| 001 | Terminal type | Response: <code>A,B _ M,e,t,t,l,e,r,-T,o,l,e,d,o,_I,D,7</code> |
| 002 | Program number | Response: <code>A,B _ I,T,0,7,-0,-0,x,x,x _</code> |
| 006 | Transfer key | Response: <code>A,B _ Keys _ _ 2,4</code> Write: <code>A,W 0,0,6 _ \$ \$ 2,4</code> |
| 007 | Current gross weight (2nd weight unit) | Response: <code>A,B _ Weight value _ Unit</code> |
| 008 | Current net weight (2nd weight unit) | Response: <code>A,B _ Weight value _ Unit</code> |
| 009 | Current tare weight (2nd weight unit) | Response: <code>A,B _ Weight value _ Unit</code> Write: <code>A,W 0,0,9 _ Weight value _ Unit</code> |
| 010 | Current weighing platform | Response: <code>A,B _ Number_2</code> Write: <code>A,W 0,1,0 _ Number_2</code> Switch over weighing platform |
| 011 | Current gross weight (1st weight unit) | Response: <code>A,B _ Weight value _ Unit</code> |
| 012 | Current net weight (1st weight unit) | Response: <code>A,B _ Weight value _ Unit</code> |
| 013 | Current tare weight (1st weight unit) | Response: <code>A,B _ Weight value _ Unit</code> Write: <code>A,W 0,1,3 _ Weight value _ Unit</code> |
| 014 | Content of display | Response: <code>A,B _ Display</code> Display = Text_20 or weight value |
| 015 | Date | Response: <code>A,B _ Date</code> Write: <code>A,W 0,1,5 _ Date</code> Date = DD/MM/YY or DD.MM.YY |
| 016 | Dynamic weighing | Response: <code>A,B _ Weight value _ Unit</code> Write: <code>A,W 0,1,6 _ No. of cycles</code> Start weighing cycle Comment: No. of cycles = 1 ... 255 |
| 018 | Difference target/actual weight | Response: <code>A,B _ Weight value _ Unit</code> |
| 019 | Date and time | Response: <code>A,B _ _ _ _ _ D,D / M,M / Y,Y _ _ _</code> <code>_ _ _ _ _ h,h : m,m : s,s</code> Europe <code>A,B _ _ _ _ _ M,M / D,D / Y,Y _ _ _</code> <code>_ _ _ _ _ A/P M _ h,h : m,m : s,s</code> USA Write: <code>A,W 0,1,9 _ D,D / M,M / Y,Y \$ \$</code> <code>_ _ _ _ _ h,h : m,m : s,s</code> Europe <code>A,W 0,1,9 _ M,M / D,D / Y,Y \$ \$</code> <code>_ _ _ _ _ A/P M h,h : m,m : s,s</code> USA Date: instead of "/" also "."; Time: instead of ":" also "/" or "." |

| No. | Content | Format | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|------------------------------|----------------------------|---|------------------------------|-------------|------------|------------------------------|-------------|------------|--------|-------------|------------------------------|---|-------------|--|--------------|--|------|--|---|---|---|---|---|---|------------------------------|-------------|--------|----|----|------------------------------|---|---|---------|-------------|---|---|---|---------|-------------|---|---|---|---------|---|---|---|---------|-------------|---|---|---|---|--------|---|---|---|---------|---|---|---|---|--------|---|---|---|---|--------|
| 020 | Current DeltaTrac | Response: <table><tr><td>A</td><td>B</td><td></td><td>Target weight (weight value)</td><td></td><td>Unit</td><td></td><td></td></tr><tr><td colspan="8">Tolerance value (number_2) %</td></tr></table> Write: <table><tr><td>A</td><td>W</td><td>0</td><td>2</td><td>0</td><td></td><td>Target weight (weight value)</td><td></td><td>Unit</td><td>\$</td><td>\$</td></tr><tr><td colspan="11">Tolerance value (number_2) %</td></tr></table> | A | B | | Target weight (weight value) | | Unit | | | Tolerance value (number_2) % | | | | | | | | A | W | 0 | 2 | 0 | | Target weight (weight value) | | Unit | \$ | \$ | Tolerance value (number_2) % | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A | B | | Target weight (weight value) | | Unit | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Tolerance value (number_2) % | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A | W | 0 | 2 | 0 | | Target weight (weight value) | | Unit | \$ | \$ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Tolerance value (number_2) % | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 021 ... 045 | Tare memory 1 ... 25 | Response: <table><tr><td>A</td><td>B</td><td></td><td>Weight value</td><td></td><td>Unit</td></tr></table> Write: <table><tr><td>A</td><td>W</td><td>0</td><td>x</td><td>x</td><td></td><td>Weight value</td><td></td><td>Unit</td></tr></table> Comment: xx = 21 ... 45 | A | B | | Weight value | | Unit | A | W | 0 | x | x | | Weight value | | Unit | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A | B | | Weight value | | Unit | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A | W | 0 | x | x | | Weight value | | Unit | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 046 ... 070 | DeltaTrac memory 1 ... 25 | Response: <table><tr><td>A</td><td>B</td><td></td><td>Target value (weight value)</td><td></td><td>Unit</td><td></td><td></td></tr><tr><td colspan="8">Tolerance value (number_2) %</td></tr></table> Write: <table><tr><td>A</td><td>W</td><td>0</td><td>x</td><td>x</td><td></td><td>Target value (weight value)</td><td></td><td>Unit</td><td>\$</td><td>\$</td></tr><tr><td colspan="11">Tolerance value (number_2) %</td></tr></table> Comment: xx = 46 ... 70 | A | B | | Target value (weight value) | | Unit | | | Tolerance value (number_2) % | | | | | | | | A | W | 0 | x | x | | Target value (weight value) | | Unit | \$ | \$ | Tolerance value (number_2) % | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A | B | | Target value (weight value) | | Unit | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Tolerance value (number_2) % | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A | W | 0 | x | x | | Target value (weight value) | | Unit | \$ | \$ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Tolerance value (number_2) % | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 071 ... 090 | Text memory 1 ... 20 | Response: <table><tr><td>A</td><td>B</td><td></td><td>Text_20</td></tr></table> Write: <table><tr><td>A</td><td>W</td><td>0</td><td>x</td><td>x</td><td></td><td>Text_20</td></tr></table> Comment: xx = 71 ... 90 | A | B | | Text_20 | A | W | 0 | x | x | | Text_20 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A | B | | Text_20 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A | W | 0 | x | x | | Text_20 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 091 | Barcode EAN 28, EAN 128 | Response: <table><tr><td>A</td><td>B</td><td></td><td>EAN 28</td><td></td><td>EAN 128 01</td><td></td><td>EAN 128 310</td><td></td><td></td></tr><tr><td colspan="10">EAN 128 330</td></tr></table> EAN 28: <table><tr><td>2</td><td>8</td><td>Article</td><td>Check digit</td><td>Weight</td></tr></table> Article: 4-digit Article No. from memory Code A Check digit: 1-digit, calculated by ID7-Base for the weight Weight: 5-digit positive weight value with 3 decimal places between 00.000 kg - 99.999 kg EAN 128 01: <table><tr><td>0</td><td>1</td><td>Article</td></tr></table> or <table><tr><td>0</td><td>1</td><td>Article</td><td>Check digit</td></tr></table> or <table><tr><td>0</td><td>1</td><td>0</td><td>Article</td><td>Check digit</td></tr></table> or <table><tr><td>0</td><td>1</td><td>0</td><td>Article</td></tr></table> Article: Article No. from memory Code A, max. 14 digits Check digit: 1-digit, calculated by ID7-Base Length: total of max. 16 digits EAN 128 310: <table><tr><td>0</td><td>1</td><td>9</td><td>Article</td><td>Check digit</td><td>3</td><td>1</td><td>0</td><td>x</td><td>Weight</td></tr></table> or <table><tr><td>0</td><td>1</td><td>9</td><td>Article</td><td>3</td><td>1</td><td>0</td><td>x</td><td>Weight</td></tr></table> Article: Article No. from memory Code A max. 12 or 13 digits Check digit: 1-digit calculated by ID7-Base x: 0 ... 6, decimal places of weight value Weight: 6-digit net weight value EAN 128 330: <table><tr><td>3</td><td>3</td><td>0</td><td>x</td><td>Weight</td></tr></table> x: 0 ... 6, decimal places of weight value Weight: 6-digit gross weight value | A | B | | EAN 28 | | EAN 128 01 | | EAN 128 310 | | | EAN 128 330 | | | | | | | | | | 2 | 8 | Article | Check digit | Weight | 0 | 1 | Article | 0 | 1 | Article | Check digit | 0 | 1 | 0 | Article | Check digit | 0 | 1 | 0 | Article | 0 | 1 | 9 | Article | Check digit | 3 | 1 | 0 | x | Weight | 0 | 1 | 9 | Article | 3 | 1 | 0 | x | Weight | 3 | 3 | 0 | x | Weight |
| A | B | | EAN 28 | | EAN 128 01 | | EAN 128 310 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| EAN 128 330 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | 8 | Article | Check digit | Weight | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 | Article | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 | Article | Check digit | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 | 0 | Article | Check digit | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 | 0 | Article | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 | 9 | Article | Check digit | 3 | 1 | 0 | x | Weight | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 | 9 | Article | 3 | 1 | 0 | x | Weight | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | 3 | 0 | x | Weight | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Content | Format |
|-------------------|--|---|
| 092 | Barcode EAN 29 | Response: A B _ 2 9 Article Check digit Weight Comment: Article: 4-digit article no. from memory Code A Check digit: 1-digit no., calculated from ID7-Base for the weight Weight: 5-digit positive weight value with 3 places to right of point between 00.000 kg ... 99.999 kg |
| 093 | Barcode EAN 29 A | Response: A B _ 2 9 Article Weight Comment: Article: 5-digit article no. from memory Code A Weight: 5-digit positive weight value with 3 places to right of point between 00.000 kg ... 99.999 kg |
| 094 ... 097 | Identification data Code A ... Code D | Response: A B _ Name (text_20) _ _ Identification (text_20) Write: A W 0 x x _ Name (text_20) \$ \$ Identification (text_20) Comment: xx = 94 ... 97 |
| 098 | Number of last Alibi entry | Response: A B _ Number_6 Note: The data record number is output with leading zeros |

6.3 INTERFACE application blocks

Application blocks are reserved for the possible interface connections.

These application blocks can only be read and written to when an ...-ID7 interface is actually installed on the interface connection concerned.

6.3.1 Serial interfaces

| No. | Content | Format |
|-----|----------------------------|---|
| 101 | Description of application | Response: A B _ ID7 Interfaces |
| 102 | Program designation | Response: A B _ IK07-0-0100 |
| 103 | Transmit buffer COM1 | Response: A B _ Transmit buffer COM1 Write*: A W 1 0 3 _ Information |
| 104 | Transmit buffer COM2 | Response: A B _ Transmit buffer COM2 Write*: A W 1 0 4 _ Information |
| 201 | Description of application | Response: A B _ ID7 Interfaces |
| 202 | Program designation | Response: A B _ IK07-0-0100 |
| 203 | Transmit buffer COM3 | Response: A B _ Transmit buffer COM3 Write*: A W 2 0 3 _ Information |
| 204 | Transmit buffer COM4 | Response: A B _ Transmit buffer COM4 Write*: A W 2 0 4 _ Information |
| 701 | Description of application | Response: A B _ ID7 Interfaces |
| 702 | Program designation | Response: A B _ IK07-0-0100 |
| 703 | Transmit buffer COM5 | Response: A B _ Transmit buffer COM5 Write*: A W 7 0 3 _ Information |
| 704 | Transmit buffer COM6 | Response: A B _ Transmit buffer COM6 Write*: A W 7 0 4 _ Information |

* Comments on the transmit buffers

- The entered information is transmitted directly via the selected interface.
- A transmit buffer contains a maximum of 256 characters.

6.3.2 Digital inputs/outputs

The following application blocks are only available when interface 4 I/O-ID7 is installed on COM5/COM6 or interface RS485-ID7 and relay box 8-ID7 is installed on COM6.

When the weighing terminal checks the outputs, the blocks concerned cannot be written to, and the EL error message appears.

| No. | Content | Format |
|-----|-----------------------------|---|
| 706 | Digital outputs 1 COM5/COM6 | Response: A B _ 8-place binary value * Write: A W 7 0 6 _ 8-place binary value * |
| 707 | Digital inputs 1 COM5/COM6 | Response: A B _ 8-place binary value * |
| 708 | Dig. outputs 2 COM6 | Response: A B _ 8-place binary value * Write: A W 7 0 8 _ 8-place binary value * |
| 709 | Dig. inputs 2 COM6 | Response: A B _ 8-place binary value * |
| 710 | Dig. outputs 3 COM6 | Response: A B _ 8-place binary value * Write: A W 7 1 0 _ 8-place binary value * |
| 711 | Dig. inputs 3 COM6 | Response: A B _ 8-place binary value * |
| 712 | Dig. outputs 4 COM6 | Response: A B _ 8-place binary value * Write: A W 7 1 2 _ 8-place binary value * |
| 713 | Dig. inputs 4 COM6 | Response: A B _ 8-place binary value * |
| 714 | Dig. outputs 5 COM6 | Response: A B _ 8-place binary value * Write: A W 7 1 4 _ 8-place binary value * |
| 715 | Dig. inputs 5 COM6 | Response: A B _ 8-place binary value * |
| 716 | Dig. outputs 6 COM6 | Response: A B _ 8-place binary value * Write: A W 7 1 6 _ 8-place binary value * |
| 717 | Dig. inputs 6 COM6 | Response: A B _ 8-place binary value * |
| 718 | Dig. outputs 7 COM6 | Response: A B _ 8-place binary value * Write: A W 7 1 8 _ 8-place binary value * |
| 719 | Dig. inputs 7 COM6 | Response: A B _ 8-place binary value * |
| 720 | Dig. outputs 8 COM6 | Response: A B _ 8-place binary value * Write: A W 7 2 0 _ 8-place binary value * |
| 721 | Dig. inputs 8 COM6 | Response: A B _ 8-place binary value * |

* 8-place binary value: Bit8, Bit7 ... Bit1

Bit8 = output/input 8 ... Bit1 = output/input 1

7 What to do if ...?

| Error / Display | Possible causes | Remedy |
|-------------------------|---|---|
| Display is dark | <ul style="list-style-type: none"> • No mains voltage • Terminal switched off • Power cord not connected • Brief malfunction | <ul style="list-style-type: none"> → Check mains → Switch on terminal → Plug in power plug → Switch terminal off and on again |
| Underload | <ul style="list-style-type: none"> • Load plate not in place • Preload not applied • Weighing range dropped below | <ul style="list-style-type: none"> → Apply load plate → Apply preload → Set zero |
| Overload | <ul style="list-style-type: none"> • Weighing range exceeded • Weighing platform locked | <ul style="list-style-type: none"> → Relieve weighing platform → Release lock |
| Weight display unstable | <ul style="list-style-type: none"> • Agitated set-up location • Draft • Agitated weighing sample • Contact between load plate and/or weighing sample and surroundings • Power malfunction | <ul style="list-style-type: none"> → Adjust vibration adapter → Avoid drafts → Weigh dynamically → Eliminate contact → Check mains |
| Wrong weight display | <ul style="list-style-type: none"> • Wrong setting to zero of weighing platform • Wrong tare weight • Contact between load plate and/or weighing sample and surroundings • Weighing platform tilted • Wrong weighing platform selected | <ul style="list-style-type: none"> → Relieve weighing platform, set to zero and repeat weighing → Delete tare or enter right tare value → Eliminate contact → Level weighing platform → Select right weighing platform |
| PLUG IN | <ul style="list-style-type: none"> • Weighing platform cable not plugged in | <ul style="list-style-type: none"> → Switch off terminal, plug in weighing platform cable and switch on terminal again → If the message appears again: contact METTLER TOLEDO Customer Service |
| IDENTCODE = | <ul style="list-style-type: none"> • Test cycle started | <ul style="list-style-type: none"> → Complete test by pressing the ZERO-SET key |
| WRONG CODE | <ul style="list-style-type: none"> • Wrong personal code | <ul style="list-style-type: none"> → Enter right personal code |

| Error / Display | Possible causes | Remedy |
|-----------------------|--|--|
| SCALE NO. ERROR | <ul style="list-style-type: none"> Error in weighing cell | <ul style="list-style-type: none"> → Repeat test → If the message appears again: contact METTLER TOLEDO Customer Service |
| OUT OF RANGE | <ul style="list-style-type: none"> Zero set range exceeded Gross weight negative Taring range exceeded Entered value outside permissible range | <ul style="list-style-type: none"> → Relieve weighing platform → Relieve weighing platform and set to zero → Relieve weighing platform and set to zero → Enter permissible value |
| NOT ALLOWED | <ul style="list-style-type: none"> Wrong cycle time for dynamic weighing Weighing platform does not exist Print with negative weight value | <ul style="list-style-type: none"> → Enter cycle time between 1 and 255 cycles → Connect weighing platform → Relieve weighing platform, set to zero and repeat weighing |
| NOT EXISTENT | <ul style="list-style-type: none"> Recalled memory not assigned | <ul style="list-style-type: none"> → Recall other memory |
| NO DATA TRANSFER | <ul style="list-style-type: none"> Weighing platform does not transmit data to the terminal | <ul style="list-style-type: none"> → Switch terminal off and on again → If the message appears again: contact METTLER TOLEDO Customer Service |
| INTERF. COM X – BREAK | <ul style="list-style-type: none"> Break in receiving cable of specified interface | <ul style="list-style-type: none"> → Check cable and connectors → Check external devices (on/off) |
| TRANSMIT BUFFER FULL | <ul style="list-style-type: none"> No transmission Too many key messages and baud rate too low | <ul style="list-style-type: none"> → Check handshake → Increase baud rate |
| KEY BUFFER FULL | <ul style="list-style-type: none"> Data string currently being edited contains too many blocks | <ul style="list-style-type: none"> → Remove blocks from data string |
| ERROR BARCODE | <ul style="list-style-type: none"> The specified application block contains no data Wrong sub-block selected, e.g. sub-block 0 | <ul style="list-style-type: none"> → Select application block which contains data → Select permissible sub-block |
| NO BLOCK | <ul style="list-style-type: none"> Entered application block does not exist | <ul style="list-style-type: none"> → Enter different application block |
| BUFFER IS FULL | <ul style="list-style-type: none"> Data string of transfer key contains more than 10 application blocks | <ul style="list-style-type: none"> → Change configuration of transfer key |


| Error / Display | Possible causes | Remedy |
|-----------------|---|---|
| DISPLAY MODE | <ul style="list-style-type: none">• Weighing cell defective• 2 weighing platforms with same scale number connected | <ul style="list-style-type: none">→ Contact METTLER TOLEDO Customer Service→ Contact METTLER TOLEDO Customer Service |

8 Technical data and accessories





8.1 Technical data

| Terminal | | | | | | | |
|--|--|--------------------|-------------|---------------------|-------------|---------------------|-------------|
| Display | <ul style="list-style-type: none"> • Active, brightly lit green VFD dot matrix display, with graphics capabilities, 40 x 170 pixels, display field 135 x 46 mm • BIG WEIGHT DISPLAY with 35 mm high characters • Cover of scratch-resistant, hardened, antireflection glass | | | | | | |
| Keypad | <ul style="list-style-type: none"> • Tactile-touch membrane keypad with acoustic acknowledgement • Scratch-resistant marking, 3-color • 4 keys A to D for identification data, 6 function keys with function change and info key, 4 scale function keys, numerical keypad • Alphanumeric input possible with function keys • Standard connection for external MFII keypad | | | | | | |
| Housing | <ul style="list-style-type: none"> • All nickel chromium steel DIN X5 CrNi 1810 • Weight: net 3.5 kg; gross 5 kg | | | | | | |
| Protection type (IEC 529, DIN 40050) | <ul style="list-style-type: none"> • Dust and water-tight as per IP68 • Resistant to high-pressure and steam jet cleaning as per IPX9K | | | | | | |
| Power supply | <ul style="list-style-type: none"> • 100 V – 240 V, +10/–15 %; 50/60 Hz • Power cord with grounded plug, length approx. 2.5 m • Power consumption approx. 60 VA | | | | | | |
| Ambient conditions as per EN 60950 | <ul style="list-style-type: none"> • Pollution degree 2 • Overvoltage category II • Maximum operating elevation in m above sea level: 2000 m | | | | | | |
| Ambient temperature | <ul style="list-style-type: none"> • Operation: –10 – +40 °C for weighing platforms of certification class III 0 – +40 °C for weighing platforms of certification class II • Storage: –25 – +60 °C | | | | | | |
| Relative humidity | 20 – 80 %, non-condensing | | | | | | |
| Weighing platform connection | <ul style="list-style-type: none"> • 1 IDNet connection standard for METTLER TOLEDO weighing platforms of the series D, F, K, N, Spider ID, DigiTOL, analog scales with AWU 3/6 and analysis and precision scales of the series B, G and R • 2 IDNet additional connections possible or 1 analog and 1 IDNet connection | | | | | | |
| Interface connection | 1 RS232 connection standard, maximum of 5 additional interface connections possible | | | | | | |
| Total load of all output voltages on the ID7- Base | <table> <tr> <td>Output voltage 5 V</td><td>max. 600 mA</td></tr> <tr> <td>Output voltage 12 V</td><td>max. 200 mA</td></tr> <tr> <td>Output voltage 24 V</td><td>max. 100 mA</td></tr> </table> | Output voltage 5 V | max. 600 mA | Output voltage 12 V | max. 200 mA | Output voltage 24 V | max. 100 mA |
| Output voltage 5 V | max. 600 mA | | | | | | |
| Output voltage 12 V | max. 200 mA | | | | | | |
| Output voltage 24 V | max. 100 mA | | | | | | |

| Weighing functions | |
|--------------------------|--|
| Tare compensation | At the press of a button or automatically, up to maximum load (subtractive) |
| Tare target value | <ul style="list-style-type: none"> • For single-range scales over entire weighing range (subtractive) • For multi-range scales depending on national calibration regulations • 25 stored tare memories, protected against power failure |
| Tare calculation | Tare addition, tare multiplication, sub-tare |
| Tare indicator | NET lights up with saved tare weight |
| DeltaTrac | <ul style="list-style-type: none"> • Analog display of dynamic measured values • With optical marks for target value and tolerances • 3 selectable applications • 25 DeltaTrac memories, protected against power failure |
| Setting to zero | Automatic or manual |
| Gross changeover | Display of weight value can be changed over to gross weight at press of a button |
| Unit changeover | Unit can be changed over to weight units kg, g, lb, oz, ozt, dwt in dependence on national calibration regulations at press of a button |
| Dynamic weighing | <ul style="list-style-type: none"> • Cycle time adjustable from 1 – 255 cycles • Automatic printout selectable |
| Stabilization detector | 4-step, with motion indicator |
| Weighing process adapter | 3-step adjustment to weighing sample |
| Vibration adapter | 3-step adjustment to ambient conditions |
| Test | Test function for displaying identcode and for checking weighing platform |
| Identification data | <ul style="list-style-type: none"> • 4 memories for 20 alphanumeric characters, can be recalled with keys A to D • Each memory can be assigned a fixed name which can be written in the marking field next to the corresponding key • 25 memories for frequently used identification data |
| Info function | Displays of current weighing data, identification data and memories at the press of a button |
| Date and time | <ul style="list-style-type: none"> • For printout or output via the data interface • Quartz-controlled, 12 or 24-hour display, automatic calendar function, Europe or US format, protected against power failures |

| Interface RS232-ID7 | |
|---|---|
| Interface type | Voltage interface as per EIA RS232C/DIN 66020 (CCITT V.24/V.28) |
| Control signals DTR, DSR | <ul style="list-style-type: none"> Signal level 0 (for $R_L > 3 \text{ k}\Omega$): $-3 \text{ V} - -25 \text{ V}$ (low level) Signal level 1 (for $R_L > 3 \text{ k}\Omega$): $+3 \text{ V} - +25 \text{ V}$ (high level) |
| Data lines TXD, RXD | <ul style="list-style-type: none"> Signal level 0 (for $R_L > 3 \text{ k}\Omega$): $+3 \text{ V} - +25 \text{ V}$ (high level) Signal level 1 (for $R_L > 3 \text{ k}\Omega$): $-3 \text{ V} - -25 \text{ V}$ (low level) |
| Interface parameters | Operating mode full duplex Transmission type bit serial, asynchronous Transmission code ASCII Data bits 7/8 Stop bits 1/2 Parity parity even, parity odd, parity space, parity mark, no parity Baud rate 150, 300, 600, 1200, 2400, 4800, 9600, 19200 baud |
| Socket  External view | 8-pin circular connector, socket Pin 1 Ground Pin 2 TXD, transmission line of scale Pin 3 RXD, receiving line of scale Pin 4 DTR, Data Terminal Ready Pin 5 +5 V, max. 250 mA (factory setting, for COM1 – COM6) or +12 V, max. 100 mA (for COM2 – COM6 only); configuring of Pin 5, see section 9.6 Pin 6 Signal Ground Pin 8 DSR, Data Set Ready |
| Cable | <ul style="list-style-type: none"> Shielded, stranded in pairs, max. 15 m Cable resistance $\leq 125 \text{ }\Omega/\text{km}$ Cable cross section $\geq 0.14 \text{ mm}^2$ Cable capacity $\leq 130 \text{ nF/km}$ |

Dimensions



Dimensions in mm

8.2 Accessories

| Applications | | Order No. |
|----------------|---|------------|
| ControlPac-ID7 | Basic functions, checking, classifying | 22 001 081 |
| CountPac-ID7 | Basic functions, convenient counting, totalizing | 22 001 075 |
| DataPac-ID7 | Basic functions, data communication | 22 001 077 |
| DosPac-ID7 | Basic functions, dispensing, filling | 22 001 079 |
| DosPac-R-ID7 | Basic functions, multi-component dispensing | 22 001 080 |
| FormPac-ID7 | Basic functions, formulation, dispensing | 22 001 076 |
| SumPac-ID7 | Basic functions, totalizing, inventory management | 22 001 078 |

| Weighing platform connections | | Order No. |
|-------------------------------|---|------------|
| IDNet ID7 | <ul style="list-style-type: none"> • Connection for an IDNet weighing platform • Max. of 2 additional connections possible | 22 001 082 |
| Analog Scale ID7 | <ul style="list-style-type: none"> • Connection for a weighing platform with an analog signal output • Max. of 1 analog weighing platform connection possible | 22 001 083 |
| LC IDNet R/G | Connection set for connecting METTLER TOLEDO R/G scales to IDNet connection of ID7-Base | 00 229 110 |
| LC IDNet B | Connection set for connecting METTLER TOLEDO B scales to IDNet connection of ID7-Base | 00 229 225 |
| GD17 | Connection set for connecting DigiTOL scales to IDNet connection of ID7-Base | 00 507 073 |

| Serial data interfaces | | Order No. |
|-------------------------------------|---|--|
| CL20mA-ID7 | CL 20 mA interface | 22 001 084 |
| Accessories for CL20mA-ID7 | CL cable, 3 m Mating connector, 7-pin Second-display cable CL20mA-ID7 – ID1 Plus/ID3s/ID7, 10 m Extension cable for second display, 10-pin, 10 m Adapter cable PE / CL, 0.3 m | 00 503 749 00 503 745 00 504 511 00 504 134 22 003 029 |
| RS232-ID7 | RS232 interface | 22 001 085 |
| Accessories for RS232-ID7 | RS232 cable/DTE, 3 m RS232 cable/DCE, 3 m RS232 cable/PC, 3 m RS232 cable/9-pin, 3 m Mating connector, 8-pin | 00 503 754 00 503 755 00 504 374 00 504 376 00 503 756 |
| RS422-ID7 | RS422 interface, electrically isolated | 22 003 031 |
| RS485-ID7 | RS485 interface, electrically isolated | 22 001 086 |
| Accessories for RS422-ID7/RS485-ID7 | RS422/485 cable, 6-pin, open end, 3 m Mating connector, 6-pin | 00 204 933 00 204 866 |
| 8-ID7 relay box | 8 digital inputs, 8 digital outputs, for connection to RS485-ID7 | 22 001 089 |
| Accessories for 8-ID7 relay box | RS422/485 cable, 6-pin, open end, 3 m Power supply unit for 8-ID7 relay box, 24 V DC | 00 204 933 00 505 544 |

| Digital inputs/outputs | | Order No. |
|---------------------------------|---|--------------------------|
| 4 I/O-ID7 | 4 digital inputs, 4 digital outputs | 22 001 087 |
| 4-ID7 relay box | Relay box for 4 I/O-ID7; 4 digital inputs, 4 digital outputs, for connection to 4 I/O-ID7 | 22 001 088 |
| Accessories for 4-ID7 relay box | Cable for 4 I/O-ID7, 19-pin, open end, 10 m Mating connector, 19-pin | 00 504 458 00 504 461 |
| 8-ID7 relay box | 8 digital inputs, 8 digital outputs, for connection to RS485-ID7 | 22 001 089 |
| Accessories for 8-ID7 relay box | RS422/485 cable, 6-pin, open end, 3 m Power supply unit for 8-ID7 relay box, 24 V DC | 00 204 933 00 505 544 |

| Digital/analog interface | | Order No. |
|--------------------------------------|--|--------------------------|
| Analog Output-ID7 | Digital/analog output 0 – 10 V, 0 – 20 mA or 4 – 20 mA | 22 001 090 |
| Accessories for Analog Output-ID7 | Cable for Analog Output-ID7, 5-pin, 3 m Mating connector, 5-pin | 00 204 930 00 205 538 |

| Alibi memory | | Order No. |
|------------------|---|------------|
| Alibi Memory-ID7 | Archiving of certification-relevant weighing data | 22 001 663 |

| Printer | | Order No. |
|----------------------|--|------------|
| GA46 | Printer in separate tabletop housing of nickel chromium steel, protection type IP21 Printing of weighing data and barcodes on 62 mm wide thermal paper Interface RS232, cable approx. 2.5 m For technical details see data sheet GA46 | 00 505 471 |
| GA46/0.4 m | As for GA46, however with 0.4 m cable | 00 507 229 |
| GA46-W | As for GA46, however with integrated paper winding device and transparent PVC cover, protection type IP65 | 00 505 799 |
| GA46-W/0.4 m | As for GA46-W, however with 0.4 m cable | 00 507 230 |
| Accessories for GA46 | Protective cover for GA46 | 00 507 224 |

| External keypad | | Order No. |
|-------------------------|--|------------|
| AK-MFII | Compact, alphanumeric membrane keypad for connection to the standard-equipment 5-pin MFII circular connector Housing of all nickel chromium steel, protection type IP65 Dimensions (W x D x H): 380 mm x 158 mm x 30 mm Cable approx. 1 m | 00 505 490 |
| Accessories for AK-MFII | Keypad-terminal adapter | 00 208 047 |

| Other accessories | | Order No. |
|-------------------|--|--------------------------|
| Protective covers | 3 pieces | 22 001 091 |
| Wall bracket | black, plastic-coated completely rust-proof | 00 504 129 00 504 130 |
| Floor stand | black, plastic-coated completely rust-proof | 00 504 131 00 504 132 |
| Stand socket | black, plastic-coated completely rust-proof | 00 503 700 00 503 701 |
| Bracket stand | black, plastic-coated completely rust-proof | 00 504 127 00 504 128 |

9 Appendix

9.1 Fix-tare

→ Copy this list and enter your tare constants.

| Fix-tare no. | Appl. block no. | Tare value | Comment |
|--------------|-----------------|------------|---------|
| 1 | 21 | | |
| 2 | 22 | | |
| 3 | 23 | | |
| 4 | 24 | | |
| 5 | 25 | | |
| 6 | 26 | | |
| 7 | 27 | | |
| 8 | 28 | | |
| 9 | 29 | | |
| 10 | 30 | | |
| 11 | 31 | | |
| 12 | 32 | | |
| 13 | 33 | | |
| 14 | 34 | | |
| 15 | 35 | | |
| 16 | 36 | | |
| 17 | 37 | | |
| 18 | 38 | | |
| 19 | 39 | | |
| 20 | 40 | | |
| 21 | 41 | | |
| 22 | 42 | | |
| 23 | 43 | | |
| 24 | 44 | | |
| 25 | 45 | | |

9.2 Delta-fix

→ Copy this list and enter your DeltaTrac constants.

| Delta-fix no. | Appl. block no. | Target value | Tolerance | Comment |
|---------------|-----------------|--------------|-----------|---------|
| 1 | 46 | | | |
| 2 | 47 | | | |
| 3 | 48 | | | |
| 4 | 49 | | | |
| 5 | 50 | | | |
| 6 | 51 | | | |
| 7 | 52 | | | |
| 8 | 53 | | | |
| 9 | 54 | | | |
| 10 | 55 | | | |
| 11 | 56 | | | |
| 12 | 57 | | | |
| 13 | 58 | | | |
| 14 | 59 | | | |
| 15 | 60 | | | |
| 16 | 61 | | | |
| 17 | 62 | | | |
| 18 | 63 | | | |
| 19 | 64 | | | |
| 20 | 65 | | | |
| 21 | 66 | | | |
| 22 | 67 | | | |
| 23 | 68 | | | |
| 24 | 69 | | | |
| 25 | 70 | | | |

9.3 Fixed texts

→ Copy this list and enter your fixed texts.

| Fixed text no. | Appl. block no. | Content | Comment |
|----------------|-----------------|---------|-------------------------|
| 1 | 71 | | |
| 2 | 72 | | |
| 3 | 73 | | |
| 4 | 74 | | |
| 5 | 75 | | |
| 6 | 76 | | |
| 7 | 77 | | |
| 8 | 78 | | |
| 9 | 79 | | |
| 10 | 80 | | |
| 11 | 81 | | |
| 12 | 82 | | |
| 13 | 83 | | |
| 14 | 84 | | |
| 15 | 85 | | |
| 16 | 86 | | |
| 17 | 87 | | |
| 18 | 88 | | |
| 19 | 89 | | |
| 20 | 90 | | appears after switch-on |

| Code | Appl. block no. | Name | Content |
|--------|-----------------|------|---------|
| Code A | 94 | | |
| Code B | 95 | | |
| Code C | 96 | | |
| Code D | 97 | | |

9.4 Table of representable characters

| hex | deci | ASCII US | hex | deci | ASCII US | hex | deci | ASCII US | hex | deci | ASCII US | hex | deci | ASCII US |
|-----|------|-------------|-----|------|-------------|-----|------|-------------|-----|------|-------------|-----|------|-------------|
| 00 | 0 | NUL | 34 | 52 | 4 | 68 | 104 | h | 9C | 156 | ᄐ | D0 | 208 | ⌚ |
| 01 | 1 | SOH | 35 | 53 | 5 | 69 | 105 | i | 9D | 157 | ₡ | D1 | 209 | ⌚ |
| 02 | 2 | STX | 36 | 54 | 6 | 6A | 106 | j | 9E | 158 | ₢ | D2 | 210 | ⌚ |
| 03 | 3 | ETX | 37 | 55 | 7 | 6B | 107 | k | 9F | 159 | ₣ | D3 | 211 | ⌚ |
| 04 | 4 | EOT | 38 | 56 | 8 | 6C | 108 | l | A0 | 160 | á | D4 | 212 | ⌚ |
| 05 | 5 | ENQ | 39 | 57 | 9 | 6D | 109 | m | A1 | 161 | í | D5 | 213 | ⌚ |
| 06 | 6 | ACK | 3A | 58 | : | 6E | 110 | n | A2 | 162 | ó | D6 | 214 | ⌚ |
| 07 | 7 | BEL | 3B | 59 | ; | 6F | 111 | o | A3 | 163 | ú | D7 | 215 | ⌚ |
| 08 | 8 | BS | 3C | 60 | < | 70 | 112 | p | A4 | 164 | ñ | D8 | 216 | ⌚ |
| 09 | 9 | HT | 3D | 61 | = | 71 | 113 | q | A5 | 165 | Ñ | D9 | 217 | ⌚ |
| 0A | 10 | LF | 3E | 62 | > | 72 | 114 | r | A6 | 166 | ª | DA | 218 | ⌚ |
| 0B | 11 | VT | 3F | 63 | ? | 73 | 115 | s | A7 | 167 | º | DB | 219 | ⌚ |
| 0C | 12 | FF | 40 | 64 | @ | 74 | 116 | t | A8 | 168 | ¿ | DC | 220 | ⌚ |
| 0D | 13 | CR | 41 | 65 | A | 75 | 117 | u | A9 | 169 | ⌚ | DD | 221 | ⌚ |
| 0E | 14 | SO | 42 | 66 | B | 76 | 118 | v | AA | 170 | ⌚ | DE | 222 | ⌚ |
| 0F | 15 | SI | 43 | 67 | C | 77 | 119 | w | AB | 171 | ½ | DF | 223 | ⌚ |
| 10 | 16 | DLE | 44 | 68 | D | 78 | 120 | x | AC | 172 | ¼ | E0 | 224 | α |
| 11 | 17 | DC1 | 45 | 69 | E | 79 | 121 | y | AD | 173 | ı | E1 | 225 | β |
| 12 | 18 | DC2 | 46 | 70 | F | 7A | 122 | z | AE | 174 | « | E2 | 226 | Γ |
| 13 | 19 | DC3 | 47 | 71 | G | 7B | 123 | { | AF | 175 | » | E3 | 227 | Π |
| 14 | 20 | DC4 | 48 | 72 | H | 7C | 124 | | B0 | 176 | ▒ | E4 | 228 | Σ |
| 15 | 21 | NAK | 49 | 73 | I | 7D | 125 | } | B1 | 177 | ▒ | E5 | 229 | σ |
| 16 | 22 | SYN | 4A | 74 | J | 7E | 126 | ~ | B2 | 178 | ▒ | E6 | 230 | μ |
| 17 | 23 | ETB | 4B | 75 | K | 7F | 127 | ⌚ | B3 | 179 | ▒ | E7 | 231 | τ |
| 18 | 24 | CAN | 4C | 76 | L | 80 | 128 | reserved | B4 | 180 | ▒ | E8 | 232 | Φ |
| 19 | 25 | EM | 4D | 77 | M | 81 | 129 | ü | B5 | 181 | ▒ | E9 | 233 | Θ |
| 1A | 26 | SUB | 4E | 78 | N | 82 | 130 | é | B6 | 182 | ▒ | EA | 234 | Ω |
| 1B | 27 | ESC | 4F | 79 | O | 83 | 131 | â | B7 | 183 | ▒ | EB | 235 | δ |
| 1C | 28 | FS | 50 | 80 | P | 84 | 132 | ä | B8 | 184 | ▒ | EC | 236 | ∞ |
| 1D | 29 | GS | 51 | 81 | Q | 85 | 133 | à | B9 | 185 | ▒ | ED | 237 | ∅ |
| 1E | 30 | RS | 52 | 82 | R | 86 | 134 | â | BA | 186 | ▒ | EE | 238 | ε |
| 1F | 31 | US | 53 | 83 | S | 87 | 135 | ç | BB | 187 | ▒ | EF | 239 | ∩ |
| 20 | 32 | SP | 54 | 84 | T | 88 | 136 | ê | BC | 188 | ▒ | FO | 240 | ≡ |
| 21 | 33 | ! | 55 | 85 | U | 89 | 137 | ë | BD | 189 | ▒ | F1 | 241 | ± |
| 22 | 34 | " | 56 | 86 | V | 8A | 138 | è | BE | 190 | ▒ | F2 | 242 | ≥ |
| 23 | 35 | # | 57 | 87 | W | 8B | 139 | ï | BF | 191 | ▒ | F3 | 243 | ≤ |
| 24 | 36 | \$ | 58 | 88 | X | 8C | 140 | î | C0 | 192 | ▒ | F4 | 244 | ┌ |
| 25 | 37 | % | 59 | 89 | Y | 8D | 141 | ì | C1 | 193 | ▒ | F5 | 245 | ┐ |
| 26 | 38 | & | 5A | 90 | Z | 8E | 142 | Ä | C2 | 194 | ▒ | F6 | 246 | ÷ |
| 27 | 39 | ' | 5B | 91 | [| 8F | 143 | Å | C3 | 195 | ▒ | F7 | 247 | ≈ |
| 28 | 40 | (| 5C | 92 | \ | 90 | 144 | É | C4 | 196 | ▒ | F8 | 248 | ° |
| 29 | 41 |) | 5D | 93 |] | 91 | 145 | œ | C5 | 197 | ▒ | F9 | 249 | • |
| 2A | 42 | * | 5E | 94 | ^ | 92 | 146 | Æ | C6 | 198 | ▒ | FA | 250 | · |
| 2B | 43 | + | 5F | 95 | _ | 93 | 147 | ô | C7 | 199 | ▒ | FB | 251 | √ |
| 2C | 44 | , | 60 | 96 | ` | 94 | 148 | ö | C8 | 200 | ▒ | FC | 252 | n |
| 2D | 45 | - | 61 | 97 | a | 95 | 149 | ò | C9 | 201 | ▒ | FD | 253 | ² |
| 2E | 46 | . | 62 | 98 | b | 96 | 150 | û | CA | 202 | ▒ | FE | 254 | . |
| 2F | 47 | / | 63 | 99 | c | 97 | 151 | ù | CB | 203 | ▒ | FF | 255 | |
| 30 | 48 | 0 | 64 | 100 | d | 98 | 152 | ÿ | CC | 204 | ▒ | | | |
| 31 | 49 | 1 | 65 | 101 | e | 99 | 153 | Ö | CD | 205 | ▒ | | | |
| 32 | 50 | 2 | 66 | 102 | f | 9A | 154 | Ü | CE | 206 | ▒ | | | |
| 33 | 51 | 3 | 67 | 103 | g | 9B | 155 | ç | CF | 207 | ▒ | | | |

9.5 Opening/closing ID7-Base weighing terminal

CAUTION

- The ID7-Base weighing terminal may only be opened by authorized personnel!
- Always pull the mains plug before opening the unit.

Opening

1. Remove screws on underside of cover.
2. Lay down cover toward front.

Closing

1. Lay device on cover and fix slightly in place with 3 screws.
2. Press unit into cover so that 3 engaging springs engage.
3. Tighten screws.

CAUTION

The IP68 protection type is only ensured when the weighing terminal is properly closed again.

- The 3 engaging springs must be completely engaged.
- Make sure that keypad cable is not pinched.


9.6 Configuring Pin 5 on RS232-ID7 interface

Pin 5 of the RS232-ID7 interface can be configured for the connection of devices which require a 12 V supply voltage (with COM2 – COM6 only).

1. Open weighing terminal.
2. Change position of jumper W1 on RS232-ID7 board.

| Jumper W1 | Voltage at Pin 5 |
|-------------------------------|------------------|
| Pin 1 and 2 (factory setting) | 5 V |
| Pin 2 and 3 | 12 V |

3. Close weighing terminal again.



10 Index

A

Accessories 68
 Acoustic signal 49
 Additional functions 11
 Additive tare function 15
 Alibi Memory ID7 5
 Alibi Memory-ID7 31
 Alphanumeric
 identification 17
 Alphanumeric keypad 20, 70
 Alphanumeric printout 48
 Application blocks 37, 48,
 54
 Applications 3
 ASCII characters 41, 75
 Automatic continuous
 transmission 33
 Autotara 9, 30
 Autozero 30

B

Barcode 19, 31, 38, 49
 Basic functions 8
 Big Weight Display 27
 Bus Slave 32, 41

C

Certified weighing
 platforms 6
 Change over weight unit 43
 Check mode 27
 Checkweighing 12
 Classifying 12
 Cleaning 7
 Command format 40
 Command overview 42
 Commissioning 6
 Communication 32
 Configuration print-outs 35
 Connect weighing
 platforms 6
 Connections 5

D

Data formats 41
 Date 27, 65
 DeltaTrac 11, 26, 45, 65
 DeltaTrac read-only
 memory 26, 73
 DeltaTrac target values 13,
 45
 Dialog mode 33, 40
 Digital inputs/outputs 60, 69
 Display 4, 48, 64
 Display Mode 63

Display update 30
 Dynamic weighing 14, 27,
 65

E

Edit data string 36, 37
 Error messages 51
 External keyboard 26
 External keypad 20, 70

F

Filling 12
 Function keys 4, 11

G

GA46 31
 Gross 15, 65

H

Housing 64

I

ID code 7, 16
 Identifications 16, 49, 65
 Interface 4 I/O-ID7 31
 Interface CL-ID7 31
 Interface connections 5, 31,
 64
 Interface description 40
 Interface RS232-ID7 66
 Interface type 31
 Introduction 3

K

Keypad 4, 64

L

Language 26

M

Mastermode 22
 METTLER TOLEDO continuous
 mode 34
 MMR command set 33, 40
 Multiplicative tare function 15

O

Operating mode 32

P

Personal code 27
 Power supply 6
 Print 19
 Print mode 33, 35
 Printout 48

R

Read-only memory 18
 Recall information 18
 Representable characters 75
 Reset scale 29
 Reset terminal 25
 Response format 40
 Restart 30
 RS... 31

S

Safety precautions 3
 Sandwich tare 16
 Second display 21, 69
 Second unit 30
 Serial interfaces 40
 Set zero 8, 43, 65
 Stability detector 29
 Status byte 52, 53
 String framing 34, 41
 Switch keypad on/off 43
 Switch off 8
 Switch on 8
 Switch over weighing
 platform 10

T

Tare 9, 44, 65
 Tare read-only memory 9,
 25, 72
 Technical data 64
 Terminal 64
 Test 65
 Test weighing platform 16
 Text for A B C D 26
 Text read-only memory 17,
 25, 74
 Time 27, 65
 Transfer data 19
 Transfer string 33
 Transmit buffer 59
 Transmit data record 47
 Transmit weight value 45

U

Unit changeover 65

V

Vibration adapter 29, 65

W

Weighing 10
 Weighing functions 65
 Weighing platform
 connections 64, 68

Weighing process
 adapter 29, 65
 What to do if ...? 61

| Mettler-Toledo (Albstadt) GmbH | | D-72458 Albstadt | T ++49-7431-14 0 | F -14 232 |
|---|---------------------------------------|-------------------------|-------------------------|------------------|
| AT | Mettler-Toledo Ges.m.b.H. | 1100 Wien | T ++43-1-604 19 80 | F -604 28 80 |
| AU | Mettler-Toledo Ltd. | Victoria 3207 | T ++61-3-9646 45 51 | F -9645 39 35 |
| BE | N.V. Mettler-Toledo S.A. | 1651 Lot | T ++32-2-334 02 11 | F -378 16 65 |
| CH | Mettler-Toledo (Schweiz) AG | 8606 Greifensee | T ++41-1-944 45 45 | F -944 45 10 |
| CN | Mettler-Toledo (Shanghai) Ltd. | Shanghai 200233 | T ++86-21-6485 0435 | F -6485 3351 |
| CZ | Mettler-Toledo spol, s.r.o. | 120 00 Praha 2 | T ++42-2-252 755 | F -242 475 83 |
| DE | Mettler-Toledo GmbH | 35353 Giessen | T ++49-641-50 70 | F -507 129 |
| DK | Mettler-Toledo A/S | 2600 Glostrup | T ++45-43 27 08 00 | F -43 27 08 28 |
| ES | Mettler-Toledo S.A.E. | 08038 Barcelona | T ++34-93 223 22 22 | F -223 02 71 |
| FR | Mettler-Toledo s.a. | 78220 Viroflay-Cedex | T ++33-1-30 97 17 17 | F -30 97 16 00 |
| HK | Mettler-Toledo (HK) Ltd. | Kowloon, Hongkong | T ++852-2744 1221 | F -2744 6878 |
| HR | Mettler-Toledo d.o.o. | 100 10 Zagreb | T ++385-1-233 6317 | F -233 6317 |
| HU | Mettler-Toledo Keresked. KFT | 1173 Budapest | T ++36-1-257 98 89 | F -256 21 75 |
| IN | Mettler-Toledo India Pvt. Ltd. | Mumbai 400 072 | T ++91-22-857 0808 | F -857 5071 |
| IT | Mettler-Toledo S.p.A. | 20026 Novate Milanese | T ++39-02-33 33 21 | F -356 2973 |
| JP | Mettler-Toledo K.K. | Osaka 540 | T ++81-6-6949 5917 | F -6949 5944 |
| KR | Mettler-Toledo (Korea) | Seoul 135-080 | T ++82-2-518 2004 | F -518 0813 |
| MY | Mettler-Toledo (M) | 47301 Petaling Jaya | T ++60-3-703 2773 | F -703 8773 |
| NO | Mettler-Toledo A/S | 1008 Oslo 10 | T ++47-22-30 44 90 | F -32 70 02 |
| NL | Mettler-Toledo B.V. | 4000 HA Tiel | T ++31-344-63 83 63 | F -63 83 90 |
| PL | Mettler-Toledo Sp.z.o.o. | 02-924 Warszawa | T ++48-22-651 92 32 | F -651 71 72 |
| RU | Mettler-Toledo AO | 101000 Moscow | T ++7-095-921 92 11 | F -921 63 53 |
| SE | Mettler-Toledo AB | 120 08 Stockholm | T ++46-8-702 50 00 | F -642 45 62 |
| SG | Mettler-Toledo (S) Pte. Ltd. | Singapore 139944 | T ++65-778 67 79 | F -778 66 39 |
| SK | Mettler-Toledo spol, s.r.o. | 831 03 Bratislava | T ++421-7-5252 170 | F -5252 173 |
| SL | Mettler-Toledo d.o.o. | 1236 Trzin | T ++61-162-1801 | F -161-1789 |
| TH | Mettler-Toledo (Thailand) | Bangkok 10310 | T ++66-2-719 64 80 | F -719 64 79 |
| TW | Mettler-Toledo (Taiwan) | Taipei | T ++886-2-579 5955 | F -579 5977 |
| UK | Mettler-Toledo Ltd. | Leicester, LE4 1AW | T ++44-116-235 70 70 | F -236 63 99 |
| US | Mettler-Toledo Inc. | Columbus, Ohio 43085 | T ++1-614-438 4511 | F -438 4755 |
| Other countries: Mettler-Toledo AG | | 8606 Greifensee | T ++41-1-944 22 11 | F -944 31 70 |