

2000 DIGITAL WEIGHING SYSTEM

SECTIONAL TRUCK SCALE INSTALLATION GUIDE



FOR SOFTWARE VERSION 1.21 (MAY 2003)



M2000 DIGITAL WEIGHING SYSTEM SECTIONAL TRUCK SCALE INSTALLATION GUIDE

Copyright © 2003 Western Scale Company Limited. All rights reserved.

Published by:

WESTERN SCALE CO. LTD.
1670 Kingsway avenue
Port Coquitlam, B.C.
Canada
V3C 3Y9

Information in this *Installation Guide* is subject to change without notice due to correction or enhancement. The information described in this manual is the property of Western Scale. No part of this manual may be reproduced or transmitted in any form, without the express written permission of Western Scale.

Western Scale Locations

Western Scale Co. Ltd.
1670 Kingsway Avenue
Port Coquitlam, B.C.
Canada
V3C 3Y9

www.westernscale.ca
info@westernscale.ca

Wescale Inc.
DIVISION OF WESTERN SCALE
3873 Airport Way
Bellingham, WA.
USA
98227 - 9754

www.wescale.com
info@wescale.com

FOR TECHNICAL SUPPORT REGARDING THIS PRODUCT, PLEASE CALL:

1-604-941-3474


TABLE OF CONTENTS

| | |
|--|----|
| Introduction..... | 1 |
| Installation Strategies..... | 2 |
| System Grounding..... | 3 |
| Getting Started..... | 4 |
| Setting the DLC ID Jumper..... | 5 |
| Wiring Loadcells to the DLC Smart Box..... | 6 |
| Wiring DLC Smart Boxes to the M2000D Indicator..... | 7 |
| Other Wiring to the M2000D Indicator..... | 9 |
| Powering Up the Indicator for the First Time..... | 10 |
| LEDs on Power Up..... | 10 |
| Calibration Mode..... | 11 |
| Entering Into Calibration Mode..... | 11 |
| Entering Calibration Commands..... | 11 |
| Setting Graduation Size..... | 12 |
| Setting Scale Capacity..... | 12 |
| Setting Calibration Units..... | 12 |
| Allocating Sections..... | 13 |
| Deadloading the Scale..... | 13 |
| Spanning a Scale with a Test Weight..... | 14 |
| Exit Calibration Mode..... | 14 |
| Navigating the M2000..... | 15 |
| Select a Section or Cell..... | 16 |
| Quick Select Method (For Sections)..... | 17 |
| Sectional Adjustment..... | 17 |
| Example..... | 18 |
| Corner & Side-to-Side Adjustments..... | 18 |
| Serial Communications..... | 19 |
| Data Bits..... | 19 |
| Baud Rate..... | 19 |
| Parity..... | 20 |
| String Formats for Continuous Output..... | 20 |
| Serial Handshaking..... | 21 |
| Com Port String Output Mode..... | 21 |
| Configuring Com Ports to Transmit in RS422 Mode..... | 21 |
| Transmission Delay for Com1 & Com2..... | 22 |
| M2000D System Specifications..... | 23 |
| Appendix A - M2000 Parameters..... | 24 |
| Appendix B - M2000D Specific Parameters..... | 26 |
| Appendix C – Error Messages..... | 27 |

INTRODUCTION

The M2000D Digital Smart Weigh System utilizes Digital Load Cell (DLC) technology to provide high-level data integrity, easier maintenance, and lightning protection for your weighing applications. Load cell connections to the DLC Smart Box (mounted on the weighbridge) are the same as connections to traditional analog summation cards. There are no pots to adjust and all sectional adjustments are made digitally through the keypad on the M2000D indicator.

Each DLC Smart Box is available with 4, 6, or 8 load cell channels (inputs). The M2000D indicator can support up to 2 DLC Smart Boxes for a maximum of 16 load cells (8 Sections) per scale system. DLC Smart Boxes communicate with the indicator digitally through a current loop interface, resulting in no data degradation for up to 1000 feet. The cable link between the M2000D indicator and the DLC Smart Box is optically isolated and contains surge suppression devices to help protect the scale from lightning damage.



DLC SMART BOX

INSTALLATION STRATEGIES


1. Mount the DLC Smart Boxes as close as possible to the weighing platform.
2. The DLC Smart Boxes must be mounted in a NEMA rated enclosure, as the modules themselves are not watertight.
3. Keep cable runs between load cells and the DLC Smart Boxes as short as possible, to help eliminate the contamination of analog load cell signals by RFI and EMI interference.
4. Identify the end of the scale where Section 1 will be located. The DLC Smart Box that connects to Section 1 will be configured as the Primary DLC.
5. Observe the green Cell/Section label on the DLC Smart Box. This label is a miniature diagram of your scale. Where the loadcell is physically connected becomes its “Electronic Address” when navigating the scale elements during calibration.

**M2000D INDICATOR**

SYSTEM GROUNDING

The M2000 Digital System provides state of the art lightning surge protection. In order for surge conditions to be diverted properly, a good earth ground path must be in place. Since the M2000D indicator is optically isolated from the DLC modules, both ends should be grounded to a good earth connection.

In most cases, the DLC Smart Box modules will be grounded to the steel structure of the weighing platform with a braided Earth Strap. The steel frame should be connected to a ground rod planted in the earth next to the weighing platform. Earth Straps should be at least 8 AWG thick and preferably no longer than 2 feet. The Earth Strap should be kept as straight as possible to reduce any loops or kinks which may cause inductive resistances to the earth ground discharge path.



(Fig. 1)

SCALE GROUNDING DIAGRAM (SAMPLE)


EXAMPLE:
GROUND WIRE
FIRMLY CONNECTED
TO DLC SMART BOX
GROUND LUG



GETTING STARTED

The most common Sectional Truck Scale installations have 4 sections with a total of 8 loadcells. Due to manufacturing preferences and loadcell cable lengths, **2** DLC Smart Box modules, each wired to 4 loadcells (2 sections) are typically used. **This type of installation will be the default example for this guide.**

- It is good practice to think of the green Cell/Section label on the DLC Smart Box as a miniature diagram of the scale. Where a loadcell is physically wired becomes its “Electronic Address”, used to identify the scale elements during calibration.
- The loadcell pair comprising the 1st Section of the scale **MUST ALWAYS** be wired into the connectors labeled CELL1 & CELL2. This DLC Smart Box will be the “Primary” DLC.
- Wire the rest of the sections the same way, with odd numbered cells on one side, even numbered cells on the other. In the case of two DLC modules, loadcell numbering will restart at 1 on the Secondary DLC module. (See Navigating the M2000)




(Fig. 2)

4 SECTION SCALE

SETTING THE DLC ID JUMPER

When using two DLC Smart Boxes, the M2000D indicator needs to differentiate between the Primary and Secondary modules. **An ID switch must be set via the ID jumpers in the bottom right hand corner of each module.** For systems utilizing only one DLC Smart Box, the jumpers must be in the “Primary” position.

- It is *extremely* important to note which module is the PRIMARY DLC as it ALWAYS identifies the first section of the scale.
- There cannot be two primary (or two secondary) DLC Smart boxes. Setting the switches properly is crucial for the system to function.




(Fig. 3)



NOTE: If changing the DLC ID jumper after the initial scale setup, the indicator must be in Calibration Mode as jumper settings are stored with Calibration data.

WIRING LOAD CELLS TO THE DLC SMART BOX

Load cells are wired to the DLC Smart Box using 5 pin terminal connectors. The connectors can be unplugged from the DLC to make wiring easier. The Primary DLC Smart Box will always contain Section 1.



(Fig. 4)

Loadcell connections are labeled as follows:

| | |
|-------|---------------------|
| - EXC | Negative Excitation |
| + EXC | Positive Excitation |
| SHLD | Loadcell Shield |
| - SIG | Negative Signal |
| + SIG | Positive Signal |

Loadcell pairs in a section must be wired directly across from each other on the DLC Smart Box. Sections are marked on the DLC module for easy reference. (See Figure 2.)



Note: The DLC Smart Box does not include SENSE line terminals for load cells. For connecting a 6 conductor load cell cable to a DLC terminal, it is recommended that the +SENSE and +EXCITATION conductors to be joined together and the –SENSE and –EXCITATION conductors to be joined together respectively.

WIRING THE DLC SMART BOXES TO THE M2000D INDICATOR

The scale wiring requires 2 pairs of shielded wire (one pair for power delivery and one pair for data communications) plus a separate shield conductor. The recommended cable type is Beldon 9873 20 AWG or equivalent. For cable runs over 100 feet, Beldon 9773 18 AWG or equivalent is recommended.

The wires that connect the M2000D indicator to the DLC Smart Boxes are labeled as follows:


| | |
|-------|--|
| CTRL- | Current loop negative (WHITE wire) |
| CTRL+ | Current loop positive (GREEN wire) |
| V+ | Positive DC supply 18-24volts (RED wire) |
| V- | Negative supply (BLACK wire) |

While wiring a single DLC Smart Box to the indicator is very straightforward, two DLC boxes will require some extra attention. The power supply V+ and V- is wired in parallel, but the digital link, being a current loop, must be wired as shown in Figures 5 & 6.




NOTE: When wiring the scale, power to the M2000D indicator should be disconnected.

ONE DLC SMART BOX



(Fig. 5)


TWO DLC SMART BOXES



(Fig. 6)

OTHER WIRING TO THE M2000D INDICATOR

All wiring to the scale indicator terminates at the main circuit board. If possible, all wiring to the M2000D motherboard should be done before power is applied to the unit.



(Fig. 7)

| | | |
|--|---|---|
| J1 RS 232/422 PORT COM1 | ① | CTS (Input – Printer telling the Indicator to send more data - RTS) |
| | ② | RX (Input – Data received by the Indicator) |
| | ③ | TX (Output – Data transmitted by the Indicator) |
| | ④ | RTS (Output – Indicator signal - Readiness to receive data) |
| | ⑤ | COM (Ground) |
| J2 RS 232/422 PORT COM2 | ① | CTS (Input –Printer telling the Indicator to send more data RTS) |
| | ② | RX (Input – Data received by the Indicator) |
| | ③ | TX (Output – Data transmitted by the Indicator) |
| | ④ | RTS (Output – Indicator signal - Readiness to receive data) |
| | ⑤ | COM (Ground) |
| J3 MAIN POWER CONNECTOR | ① | V- (Negative) |
| | ② | GND (Earth ground) |
| | ③ | V+ (Positive power) |
| J5 SMARTWIRE (FOR PERIPHERAL INTERFACE) | ① | NC (No connection) |
| | ② | B (RS485 differential signal) |
| | ③ | A (RS485 differential signal) |
| | ④ | V+ (SMARTWIRE Power supply) |
| | ⑤ | V- (SMARTWIRE Power supply) |

POWERING UP THE INDICATOR FOR THE FIRST TIME.

The M2000 Digital System must be used with the 12V power supply adapter included with the indicator.

The M2000D indicator powers up and should display a scrolling “112000” followed by the software version number. If this is the first time powering up the indicator, the software version number may be followed by a set of dashes across the display “-----”. The dashes are *NOT* an error. They are a result of the indicator not recognizing new DLC Smart Boxes. The DLCs must be allocated in the indicator’s Calibration Mode. (See Allocating Sections - Parameter 521)




It is important to note that in very noisy industrial environments, power-conditioning filters would be a requirement to ensure a fail-safe operation under all conditions. Indicators should not share AC power with electrical motors and switchgear. Consult with the site engineer for clean AC power.

LEDs ON POWER UP

There are three diagnostic LED lights on the DLC Smart Box. On power up:

1. The **LINK** light must be illuminated. If the **LINK** light is not illuminated, there is a problem with the wiring of CTRL- and CTRL+ signals. (See Fig. 5 & 6, Wiring the DLC Smart Box to the M2000 Indicator)
2. The **STATUS** light is the DLC “heartbeat”. It must be blinking. The **STATUS** LED light should be blinking consistently once per second to indicate a properly running PRIMARY DLC module. A **STATUS** LED blinking rapidly 10 times per second indicates a properly functioning SECONDARY DLC module.
3. The **TX** light may not be active at this point in time



(Fig. 8)

CALIBRATION MODE

ENTERING INTO CALIBRATION MODE


All calibration functions are executed from the keypad. Each calibration function or parameter has a unique code with which to access and edit values.

To enter into calibration mode:



1. Enter **19** followed by the **[PRINT/SELECT]** key.

2. The display will flash “**PASS**”. At this point, a four-digit password is required.



3. Enter **1111**, which is the factory default password. A blinking “**C**” should appear on the left hand side of the display, indicating Calibration Mode.



Note: To calibrate Channels 2 & 3, use **29** & **39** respectively

ENTERING CALIBRATION COMMANDS

Calibration parameters are selected using their unique numeric code and the **[PRINT/SELECT]** key. After a parameter is selected, its current value will be displayed. There is a 6 second window to edit the parameter. Parameter values are entered using the numeric keys followed by the **[PRINT/SELECT]** key. The **[CLEAR]** key can be used to abort any parameter change.

Following are examples of setting the first 3 parameters necessary to get the system up and running: Graduation Size, Capacity, and Calibration Units. Remember, the indicator must be in Calibration Mode before calibration parameters can be entered. A quick reference list of all calibration parameters is provided. (Appendices A & B)

SETTING GRADUATION SIZE (PARAMETER 3)

The factory default for Grad Size is 1. This example sets the parameter to 20.



1. To select Parameter 3, press **3** on the keypad followed by **[PRINT/SELECT]**. The current Grad Size is displayed.
2. Enter the new value (**20**) followed by the **[PRINT/SELECT]** key. This saves the entry. The Grad Size is now 20.
3. To verify the change, simply access Parameter 3 again (Press **3**, **[PRINT/SELECT]**) and the new value of 20 should be displayed. Hit the **[CLEAR]** key to cancel and return to weighing mode.



NOTE: ALL parameters for M2000 Indicators are entered and edited in this way.

SETTING SCALE CAPACITY (PARAMETER 4)

1. To select Parameter 4, press **4** on the keypad followed by **[PRINT/SELECT]**. The current capacity is displayed.
2. Enter the new capacity weight on the keypad (For Example: **100000**) followed by the **[PRINT/SELECT]** key.
3. To verify the change, simply access Parameter 4 again (Press **4**, **[PRINT/SELECT]**) and the new value of should be displayed. Hit the **[CLEAR]** key to cancel and return to weighing mode.


SETTING CALIBRATION UNITS (PARAMETER 7)

1. To select Parameter 7, press **7** on the keypad followed by **[PRINT/SELECT]**. This will toggle the Calibration Units between Lbs & Kgs.
2. Make sure the correct Unit Indication light is illuminated.

ALLOCATING SECTIONS (PARAMETER 521)

For an initial scale installation, the M2000D indicator needs to be told how many sections are in the scale. The scale must be installed and wired to the DLC Boxes before executing this command. There can be a maximum of 8 sections per scale. If the DLC Smart Boxes have not been allocated, dashes will appear on the display.


EXAMPLE: Allocate a 4 section scale (default example).



1. Press **521** on the keypad followed by the **[PRINT/SELECT]** key. The message “*ALLOC*” will appear on the display followed by “*SEC*” (Allocate Sections).



2. Press **4** followed by the **[PRINT/SELECT]** key. It will take a couple of seconds for the indicator to communicate with the DLC boxes. The display will then switch from dashes to a weight.




Note: A 6 section scale would require a parameter value of 6

DEADLOADING THE SCALE (PARAMETER 12)

Once the scale sections have been allocated, the scale must be deadloaded.

1. Remove any load from the scale.




2. Press **12** on the keypad followed by the **[PRINT/SELECT]** key. “*PASS*” will appear on the display as the password is required to activate this command.
3. Enter the password (factory default “**1111**”), followed by the **[PRINT/SELECT]** key to confirm. The indicator will then deadload the scale. The display should show “*0*”.

SPANNING A SCALE WITH A TEST WEIGHT (PARAMETER 13)

1. Place your test weights on the scale.



2. Press **13** followed by the **[PRINT/SELECT]** key.



3. Enter the test weight value (Example: **10000**) followed by the **[PRINT/SELECT]** key. The indicator will calibrate the scale and the correct weight will be displayed.




Pressing the **[ON/OFF]** key cycles the display between Graduated Counts (Displayed Weight prefixed by the blinking letter “**C**”) and Raw Counts (prefixed by the blinking letter “**R**”).

HOW TO EXIT CALIBRATION MODE (PARAMETER 99)



- To exit Calibration Mode, enter **99** followed by the **[PRINT/SELECT]** key.

- The indicator display will show “**CAL**”, “**SAVE**”, and “**LOAD IT**”.




- Weigh Mode will be entered with the scale weight being displayed without the blinking “**C**” on the left hand side.



NOTE: None of the calibration changes are permanently saved until Calibration Mode is exited.

NAVIGATING THE M2000

The “Status / Electronic Address” screen appears in Calibration Mode and is used to navigate through the various elements of the scale. Details of Scale Set-up and Status are also displayed. The most important LED digits for navigation are the 2nd digit (**P** or **S**) and the last two digits (**CH** on the diagram). These are the “Electronic Address”.



Note: Press the **[TARE]** or **[PRINT/SELECT]** key to display the Electronic Address Screen.

SELECT A SECTION OR CELL (SCROLLING METHOD)

Starting with the scale as a whole, sections and individual cells may be selected easily, using their “Electronic Address”.



OR



1. Press the **[TARE]** or **[PRINT/SELECT]** key to display the Electronic Address screen. The address of the currently selected scale element will appear.

Before the indicator returns to weight display,



2. Press the **[TARE]** key to scroll forward through the scale elements' Electronic Addresses, *OR...*



3. Press the **[PRINT/SELECT]** key to scroll backwards.

EXAMPLE: Scrolling forward through all the sections and cells in a 4 section truck scale with 2 DLCs.

| Status-Electronic Address Screen | Description |
|-------------------------------------|--|
| SP 4.1.C | Section 1 Combination. The total of the 2 cells in Section 1 |
| SP 4.1.1 | Section 1, Cell (corner) 1. For Individual Cell Adjustments |
| SP 4.1.2 | Section 1, Cell (corner) 2. For Individual Cell Adjustments |
| SP 4.2.C | Section 2 Combination. The total of the 2 cells in Section 2 |
| SP 4.2.3 | Section 2, Cell (corner) 3. For Individual Cell Adjustments |
| SP 4.2.4 | Section 2, Cell (corner) 4. For Individual Cell Adjustments |
| *SS 4.3.C | Section 3 Combination. The total of the 2 cells in Section 3 *Note Address located on SECONDARY DLC |
| SS 4.3.1* | Section 3, Cell (corner) 1. For Individual Cell Adjustments *Note Loadcell # 1 SECONDARY DLC |
| SS 4.3.2 | Section 3, Cell (corner) 2. For Individual Cell Adjustments |
| SS 4.4.C | Section 4 Combination. The total of the 2 cells in Section 4 |
| SS 4.4.3 | Section 4, Cell (corner) 3. For Individual Cell Adjustments |
| SS 4.4.4 | Section 4, Cell (corner) 4. For Individual Cell Adjustments |

QUICK SELECT METHOD (FOR SECTIONS)

This method allows a technician to go directly to a particular section instead of scrolling through all the scale elements. To quickly jump to a section, enter the section number followed by the **[TARE]** key.

EXAMPLE: Select Section 3.



1. Enter **3** followed by **[TARE]**. The display will briefly show the Electronic Address for confirmation and return back to weigh mode.

SP 4.3.C

SECTIONAL ADJUSTMENT (PARAMETER 531)

Before a sectional adjustment can be made, the specific section must be selected.



1. Enter **531** followed by the **[PRINT/SELECT]** key. The display will flash the currently selected section.



2. Confirm the correct section by pressing the **[PRINT/SELECT]** key. The display will confirm by briefly showing the selected section with a flashing “A” to indicate that “**ADJUST**” mode has been entered. The display will return to weigh mode, showing the current weight on the scale.

SP A 4.1.C



3. **TO INCREASE THE DISPLAYED WEIGHT:** Pressing the **[IN]** key will increment the number of counts, causing the displayed weight to increase. The keys **1, 2, 3** and **4** select the coarseness of the adjustment, where **4** is a very coarse and **1** is a very fine weight increment. When using fine weight increments, the **[IN]** key may need to be pressed several times to see the weight change.




TO DECREASE THE DISPLAYED WEIGHT: Pressing the **[OUT]** key will decrement the number of counts, reducing the displayed weight. The same Coarse and Fine adjustments apply.

Once the correction is complete, press the **[TARE]** button to exit Adjustment Mode.

EXAMPLE: Weight Correction on Section 2.

Section 2 is weighing 9920 lbs. The actual weight on the scale is 10,000 lbs.


1. Use the Quick Select Method to select Section 2. Enter **2** followed by the **[TARE]** key. The display will briefly confirm that you are pointing to Section 2.




2. Enter **531** followed by the **[PRINT/SELECT]** key.




3. Press **[PRINT/SELECT]** again to confirm Section 2. Note the flashing 'A' in the Channel Information digit. The weight (**9920**) will be displayed. The section can now be adjusted.




4. Press **[IN]** to increase the displayed weight. If nothing happens, select a courser adjustment. (Step 5)
5. Press **4**. Pressing the **[IN]** key will now cause a jump in the weight. Continue to press **4** until the displayed weight approaches 10,000 lbs. If you overshoot the target weight, press **[OUT]** to reduce the weight.



6. At this point, fine-tuning may be required.



7. Press **[TARE]** to save adjustment values.



CORNER & SIDE-TO-SIDE ADJUSTMENTS (PARAMETER 531 CONTINUED)

Corner adjustments are identical to sectional adjustments. Instead of selecting a section to correct, select an individual loadcell.



NOTE: None of the calibration changes are permanently saved until Calibration Mode is exited.

SERIAL COMMUNICATIONS

The M2000 has two fully independent serial ports (COM1 and COM2) on the back of the indicator. The factory default settings allocate COM1 for printing tickets at 9600 baud. COM2 is allocated for outputting a weight string (DF1500) in continuous mode at 9600 baud.

DATA BITS (PARAMETER 27 - COM2 ONLY)

COM1 on the M2000 is fixed at 8 Data Bits. However, if EVEN or ODD Parity is selected then 7 Data Bits will automatically be used.

COM2 allows for independent selection of Data Bits.

| Parameter Value | Data Bits |
|-----------------|-----------------------------------|
| 0 | COM2 Data Bits set to 4 |
| 1 | COM2 Data Bits set to 5 |
| 2 | COM2 Data Bits set to 6 |
| 3 | COM2 Data Bits set to 7 |
| 4 | COM2 Data Bits set to 8 (default) |

BAUDRATE (PARAMETER 30 & 32)

Baud rate for COM1: Parameter 30
Baud rate for COM2: Parameter 32

| Parameter Value | Baud Rate |
|-----------------|------------------------|
| 0 | 150 |
| 1 | 300 |
| 2 | 600 |
| 3 | 1200 |
| 4 | 2400 |
| 5 | 4800 |
| 6 | 9600 (factory default) |
| 7 | 14400 |
| 8 | 19200 |
| 9 | 32400 |

PARITY (PARAMETER 31 & 33)

Parity for COM1: Parameter 31
Parity for COM2: Parameter 33

| Parameter Value | Parity |
|-----------------|-----------------------------|
| 0 | No parity (factory default) |
| 1 | ODD parity |
| 2 | Even parity |

STRING FORMATS FOR CONTINUOUS OUTPUT (PARAMETER 34 & 35)

String Format for COM1: Parameter 34
String Format for COM2: Parameter 35

Several different indicator string formats are supported on the M2000. If creating a custom Output string for a ticket, the Com port connected to the printer must be set to 99. (See M2000 Ticket Formatting Guide)

| Parameter Value | Output String |
|-----------------|--|
| 1 | DF1000 |
| 3 | DF2000 |
| 5 | DF2500 mode1 |
| 8 | DF1500 (factory default) |
| 9 | DF2500 mode 6 |
| 10 | DF2500 mode 7 |
| 12 | AD4321, AD4323, AD5000 |
| 13 | Cardinal 708 |
| 14 | Cardinal 738 |
| 15 | Toledo & Fairbanks R2500 |
| 16 | Weightronix 120 |
| 17 | Consolidated Controls UMC600 |
| 18 | Analogic 5316 |
| 99 | Set the com port to custom transmit mode |

EXAMPLE: Output a UMC600 string from COM2.

1. Enter **35** on the keypad followed by the **[PRINT/SELECT]** key.
2. Press **17** followed by the **[PRINT/SELECT]** key.

SERIAL HANDSHAKING - RTS/CTS (PARAMETER 36 & 37)

Handshaking for COM1: Parameter 36

Handshaking for COM2: Parameter 37

| Parameter Value | Hardware Handshaking |
|-----------------|----------------------|
| 0 | Disabled (default) |
| 1 | Enabled |

COM PORT STRING OUTPUT MODE (PARAMETER 38 & 39)

String Output Mode for COM1: Parameter 38

String Output Mode for COM2: Parameter 39

Both COM ports output continuously by default.

| Parameter Value | String Transmits To COM Port... |
|-----------------|---|
| 1 | When the PRINT/SELECT key has been pressed |
| 2 | When the COM port receive data input is at logic low (-9 volts dc) |
| 3 | When the COM port receive data input is at logic high (+9 volts dc) |
| 4 | When the '?' character is received |
| 5 | Continuously (default) |

CONFIGURING COM PORTS TO TRANSMIT IN RS422 MODE (PARAMETER 40)

The wire connections to the COM ports on the back of the indicator are different for RS422 then for RS232. RS422 requires 2 lines for transmit (TX+ and TX-) and 2 lines for receive (RX+ and RX-).

FOR RS422 COMMUNICATIONS:

| | | |
|------------|--------------------------|-------------|
| CTS | on the connector becomes | RX - |
| RX | on the connector becomes | RX + |
| TX | on the connector becomes | TX + |
| RTS | on the connector becomes | TX - |

| Parameter Value | COM1 | COM2 |
|-----------------|-------------------------|-------|
| 0 (default) | RS232 | RS232 |
| 1 | RS422 | RS232 |
| 2 | NOT CURRENTLY SUPPORTED | |
| 3 | RS422 | RS422 |

TRANSMISSION DELAY FOR COM1 AND COM2 (PARAMETER 65)

Some older equipment may experience problems keeping up to the high update rate of the M2000. Parameter 65 inserts delays between string transmissions to slow down the output rate. The delay can be set with ¼ second increments. Calibration mode must be exited before this parameter takes effect.

The value entered for Calibration Parameter 65 must be a number between 0 – 100.

EXAMPLE: Update the strings on the serial ports once every second.

1. Enter **65** on the keypad followed by the **[PRINT/SELECT]** key.
2. Press **4**, followed by the **[PRINT/SELECT]** key. For the fastest possible update, enter **0**, which is the factory default.

M2000D SYSTEM SPECIFICATIONS

| INDICATOR PERFORMANCE (NTEP Certified) | |
|---|---|
| UNIT CONVERSION | Lbs/kg |
| ZERO TRACKING | 1-99% of d or 1,2,3d |
| RESOLUTION | +/- 256 000 A/D counts per load cell |
| SAMPLING RATE | 100 times a second per AD/ channel |
| SPAN STABILITY | 2ppm/ Celsius |
| ZERO STABILITY | 5nV/Celsius |
| LINEARITY CORRECTION | 5 span entries |
| CALIBRATION METHOD | Calibration through software stored in Flash memory |
| CALIBRATION SEALING | Class 1 Audit Trail System, password protected |
| FILTERING | FAST STEP quick response |
| MODES | Display from CH1,CH2,CH3 and Total of all Channels |
| FIRMWARE UPGRADING | Flash Memory - In field Firmware upgrading without affecting calibration data |
| DLC REMOTE LOAD CELLS | 16 Load cells using two DLC slaves |

| DLC LOAD CELL INPUTS | |
|-----------------------------|--|
| DLC REMOTE LOAD CELLS | 8 AD converters per DLC module |
| FULL SCALE | 4 ranges 0-9mV, 0-19mV,0-39 and 0-79V |
| EXCITATION | 5VDC,16x350,32x700 ohm in total |
| RESOLUTION | +/- 256 000 A/D counts per load cell |
| DLC CABLE LENGTH | 1000 feet - DLC module may be up to 1000 feet from indicator |
| DLC CURRENT | 500mA per slave with 16 *350 ohm load cells connected |

| COMMUNICATIONS | |
|-----------------------------|--|
| SERIAL OUTPUTS | 2 full duplex RS232/RS422 |
| IO INTERFACE | SMART WIRE peripheral expansion - RS485 multi-drop |
| EXTERNAL IO – SETPOINTS | 6 channel setpoint via SMART WIRE (optional) |
| EXTERNAL IO- ANALOG OUTPUT | 4-20mA board via SMART WIRE (optional) |
| EXTERNAL IO- DIGITAL INPUTS | 6 optically isolated inputs via SMART WIRE (optional) |
| NETWORKING | RS485 Multi-drop Networking of up to 32 indicators as slaves |

| ELECTRICAL | |
|--------------------|--------------------|
| POWER REQUIREMENTS | 12VDC 1.5A maximum |
| TEMPERATURE RANGE | -10C to +40C |

| ENCLOSURE | |
|------------------|--|
| STAINLESS | Washdown stainless steel enclosures. Panel mount, swivel bracket, or desktop Stainless or NEMA 4-X |

APPENDIX A – M2000 PARAMETERS

| Parameter | Function |
|-----------|--|
| 1 | Reload Factory Default Values |
| 2 | Decimal Point Position |
| 3 | Display Divisions |
| 4 | Scale Capacity |
| 5 | Motion Window |
| 6 | Power On Units |
| 7 | Calibration Scale Units |
| 8 | Scale Over |
| 9 | Power On Rest Warning |
| 10 | Power Switch Bypass |
| 11 | Selecting Input Range |
| 12 | Deadloading the Scale |
| 13 | Set Span (Spanning the Indicator) |
| 15 | Clearing the Span Tables |
| 16 | Incrementing the Span Table Pointer |
| 17 | Decrementing the Span Table Pointer |
| 19 | Display Update Rate |
| 20 | Scale Over Message |
| 21 | Push to Zero Window |
| 22 | Auto Zero ON/OFF |
| 23 | Zero Tracking Window |
| 24 | Motion Settle Time |
| 25 | Offset Value |
| 26 | Offset Flag |
| 27 | COM 2 Data Bit Rate |
| 28 | Sound Volume |
| 29 | Keypress Feedback |
| 30 | Changing the Baud Rate on the COM 1 Port |
| 31 | Changing the Parity |
| 32 | Changing the Baud Rate on the COM 2 Port |
| 33 | Parity for COM 2 |
| 34 | String Mode for the COM 1 Port (Enabling the Bar Code Scanner) |
| 35 | Setting the String Mode for the COM 2 Port |
| 36 | Flow Control for COM 1 |
| 37 | Flow Control for COM 2 |
| 38 | String Output Mode for COM 1 |
| 39 | String Output Mode for COM 2 |
| 40 | Changing COM Port Driver Configuration |
| 41 | Digital Averaging Filters |
| 42 | Filter Faststep Threshold |
| 43 | Faststep Sensitivity |
| 44 | Disable Faststep |
| 45 | Power Up Zero |
| 46 | Selecting Power Up Default Channel |
| 47 | Serial String Output Routing for COM 1 (Channel Allocation) |
| 48 | Serial String Output Routing for COM 2 (Channel Allocation) |

| | |
|-----|--|
| 50 | Tare Function Mode |
| 51 | Set Weight for Setpoint 1 |
| 52 | Set Weight for Setpoint 2 |
| 53 | Set Weight for Setpoint 3 |
| 54 | Set Weight for Setpoint 4 |
| 55 | Set Weight for Setpoint 5 |
| 56 | Set Weight for Setpoint 6 |
| 57 | Set Point Control Mask |
| 58 | Set Point Hysteresis Adjustments |
| 59 | Enabling SmartWire Interface |
| 60 | Selecting Scale Channel to Connect to Current Loop |
| 61 | Current Loop Offset Adjustment |
| 62 | Current Loop Span Adjustment |
| 63 | Current Loop Gross or Net Mode |
| 63 | Current Loop Gross or Net Mode |
| 64 | Current Loop Span |
| 65 | Serial Port Update Rate for COM 1 and COM 2 |
| 70 | Enable Total Mode |
| 71 | Force Zero for Keyboard Tare |
| 75 | Transit Calibration Information to Serial Port |
| 76 | Capture Calibration Information From a Serial Port |
| 77 | Transmit Ticket Buffer Information To Serial Port |
| 78 | Capture Ticket Buffer Information From Serial Port |
| 80 | Set Time of Day |
| 81 | Set the Date |
| 83 | Time Format Mode |
| 84 | Add New Ticket |
| 85 | Edit Existing Ticket |
| 86 | Number of Ticket Saved in the Ticket Buffer |
| 87 | Show Available Space in Custom Ticket Buffer |
| 88 | Clear Custom Ticket Buffer |
| 89 | Print Specific Ticket |
| 90 | Scanner Handshaking Mode |
| 95 | Assigning a Ticket Event to the Scanner |
| 98 | Enables Scale Channel |
| 99 | Exit Calibration Mode |
| 100 | Delete Truck IN/OUT Database |
| 101 | Delete Truck IN/OUT Database |
| 105 | Disable Units Function |
| 240 | Boot Loader Version Information |
| 244 | Testing Battery Information |
| 255 | Software Upgrade Download |
| 260 | Complete Factory Initialize |

APPENDIX B – M2000 D SPECIFIC PARAMETERS

| Parameter | Function |
|-----------|--|
| 500 | Clear All Remote DLC Scale Allocations |
| 501 | Clear Scale 1 Allocation |
| 502 | Clear Scale 2 Allocation |
| 503 | Clear Scale 3 Allocation |
| 520 | Assign a Hopper Scale |
| 521 | Assign a Sectional Scale |
| 525 | DLC Load Cell Masking |
| 530 | Reset Corner Field Adjustment Entries |
| 531 | Corner / Section Manual Span Adjustment |
| 532 | Auto Corner Span Adjustment |
| 551 | DLC Communications Error Counter |
| 552 | DLC Packet Counter |
| 555 | DLC Software Upgrade Download |
| 556 | Obtain DLC BIOS Firmware Version Information |
| 557 | Obtain DLC BOOT Firmware Version Information |
| 558 | DLC Set AD Range For Active Corner |
| 591 | Backup System Setup To a DLC Slave |
| 592 | Restore System Setup To a DLC Slave |
| 594 | Reload Scale Allocation (filed replacements) |
| 600 | Scale Status / Diagnostics Information |
| 620 | DLC Slave Line Status |

APPENDIX C - ERROR MESSAGES

| | |
|----|---|
| 1 | Invalid parameter number for calibration mode |
| 2 | Graduation size invalid |
| 3 | Decimal Position Invalid |
| 4 | Flag values must be 1 for 'ON' and 0 for 'OFF' |
| 5 | Push to Zero Window must be 0-99 |
| 6 | Zero tracking must be 1-99 or 100, 200, 300. |
| 7 | Only 1 will reset parameters |
| 8 | Only 1 will reset span table |
| 9 | Span exceeds maximum capacity or span too small |
| 10 | IZSM value can be 1 for ON and 0 for OFF |
| 11 | Test Weight units must be 0=lb or 1=kg. |
| 12 | Motion settle time out of range 1-100 |
| 13 | Power on units may only be 0=lb, 1=kg. |
| 14 | Invalid Time entry HH.MM.SS |
| 15 | Invalid Date entry YY.MM.DD |
| 16 | Motion value is out of range |
| 17 | Press tare to increment span table, any other key invalid |
| 18 | Press tare to decrement span table, any other key invalid |
| 19 | Span table cannot be decremented past 1 |
| 20 | Parameter memory write error, indicator requires service |
| 21 | Parameter checksum error, parameters have been lost. |
| 22 | Program check fault, indicator requires service |
| 23 | Invalid Serial Port speed setting |
| 24 | Invalid Serial Port Parity parameter |
| 25 | Cannot increment Span Table any further |
| 26 | Entered offset larger than Capacity |
| 27 | Invalid String mode for com port |
| 28 | Power on Zero warning 0=Off, 1=On |
| 29 | Channel enable is 0=Off and 1=On |
| 30 | Only 1 will set the deadload |
| 31 | Sound Volume can be between 0-3 |
| 32 | Keypress feedback can be 0=OFF or 1=ON |
| 33 | Invalid Com String mode parameter |
| 34 | Invalid Com Port Interface value |
| 35 | * |
| 36 | * |
| 37 | Channel 1 cannot be disabled |
| 38 | Invalid Print Select Function Number |
| 39 | * |
| 40 | Scale channel is not enabled |
| 41 | Pushbutton Tare is invalid (Over, Motion, or disabled) |
| 42 | Keyboard tare available on channel 1 only |
| 43 | Tare greater than capacity |
| 44 | Invalid Password number range, can only be 0000-9999. |
| 45 | Only a value of 0, 1 or 80 is accepted as a parameter |
| 46 | * |
| 47 | Invalid Filter value |
| 48 | Invalid Filter Fast step value |
| 49 | Invalid Fast step Sensitivity |
| 50 | Invalid Fast step on/off |
| 51 | Invalid Tare Function Parameter 0-4 |

| | |
|-----|--|
| 52 | Invalid input for AD voltage range |
| 90 | Calibration checksum failed |
| 100 | SRAM failure |
| 110 | RTC RAM failure |
| 112 | Clock Reset |
| 115 | Clock Failed |
| 120 | Battery flat or does not exist |
| 121 | Battery must be removed |
| 130 | COM1 loop back test failed |
| 131 | COM2 loop back test failed |
| 133 | COM driver chip failed |
| 140 | FLASH memory erase failed |
| 141 | FLASH memory write failed |
| 150 | Audit trail CRC failed |
| 151 | Database CRC failed |
| 152 | CAL copy CRC failed |
| 153 | Ticket Buffer CRC failed |
| 154 | DPAGE stack overflow |
| 160 | DLC slaves not detected communications failure |
| 161 | Scale 1 allocation action table does not verify with slave entries |
| 162 | Scale 2 allocation action table does not verify with slave entries |
| 163 | Scale 3 allocation action table does not verify with slave entries |
| 165 | Slave assigned to a scale but not detected by system |
| 170 | Scale 1 allocation action table does not verify with slave entries |
| 171 | Scale 2 allocation action table does not verify with slave entries |
| 172 | Scale 3 allocation action table does not verify with slave entries |
| 185 | SMART wire COM link not responding |
| 186 | SMART wire set-point checksum failed |
| 191 | Channel 1 AD converter not responding |
| 192 | Channel 2 AD converter not responding |
| 193 | Channel 3 AD converter not responding |
| 200 | General communications timeout – non critical |
| 210 | Scale allocation was not successful |
| 215 | Scale validity checksum failed - scale not valid |