

X Series access code

The default settings (made in the manufacturer works) of the access codes required for the operator access level and supervisor access level are as follows:

Operator access level: 2

Supervisor access level: 3

Tear out this page and keep it in a safe location. Should you lose it, contact the after-sales service (Mettler Toledo or Garvens Automation GmbH) for help and specify the checkweigher type.
