



WPI-135 Indicator Service Manual

Table of Contents
Specifications
Introduction5
About This Manual5
Front Panel Keys and Functions5
Hard Keys6
Soft Keys7
Menu Structure7
Instructions for Accessing the Menus8
User Menu8
User-CLOCK9
User-SELECT10
User-SET11
User-VIEW
Configuration Menu14
Configuration-MENU116
Configuration-MENU219
Configuration-MENU323
Configuration-MENU425
Calibratation Menu25
Calibrate-SETUP26
Calibrate-CAL27
Calibrate-INFO
Calibrate-EXIT31
Test Menu
Disassembly and Reassembly
Appendix 1: Display Samples
Appendix 2: Tips on Using Harmonizer
Enclosure, Parts and Assy41
Parts List
System Block Diagram
Display/Keypad Interface Board
Power Supply and Serial I/O PC Board45
Main PC Board46
I/O Cable Identification Pinouts

Specifications

Power Input	85-265 VAC, 50/60Hz, single phase
Excitation	10 Volts DC or 10 volts AC square wave capable of driving up to thirty-two 350-ohm weight sensors. Indicator is also capable of driving three Quartzell [™] transducers
Operational Keys	Zero, Tare, Print, Units, Select, Enter, Escape, Clear, 0-9, Decimal Point and Five Soft Keys labeled per selected operational routine.
Operational Annunciators	Displayed symbols indicate motion, center of zero, unit of measure and more.
Display	Model 135—1" H x 4.3" W vacuum fluorescent dot graphic display (32 X 128 dot layout)
Display rate	Selectable, from once every ten seconds to 10 times per second
A to D Conversion Rate	60 times per second
Unit of Measure	Pounds, kilograms, grams, ounces, pounds and ounces and four programmable custom units
Capacity Selections	Up to 10,000,000 selectable
Incremental Selections	Multiples and sub multiples of 1, 2, 5
Decimal locations	8888888 pick any location relative to division size
Displayed Resolution	Up to 1 part in 10,000,000
Audio Output	Audio tone for key contact assurance or operational alarms
Time and Date	Battery protected real time clock is standard
Internal Resolution	1,000,000 counts analog, Quartzell™ transducer higher
Harmonizer [™] digital filtering:	Fully programmable to ignore noise and vibration
Standard input and outputs: (internally)	Com 1: RS232, RS-485/422, Quartzell [™] Com 2: RS232, 20 mA current loop Com 3: RS232, RS-485/422, Quartzell [™] , 16550 UART Com 4: RS232, RS-485/422, Quartzell [™] , 16550 UART (<i>One bidirectional signal per port</i>) Four set point I/O ports via OPTO 22 I/O modules 1 Analog scale input
Dimensions	7.25" H x 11" W x 8.25" D (184 mm x 279 mm x 205 mm)
Available Options	 Multiple analog scale inputs, up to seven additional Eight fully isolated, programmable analog outputs, selectable 4-20mA, 0-5VDC, 0-10VDC, 0-20mA, 0-24mA, ±5VDC, ±10VDC Remote expanded control interface for TTL or up to 64 solid state I/O modules OPTO 22 Generation 4 I/O Modules PC/104 Compatible expansion bus Expanded memory PC (AT) style alphanumeric keyboard Alphanumeric, serial PC-style keyboard RS232/TTL Field programmable with SimPoser[®] Fieldbus Network Interfaces Device Net[™], ProfiBus[®], ControlNet[™], InterBus-S, ModBus+, Ethernet (TCP/IP-ModBus)
Operating Temperatures	14 to 104° F (-10 to 40° C), 10 to 90% relative humidity
Enclosure	Stainless steel wash down enclosure NEMA 4X
Weight	17 lb, 7.7 kg
Agencies	NTEP Class III/IIIL:10,000d (pending) Canada Consumer Affairs (pending) UL/CUL (pending) OIML (pending) CE (pending) FCC Class A
Warranty	2 year

Introduction

About This Manual

This manual covers the information you need to configure and service your WPI-135 Weight Processing Indicator.

Major sections of this manual are headed by titles in a black bar like *Introduction* above. Subheadings appear in the left column. Instructions and text appear on the right side of the page. Occasionally notes, tips, and special instructions appear in the left column.

Front Panel Keys and Functions

The front panel is shown in Figure 1.

Plug the WPI-135 into an easily accessible grounded outlet only. Never use the unit without an appropriate earthground connection.

Any computer based system should have a separate, grounded power circuit. We recommend one for the WPI-135.



Figure 1 WPI-135 Front Panel

The keys on the front panel of the WPI-135 are of two types, hard keys and soft keys. Hard keys are labeled directly and soft key labels appear on the display. Soft keys function differently at different times so their labels change as needed. (F1-F5)

Hard Keys

Below are brief descriptions for each of the hard key functions:



Repeatedly press the **SELECT** key to scroll through the available weight reading displays. (Examples - gross, net, tare, minimum, maximum, etc.)



Press the **UNITS** key to scroll through the available units of measure

By default the print format #0 sends:

Gross

Tare



Net They are transmitted from port one only.

During motion an M will appear

below the center-of-zero icon.



ZERO

→0←

Press the **PRINT** key to send data to a connected printer. By default this key performs a DOPRINT command followed by a DOACCUM command.

Press the **TARE** key to enter a tare weight, then repeatedly press **SELECT** to scroll through the tare, gross and net weight displays.

Press the **ZERO** key to establish a zero reference. A center-of-zero icon will be displayed when the weight is within ¼ division of zero.



Press the **ESCAPE** key to back out of menus or cancel a numeric entry without accepting the value.

ON/OFF

If the indicator is powered down via the **CE** key or by a sleep mode, press any key to power the indicator back up.



Press the **CLEAR** to clear values from the display prompts. Press and hold the **CE** key for five seconds to power down the indicator.



Press the **ENTER** key to enter a keyed in value or accept a displayed choice.

7	8	9
4	5	6
	2	3
	0	•

The numeric keypad is for entering numbers.



MOTION

Soft Keys

Soft keys are so-called because their function is not fixed. Function can change as the mode of operation changes or as the program for your particular setup changes.

Their are five soft keys (labeled F1-F5) located directly below the display. If the keys are needed during any operation, a label for each active key appears in the display directly above. There are only five key labels available at one time but this does not limit the potential usefulness of these keys. Programs can be created to enable one key to access another menu of operation with more key names and functions.

Menu Structure

There are several menus you use to setup or service the WPI-135. You access the menus described below through the front panel. Each menu is briefly described here. For in depth information about a menu, go to that menu's section in this manual.

User menu (default password is 111)

The first menu covered in this manual is the **User** menu. The items in this menu are the most commonly changed values and parameters that you will use in the course of operating the WPI-135.

Configuration menu (default password is 2045)

The second menu covered is the **Configuration** menu. These items deal with some of the basic functions of the WPI-135 and do not need to be accessed very often.

Calibration menu (default password is 30456)

The third menu is the **Calibration** menu. This section will need to be accessed only when the scale is being calibrated or if you change scale capacity or division size.

Diagnostic menu (default password is 911)

This menu is used to access several tests which can help isolate problems.

Instructions for Accessing the Menus

You must key in the password within 5 seconds of accessing the password screen or the WPI-135 returns to normal operation. A different password is needed to access each menu. Once you access the menu you want, the display presents a series of soft key choices. By pressing the appropriate soft key and following text prompts on the display, you can set up your WPI-135 to suit your needs.

Following are the instructions you need to access the menus of the WPI-135.

1. Press and hold the **ESCAPE** key until the WPI-135 beeps...

The display asks for a password and looks like Figure 2.



Figure 2 Password display

2. Key in the password for the menu you want to access and press **ENTER**...

The soft keys for the menu appear.

After you are finished in a menu you can press the EXIT soft key to return to normal operation. You may be asked if you want to save changes you have made. Follow the instructions on the display.

Below are the details for each menu.

User Menu

IMPORTANT NOTE

The WPI-135 can be sealed for legal for trade use and the software protected from change by a hardware connection. If the system is sealed, programs cannot be downloaded or altered. If the system is not sealed, programs can be downloaded from the SimPoser software. Sealing the WPI-135 does not affect the USER menu. This menu can be accessed and changed no matter what the system seal state is.

To seal or unseal the WPI-135, remove the nylon plug on the rear of the enclosure and press the button underneath. Access the User menu using the instructions found in *Instructions for Accessing the Menus*. Use the default password 111. You will see the screen shown in Figure 3.

1	 						
1							
1							
ł	 	 	 	 	 	 	
-	 	 	 	 	 	 	

Figure 3 User menu soft key group

Figure 4 is a flowchart showing what soft keys or choices appear as you press the soft keys shown in Figure 3.

The User menu is not affected if the indicator is sealed or unsealed.

The values under SELECT in the flowchart to the right are not saved after a power down and power up.



Soft key flowchart for User menu

Press the **CLOCK** soft key to access the time and date setting function.

- The display shows the current 1. hour value. If this is not correct key in a new value and press ENTER or press ENTER to accept the current value. . .
- Repeat step 1 for minutes, 2. seconds, year, month and day. (The day of the week is calculated automatically from the four digit year.)

The display shows the minutes value.

Display returns to display shown in Figure 3.

User **CLOCK**

> Hours must be entered in military format: 23 = 11pm 13 = 1pm 1 = 1am

User — SELECT

While in the this menu the display will show USER-SELECT in the top left to remind you of where you are in the USER menu.

User — SELECT —DISP

> The display mode you pick may not be the one that appears on the display. A display mode called out in the WT BASIC program overrides the setting you make through the front panel.

Variable (#11) is a variable value called out in a WT-BASIC program. ADC (#13) stands for Analog to Digital Counts.

User
-SELECT
-SCALE

You cannot select a scale number unless it has been activated in the SimPoser program and downloaded to the WPI-135, or enabled in the Config menu.

User —SELECT —TARE

Press the **SELECT** soft key to access the User—SELECT soft key group:

DISP	Press this key to set the current display mode and active value
SCALE	Press this key to select the scale number you want to use.
TARE	Press this key to enter a known tare weight.
UNIT	Press this key to select the active units of measure.
Following is	a detailed description of the four functions listed above.

If you press the **DISP** soft key, follow these instructions:

1. The display shows the current display mode number. Press ENTER to accept this value or key in a new number from the list in Appendix 1, then press **ENTER** to accept it. The display asks for the ACTIVE VALUE. This is the active display value. 2. Choose one of the following active display values by keying in 0-13, then press ENTER... The display returns to the USER-SELECT screen. 0 = Gross8 = Count Total 4 = Max12=Piece Weight 9 = Trans. Total 13=ADC 1 = Net5 = Rate of Change 6 = Gross Total 10=Count 2 = Tare3 = Min7 = Net Total 11=Variable

If you press the **SCALE** soft key the display will ask you to select a scale number. The currently active scale number is displayed. You can simply type a new scale number and press the **ENTER** key. If you have multiple scales attached to the indicator, this function chooses which scale's weight is displayed and which one the **ZERO** and **TARE** keys will affect.

If you press the **TARE** soft key the display will show the current tare value for the active scale. You may key in a new tare weight and press the **ENTER** key to override the previous tare weight. User —SELECT —UNIT

User

-SET

-PEAKS

If you press the **UNIT** soft key the display will ask you to key in a number (0-6) which represents the value you want to be active. Below are the seven units to choose from and the corresponding number you need to key in for this function:

0- lb	3- oz	6- custom 2
1- kg	4- lb oz	7 - custom 3
2- g	5- custom 1	8 - custom 4

Press the **EXIT** soft key to return to the USER menu soft key group.

User	Press the s below:	SET	soft key to access the	User—SET soft ke	y group shown								
	GRAPH	Pre wei	ess this key to set the p ighing functions.	arameters for bar	graph and check-								
	PEAKS	Press this key to reset the Min/Max.											
	ACCUM	Press this key to set the accumulator totals.											
	PCWT	Pre	ess this key to set the p	ieceweight for cou	nting functions.								
	EXIT	Pre	ess this key to go back	to the previous sof	t key set.								
	Following i	sad	letailed description of th	ne four functions lis	sted above.								
User -SET -GRAPH Variable (#11) is a variable value called out in a WT- BASIC program. ADC (#13) stands for Analog to Digital counts.	If you pres 1. The cu display accept value a 2. Repea change OVER BASIS values 0 = Gros 1 = Net 2 = Tare 3 = Min	s the rrrent ved. I t this and p t step t t step , MA. (0-1	e GRAPH soft key, follo t MIN setting is Press ENTER to value or key in a new press ENTER p 1 and accept or value, for UNDER, X and BASIS values. ame as the active 3) shown below. 4 = Max 5 = Rate of Change 6 = Gross Total 7 = Net Total	w these instruction The UNDER values These values now the bar graph or o display. 8 = Count Total 9 = Trans. Total 10=Count 11=Variable	is: ie is displayed. w apply when using checkweighing 12=Piece Weight 13=ADC								

If you press the **PEAKS** soft key the display asks if you want to reset the MIN and MAX values now in memory. You are given the choice of YES or NO. After choosing the display returns to the USER-SET menu display.

User	If you press the ACCUM soft key, follo	w these instructions:
—SET —ACCUM	 The display shows you the current GROSS TOTAL in the accumulator. You can change this by keying in a new number and pressing ENTER or press ENTER to move to the next ACCUM value 	The display shows the NET TOTAL value.
	2. Repeat step 1 for NET TOTAL, COUNT TOTAL, and TRANS(action) TOTAL	The display returns to the USER- SET screen.
User —SET —PCWT	If you press the PCWT soft key the dis piece weight. Accept this by pressing t weight and press ENTER .	play shows the current value for the he ENTER key or key in a new piece
	Press the EXIT key to return to the Us	er menu soft key group.

User	Press the V	/IEW soft key to access the User-VIEW soft key group:
-VIEW	VERS	Press this key to see WPI-135 firmware part number, revision information (time, date and revision letter), serial number, Xilinx part number and revision, and information about a downloaded SimPoser program (license number, company name, version number, name of file and time and date downloaded.
	SEAL	Press this key to view/set the condition of the physical seal setting.
	VARS	Press this key to view the BASIC variables.
	STORES	Press this key to view the numeric and string values used with store and recall.
	COUNT	Press this key to view the calibration and configuration audit counters.
	Following i	s a detailed description of the functions listed above.
User —VIEW —VERS	If you press • Firmv • Part r • Seria • XILIN • XILIN • XILIN	s the VERS soft key you will see the following information: ware version number and revision level I number of the indicator IX version IX part number IX revision level

	 SimPoser license number and license holder of the person that saved the file SimPoser license number and license holder of the person that downloaded the file Version of the SimPoser that created the file File name Time and date file was created Press any key again and the User-VIEW soft key set is displayed.
User —VIEW —SEAL	Press the SEAL soft key to see the current state the physical seal setting. The display will show Seal Status: Sealed or Unsealed . Press the seal switch (S1) to toggle the physical seal state of the indicator.
User —VIEW —VARS	If you press the VARS soft key you will be able to scroll through the vari- ables you have in your basic program. Press the FIRST soft key to see the first one and the NEXT soft key to scroll to the next one. Repeat this until you are through and press the EXIT soft key to return to the User—VIEW menu. If no variables are defined the screen will show NO VARIABLES DEFINED .
User —VIEW —STORES If you press the Prev key when Store (0) is displayed, the display will show the max memory location. This is a good way to see how much memory is available for your WT-BASIC program.	If you press the STORES soft key, follow these instructions: The display asks if you want to DISPLAY NUMERICS?, and gives you the choice of YES or NO. If you press YES the display will look like this: STORECO: 0.0000000 TREU INERT STORECO: 0.0000000 REXT STORECO: 0.0000000 REXT to see the next numeric record. Press NEXT to see the next numeric record. Press SELECT and the display will let you enter a specific numeric record number. When you press ENTER that record number will be displayed.

3. If you press **NO** in step 1 the following screen is displayed.



If you press the **Prev** key when Store (0) is displayed, the display will show the max memory location. This is a good way to see how much memory is available for your WT-BASIC program.

- 4. This screen lets you view all the strings stored in your BASIC program. View them the same way you did the numeric values.
- 5. Press **EXIT** to return to the User-VIEW menu.

Press **ESC** to return to the User menu. Press **EXIT** to return to normal operation. You have now seen all the parts of the User menu.

Configuration Menu

You must key in the password within 5 seconds of accessing the password screen or the WPI-135 returns to normal operation. Access the Configuration menu using the instructions found in *Instructions for Accessing the Menus*. Use the default password 2045. You will see the screen shown in Figure 5.

Figure 5 Configuration menu display

Figure 6 is a flowchart showing what soft keys or choices appear as you press the soft keys shown in Figure 5.





Configuration	Press the	MENU1 soft key to access the	ne following soft key group:
—MENU 1	#SCL	Press this key to set numb	per of active scales,
	UNITS	Use this key to enable/disa	able units of measure.
	KEYS	Use this key to enable or c	lisable front panel keys
	SERIAL	Use this key to set port #, I shake, mode, and EOM ch	baud rate, parity, databits, hand- naracter.
	VALS	Use this key to enable/disa weight display	able values to be shown in the main
	Following	are detailed instructions for s	setting these parameters.
Configuration	If you pres	ss the #SCL soft key, follow t	hese instructions:
—MENU1 —#SCL	1. The d of acti pressi in the scales key	isplay will show the number ve scales. Accept this by ing the ENTER key or key number of attached s and press the ENTER	The display returns to the MENU1 display.
Configuration	If you pres	ss the UNITS soft key, follow	these instructions:
MENU1 UNITS Custom Units prompts for how many calibration units equal how many custom units. Example: 2000 lb = 1 ton	1. The d enable and sl (<i>ON</i> o as you ENTE chang YES o ENTE unit of	isplay asks if you want to the LB unit of measure hows you the current state or OFF). If the condition is a want it, simply press the R key. If you want to be the condition, press the or NO soft key, then the R key to move to the next f measure	The kilogram unit of measure is the next one shown.
	2. Repea grams ounce The d units, units t Key ir ENTE	at step 1 for kilograms, s, ounces, pounds & es, and custom units 1 - 4. isplay asks for calibration then the number of custom hat are equivalent. the values and press R	The display returns to the MENU1 display.

Configuration	If you press the KEYS soft key, follow	these instructions:
-MENU1 -KEYS	 The display asks if you want to enable the SELECT key and shows you the current state (ON or OFF). If the condition is as you want it, simply press the ENTER key. If you want to change the condition, press the YES or NO soft key, then the ENTER key to move to the next key 	The UNITS key is the next one shown.
	2. Repeat step 1 for UNITS, PRINT, TARE, ZERO, AUTOTARE and KEYPAD TARE	The display returns to the MENU1 display.
Configuration —MENU1 —SERIAL	 If you press the SERIAL soft key, follo The display prompts you for serial port # to configure. Press ENTER if displayed port is OK or 	w these instructions:
	 Press ENTER to accept the baud rate or key in a new baud rate from the table below and press ENTER. 	The baud rate is displayed.
	Baud Rates 300 9600 1200 19,200 2400 38,400 4800 56,700	
CTS is a hardware handshake (ready/busy) which requires two extra wires in your cable.	3. Press ENTER to accept the parity or key in a new parity code number from the table below and press ENTER	The databits setting is displayed.
Xon/Xoff is a software hand- shake requiring no additional hardware.	Parity Codes $0 = NONE$ $3 = SET$ $1 = ODD$ $4 = CLEAR$ $2 = EVEN$	
	4. Press ENTER to accept the databits setting or key in the new databits value (7 or 8) and press ENTER	The handshake protocol code number is displayed.

	 5. Press ENTER to accel handshake protocol sikey in a new code nur the handshake from the below and press ENT Handshake Protocol 0 = NONE 2 	pt the etting or nber for ne table ER The mode code number is dis- played.	
	1 = CTS 3	= BOTH	
	 Press ENTER to acce mode setting or key in code number from the below and press ENT 	pt the ⊫a new e table ER	
	Serial Mode Con	displayed.	
	0 = BASIC contro 1 = Keyboard	2 = Disabled 4 = Computer 3 = Multidrop	
	BASIC Control - Contr execu	ol of the serial port is through the BASIC program uting in the WPI-135.	
	Keyboard - Contr board	ol of the serial port is through an attached key-	
	Disabled - The s Multidrop - The s Computer- Make port.	erial port is not in use for this configuration. erial port is configured in RS-485 Multidrop mode. s certain indicator functions available via serial	
EOM ASCII code #13 is carriage return.	7. Press ENTER to acce EOM character or key number from 0-256 ar ENTER	pt the in a new nd press The display returns to the CONFIGURE-MENU1 display unless you are configuring port 2 or 4. If you are configuring port 2 or 4, you must choose from the following: Serial port 2: RS-232 or 20mA Serial port 4: RS-232 or IR (Infrared)	
Configuration —MENU1 —VALS	Press the VALS soft key t played on the main weigh the instructions for the VA	o enable or disable the value which can be dis- t display when using the SELECT key. Below are LS soft key:	
	 The current setting (enabled ON or OFF) for the GROSS display value is displayed. Press YES to enable the active value or NO to disable this active display value, then press ENTER The current setting for th active value is displayed. 		

 Repeat step 1 for all the display values (NET, TARE, MIN., MAX., ROC, G-TOT, N-TOT, C-TOT, #-TOT, COUNT, VALUE, PCWT and ADC...

The display returns to the MENU3 display.

This completes the instructions for all the parameters of Menu1.

Configuration —MENU 2

These configuration items pertain to a particular scale. If you have enabled multiple scales, you will be asked which scale you want to configure. Key in the scale number, press **ENTER** and continue. If you have enabled only one scale, continue with the following instructions.

Press the **MENU2** soft key to access the following soft key group:

- **MOTION** Use this key to set the motion detection window size in divisions and the time window in seconds.
- **AZT** Use this key to set the AZT window size in divisions and the time window in seconds.
- **FILTER** Use this key to set up the Harmonizer filtering to counteract vibration of the scale.
- **ZERO** Use this key to set the zero range. This is a percent of capacity that is allowed to be zeroed when pressing the **ZERO** key. (0-100% allowed)
- **MORE** This accesses the following three soft keys.
- **RATE** Press this key to configure the display update rate in updates per second.
- **ROC** ROC stands for Rate of Change. Press this key to set up your WPI-135 Indicator to calculate Rate of Change for flow rate, or weight/time, applications.
- **RZ/TO** Press this key to configure Print Return to Zero (RZ), Accumulator RZ, Accumulator Timeout, Print Timeout and Zero Timeout.

Following are detailed instructions for setting these parameters.

Configuration —MENU 2 —MOT'N Use this key to set the motion detection window size in divisions and the time window in seconds.

For example: If you set divisions to 3 and seconds to 1, if the weight value does not change more than 3 divisions in one second, the scale or weight is considered stable.

If you press the **MOT'N** soft key, follow these instructions:

1. The current value for the motion window size, in divisions, is shown. Press **ENTER** to accept this value or key in a new value and press **ENTER**...

The current time window in seconds is displayed.

	2. Press ENTER to accept this time period or key in a new value and press ENTER	The display returns to the MENU2 display.		
Configuration —MENU 2 —AZT	Use this key to set the AZT window div onds. The division size you pick define When scale weight is inside this range picked, ½ of the weight will be zeroed. the weight every X seconds. X being th picked.	vision size and time window in sec- es a range above and below zero. for the number of seconds you The indicator will repeat removing ½ ne number of seconds you have		
	If you press the AZT soft key, follow th	ese instructions:		
	 The current value for the AZT window size, in divisions, is shown. Press ENTER to accept this value or key in a new value and press ENTER 	The current time window in seconds for AZT is displayed.		
	2. Press ENTER to accept this time period or key in a new value and press ENTER	The display returns to the MENU2 display.		
Configuration —MENU 2 —FILTER	Use this key to set up the Harmonizer scale. A full explanation is given below Harmonizer.	filtering to counteract vibration of the v. See Appendix 2 for tips on using		
	The A-D weight conversion happens 60 times per second in the WPI-135. AVG is the number of conversions you want to average. For example, if you pick 30, the unit will average the weight values from the last 30 conversions or ½ second and uses that value for displayed data.			
In the SimPoser software the	The next choice you have is for turning you turn the Harmonizer filtering on yo stant. Typical values are between 1-10 vibration problems and higher for more	g the Harmonizer filtering on or off. If u need to set the Harmonizer Con-). Set the number low for small e dampening effect.		
Harmonizer constant choices are 1 through 10. This setting is to be made in the "real world" on a working system so there are more menus avail- able from the front panel.	The purpose of the Harmonizer Thresh quickly to large weight changes. Harm weight change, in calibration units, bey temporarily disabled. For example, if y over 10 pounds occurring during the sa will disable the Harmonizer until the we drops below 10 lbs.	hold is so the indicator will respond onizer Threshold is the amount of yond which the Harmonizer will be ou set this to 10 lbs, a weight change ample time ($\frac{1}{2}$ sec. in our example) eight change during the sample time		
	If you press the FILTER soft key, follow	w these instructions:		
	 The display shows the current value for the number of samples to average. Press ENTER to accept this value or key in a new value and press ENTER 	The display shows the state of the Harmonizer filtering(ON or OFF).		

	 Press YES to enable Harmonizer or NO to disable the Harmonizer parameter, then press ENTER 	The current Harmonizer Constant value is displayed.
	3. Press ENTER to accept this value or key in a new value and press ENTER	The current Harmonizer Threshold value is displayed. This value is in calibration units.
	 Press ENTER to accept this value or key in a new value and press ENTER 	The display returns to the MENU2 display.
Configure —MENU2 —ZERO	If you press the ZERO soft key you are the displayed value by pressing ENTER ENTER . The display returns to the MEI	prompted for a zero range. Accept R or key in a new one and press NU2 display.
Configure —MENU2 —MORE	This soft key accesses the last three so described below.	oft keys in this menu. They are
Configure —MENU2 —MORE —RATE	If you press the RATE soft key you are Accept the displayed value by pressing press ENTER . The following values are available: 0.1, a value not in the list, the unit defaults to The display returns to the MENU2—MC	prompted for a display update rate. ENTER or key in a new one and 0.25, 0.5, 1, 2, 5 and 10. If you enter to five. DRE display.
Configure —MENU2 —MORE —ROC	ROC stands for Rate of Change. Press Indicator to calculate Rate of Change for tions. ROC Samples The number of samples over which the mined. The WPI-135 converts weight for ROC Samples is set to 60, the WPI-13 change over one full second.	e this key to set up your WPI-135 or flow rate, or weight/time, applica- e rate of change of weight is deter- rom A to D at 60 times per second. If 5 is determining the rate of weight

	ROC Mult The ROC Multiplier allows you to enter weight to some other unit of measure, unit based upon the calibration unit of	a conversion factor to translate such as gallons or some other weight measure.	
	<i>ROC Examples:</i> If pounds is your calibratio a multiplier of 1. The displa pounds/second.	n unit, pick a sample value of 60 and ay will show the rate of change in	
$\frac{\text{Cal Unit}}{\text{Custom Unit weight}} = \frac{1}{8} = 0.125$	For gallons of water/secon multiplier to 0.125. Water = for our example) so their a formula to the left.	d set the sample value at 60 and the = 8 lbs/gallon (8 lbs is close enough re 0.125 gallons per pound. See	
	To get gallons/minute, do multiply the 0.125 by 60 to minute (7.5). The display v gallons per minute. (This is over a whole minute's time	not change the sample size but rather get a value equal to gallons/pounds/ vill then show you a rate of change in s the flow over the last second not e.)	
	If you press the ROC soft key, follow th	nese instructions:	
	 The display shows the current value for SAMPLES. Press ENTER to accept the current value or key in a new one and press ENTER 	The current multiplier value is displayed.	
	2. Press ENTER to accept the current value or key in a new one and press ENTER	The display returns to the MENU2—MORE display.	
Configure —MENU2	Press this key to configure Print Return TimeOut, Print TimeOut, Zero TimeOu	n to Zero (RTZ), Accum RTZ, Accum t and Tare TimeOut.	
—MORE —RT / TO	For the RTZ functions, set the percent of capacity the weight must fall below before another Print or Accum action can occur.		
	For the TimeOut functions, set the amo will retry the function before it gives up	ount of time, in seconds, the indicator	
	If you press the RT / TO soft key, follow	w these instructions:	
	 The current value for PRINT RTZ is displayed. Press ENTER to accept this value or key in a new value and press ENTER 	The Accum RTZ value is displayed.	
	2. Repeat step 1 for Accum RTZ, Accum TimeOut, Print Timeout, Zero Timeout, and Tare		
	l imeout	I ne display returns to the MENU2—MORE display.	
	Press the ESC key twice to return to th	e CONFIGURE display.	

Configure —MENU3

When using the Showsetpt, make sure you use a display mode that will not interfere with the dots, such as display mode 16.

Configure —MENU3 —SETPT

Configure —MENU3 —FMTPT

Configure —MENU3 —DMODE

Configure —MENU3 —MISC Press the **MENU3** soft key to access the following soft key group:

- **SETPT** Press this key to enable or disable viewing of setpoint state in the right corner of the weight display.
- **FMTPT** Press this key to configure a port to use for each print format.
- **DMODE** Press this key to pick a power-up display mode from those available in *Appendix 1: Display Samples*.
- MISC Press this key to do the following: Choose the excitation for the loadcell, set default print format, choose date format preference, set beeper volume, choose uppercase or lowercase for the small font, enable or disable the display cycle using the decimal (.) key on the front panel and set up the sleep timer.

Following are detailed instructions for setting these parameters.

If you press the **SETPT** soft key you are asked if you want to show setpoints. Press **YES** if you want to see the setpoint state in the upper right corner of the display. Press **NO** if you do not want to see this. The display returns to the MENU3 display.

If you press the **FMTPT** soft key you are shown a format number and a port number. Accept the port number for each format or key in a new port number for up to 32 formats. After the last entry or when you press **ESC**, the display returns to the MENU3 display.

If you press the DMODE soft key you are asked what power up display mode you would like. Press **ENTER** to accept the displayed display number or key in a new number and press **ENTER**. Choose the display from those shown in *Appendix 1: Display Samples*.

If you press the **MISC** soft key, follow these steps:

- The current excitation is displayed next to SELECT EXCITATION: If this is OK, press ENTER. If there is no excitation displayed, or if you want to change the excitation, press the appropriate softkey from this list of choices: DC, 300HZ, 600HZ, or 1.2KHZ. Press ENTER to accept the choice...
- 2. Choose the date format you want (MMDDYY, DDMMYY, or YYMMDD) and press **ENTER**...

The date format screen is displayed.

The beeper volume screen is displayed.

3.	Press ENTER to keep the displayed volume or press the soft key for: OFF, LOW, MED or HIGH. Press ENTER after making your choice	The default print format screen is displayed.
4.	Press ENTER to keep the displayed default print format or type in a new format number and press ENTER to accept it	The current setting for the small font is shown.
5.	Press ENTER to keep the current choice. Press NO to disable lowercase font on the display. Press YES to enable lower case letters on the display. Press ENTER to accept your choice	The current setting for the display cycle is shown.
6.	Press ENTER to keep the current choice. Press NO to disable the decimal (.) key from cycling through the display modes. Press YES to enable this function. Press ENTER to accept your choice	The current setting for the sleep timer is shown.
7.	Press ENTER to keep the current setting or press the NO soft key to disable it or the YES soft key to enable it. Press ENTER to accept your choice. If you pick YES, you are prompted to enter a time in hours, then prompted to enable or disable a warning beeper. If no indicator activity occurs in this period of time, the indicator will turn itself off preceded by a series of warning beeps. Press ENTER to accept your choices	The display returns to the MENI 13
		display.

Configure —MENU4

The only soft key in MENU4 is the CLRPRG key. Press this key only if you want to clear the BASIC program from the indicator memory.

WARNING: Do this only if you are sure it is absolutely necessary!

Press the **ESC** key then the **EXIT** soft key to exit the Configure menu. You will be prompted to save any changes you have made. Press **YES** to save the changes. Press **NO** to exit without saving the changes. The indicator restarts.

Calibration Menu

Access the Calibration menu using the instructions found in *Instructions for Accessing the Menus*. Use the default password 30456. You will see the screen shown in Figure 7.

CALIBRA	ATE			
SETUP	CAL	INFO		EXIT
			7	

Calibration menu display

Figure 8 is a flowchart showing what soft keys or choices appear as you press the soft keys shown in Figure 7.



Figure 8 Soft key flowchart for Calibration menu

—SETUP CAPAC Press this key to enter the capacity of the scale and the divis size. OPTION Press this key to enable or disable multi-interval use. Following are detailed instructions for setting these parameters. Calibrate If you press the CAPAC soft key, follow these instructions: SETUP If you press the CAPAC soft key, follow these instructions: 1. The display shows the current value for the capacity. Press ENTER to accept this value or key in a new capacity and press ENTER ENTER The current division size is displayed.	Calibrate	Press the SETUP soft key to access the following soft key group:		
OPTION Press this key to enable or disable multi-interval use. Following are detailed instructions for setting these parameters. Calibrate SETUP CAPAC If you press the CAPAC soft key, follow these instructions: 1. The display shows the current value for the capacity. Press ENTER to accept this value or key in a new capacity and press ENTER. ENTER. The current division size is displayed.	-SETUP	CAPAC Press this key to enter the capacity of the scale and the division size.		
Calibrate If you press the CAPAC soft key, follow these instructions: SETUP 1. The display shows the current value for the capacity. Press ENTER to accept this value or key in a new capacity and press ENTER The current division size is displayed.		OPTION	Press this key to enable o	r disable multi-interval use.
Calibrate If you press the CAPAC soft key, follow these instructions: -SETUP 1. The display shows the current value for the capacity. Press ENTER to accept this value or key in a new capacity and press ENTER The current division size is displayed.		Following	are detailed instructions for	setting these parameters.
 Press ENTER to accept the division size or key in a new one and press ENTER The display returns to the SETUI 	Calibrate —SETUP —CAPAC	If you pres 1. The di value i ENTE key in ENTE 2. Press divisio and pr	es the CAPAC soft key, follow splay shows the current for the capacity. Press R to accept this value or a new capacity and press R ENTER to accept the on size or key in a new one ress ENTER	w these instructions: The current division size is dis- played. The display returns to the SETUP

Calibrate
—SETUP
-OPTION

Press the **OPTION** soft key to enable or disable the multi-interval option. If you enable the multi-interval option, the division size you choose under **CAPAC** applies to weight on the scale from 0 to ½ capacity. For weight on the scale from ½ capacity to full capacity the division size will double.

When multi-interval is enabled, the division used to check for stability, center of zero, and AZT is always the smaller division size. Overload and underload is always calculated based on the upper division size.

The displaying and printing division size depends on which interval the scale is in. The active interval is chosen based on net when a tare weight is active, and gross weight when a tare is not active.

When gross is displayed or printed (regardless of the tare value) the division size used depends on the interval used.

Press the CAL soft key to access the softkey set used to set zero and span,

After pressing **ENTER** to accept your choice of enabling or disabling the multi-interval option, the display returns to the SETUP soft key choices.

sho	wn belo	w:		
 ZER	RO	Use this key	y to set the zer	o reference.
SPA	AN	Use this key	y to span the s	cale.
SPE	EC	Use this key calibration.	y to access and	other set of soft keys for specialized
Foll	owing a	re detailed ir	nstructions for	setting these parameters.
If yc from poin you you' to th	ou press in the sc int, the d will see 've chos ine CAL	s the ZERO s ale then pres isplay says I the weight o sen. If not yo display.	soft key the dis as ENTER . Afte DONE and asks displayed. It sh u should perfo	play asks you to remove all weight er the indicator has calibrated the zero s you to press any key. Above the text ould read zero in the increments rm this step again. The display returns
lf yo	ou press	s the SPAN s	oft key, follow	these instructions:
1.	The cur weight ENTER key in a ENTER	rrent span ca is displayed. to accept th a new one an t	llibration Press is weight or id press	The display prompts you to apply the test weight load to the scale.
2.	Apply ti scale a	he test weigh nd press EN	nt load to the TER	The indicator determines the span and tells you when it is done. Above the text, the display should show you the correct test weight. If not perform the span again.
3.	Press a CAL dis	any key to ret splay.	turn to the	

Calibrate
—CAL

Calibrate —CAL —ZERO

Calibrate —CAL —SPAN

Use the SPEC soft key to access three new softkeys. These soft keys are listed below.						
TZERO	This stands for temporary zero. This calibration procedure is useful when a scale has weight on it that is impractical to remove, such as a hopper or bin which is partially full of mate rial. This calibration allows you to establish a temporary zero, add weights to the scale and do a span without losing the zer reference point.					
KEY IN	This calibration procedure mV/V or counts. This mea between different indicato procedure need be done.	e allows you to key in calibration data, ans calibration data can be transferred ors if one fails and no new calibration				
R-CAL	This stands for reverse calibration. Use this procedure when it is impractical to hang weights from a full or partially full hopper or bin. You can key in a span weight, unload that weight onto another scale, perform a zero calibration and your scale is calibrated.					
Following are detailed instructions for these soft keys.						
If you press the TZERO soft key, you are shown two new soft keys, TZERO and SPAN .						
To perform the temporary zero spanning procedure, press the TZERO soft key. The indicator performs a zero function, the display says DONE and asks you to press any key. Above the text you will see the weight displayed. It should read zero in the increments you've chosen. If not you should perform this step again. The display returns to the TZERO display.						
Next, press the SPAN soft key.						
1. The c weigh ENTE key in ENTE	urrent span calibration It is displayed. Press It is accept this weight or a new one and press It	The display prompts you to apply the test weight load to the scale.				
2. Add tl scale	ne test weight load to the and press ENTER	The indicator determines the span and tells you when it is done. Above the text, the display should show you the correct test weight. If not perform the span again.				
3. Press TZER	any key to return to the O display.					
	Use the S listed belo TZERO KEY IN R-CAL Following If you pret and SPAN To perform key. The i asks you to lt should r perform th Next, pres 1. The c weigh ENTE key in ENTE 2. Add th scale	 Use the SPEC soft key to access thread listed below. TZERO This stands for temporary useful when a scale has a remove, such as a hopperial. This calibration allow add weights to the scale a reference point. KEY IN This calibration procedure mV/V or counts. This mead between different indicate procedure need be done. R-CAL This stands for reverse calibrated. Following are detailed instructions for the indicator perform the temporary zero spann key. The indicator performs a zero fur asks you to press any key. Above the It should read zero in the increments of perform this step again. The display reform this step again. The display reform the scale perform the temporary zero spann key. The indicator performs a zero fur asks you to press any key. Above the It should read zero in the increments of perform this step again. The display reform this step again. The display reform the scale press ENTER to accept this weight or key in a new one and press ENTER Add the test weight load to the scale and press ENTER Press any key to return to the TZERO display. 				

Press **ESC** to return to the SPEC display.

Calibrate —CAL —SPEC

Calibrate —CAL —SPEC —KEY IN	Press the KEY IN soft key if you want to set up a new indicator to replace another indicator and keep the original indicator's calibration settings. To do this you must have recorded the zero counts or mV/V values of the original indicator in order to transfer that information to the new indicator. This information can be found in the Calibrate menu under the INFO and FAC- TOR soft keys. If you press KEY IN , you are asked if you want to set up the calibration					
	using zero counts or mv/v. Choose on	e.				
Calibrate	If you press CNTS, follow these steps:					
—CAL —SPEC —KEY IN —CNTS	 The display shows the current zero counts value. Key in the value from the original indicator and press ENTER 	The display shows the current span weight.				
	2. Key in the span weight from the original indicator and press ENTER	The display shows the span counts.				
	 Key in the span factor from the original indicator and press ENTER 	Display returns to the SPEC soft keys.				
Calibrate	If you press MV/V , follow these steps:					
—CAL —SPEC —KEY IN —MV/V	 The display prompts for the cal zero mV/V value. Key in the value from the original indicator and press ENTER 	The display shows the current cal weight.				
	2. Accept the displayed cal weight, if it is the same as the cal weight of the original indicator, by pressing ENTER or key in the correct value from the original indicator and press ENTER	The display shows the span mV/V.				
	3. Accept the displayed span mV/V, if it is the same as the span mV/V of the original indicator, by pressing ENTER or key in the correct value from the original indicator and press ENTER	Display shows the SPEC soft keys.				

Calibrate —CAL —SPEC —R-CAL	If you press the R-CAL soft key, you can perform a reverse calibration. In other words, you start with a loaded scale, remove all the weight from the scale for spanning, then get your zero reading. This may require a container on a separate scale into which you discharge the material.		
	1.	Press the R-CAL soft key	Display shows the title <i>Reverse</i> <i>Calibration Span</i> and prompts you to press ENTER .
	2.	Press ENTER	The indicator determines span point #1 and shows DONE when finished. The display prompts you to press any key to continue.
	3.	Press any key	Display prompts you to enter a calibration weight. This is the weight that is currently on the scale. You will remove all this weight from the scale in step 5. This value is used for spanning the scale. Reference zero is also acquired at this time.
	4.	Key in a calibration weight value equal to the amount to be removed from the scale in step #5 and press the ENTER key	The indicator prompts you: "REVERSE CALIBRATION ZERO: Remove load, Press ENTER."
You need to remove all the weight from the scale in this step.	> 5.	Empty the scale and press ENTER	The indicator acquires span point #2 and shows DONE when finished.
	6.	Press any key to return to the SPEC display.	

Calibrate	Press the INFO soft key to access the following soft key group:		
-INFO	VERS	Press this key to view firmware and downloaded file informa- tion.	
	VIEW	Press this key to view calibration information.	
	FACTOR	Press this key to view the calibration data (mV/V and counts) for the current scale.	
	PRINT	Press this key to print out calibration data from the selected serial port.	
	Following are detailed instructions for setting these parameters.		

Calibrate —INFO —VERS	If you press the VERS soft key, you can see all the following information on consecutive screens as you press any key to continue. The SimPoser information will be available only if a file has been downloaded to the indicator.
	 Firmware version Part number and revision level Serial number of the indicator XILINX version XILINX part number XILINX revision level SimPoser license number and license holder of the person that saved the file SimPoser license number and license holder of the person that downloaded the file Version of the SimPoser that created the file File name Time and date file was created After viewing the last screen, the display returns to the INFO display.
Calibrate —INFO —VIEW	If you press the VIEW soft key, you can view the following information about calibration: • Calibration date • Calibration weight • Displayed weight following calibration
Calibrate —INFO —FACTOR	If you press the FACTOR soft key, you can see the following: • CAL ZERO in mV/V • CAL FACTOR in mV/V • CAL ZERO in counts • CAL FACTOR in counts per divison • CFG • GAIN • DAC • AINRO • URFNO
Calibrate —INFO —PRINT	If you press the PRINT soft key you are given a choice of four ports through which to print the calibration information. Pick port 1-4 and the information is transmitted and the screen returns to the INFO display.
Calibrate —EXIT	Press the EXIT softkey to return to normal weighing operation. You will be prompted to save any changes made. Press NO to exit without saving changes. Press YES to exit and save changes.

Test Menu

There is one more menu that you can access for testing purposes. The flowchart of soft keys in the menu are shown in Figure 9.



• Software version of the cell (vD.A in this example)

For analog scales you are shown:

- a raw count value and its equivalent mV/V value. (These values should be positive and increase as weight is applied.
- **SERIAL** Use this to test your ports. Select Port #1 through 4 then short the TX and RX on the selected port. The display will change from NO LOOP to LOOP indicating the port is good. Jumper RTS to CTS to test the handshake lines.
- **MORE** Accesses the following keys:
- **INPUT** Allows you to Activate/Deactivate any input setpoint device such as a switch or contact closure remotely and monitor it with this menu.
- **OUTPT** Allows you to Activate/Deactivate any output setpoints to verify correct hardware operation during installation or for trouble-shooting purposes.
- **DISP** This test continuously cycles the display through various patterns.
- **NET** This diagnostic will only appear if a network option card is installed. Follow the instructions on the display.

Inputs and outputs have to be defined in the WT-BASIC program for them to work.

Disassembly and Reassembly

Following are the steps for disassembly and reassembly of the WPI-135 for service purposes.

- 1. Disconnect the WPI-135 from power and all peripheral equipment.
- 2. Remove the 14 acorn nuts holding the rear panel to the case. See Figure 10.



Figure 10 Removing the acorn nuts

3. Carefully pull the back from the case and lay it down. See Figure 11.



Figure 11 Back removed

3. If you need to remove the power supply board from the inside of the back cover, begin by disconnecting the power supply wires and the wires leading to the main board. Remove the eight screws holding the pc board as shown in Figure 12.



4. If you need to remove the main board, disconnect the cables from the main board. Remove the six hold down screws on the board, as shown in Figure 13 and pull out the main board. The sixth screw is located under the ribbon cable in the photograph. Take care because there is a hidden connector between the main board and the display board beneath it. Disconnect this by pulling the main board straight back from the display board.



Figure 13 Main board 5. There is a display pc board and a display module attached to the backer plate. If you need to remove the display board, disconnect the cables and remove the three standoffs and two nuts shown in Figure 14



6. To remove the display module, disconnect the cables and remove the four screws holding the module to the backer plate and pull it from the case. See Figure 15.



Figure 15 Display module

Replace any of the boards if needed and reassemble the unit by reversing the disassembly procedure.
Appendix 1: Display Samples



LB #17 GROSS #26 LT-BASIC TEXT #26 ENTIME STORE #26	WT-BASIC Text WT
LB LB #18 GROSS GROSS #27 MT-BASIC TEXT MT-BASIC TEXT #28 MINING REPORT REPORT OF REPORT	WT-BASIC Text WT WT-BASIC Text WT WT-BASIC Text WT WT-BASIC Text WT
INT-BASIC TEXT INT-BASIC TEXT #19 INT-BASIC TEXT INT-BASIC TEXT #28 INT-BASIC TEXT INT-BASIC TEXT : #28 : START STOP SCREET 03:55 = 101 = 118	WT-BASIC Text WT WT-BASIC Text WT IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII
2000 LB GROSS #20 MT-BASIC TEXT MT-BASIC TEXT 1 1 #29 MT-BASIC TEXT MT-BASIC TEXT 1 1 #29 MT-BASIC TEXT MT-BASIC TEXT 1 1 1 #29	2000 LB GROSS MT-BASIC Text MT MT-BASIC Text MT MRX MOX BEDIADERS
Image: Market M Market Market Mark	2000 LB GROSS WT-BASIC Text WT BASS BASS BASS
#22 #22 #31	20000 LB GROSS WT-BASIC Text WT BMS BOOK BEAGE DESS
#23 GROSS #32 #32	2000 LB GROSS WT-BASIC Text WT IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII
#24 GROSS #33 WT-BASIC Text WT	WT-BASIC Text WT
#25 #1 - 13 A S I C 1 C 2 C 1 A I #25 # 1 - 13 A S I C 1 C 2 C 1 C 2 C 1 A I A I A I A I A I A I A I A I A I A	

The following are multi-scale displays. If all the lines are not used for scales, they are available for Basic text. #34, 35, 40 and 41 are small basic text. #36, 37, 42 and 43 are large basic text.

	LB GROSS 1 LB ÞO4GROSS 2 LB ÞO4GROSS 3 LB ÞO4GROSS 4	#34 #39		LB GROSS 1 LB Þ04 GROSS 2
	LB GROSS 1 LB ÞO4GROSS 2 LB ÞO4GROSS 3 LB TOTAL	#35 #40 	0 LB 0 LB +0 T UT-BASIC T 23202000818	GROSS 1 4GROSS 2 EXT [5][[0][[5]]2]
30 MI-BASIC MI-BASIC	LB GROSS 1 LB ÞodGRoSS 2 Text MT Text MT	#36 #41 	LB LB LIT-BASIC 	GROSS TOTAL YEXT ISI DILENIK
ЗО ЭО MT-BASIC	LB GROSS 1 LB ÞO4GROSS 2 LB TOTAL Text MT	#37 #42	IC Ie>	GROSS 1 04GROSS 2 5 t 14 T 18 10 19 19
	LB GROSS 1 LB PO4 GROSS 2	#38 #43	l LB LB IC Te>	GROSS TOTAL : t MIT

Appendix 2: Tips on Using Harmonizer

To find the best settings for your filter needs, follow the steps listed below.

1. What to Do: Determine the amount of positive and negative force exerted by the vibration on the scale.

How to Do It: Set Threshld to 0.0, Constant to OFF, and Samples to Average to 1.0 A-Ds. Return to weigh mode and observe the weight swings. Record the difference between the highest and lowest displayed weight values. Add 30 to 50% to this value. This is a good starting value for the Threshld setting. Do not set your indicator to this value until told to in step 7.

2. Setting the Average to higher values increases the filtering effect.

What to Do: Set Threshld to 0.0, Constant to OFF and Samples to Average to 12 A-Ds. Check the stability of the scale.

How to Do It: Save changes and exit to normal weight mode. Observe the Center of Zero light. If it is on all the time your scale is stable within ¼ division. If the Center of Zero light blinks more filtering is required. Go to step 3.

- 3. Repeat step 2 but increase the Samples to Average by 12 A-Ds. Keep repeating steps 2 and 3 until the scale is stable or you've tried the entire range of Samples to Average (60 A-Ds). If the scale is still not stable go to step 4.
- 4. Setting the Constant to higher values increases the filtering effect.

What to Do: Set Threshld to 0.0, Constant to 1.0 and Samples to Average to 60 A-Ds. Check the stability of the scale.

How to Do It: Save changes and exit to normal weight mode. Observe the Center of Zero light. If it is on all the time your scale is stable within ¼ division. If the Center of Zero light blinks more filtering is required. Go to step 5.

- 5. Repeat step 4 but increase the Constant by 1.0. Keep repeating steps 4 and 5 until the scale is stable or you've tried the entire range of Constant (10). If the scale is still not stable, decrease your display update rate and start over at step 1 using the new, slower display rate.
- 6. After the Constant value is established you may wish to lower the Samples to Average value to improve display response time.
- 7. After a final value for Constant and Samples to Average has been set, enter the Threshld value established in step 1. If this value is too small your scale will act as if the filtering is off or not working. Increase the Threshld value until your scale stabilizes.

If the Threshld value is too high your scale will react slowly to weight changes.

When Harmonizer is properly adjusted the scale will be stable at zero and will rapidly display a stable test weight value.



ITEM	DESCRIPTION		ΟΤΥ
NO.	DESCRIPTION	VV-1 F/IN	QII
1	Power Cable assy (display bd. to displ. Module)	47275-0017	1
2	Ground wire assy (enclosure to rear cover)	48712-016	1
3	Power Cable assy (power supply Bd. To main bd.)	52944-0018	1
4	Interface Cable assy (power supply Bd. To main bd.)	52945-0017	1
5		52946-0016	1
6	Keypad Overlay	52937-0017	1
/	Main pc board assy	50692-0016	1
8	Power Supply board w/ Serial I/O	50799-0018	1
9	Display pc Board assy	51631-0018	1
10	WPI-135 Enclosure	52938-0024	1
11	Power Cord Kit (USA)	49180-0116	1
12	Rear Cover Gasket	52939-0015	1
13	Bezel (front) Gasket	52940-0012	1
14	Stand Bracket	52941-0011	1
15	Rear Cover	52942-0010	1
16	Keypad Backer Plate (vfd)	52943-0019	1
17	Nylon Plug (threaded)	1019-11926	1
18	Screw, # 8 x 7/16" L	14473-0363	4
19	Screw/Washer assy, #6 x ¼" L	26380-0021	18
20	Flat Washer (neoprene)	1030-12680	1
21	Lock Washer, #8	14474-0040	4
22	Tooth Washer, 3/8"	15698-0179	2
23	Flat Washer, 3/8"	16163-0066	2
24	Washer (neoprene)	26357-0038	1
25	Washer (neoprene)	26357-0046	4
26	Washer (neoprene)	26357-0053	4
27	Standoff, #6 x 1/2" L (f/f)	14510-0756	4
28	Standoff, #6 x 1 1/8" L (f/f)	14510-0814	3
29	Standoff, #6 x 1 1/2" L (f/f)	14510-0848	3
30	Standoff, #4 x 9/16" L (m/f)	15437-0191	4
31	Standoff, #6 x 5/8" L (f/f)	14510-0772	4
32	Standoff, #6 x 5/16" L (m/f)	15437-5026	5
33	Nut, #6	16064-0033	2
34	Kep Nut, #4	1025-00107	4
35	Kep Nut, #8	1025-00125	25
36	Cap Nut, #8	15771-0039	4
37	Cap Nut, 3/8"	15771-0070	2
38	Cap Nut, #10	15786-0016	12
39	Locking Nut 1/2" (notched)	17777-0021	4
40	Cap Nut #10 (modified)	26513-0013	2
41	Strain Relief (w/nut)	15257-0024	4
42	Strain Relief (w/nut)	15257-0040	1
43	Strain Relief (used w/ lock nut, item no. 39)	15257-0057	4
44	Rubber Bumper foot	15349-0024	4
45	Neoprene washer	19563-0025	2
46	Neoprene Cord (plug) for Strain relief (1/4" dia)	27429-0014	8" long
47	Neoprene Tubing, ¼"ID x 1/16" wall (used w/ item 46)	45089-0017	4" long
48	Display Module (VFD)	46557-0026	1
49	Foam Tape, 2-side sticky, ½"w x 1"L (used w/ item 50)	1045-05982	1
50	Dessicant bag	1088-12126	1
51	Corrosion Vapor Emitter	48680-0014	1
52	Standard WPI-135 E-Prom (U17)	52957-0012	1
53	Standard WPI-135 E-Prom (U18)	52957-0020	1







WPI-135 INDICATOR

KEYPAD AND SCHEMATIC P/N 52937-0017







WPI-135 INDICATOR MAIN PC BOARD P/N 50692-0016

WPI-135 POWER SUPPLY / MAIN PC BOARD TERMINAL *PIN-OUT* CHARTS

POWER SUPPLY BD						
TB25 - pin no.	PC-KEYBOARD	NOTES				
1	CLOCK	(do not ground)				
2	DATA	(do not ground)				
3	NOT USED					
4	GROUND					
5	(+) 5.0 VDC	(do not ground)				

POWER SUPPLY BD						
TB30-pin no.	NOTES					
1	SERIAL CLOCK	(do not ground)				
2	SERIAL DATA	(do not ground)				
3	INTERRUPT	(do not ground)				
4	GROUND					
5	(+) 5.0 VDC	(do not ground)				
6	RESET	(do not ground)				
7	(SHIELD) GROUND					

POWER SUPPLY BD							
TB26-A pin no.	COMM #1	SIGNAL	NOTES				
1	TRANSMIT	RS-232	data out (do not ground)				
2	RECEIVE	RS-232	data in (do not ground)				
3	RTS	RS-232	hardware handshaking out (do not ground)				
4	CTS	RS-232	Hardware handshaking in (do not ground)				
5	GROUND	RS-232					
6	(+) 5.0 VDC		(do not ground)				
TB26-B pin no.							
1	(+) 7.5 VDC	QDT	(do not ground)				
2	GROUND	QDT, RS422/485					
3	RECEIVE-A	QDT, RS422/485	data in (do not ground)				
4	RECEIVE-B	QDT, RS422/485	data in (do not ground)				
5	TRANSMIT-A	QDT, RS422/485	data out (do not ground)				
6	TRANSMIT-B	QDT, RS422/485	data out (do not ground)				
7	GROUND	QDT, RS422/485					
8	(+) 15 VDC		(do not ground)				

POWER SUPPLY BD							
TB27 pin no.	COMM #2	COMM #2 SIGNAL NOTES					
1	TRANSMIT	RS-232	data out (do not ground)				
2	RECEIVE	RS-232	data in (do not ground)				
3	RTS	RS-232	hardware handshaking out (do not ground)				
4	CTS	RS-232	Hardware handshaking in (do not ground)				
5	GROUND	RS-232					
6	(+) 5.0 VDC		(do not ground)				
7	TRANSMIT(+)	CURRENT LOOP	data out (do not ground)				
8	TRANSMIT(-)	CURRENT LOOP	data out (do not ground)				
9	RECEIVE(+)	data in (do not ground)					
10	RECEIVE(-)	CURRENT LOOP	data in (do not ground)				

TERMINAL PIN-OUT CHARTS (CONTINUED)

POWER SUPPLY BD						
TB28-A pin no.	COMM #3	SIGNAL	NOTES			
1	TRANSMIT	RS-232	DATA OUT (do not ground)			
2	RECEIVE	RS-232	DATA IN (do not ground)			
3	RTS	RS-232	hardware handshaking out (do not ground)			
4	CTS	RS-232	Hardware handshaking in (do not ground)			
5	GROUND	RS-232, *TTL, KB				
6	(+) 5.0 VDC	*TTL, KB	(do not ground)			
7	XTL	*TTL	DATA OUT (do not ground)			
8	RTL	*TTL, KB	DATA IN (do not ground)			
TB28-B pin no.						
1	(+) 7.5 VDC	QDT	(do not ground)			
2	GROUND	QDT, RS422/485				
3	RECEIVE-A	QDT, RS422/485	DATA IN (do not ground)			
4	RECEIVE-B	QDT, RS422/485	DATA IN (do not ground)			
5	TRANSMIT-A	QDT, RS422/485	DATA OUT (do not ground)			
6	TRANSMIT-B	QDT, RS422/485	DATA OUT (do not ground)			
7	GROUND	QDT, RS422/485				
8	(+) 15 VDC		(do not ground)			

*TTL connections for TUFF KEY keyboard (KB) or other TTL serial connections.(ie radio link) Jumper P74-1 to P74-2 for RS-232 ------- Jumper P74-2 to P74-3 for TTL (comm #3 only)

POWER SUPPLY BD							
TB29-A pin no.	COMM #4	SIGNAL	NOTES				
1	TRANSMIT	RS-232	DATA OUT (do not ground)				
2	RECEIVE	RS-232	DATA IN (do not ground)				
3	RTS	RS-232	hardware handshaking out (do not ground)				
4	СТЅ	RS-232	Hardware handshaking in (do not ground)				
5	GROUND	RS-232					
6	(+) 5.0 VDC		(do not ground)				
TB29-B pin no.							
1	(+) 7.5 VDC	QDT	(do not ground)				
2	GROUND	QDT, RS422/485					
3	RECEIVE-A	QDT, RS422/485	DATA IN (do not ground)				
4	RECEIVE-B	QDT, RS422/485	DATA IN (do not ground)				
5	TRANSMIT-A	QDT, RS422/485	DATA OUT (do not ground)				
6	TRANSMIT-B	QDT, RS422/485	DATA OUT (do not ground)				
7	GROUND	QDT, RS422/485					
8	(+) 15 VDC		(do not ground)				

POWER SUPPLY BD						
TB31-pin no.	SETPOINT INTERACE	NOTES				
1	+12VDC	(do not ground)				
2	+ SETPOINT 1					
3	- SETPOINT 1					
4	+ SETPOINT 2					
5	- SETPOINT 2					
6	+ SETPOINT 3					
7	- SETPOINT 3					
8	+ SETPOINT 4					
9	- SETPOINT 4					
10	GROUND					

MAIN BD					
TB8-pin no.	WEIGHT SENS INTERFACE	NOTES			
1	- EXCITATION	(do not ground)			
2	+ EXCITATION	(do not ground)			
3	- SENSE	(do not ground)			
4	+ SENSE	(do not ground)			
5	- SIGNAL	(do not ground)			
6	+ SIGNAL	(do not ground)			

WPI-135 INDICATOR I/O CABLE IDENTIFICATION PIN-OUTS







-135	SIGNAL	SERIAL CLOCK	SERIAL DATA	INTERRUPT	<pre><ldgic> GRDUND</ldgic></pre>	+5 VOLTS	RESET	<pre>< SHIELD> GND</pre>	INIGET	
BDARD TD WPI	DESTINATION	TB-35-OR-TB37 (1)	TB-35- <u>OR</u> -TB37 (2)	TB-35- <u>OR</u> -TB37 (3)	TB-35- <u>OR</u> -TB37 (4)	TB-35- <u>OR</u> -TB37 (5)	TB-35- <u>OR</u> -TB37 (6)	SISSWHD		
<pre>CEXTERNAL I / D CABLE ASSY P/N</pre>	DRIGIN TERMINATION	TB30 (1)P/S BD	TB30 (2)P/S BD	TB30 (3)P/S BD	TB30 < 4>P/S BD	TB30 <5>P/S BD	TB30 (6)P/S BD	GND STUD		
SSCU Z	V-T VIRE COLOR	DRANGE	YELLOV	GREEN	BLACK	RED	BRDVN	SHIELD		

(This page intentionally blank)

WPI-135 INDICATOR MULTI SCALE BOARD (OPTIONAL) P/N 50795: -0012 (2(6) SCALE INTERFACE), -0020 (3(7) SCALE INTERFACE), -0038 (4(8) SCALE INRERFACE), -0046 (5 SCALE INTERFACE)



TERMINAL PIN-OUT CHARTS (CONTINUED)



WPI-135 (2 through 5 SCALES) J-BOX ASSEMBLY P/N 47404: -0011 (2-SCALES), -0029 (3-SCALES), -0037 (4-SCALES), -0045 (5-SCALES) .



		WIRE IDENTIFICATION					
			J-BOX 4740)4			
	W-T	ORIGIN	DESTINATION	SIGNAL			
	COLOR	MAIN PC. BOARD P/N 50692-0016					
Ţ	BLACK	TB8-1	J1-D	-EXC-1			
1.1	GREEN	TB8-2	J1-B	+EXC-1			
	BLUE	ТВ8-З	J1-E	-SENSE-1			
\triangleleft	YELLOW	TB8-4	J1-F	+SENSE-1			
S	RED	TB8-5	J1-A	-SIGNAL-1			
	WHITE	TB8-6	J1-C	+SIGNAL-1			
	BLACK	GND-1	J1-G	SHIELD-1			
		MULTI-SCALE BD P/N 50795, SCALE 2 THRU 5					
	WHT/BRN	TB40-1	JS-D	-EXC-5			
01	BROWN	TB40-2	J2-B	+EXC-2			
	WHT/BLK	TB40-3	J2-E	-SENSE-2			
	DRANGE	TB40-4	J2-F	+SENSE-2			
\exists	GRAY	TB40-5	J2-A	-SIGNAL-2			
SO	VIOLET	TB40-6	J2-C	+SIGNAL-2			
	BLACK	GND-1	J2-G	SHIELD-2			
	SHIELD		GND-1	DRAIN WIRE			

-SENSE-4 +SENSE-4 -SIGNAL-4 +SIGNAL-4 SHIELD-4

_										
	WIRE	E IDENTIFICA	TION					WIRE	IDENTIFICAT	ION
	J	<u>-BOX 4740</u>	4					. -	-BUX 4740	4
[JRIGIN	DESTINATION	SIGNAL	-)./_T		RIGIN	DESTINATION	SIGNAL
JLT: /N : CALI	I-SCALE BD 50795, E 2 THRU 5						MULTI- P/N 50 SCALE	SCALE BD 795, 2 THRU 5		
	J2-D	J3-D	-EXC-3			WHT/BRN		J3-D	J4-D	-EXC-4
	J2-B	J3-B	+EXC-3		4	BROWN		ЈЗ-В	J4-B	+EXC-4
	TB41-3	J3-E	-SENSE-3		ш	WHT/BLK/RED	Т	B42-3	J4-E	-SENSE-4
	TB41-4	J3-F	+SENSE-3			WHT/VID	Т	B42-4	J4-F	+SENSE-4
	TB41-5	J3-A	-SIGNAL-3		Ŭ	WHT/BLK/BRN	Т	B42-5	J4-A	-SIGNAL-
	TB41-6	J3-C	+SIGNAL-3		\sim	WHT/GRA	Т	B42-6	J4-C	+SIGNAL-
	J2-G	J3-G	SHIELD-3			BLACK		J3-G	J4-G	SHIELD-4

		-				
			WIF	RΕ	IDENTIFICAT	ION
				J-	-BOX 4740	4
) (т	DR	IGIN		DESTINATION	SIGNAL
		MULTI-SO	CALE BD			
		SCALE 2	THRU 5			
\cap	WHT/BRN		J4-D		J5-D	-EXC-5
	BROWN	_	J4-B		J5-B	+EXC-5
ЦЦ	WHT/BLK/BLU	ТB	43-3		J5-E	-SENSE-5
₹	WHT/BLK/ORN	ТB	43-4		J5-F	+SENSE-5
\bigcirc	WHT/BLK/GRN	ТΒ	43-5		J5-A	-SIGNAL-5
• /	WHT/BLK/YEL	TB	43-6		J5-C	+SIGNAL-5
	BLACK	-	J4-G		J5-G	SHIELD-5

\ <i>и</i> т	URIGIN	DESTINATION	SIGNAL
	MULTI-SCALE BD P/N 50795, SCALE 2 THRU 5		
WHT/BRN	J2-D	J3-D	-EXC-3
BROWN	JS-B	J3-B	+EXC-3
WHT/BLU	TB41-3	J3-E	-SENSE-3
WHT/RED	TB41-4	J3-F	+SENSE-3
WHT/GRN	TB41-5	J3-A	-SIGNAL-3
WHT/YEL	TB41-6	J3-C	+SIGNAL-3
BLACK	J2-G	J3-G	SHIELD-3

 \odot

SCALE

WPI-135 (6 through 8 SCALES) J-BOX ASSEMBLY P/N 47405: -0010 (6 SCALES), -0028 (7 SCALES), -0036 (8 SCALES)

		WIRE	IDENTIFICAT	NDI.
		-	-BOX 4740	15
	V-T	DRIGIN	DESTINATION	SIGNAL
	COLOR	MULTI-SCALE BD P/N 50795, SCALE 6 THRU 8		
	WHT/BRN/YEL	TB40-1	J6-D	-EXC-6
9	WHT/ORN	TB40-2	J6-B	+EXC-6
)	WHT/BRN/DRN	TB40-3	J6-E	-SENSE-6
3	WHT/BLK/VID	TB40-4	J6-F	+SENSE-6
1∀	WHT/BRN/RED	TB40-5	J6-A	-SIGNAL-6
20	WHT/BLK/GRA	TB40-6	J6-C	+SIGNAL-6
S	BLACK	GND-1	J6-G	SHIELD-6

		WIRE	E IDENTIFICAT	NDI
			J-BOX 4740	S
	1./_T	DRIGIN	DESTINATION	SIGNAL
		MULTI-SCALE BD		
		SCALE 6THRU 8		
L	WHT/BRN	J6-D	U7-D	-EXC-7
	BRDWN	J6-B	J7-B	+EXC-7
3-	WHT/BRN/GRA	TB41-3	J7-E	-SENSE-7
14:	WHT/BRN/GRN	TB41-4	J7-F	+SENSE-7
SC	WHT/BRN/VID	TB41-5	J7-A	-SIGNAL-7
>	WHT/BRN/BLU	TB41-6	J7-C	+SIGNAL-7
	BLACK	J6-G	J5-G	SHIELD-7

		IM	RE IDENTIFICA	
		NIULOL		STGNAL
	V-T COLOR	MAIN PC. BLARD		
	RI ACK	TRR-1	ц-1г.	-FXC-1
I		C Off	5 =	
Ξ-	BILF	TB8-3	-11-E	-SENSE-1
١A	YELLOW	TB8-4	J1-F	+SENSE-1
ZC	RFD	TB8-5	J1-A	-SIGNAL-1
>	WHITE	TB8-6	J1-C	+SIGNAL-1
	BLACK	GND-1	-11-G	SHIELD-1
		MULTI-SCALE BD P/N 50795, SCALE 2 THRU 5		
	WHT/BRN	TB40-1	J2-D	-EXC-2
c	BRDWN	TB40-2	J2-B	+EXC-2
2	WHT/BLK	TB40-3	J2-E	-SENSE-2
Ξ-	DRANGE	TB40-4	J2-F	+SENSE-2
١À	GRAY	TB40-5	J2-A	-SIGNAL-2
30	VIDLET	TB40-6	J2-C	+SIGNAL-2
2	BLACK	GND-1	J2-G	SHIELD-2
		MULTI-SCALE BD P/N 50795, SCALE 2 THRU 5		
	WHT/BRN	Ū−2ſ	13-D	-EXC-3
3	BRDWN	J2-B	J3-B	+EXC-3
-	WHT/BLU	TB41-3	J3-E	-SENSE-3
37	WHT/RED	TB41-4	J3-F	+SENSE-3
₩.	WHT/GRN	TB41-5	J3-A	-SIGNAL-3
SC	WHT/YEL	TB41-6	J-EL	+SIGNAL-3
	BLACK	J2-6	J3-6	SHIELD-3
		NII TI-SCALE BD	- F	
		P/N 50795, SCALE 2 THRU 5		
	WHT/BRN	_13−D		-EXC-4
4	BRDWN	-В-	J4-B	+EXC-4
3	WHT/BLK/RED	TB42-3	J4-E	-SENSE-4
٦٢	WHT/VID	TB42-4	J4-F	+SENSE-4
70	WHT/BLK/BRN	TB42-5	J4-A	-SIGNAL-4
S	WHT/GRA	TB42-6	_4−C	+SIGNAL-4
	BLACK	J3-G	J4-G	SHIELD-4
		MULTI-SCALE BD P/N 50795, SCALE 2 THRU 5		
\subseteq	WHT/BRN	J4−D	J5-D	-EXC-5
, .	BRDWN	J4-B	J5-B	+EXC-5
Ξ-	WHT/BLK/BLU	TB43-3	J5-E	-SENSE-5
1A:	WHT/BLK/DRN	TB43-4	J5-F	+SENSE-5
SC	WHT/BLK/GRN	TB43-5	J5-A	-SIGNAL-5
>	WHT/BLK/YEL	TB43-6	JS-C	+SIGNAL-5
	BLACK	J4-G	J5-G	SHIELD-5
	SHIELD		GND-1	DRAIN WIRE



(This page left intentionally blank)

WPI-135 INDICATOR SOLID STATE CONTROL UNIT (SSCU-8) (OPTIONAL) PARTS AND ASSEMBLY



ITEM NO.	DESCRIPTION	W-T P/N	QTY
1	Strain Relief	22380-0053	1
2	Strain Relief	15257-0024	2
3	Cable , (SSCU-To-WPI-135)	47388-0011	1
4	Enclosure (Steel, Painted)	47665-0015	1
5	Enclosure (Stainless)	47665-0023	1
6	Remote Exp. Control I/O Pc Bd	47183-0018	1
7	Lock Nut (Self Sealing)	22381-0011	1

WPI-135 INDICATOR REMOTE EXPANDED CONTROL: I/O BOARD (OPTIONAL) P/N 47183-0018



Table 1: Setpoints 33 thru 40

SW1 (1)ON		(2)ON	(3)OFF
SETF	POINT #	TB #	PIN #
33	(+)	46	1
33	(-)	46	2
34	(+)	46	3
34	(-)	46	4
35	(+)	46	5
35	(-)	46	6
36	(+)	46	7
36	(-)	46	8
37	37 (+)		1
37 (-)		47	2
38 (+)		47	3
38 (-)		47	4
39 (+)		47	5
39	(-)	47	6
40	(+)	47	7
40	(-)	47	8

Table 3: Setpoints 49 thru 56

SW1	(1)ON	(2)OFF	(3)OFF
SETF	POINT #	TB #	PIN #
49 49 50 50 51 51 52 52 53 53 54	(+) (-) (+) (-) (+) (+) (-) (+) (+) (-) (+) (+) (-) (-) (+) (-) (-) (+) (-) (-) (-) (+) (-)	46 46 46 46 46 46 46 46 47 47 47	1 2 3 4 5 6 7 8 1 2 3
55 55	(-) (+) (-)	47 47 47	4 5 6
56 56	(+) (-)	47 47	7 8

Table 2: Setpoints 41 thru 48

SW1	(1)OFF	(2)ON	(3)OFF
SETF	POINT #	TB #	PIN #
41	(+)	46	1
41	(-)	46	2
42	(+)	46	3
42	(-)	46	4
43	(+)	46	5
43	(-)	46	6
44 (+)		46	7
44 (-)		46	8
45 (+)		47	1
45 (-)		47	2
46 (+)		47	3
46 (-)		47	4
47 (+)		47	5
47	(-)	47	6
48	(+)	47	7
48	(-)	47	8

Table 4: Setpoints 57 thru 64

SW1	(1)OFF	(2)OFF	(3)OFF	
SETP0INT #		TB #	PIN #	
57	(+)	46	1	
57	(-)	46	2	
58	(+)	46	3	
58	(-)	46	4	
59	(+)	46	5	
59	(-)	46	6	
60	60 (+)		7	
60	60 (-)		8	
61	61 (+)		1	
61	(-)	47	2	
62	62 (+)		3	
62 (-)		47	4	
63 (+)		47	5	
63 (-)		47	6	
64 (+)		47	7	
64 (-)		47	8	



(This page left intentionally blank)

Setpoint Operation

If setpoints 1 thru 4 are programmed in SimPoser as inputs, the physical location for these will always be on the power supply TB31. The setpoint location for setpoints 1 thru 4 on the option card(s) will then be invalid, and do not function.

If setpoints 1 thru 4 are programmed in SimPoser for outputs, the TB31 location on the power supply board will act in parallel to the physical location of setpoints 1 thru 4 (set by switches on remote expanded control PCBs) on the option card(s).

When only using OPTO modules (4 maximum) on the power supply board without any setpoint option cards, they can be used as either inputs or outputs. We recommend low voltage OPTO modules on the power supply board.



Opto-22 Output Module Fuse Table

W-T P/N 46618	Rated Current (amp)	Wickmann TR5-F P/N	W-T P/N 46618	Rated Current (amp)	Wickmann TR5-F P/N
-0015	.050	19373K-50A	-0122	.630	19373K-630A
-0023	.063	19373K-63A	-0130	.800	19373K-800A
-0031	.080	19373K-80A	-0148	1.0	19373K-1A
-0049	.100	19373K-100A	-0155	1.25	19373K-1,25A
-0056	.125	19373K-125A	-0163	1.6	19373K-1,6A
-0064	.160	19373K-160A	-0171	2.0	19373K-2A
-0072	.200	19373K-200A	-0189	2.5	19373K-2,5A
-0080	.250	19373K-250A	-0197	3.15	19373K-3,15A
-0098	.315	19373K-315A	-0205	4.0	19373K-4A
-0106	.400	19373K-400A	-0213	5.0	19373K-5A
-0114	.500	19373K-500A	-0221	6.3	19373K-6,3A

OPTO-22 CONTROL INTERFACE DEVICES Specifications

The OPTO-22 Generation 4 I/O modules can be used on the power supply board (max. 4) or on the optional Remote Expanded Control Interface Boards (max. 64).

P/N 48552	OPTO-22 P/N	I/O Type AC or DC Input or Output	Color	External circuit voltage range	External circuit Max. Current	Turn on time msec.	Turn off time msec.	I/O operating temperature range
-0019	G4IDC5D	DC only (input)	White	2.5-28 vdc only	30mA	1.0	1.5	-30°Cto 70°C
-0027	G4IDC5B	DC only (input)	White	4.0-16 vdc only	45mA	0.05	0.1	-30°Cto 70°C
-0035	G4IDC5	AC/DC (input)	White	12-32	25mA	5	5	-30°Cto 70°C
-0043	G4IDC5G	AC/DC (input)	White	35-60	25mA	10	15	-30°Cto 70°C
-0050	G4IAC5	AC/DC (input)	Yellow	90-140	11mA	11	20	-30°Cto 70°C
-0068	G4IAC5A	AC/DC(input)	Yellow	180-280	6.5mA	2	20	-30°Cto 70°C
-0076	G4ODC5	DC ouput N.O. Normally Open	Red	5-60 vdc only	3A@45°C 2A@70°C	100	750	-30°Cto 70°C
-0084	G4ODC5A	DC (output) N.O. Normally Open	Red	5-200 vdc only	1A@45°C 0.55A@70°C	100	750	-30°Cto 70°C
-0092	G4OAC5	AC (output) N.O. Normally Open	Black	12-140 AC only	3A@45°C 2A@70°C			-30°Cto 70°C
-0100	G4OAC5A	AC (output) N.O. Normally Open	Black	24-280 AC only	3A@45°C 2A@70°C			-30°Cto 70°C
-0118	G4OAC5A5	AC (output) N.C. Normally Closed	Black	24-280 AC only	3A@45°C 2A@70°C			-30°Cto 70°C
-0126	G4ODC5R	AC/DC (output) N.O. Dry contact Normally Open	Red	130VAC/100VDC	1.5A	500	500	0°C to 70°C
-0134	G4ODC5R5	AC/DC (output) N.C. Dry contact Normally Closed	Red	130VAC/100VDC	1.5A	500	500	0°C to 70°C

Each I/O module has an LED that lights indicating an active state. The output modules also have a replaceable fuse for circuit protection. These modules are LOW CURRENT devices. Refer to OPTO-22 data specifications for additional information.

Below is a diagrm of the different I/O control modules:

A	В	С	D	Е
46571-0010	46571-0036, 46571-0044	46571-0077	46571-0093	46571-0127
46571-0028	46571-0051, 46571-0069	46571-0085	46571-0101	46571-0135
			46571-0119	

С









NEGATIVE TRUE LOGIC







SSCU-8 Caution!

The Solid State Control Unit 8 (SSCU-8) option boards require that the total cable length from the indicator to the last SSCU-8 box/card be two meters (approx. six feet) maximum. Noise problems and intermittent communications with the SSCU-8 card will occur if this guideline is not followed.



(This page left intentionally blank)

(This page left intentionally blank)

WPI-135 INDICATOR-TO-PC KEYBOARD **CABLE CONNECTIONS**

PC KEYBOARD-TO WPI-135 CONNECTION

- 1. Remove the back panel from the WPI-135 enclosure.
- 2. Insert the cut end of cable through water-tight connector at bottom of enclosure and pull cable into enclosure.
- 3. Strip covering back from cable to reveal five seperate wires.
- \ast 4. Connect wires at PC keyboard port (TB25) as shown in pin-out chart (see below).

Ж



WI-135 INDICATOR REMOTE TTL KEYBOARD OPTION



KEYBOARD SPECIFICATIONS ENVIRONMENTAL: 32°f to 130°f (0°c to 55°c). COMMUNICATION OUTPUT: 1 start bit , 8 data bits , 1 stop bit, , selectable baud rates, TTL Asynchronous Serial. WEIGHT: 2 lb/.9 kg nominal .

BAUD RATE	STANDKEY SWITCH SETTINGS							
	1	1 2 3 4						
300	ON	OFF	ON	OFF				
1200	OFF	OFF	ON	OFF				
9600	ON OFF OFF OFF							

BAUD RATE	TUFKEY SWITCH SETTINGS			
	1	2		
300	ON	ON		
1200	ON	OFF		
9600	OFF	ON		

TTL KEYBOARD-TO WPI-135 CONNECTION

- 1. Remove the back panel from the WPI-135 enclosure.
- 2. Insert the cut end of cable through water-tight connector at bottom of enclosure and pull cable into enclosure.
- 3. Strip covering back from cable to reveal five seperate wires.
- 4. Install jumper on pins 2-3 of P74.
 - NDTE: A port set in keyboard mode can still output to a printer or remote display. However, a designated keyboard port cannot accept input other than the keyboard.
- * 5. Connect wires at port 3 (TB28A) as shown in pin-out chart (see below).
 - Wire color not shown due to ongoing color changes from our vendor. Use pinout chart for pin I.D.







(This page left intentionally blank)

WPI-135 INDICATOR NETWORK INTERFACE BOARD (OPTIONAL) P/N 53021-0012



Note:

For more information about configuring and using the Network Interface Option boards, refer to the WPI-135 Network Installation Guide, P/N 29762-0015.

ModBus /TCP Ethernet NETWORK INTERFACE MODULE PC BOARD (OPTIONAL)

 ModBus /TCP Ether	net								
Module		ADDRESS SETTING	MODBUS/TCP ETHERNET						
P/N 52611-0036			TB77		RJ 45		DB-9 FEMALE		
			PIN ND.	SIGNAL	PIN ND.	SIGNAL	PIN ND.	SIGNAL	
			1	GND					
			2	NC					
			3	NC					
			4	NC					
			5	TD+	1	TD+	8	TD+	
			6	TD-	2	TD-	3	TD-	
	10		7	RD+	3	RD+	7	RD+	
	<u> </u> 		8	NC					
			9	RD-	6	RD-	2	RD-	
			10	NC					
34 6 **** *** ***************** **********	1 🔳								

ModBus+ NETWORK INTERFACE MODULE PC BOARD (OPTIONAL)





* +5V AND GND ARE USED FOR BUS TERMINATION AND DPTICAL TRANCEIVERS. RTS IS USED BY SOME EQUIPMENT TO DETERMINE THE DIRECTION OF THE TRANSMISSION.





DEVICE NET						
٢F	(PLUGGABLE CONNECTOR)					
PIN ND.	SIGNAL					
1	V- (BUS POWER GND)					
2	CAN_LOW					
3	3 SHIELD					
4	CAN_HI					
5 V+ (+24VDC)*						

* AN EXTENDED POWER SUPPLY WILL BE USED TO SUPPLY V+ POWER. TYPICALLY THIS SUPPLY WILL BE PREVIOUSLY INSTALLED.
InterBus S NETWORK INTERFACE MODULE PC BOARD (OPTIONAL)



INTERBUS S				
			DB-9 MALE	
PIN ND.	SIGNAL	PIN ND.	SIGNAL	
1	PE		HOUSING	
2	GND			
3	NC			
4	RBST	9	RBST	
5	NC			
6	GND	3, 5	GND	
7	/DI2	7	/DIS	
8	/D02	6	/002	
9	DIS	2	DIS	
10	DOS	1	DO2	

INTERBUS S				
TB80 (BUS IN)		DB-9 FEMALE		
PIN ND.	SIGNAL	PIN ND.	SIGNAL	
1	PE		HOUSING	
2	DD1	1	DD1	
3	DI1	2	DI1	
4	/D01	6	/D01	
5	/DI1	7	/DI1	
6	GND	3	GND	
7	NC			
8	NC			
9	NC			
10	NC			





(This page left intentionally blank)

Weigh-Tronix

1000 Armstrong Dr. Fairmont, MN 56031 USA Telephone: 507-238-4461 Facsimile: 507-238-4195 e-mail: industrial@weigh-tronix.com www.wtxweb.com

Weigh-Tronix Canada, ULC

217 Brunswick Blvd. Pointe Claire, QC H9R 4R7 Canada Telephone: 514-695-0380 Facsimile: 514-695-6820



Weigh Bar[®] is a registered trademark of Weigh-Tronix Inc. 09/07/00 135SERV.P65 PN 29750-0019e3 Printed in USA