

# **WEIGH-TRONIX**



## **PC-802 Counting Scale Service Manual**



# Table of Contents

|  |    |
|--|----|
| Table of Contents .....                                      | 3  |
| Specifications .....   | 4  |
| What's in This Manual? .....                                 | 5  |
| Accessing Menus and Modes .....                              | 5  |
| Scale Menu .....   | 6  |
| CALib (Calibration) .....                                    | 7  |
| ConFig (Configuration) .....                                 | 7  |
| rEStArt (Restart) .....                                      | 8  |
| SEAL (Seal) .....  | 8  |
| done (Done) .....  | 8  |
| Diagnostic Menu .....  | 9  |
| ConFig (Configuration) Menu .....                            | 11 |
| Error Messages .....   | 14 |
| Serial Communications .....                                  | 14 |
| Preset Print Formats .....                                   | 15 |
| Computer Protocol .....                                      | 16 |
| Disassembly Instructions .....                               | 18 |
| 10 lb / 5 kg cap. Parts and Assembly .....                   | 19 |
| Draft Shield Parts and Assembly .....                        | 20 |
| 50 lb / 25 kg and 100 lb / 50 kg cap Parts and Assy. ....    | 21 |
| System Wiring Block Diagram .....                            | 22 |
| Main P.C. Board / Display Bd. / Keypad Overlay .....         | 23 |
| Battery Installation .....                                   | 24 |
| Dimensional Outline for 12" x 14" Base .....                 | 25 |
| Battery Charger Parts List .....                             | 26 |
| Wall-Mount Bracket and Remote Tower Parts and Assembly ..... | 27 |

# Specifications

## Capacities and Resolutions:

| Capacity | Normal Resolution | Expanded Resolution |
|----------|-------------------|---------------------|
| 10 lb    | 0.001 lb          | 0.00005 lb          |
| 50 lb    | 0.005 lb          | 0.0002 lb           |
| 100 lb   | 0.01 lb           | 0.0005 lb           |
| 5 kg     | 0.0005 kg / 0.5 g | 0.00002 kg / 0.02 g |
| 25 kg    | 0.002 kg / 2 g    | 0.0001 kg / 0.1 g   |
| 50 kg    | 0.005 kg / 5 g    | 0.0002 kg / 0.2 g   |

## Overcapacity Limits:

Overcapacity indication (upper dashes) will occur at 9 divisions over rated capacity or 102% of full scale capacity.

## Internal Resolution:

1 part in 2,000,000 (QDT™)

## Filters:

Standard digital software filtering

## Display:

Seven digits of seven-segment, high-contrast black LCD, .5" (1.3 cm) high with blue electro-luminescent backlight

## Power:

15VDC at 300mA from a 117VAC 60Hz inline transformer  
Optional 12VDC lead acid battery

## Output:

Bidirectional RS-232 output with selectable baud rate

## Operating environment:

14° to 104° F (-10° to 40° C)  
10 to 90% relative humidity, non-condensing

# What's In This Manual?

This manual contains the information you need to configure, calibrate and service the PC-802B counting scale. The manual is divided into the following sections:

- Scale Menu
- Diagnostic Menu
- Configuration Menu
- Communication
- Technical Drawings and Assemblies

## Accessing Menus and Modes

*Calibration, diagnostics, and configuration can also be accessed by pressing and holding the **PRINT** key for five seconds.*


*Switches not listed in Table are irrelevant to the mode. It does not matter what position they are in for that particular mode.*

*The scale defaults to 10,000d displayed resolution after calibration. Reset to your desired resolution.*

The different modes of operation are accessed by placing the switches of SW1 in the positions described in Table 1. Switch SW1 is located under the scale shroud on the right side of the scale. See Figure 1.

| Switch SW1 |     |                                   |
|------------|-----|-----------------------------------|
| ON         | OFF | Mode of Operation                 |
| 1, 2       |     | Normal Operation Mode             |
| 2          | 1   | Menu Mode (Scale, Diag., Config.) |
|            | 3   | External Display Mode             |

**Table 1**  
Switch settings



**Figure 1**  
Switch SW1 location

# Scale Menu

*Because a 7 segment display cannot show all of the alphabet, the words on the display are the closest representations of the words they stand for that can be accomplished. The menus show the words as all caps and clarified in some instances. The explanations in the text will use the letters and case you will see on the display.*

The first menu you see when entering the menu mode is the Scale menu. Follow these steps to explore the Scale menu.


1. Press and hold the **PRINT** key for five seconds or set SW1-2 to the ON position and SW1-1 to the OFF position. . .
2. Follow the legend at the top of the menu to navigate through the menu. Each item is explained on the next pages.

The display shows **SCALE**. The entire Scale menu is shown in Figure 2 below.

To move →, press the **ZERO** key.

To move ↓, and to choose an option, press the **SAMPLE** key.

Press **COUNT/WEIGHT** key to go up one menu level.



**Figure 2**  
Scale Menu

## CALib (Calibration)

| Table 2<br>Alternate Span Weights |       |       |
|-----------------------------------|-------|-------|
| Scale Capacity                    | Alt 1 | Alt 2 |
| 5                                 | N/A   | N/A   |
| 10                                | N/A   | N/A   |
| 25                                | 10    | 25    |
| 50                                | 10    | 25    |
| 75                                | 10    | 50    |
| 100                               | 10    | 50    |
| 125                               | 10    | 50    |
| 150                               | 10    | 50    |
| 200                               | 50    | 100   |
| 250                               | 50    | 100   |
| 300                               | 50    | 100   |
| 500                               | 50    | 200   |

Press any key except the **SAMPLE** key to abort calibration. If you abort the procedure, **Abort** is displayed briefly then **CALib**.

During calibration the display may show **bUSY** if scale motion is detected. Wait to see if the display clears. If not, turn off the scale and turn back on. Repeat the calibration procedure

**CALib** is the calibration function for the scale. Follow these steps to calibrate your scale.

- With **CALib** displayed, press the **SAMPLE** key. . . **PoUnd** or **1000 g** is displayed. These are your choices for unit of measure for the calibration test weight.
- Toggle between these two units of measure by pressing the **ZERO** key. With the unit of measure you want displayed, press the **SAMPLE** key. . . A weight capacity is shown on the screen.
- Press the **ZERO** key to scroll through the choices of scale capacity. With your choice displayed, press the **SAMPLE** key. . . **LoAd 0** is displayed. Be sure all weight is removed from the scale.
- Press the **SAMPLE** key. . . **bUSY** is briefly displayed then **LoAd X**. **X** is the amount of weight to put on the scale for calibration. You can scroll to an alternate weight by pressing the **ZERO** key. See Table 2 at left.
- With **LoAd X** displayed, place **X** weight on the scale and press the **SAMPLE** key. . . **bUSY** is briefly displayed then **done**. The display then returns to **CALib**.
- After calibration has been successfully performed you must reset the scale to your desired display resolution. Calibration automatically resets resolution to 1 in 10,000.

## ConFig (Configuration)

ConFig (scale configuration) is the next item under the Scale menu. Below are descriptions of each item in this submenu. Use the **ZERO** and **SAMPLE** keys as you did in the calibration section to navigate through the choices and select the configuration items you want.

- 0 rAngE** Zero range  
Choices: **100%** or 2% of full capacity  
Use this to set the allowable zero range.
- 0 Start** Zero Start  
Choices: **YES** or **NO**  
If **YES** is select, the scale zeros when it powers up. If **NO** is selected, the scale will display the weight on the platter when it powers up.

*The scale defaults to 10,000d resolution after calibration. Reset to your desired resolution.*

*Bold selections are factory defaults.*

|                |  |
|----------------|--|
| <b>Azt rng</b> | Auto zero tracking range<br>Choices: Off, <b>0.5d</b> , 1d, 2d, 3d, 5d<br>Use this to set the allowable zero tracking range. This will not affect the count or sample modes.                                 |
| <b>ovr CAP</b> | Over capacity<br>Choices: <b>102%</b> or full capacity or 9 divisions<br>Use this to set the overcapacity limit.   |
| <b>StAbIE</b>  | Stability<br>Choices: Off, 0.25d, 0.5d, 1d, 2d, <b>5d</b><br>Use this to set the stability limit. This is the allowable motion for zero acceptance, tare acceptance and the stable indicator.<br>Off = 100d. |
| <b>rESo</b>    | Resolution<br>Choices: 5k, <b>10k</b> , 12.5k, 15k, 20k, 25k, 30k, 40k, 50k, 75k, 100k, 125k, 150k, 200k, 250k, 300k, 400k, 500k<br>Use this to set the desired scale resolution.                            |
| <b>FiLteR</b>  | Filter<br>Choices: <b>Normal</b> and Fast<br>Use this to set the amount of filtering needed for your situation. Choose Fast in situations with excess vibration.   |
| <b>UPdAtE</b>  | Update<br>Choices: 1 time/second, 2 times/second, 8 times/second, <b>16 times/second</b><br>Use this to set the display update rate.   |
| <b>dEFAULT</b> | Default<br>Choices: Yes, <b>No</b><br>Use this to reset the Config. factory defaults. Calibration will not be affected.  |
| <b>LFilT</b>   | LFilter<br>Choices: <b>4</b> , 5<br>Sets filtering of the Quartzell loadcell. A setting of 4 is more accurate but slows response compared to a setting of 5.   |
| <b>done</b>    | Done<br>Hit the SAMPLE key with this displayed to move back to the <b>ConFig</b> display.  |

## **rEStArt (Restart)**

Restart is the next menu item. Use this to reinitialize the scale. You will need to recalibrate if you choose yes.

## **SEAL (Seal)**

Seal is the next menu item. Choose **Yes** if you want to disable access to the scale menu through the front panel **PRINT** key. If yes is chosen and you try to access the scale menu, **SEALed** will be displayed. Choose **No** if you want to leave front panel access to the scale menu available.


## **done (Done)**

Done is the last menu item in the Scale menu. Press the **SAMPLE** key to return to the **SCALE** display.



# Diagnostic Menu

Figure 3 shows the Diagnostic menu. To enter the menu, press and hold the **PRINT** key for five seconds.



**Figure 3**  
Diagnostic menu

*A PC-802 with the backlight enabled and a fully charged battery may be expected to last 12 hours before recharging is necessary. With the backlight disabled the battery will last approximately 24 hours.*

Access the diagnostic menu by following the instructions in the section *Accessing Menus and Modes*. Below are explanations for each of the items in this menu. With the test name displayed, press the **SAMPLE** key to perform the test.


- BAttery** Battery  
Choose this to display the current battery voltage. Battery voltage will usually read from 11 to 13 volts. The Lo Bat annunciator will show up when voltage drops to 11.5 volts. The scale will shut off when voltage is 10 volts. While recharging, this display will show 13-14.5 volts and if AC powered the display will show approximately 14.5 volts.
- C CRYSt** Compression Crystal  
Choose this to display the raw digital counts from the compression crystal in the load cell. A typical count with no load on the scale is approximately 2.08 million. This number should increase as weight is applied to the scale. Press the **ZERO** key to end the test.
- t CRYSt** Tension Crystal  
Choose this to display the raw digital counts from the tension crystal in the load cell. A typical count with no load on the scale is approximately 2.08 million. This number should decrease as weight is applied to the scale. Press the **ZERO** key to end the test.

|                |  |
|----------------|--|
| <b>Count</b>   | Count<br>Choose this to display the raw, digital counts from the Quartzell™ loadcell. Count should be approximately 200,000.   |
| <b>SERIAL</b>  | Choose this to perform a serial loopback test. You must connect the Transmit and receive lines together for this test to work. Display will show pass or fail.                         |
| <b>DISPLAY</b> | Display<br>Choose this to display the model number, software version and revision and to perform a display segment test.   |
| <b>HI RESA</b> | High resolution with AZT enabled<br>Choose this to display weight data with 1,000,000 count resolution. AZT is enabled during this test. Press the <b>SAMPLE</b> key to stop the test. |
| <b>HI RESn</b> | High resolution with no AZT<br>Choose this to display weight data with 1,000,000 count resolution. AZT is disabled during this test. Press the <b>SAMPLE</b> key to stop the test.     |

# Config. (Configuration) Menu

The Config. menu is shown in Figure 4. Access the Config. menu by following the instructions in the section *Accessing Menus and Modes*. Below are explanations for each of the items in this menu.

To enter the menu, press and hold the **PRINT** key for five seconds.



**Figure 4**  
Configuration menu

*Bold selections are the factory defaults.*

*Word length is 10 bits.  
1 start, 7 data, 1 parity, 1 stop  
bit*

|                  |  |
|------------------|--|
| <b>Units</b>     | Units<br>Choices: <b>pounds</b> , grams or kilograms.<br>Choose the unit of measure you want to use.   |
| <b>Spl Lo</b>    | Sample low<br>Choices: 1, 2, <b>5</b> , 10, 25, 50, 100<br>Choose the minimum allowable sample size. For example; 5 is the default so 1 and 2 do not appear as sample size choices   |
| <b>AccY-Lo</b>   | Accuracy low<br>Choices: Off, 95%, <b>98%</b> , 99%<br>Choose the minimum desired accuracy. Reducing sample accuracy requires smaller samples.   |
| <b>Spl-typeE</b> | Sample type<br>Choices: <b>bul</b> (bulk) and dri (dribble)<br>Choose the type of sampling you want to use. Pick bulk sampling if you want to place all the sample parts on the scale at the same time. Pick dribble sampling if you will be counting (dribbling) parts onto the scale.  |
| <b>PIE-rnd</b>   | Piece weight rounding<br>Choices: <b>Off</b> , 1%, 2%, 5%<br>Choose the percent of piece weight rounding you want. This rounds the calculated piece weight by the selected percentage.   |
| <b>Serial</b>    | Serial<br>Use this submenu to configure the serial interface.  |
| <b>dDEVICE</b>   | Device<br>Choices: <b>none</b> , broadcast, imp printer, computer<br>Use this to choose the device to be interfaced with your scale. If you select imp, the output format will be selected by the format menu. If you select computer, the output format is determined by the commands received. Select broadcast to continuously output the format selected in the format menu. |
| <b>bAUd</b>      | Baud<br>Choices: 1200, 2400, 4800, <b>9600</b> , and 19,200<br>Choose the baud rate for your serial communication.   |
| <b>dAtAbit</b>   | Databit<br>Choices: 7 or <b>8</b><br>Choose the data bits to be used in serial communication.  |
| <b>PARitY</b>    | Parity<br>Choices: <b>none</b> , even, odd<br>Choose the parity to be used in serial communication.  |
| <b>AdvAnCE</b>   | Advance<br>Choices: <b>0</b> , 1, 2, 3, 4, 5, 6, 7, 8, 9<br>If you are using a printer, use this to choose the number of line feeds to be inserted after the formatted transmission.   |

A PC-802 with the backlight enabled and a fully charged battery may be expected to last 12 hours before recharging is necessary. With the backlight disabled the battery will last approximately 24 hours. Recharging takes approximately 8 hours.

|                  |   |
|------------------|---|
| <b>ForNat</b>    | Format<br>Choices: 0, 1, 2, 3, 4, <b>5</b> , 6, 7<br>If you are using an impact printer or Broadcast, choose from 8 preformatted outputs. These are described in the <i>Serial Communications</i> section of this manual.   |
| <b>Auto</b>      | Autoprint<br>Choices: <b>No</b> and Yes<br>If you are using an impact printer, choose no to disable autoprint and yes to enable autoprint. If enabled the weight will automatically be printed after each weight is added and stabilizes. Autoprint will re-arm after the weight has returned to within 10 divisions of net zero.   |
| <b>donE</b>      | Done<br>Press the <b>SAMPLE</b> key to return to the <b>Serial</b> display.   |
| <b>IdLE</b>      | Idle<br>Choices: <b>off</b> , 5, 10, 15, 20, 25, 30 minutes<br>Choose the amount of idle time the scale will remain powered when operating under battery power. Choose off if you do not want the scale to automatically shut off.  |
| <b>Backlight</b> | Backlight<br>Choose to turn backlight on or off. On is the default setting.   |
| <b>Latch</b>     | Latch<br>Choices are: Off, 1, <b>2</b><br>Sample Latching, if enabled, gives the appearance of stability immediately following the sample process. The sample latch is broken when motion is detected or if the calculated count is over two pieces (default setting) away from the sample size. The latch will not function again until another sample process is completed. |
| <b>donE</b>      | Done<br>Press the <b>SAMPLE</b> key to return to the <b>ConFig</b> display.   |

## Error Messages

The error messages you might see on the display are shown below.

|                |  |
|----------------|--|
| <b>EPr Err</b> | EEPROM error - press the <b>TARE</b> key to acknowledge the error  |
| <b>CAL Err</b> | Calibration error - perform calibration procedure to correct   |
| <b>Lo Bat</b>  | Low battery voltage - this annunciator will appear when battery voltage reaches 11.5 volts. The scale will shut off at 10 volts. |
| ----           | Upper dashes mean overload. Remove weight.   |
| ----           | Lower dashes mean an underload. Check weight plattter.   |

## Serial Communications

### Cable Pinouts

*A straight through cable (1 to 1, 2 to 2, etc.) can be used from a 9-pin computer serial port to connect this scale.*

Pinout assignments for the serial communication are shown below.

| 9-pin Female Scale |      |           |
|--------------------|------|-----------|
| Pin                | Name | Direction |
| 2                  | TXD  | OUT       |
| 3                  | RXD  | IN        |
| 5                  | SG   | -         |

## Preset Print Formats

*If the scale is in count mode, displayed weight formats will send weight, not count.*

There are seven preset serial print formats. Choose the one you want to use during configuration of the scale. The formats are described below.

Abbreviations:

CR = carriage return

LF = line feed

SP = space

U = units character

W = weight character

C = count character

T = tare character

G = gross weight character

P = piece weight character

I = weight type identifier (G for gross, T for tare and N for net)

### Format 0

Net weight only:

**WWWW.WW<CR><LF>**

### Format 1

Net weight with units:

**WWWW.WW<SP>UU<CR><LF>**

### Format 2

GTN with units:

**'G'<SP>GGGG.GG<SP>UU<CR><LF>**

**'T'<SP>TTTT.TT<SP>UU<CR><LF>**

**'N'<SP>WWWW.WW<SP>UU<CR><LF>**

### Format 3

Displayed weight with identifier:

**I<SP>WWWW.WW<CR><LF>**

### Format 4

In Count Mode the output will be:

**N<SP>CCCC<SP>PCS<CR><LF>**

In Weight Mode the output will be:

**I<SP>WWWW.WW<SP>UU<CR><LF>**

### Format 5

Net weight with units, count and piece weight:

**Net = WWWW.WW<SP>UU<CR><LF> (Net = or Gross =)**

**Count = CCCCCC<CR><LF>**

**Piece Wt = .PPPPPP<SP>UU<CR><LF>**

### Format 6

Fixed length (nine digits) displayed weight with units.

**sxxxxx.xx uu<CR> (s = positive (a space) or negative (-) weight)**

### Format 7

COUNT: **CCCC<SP>PCS<CR><LF>**

## Computer Protocol

The scale's RS-232 bidirectional communication works in a master/slave protocol. A computer or master sends a command code to the scale (slave) which will return a response to the master device or perform a scale function. Commands to the scale are in uppercase, terminated with a carriage return. Scale responses begin with the lowercase equivalent of the command code.

| COMMAND         | RESPONSE            | DESCRIPTION   |
|-----------------|---------------------|---|
| CA<CR>          | none                | Clear Sample  |
| CC<CR>          | cc_XXXX<CR>         | Request piece count                                   |
| CP<CR>          | cp_XXXX_uu<CR>      | Request piece weight value                            |
| CM<CR>          | none                | Switch to count mode                                  |
| DIxxxxxxx<CR>   | none                | Display Message xxxx<br>(message is 8 characters max) |
| IC<CR>          | none                | Reset Scale (warm start)                              |
| PWx.xxxx_uu<CR> | none                | Loads x.xxxx as piece weight                          |
| TR<CR>          | tr_x.xxx_uu<CR>     | Request tare value                                    |
| TZ<CR>          | none                | Clear the current tare                                |
| Txxx.x_uu<CR>   | none                | Loads xxx.x as tare                                   |
| WD<CR>          | ws_x.xxxx<CR>       | Request net weight                                    |
| WE<CR>          | we_x.xxx_uu<CR>     | Request net weight with units                         |
| W<CR>           | we_x.xxxx_uuHML<CR> | Request net weight with units and status              |
| WG<CR>          | wg_x.xxx_uu<CR>     | Request gross weight with units                       |
| WM<CR>          | none                | Switch to weight mode                                 |
| WS<CR>          | ws_HML<CR>          | Request scale status                                  |
| WZ<CR>          | none                | Zero the scale  |


### Legend:

- 1) " " ..... represents the ASCII space character
- 2) "u" ..... represents the units of measure character(s):  
 ..... "LB" for pounds  
 ..... "KG" for kilograms  
 ..... "G" for grams
- 3) <CR> .. represents the ASCII carriage return
- 4) HML .... represents three bytes of scale status information as described on the next page.
- 5) Value entered is assumed to be in same units of measure as what the scale is currently in.
- 6) Display messages are limited to seven characters.




### Scale Status Byte H:

BIT: 7 6 5 4 3 2 1 0  
0 0 1 1 X X X X




### Scale Status Byte M:

BIT: 7 6 5 4 3 2 1 0  
0 0 1 1 X X X X



### Scale Status Byte L:

BIT: 7 6 5 4 3 2 1 0  
0 0 1 1 0 0 0 X



# Disassembly Instructions



## Warning


*WARNING! Be sure to counter the torque force applied when loosening or tightening screws connected to the weight sensor, or weight sensor damage may result. Also do not use a "T" handle allen wrench and always lay the palm of your hand on the aluminum top plate when your break loose the top screws.*

If it is necessary to service the PC-802, follow this checklist for disassembly and re-assembly.

- ☐ 1. Disconnect the scale from the power source and remove the scale shroud.

**SEE WARNING TO THE LEFT.**

- ☐ 2. Remove the two socket-head screws securing the top plate to the weight sensor. Lift off the top plate. Do not lose the weight sensor spacer located between the top plate and the weight sensor.



**Figure 5**  
**Spacer location**


**To access the electronics:**

- ☐ 3. Disconnect the display cable from the scale base.
- ☐ 4. Remove the four screws holding the electronics cover plate to the base and lift off the cover.

**To remove the power supply board:**

- ☐ 5. Remove the weight sensor interface cable from the pins on the power supply board.
- ☐ 6. Remove the screws holding the PC board to the base and lift out the PC board.


PC-802B COUNTING SCALE  
10 lb / 5 kg cap. , 12" x 14" BASE  
PARTS AND ASSEMBLY




| ITEM NO. | DESCRIPTION                                 | W-T P/N       | QTY |
|----------|---|---------------|-----|
| 1        | Remote Display Cable Assy                   | 1140-11832    | 1   |
| 2        | Shroud (10 lb.)                             | 1076-15929    | 1   |
| 3        | Quartzell Assy                              | 7153-15694-05 | 1   |
|          | Quartzell EPROM (not shown)                 | 50705-0078    | 1   |
| 4        | Screw, #10-32 x .25"L                       | 1006-09173    | 2   |
| 5        | Vinyl Cap                                   | 1051-13968    | 3   |
| 6        | I/O Connector Mtg Bracket                   | 1067-15693    | 1   |
| 7        | PVC Wire Duct                               | 1074-15171-04 | 1   |
| 8        | Display Mtg Plate                           | 1069-14869    | 1   |
| 10       | Screw, Flat Head, Hex Soc, 1/4-20 X 1.00"L  | 1018-11594    | 2   |
| 11       | Main Interconnect Pc Board                  | 49995-0012    | 1   |
| 12       | Pwr Supply, 120vac/14vdc, 0.7 amp           | 1148-16069    | 1   |
|          | Pwr Supply, 230vac/14vdc, 0.7 amp           | 1148-16070    | 1   |
| 13       | Pwr Supply Mtg Bracket                      | 1067-15647    | 1   |
| 14       | Platter                                     | 1076-14702    | 1   |
| 15       | Screw, #6 x .38"L                           | 1009-05758    | 6   |
| 16       | Aluminum Spacer                             | 1043-13977    | 1   |
| 17       | Foot Assy                                   | 7075-16213    | 4   |
| 18       | Capscrew, 1/4 x .1.00"L                     | 1007-02617    | 2   |
| 20       | Standoff,m/f #4 x 3/16 HEX x .19"L          | 1044-01085    | 2   |
| 21       | Cable Clamp                                 | 1074-00392    | 1   |
| 22       | Level Bubble                                | 1083-00095    | 1   |
| 23       | Level Bubble Tape                           | 1045-15177    | 1   |
| 24       | Flat Washer, 1/4"                           | 1029-00099    | 2   |
| 25       | Acorn Nut, #10                              | 1028-16157    | 4   |
| 26       | Base  | 7069-15914-02 | 1   |
| 27       | Tooth Washer, #6                            | 1031-00128    | 3   |
| 28       | Slotted Stud, 1/4-20 x 2.00"L               | 1015-14427    | 4   |
| 29       | Shroud Spacer                               | 1043-14426    | 4   |
| 33       | Loadbridge                                  | 1066-13958    | 1   |
| 34       | Screw, Locking Hex Socket,                  | 1011-04367    | 1   |
| 35       | Cable Assy (Quartzell-to-main)              | 7140-14118    | 1   |
| 36       | Screw,#6-32 x .25"L                         | 1009-10039    | 2   |
| 37       | Screw,#6-32 x .38"L                         | 1006-02605    | 4   |
| 38       | Display Enclosure, Top                      | 106911065     | 1   |
| 39       | Display Enclosure, Bottom                   | 106911066     | 1   |
| 40       | Keypad                                      | 1163-15687    | 1   |
| 41       | Display Pc Board Assy                       | 7405-15834-02 | 1   |
| 42       | Battery Kit, (battery,cable,bracket,screws) | 50236-0019    | 1   |
| 43       | Battery , 12VDC                             | 15553-0074    | 1   |
| 44       | Battery Cable Assy                          | 50048-0017    | 1   |
| 45       | Battery mtg. Bracket                        | 52034-0011    | 1   |
| 46       | Remote Display (complete assy)              | 7516-15691    | 1   |

802sv

**PC-802B COUNTING SCALE**  
DRAFT SHIELD (10 lb. / 5 kg. 12" x 14" BASE VERSION ONLY)  
PARTS AND ASSEMBLY




NOTES:  
TO INSTALL DRAFT SHIELD, THE HEXNUT AND PLASTIC CAP  
AT THE CORNERS OF THE SHROUD NEED TO BE REMOVED AND  
DISCARDED BEFORE ATTACHING CORNER RODS.



| ITEM NO. | DESCRIPTION               | W-T P/N    | QTY | QTY |
|----------|---------------------------|------------|-----|-----|
| 1        | SUPPORT POST              | 1058-15413 | 2   | 2   |
| 2        | SHIELD DOOR               | 1069-15404 | 1   | 1   |
| 3        | SHIELD TOP PANEL          | 1069-15403 | 1   | 1   |
| 4        | SHIELD REAR PANEL         | 1069-15406 | 1   | 1   |
| 5        | SHIELD SIDE PANEL         | 1069-14604 | 2   | 2   |
| 6        | SUPPORT POST w/SIDE HOLE  | 1058-14424 | 2   | 2   |
| 7        | THREADED SPRING / PLUNGER | 1068-14610 | 2   | 2   |
| 8        | KNOB                      | 1091-14144 | 1   | 1   |
| 9        | HEX NUT, #10-32           | 1020-00132 | 1   | 1   |
| 10       | SCREW, #6-32 x .31" LG    | 1001-13790 | 2   | 2   |
| 11       | STANDOFF, #6-32 x .31" LG | 1044-00121 | 2   | 2   |
| 12       | VINYL CAP                 | 1051-13968 | 2   | 2   |
| 13       | SCREW, .25"-20 x .50" LG  | 1007-00538 | 4   | 8   |


PC-802B COUNTING SCALE  
50 lb / 25 kg , AND 100 lb / 50 kg cap. , 12" x 14" BASE  
PARTS AND ASSEMBLY



| ITEM NO. | DESCRIPTION                                 | W-T P/N       | QTY |
|----------|---|---------------|-----|
| 1        | Remote Display Cable Assy                   | 1140-11832    | 1   |
| 2        | Shroud (dished)                             | 1076-14741    | 1   |
| 3        | Quartzell Assy (50lb / 25kg cap.)           | 7153-15694-32 | 1   |
|          | Quartzell Assy (100lb / 50kg cap.)          | 7153-15694-50 | 1   |
|          | Quartzell EPROM (not shown)                 | 50705-0078    |     |
| 4        | Screw, #10-32 x 3/8"L                       | 1006-02039    | 2   |
| 6        | I/O Connector Mtg Bracket                   | 1067-15693    | 1   |
| 7        | PVC Wire Duct                               | 1074-15171-04 | 1   |
| 8        | Display Mtg Plate                           | 1069-14869    | 1   |
| 9        | Loadbridge                                  | 1066-15993    | 1   |
| 10       | Capscrew, Hex, 1/4-20 X 1.00"L              | 1007-02617    | 4   |
| 11       | Main Interconnect Pc Board                  | 7405-15695    | 1   |
| 12       | Pwr Supply, 120vac/14vdc, 0.7 amp           | 1148-16069    | 1   |
|          | Pwr Supply, 230vac/14vdc, 0.7 amp           | 1148-16070    | 1   |
| 13       | Pwr Supply Mtg Bracket                      | 1067-15693    | 1   |
| 14       | Sealing Cover Label                         | 1070-60103    | 1   |
| 15       | Screw, #6 X .38"L                           | 1009-05758    | 6   |
| 17       | Foot Assy                                   | 7075-16213    | 4   |
| 19       | Ground Spring                               | 1068-07674    | 2   |
| 20       | Standoff,m/f #4 x 3/16HEX x .19"L           | 1044-01085    | 2   |
| 21       | Cable Clamp                                 | 1074-00392    | 1   |
| 22       | Level Bubble                                | 1083-00095    | 1   |
| 23       | Adhesive Tape (for bubble)                  | 1045-13049    | 1   |
| 24       | Flat Washer, 1/4"                           | 1029-00099    | 4   |
| 25       | Access / Security Cover                     | 1069-15766    | 1   |
| 26       | Base  | 7069-15278    | 1   |
| 27       | Tooth Washer, #6                            | 1031-00128    | 3   |
| 28       | Shipping Block                              | 1084-15131    | 1   |
| 29       | Load Stop Pin (for 50lb / 25kg)             | 1070-60074-32 | 4   |
|          | Load Stop Pin (for100lb / 50kg)             | 1070-60074-50 | 4   |
| 33       | Ball Top Shroud (optional)                  | 7076-15118    | 1   |
| 34       | Screw, Locking Hex Socket,                  | 1011-15213    | 1   |
| 35       | Cable Assy (Quartzell-to-main)              | 7140-14118    | 1   |
| 36       | Screw,#6-32 x .25"L                         | 1009-10039    | 2   |
| 37       | Screw,#6-32 x .38"L                         | 1006-02605    | 4   |
| 38       | Display Enclosure, Top                      | 106911065     | 1   |
| 39       | Display Enclosure, Bottom                   | 106911066     | 1   |
| 40       | Keypad                                      | 1163-15687    | 1   |
| 41       | Display Pc Board Assy                       | 7405-15834-02 | 1   |
| 42       | Battery Kit, (battery,cable,bracket,screws) | 50236-0019    | 1   |
| 43       | Battery, 12VDC                              | 15553-0074    | 1   |
| 44       | Battery Cable Assy                          | 50048-0017    | 1   |
| 45       | Battery mtg. Bracket                        | 52034-0011    | 1   |
| 46       | Remote Display (complete assy)              | 7516-15956    | 1   |

## PC-802B COUNTING SCALE

### SYSTEM WIRING BLOCK DIAGRAM






**PC-802B COUNTING SCALE**  
**BATTERY INSTALLATION**  
 (Battery Kit P/N 29676-0010)





DIRECTIONS FOR INSTALLING PC-802 BATTERY KIT:

1. REMOVE BRACKET HOLDING INLINE 15 VDC POWER SUPPLY IN PLACE.
2. REMOVE INLINE POWER SUPPLY AND FOAM SHIPPING PAD FROM UNDER THE POWER SUPPLY.
3. CUT A 4.5" LENGTH OF FOAM STRIP FROM THE 16.5" PIECE OF FOAM INCLUDED IN KIT.
4. PLACE THE 4.5" PIECE OF FOAM CENTERED TO BOTTOM OF OPENING AS SHOWN.
5. PLACE THE 12" PIECE OF FOAM ON THE SIDE OF OPENING STARTING AT CORNER "C" (GOING CLOCKWISE) APPROXIMATELY HALF WAY DOWN IN THE OPENING.
6. INSERT BATTERY AS SHOWN.
7. INSTALL HOLDER BRACKET AS SHOWN.
8. CONNECT BATTERY CABLE TO "BATTERY POWER" ON BACK OF SCALE.
9. IF POWER SUPPLY REMAINS CONNECTED TO PC-802, IT PROVIDES INTERNAL RECHARGING OF BATTERY AND POWERS THE UNIT SIMULTANEOUSLY. A TOTALLY DISCHARGED BATTERY WILL BE FULLY CHARGED IN 8 HOURS MAXIMUM TIME.







PC-802B COUNTING SCALE  
 SCALES AND BASES  
 DIMENSIONAL OUTLINE FOR 12" x 14" BASE




PC-802B COUNTING SCALE  
BATTERY CHARGER (optional)  
PARTS LIST




| ITEM NO. | DESCRIPTION                  | W-T P/N    | QTY |
|----------|------------------------------|------------|-----|
| 1        | Battery Charger PC BD Assy   | 50093-0011 | 1   |
| 2        | Base Plate Assy              | 45911-0045 | 1   |
| 3        | Grommet                      | 15347-0018 | 1   |
| 4        | Standoff, M/Fem, #6 x 7/8" L | 15437-0472 | 1   |
| 5        | Screw,#6 x 3/8" L            | 14473-0249 | 1   |
| 6        | Lock Washer, #6              | 14474-0032 | 1   |
| 7        | Screw,#4 x 1/4" L            | 14473-0108 | 3   |
| 8        | Lock Washer,                 | 14474-0024 | 3   |

PC-802B COUNTING SCALE  
WALL-MOUNT BRACKET AND REMOTE TOWER (optional)  
PARTS AND ASSEMBLY



| ITEM NO. | DESCRIPTION                | W-T P/N    | QTY |
|----------|----------------------------|------------|-----|
| 1        | Tower Support Channel      | 49658-0010 | 1   |
|          | Tower Support Channel      | 49658-0028 | 1   |
| 2        | Screw,#6 x 3/8" L          | 14473-0249 | 2   |
| 3        | Grommet                    | 15347-0018 | 1   |
| 4        | Tower Channel (9")         | 49659-0019 | 1   |
|          | Tower Channel (18")        | 49659-0027 | 1   |
| 5        | Screw,#10 x 1/2" L         | 14473-0496 | 2   |
| 6        | Tower Base                 | 50085-0011 | 1   |
| 7        | Wall-Mount Display Bracket | 49599-0012 | 1   |



**Weigh-Tronix**

1000 Armstrong Dr.  
Fairmont, MN 56031 USA  
Telephone: 507-238-4461  
Facsimile: 507-238-4195  
e-mail: [industrial@weigh-tronix.com](mailto:industrial@weigh-tronix.com)  
[www.wtxweb.com](http://www.wtxweb.com)

**Weigh-Tronix Canada, ULC**

217 Brunswick Blvd.  
Pointe Claire, QC H9R 4R7 Canada  
Telephone: 514-695-0380  
Facsimile: 514-695-6820

**WEIGH-TRONIX**

Weighing Products & Systems