

ZQ375
Checkweigher



User Instructions

© Avery Weigh-Tronix, LLC 2012. All rights reserved.

No part of this publication may be reproduced, stored in an electronic retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise without the prior written consent of the copyright owner, or as permitted by law or under license. Full acknowledgment of the source must be given. Avery Weigh-Tronix is a registered trade mark of the Avery Weigh-Tronix, LLC. This publication was correct at the time of going to print however, Avery Weigh-Tronix, LLC reserves the right to alter without notice the specification, design, price or conditions of supply of any product or service at any time.

All third party brands and product names used within this document are trademarks or registered trademarks of their respective holders.

Table of Contents

	<i>page</i>
Chapter 1 General information and warnings	7
About this manual	7
Text conventions	7
Special messages	7
Installation	8
Safe handling of equipment with batteries	8
Wet conditions	8
Routine maintenance	8
Cleaning the machine	9
ZQ375 cleaning process	9
Indicator	10
Cleaning the Rear of the Column	11
Base Cleaning	11
Training	11
Sharp objects	12
FCC and EMC declarations of compliance	12
United States	12
Canada	12
European Countries	12
Declaration of Conformity	13
Chapter 2 Introduction	14
Initial setup	14
Front panel	15
Annunciators	17
Tolerance entry procedure	18
Example: To increase a value of 0.002 to 0.125:	18
Numeric entry procedure	19
Example: To key in the number 507:	19
ID Entry Procedure	19
Powering up the ZQ375	20
Battery option	20
Installation	21
Battery charging and operation	22
Checkweigher Operation on Battery Power	22
Light stack option	23
Light stack operation	23
Chapter 3 Checkweighing applications	24
Checkweighing terminology	24
Normal weighing procedures	25
Gross weighing	25
Tare/Net weighing	25
Using Pushbutton Tare (if enabled)	26
Using Preset Tare (if enabled)	26
Sim375 application	28
Checkweighing	28
Switching Between Checkweighing and Normal Weighing Mode	28
Setting a New Target Weight and Simple Checkweighing	28
View the High and Low Tolerances	28
Set New High and Low Tolerances	29

Clearing a Target Weight	29
Mid375 application	30
SELECT key operation	30
Checkweighing	30
Setting a New Target Weight and Checkweighing	30
Quick Check Method	30
Preset Target Weight	31
View the Target Weight and Upper and Lower Tolerances	31
Set New Upper and Lower Tolerances	31
Transaction counter	32
Adv375 application	33
SELECT key operation	33
Checkweighing	33
Setting a New Target Weight and Checkweighing	34
Choosing a PLU and Checkweighing	34
View the Upper and Lower Tolerances	35
Set New Upper and Lower Tolerances	35
Transaction counter	36
Statistical Package and Packrun	36
X-Bar/R Program	36
Per375 application	37
Checkweighing	37
Setting a New Target Percentage and Checkweighing	37
Choosing a PLU and Checkweighing	38
View the Upper and Lower Tolerances	38
Set New Upper and Lower Tolerances	38
Grad375 application	40
Grade classifying	40
Setting weight grades	40
Weighing using grades	41
Chapter 4 Menus	42
Accessing the menus	42
Menu annunciators	42
Exiting the menus	43
USER level menus	43
User menu	44
Time	44
Date	45
Site ID	46
Seal	46
About menu	47
Boot	47
Firm and App	48
Serial	48
Option	48
Enet	49
Dload	50
Audit menu	50
Counter	51
Print	51
Chapter 5 Error messages	52
Chapter 6 Communications	53
Default print formats	53
Chapter 7 Supervisor menu	55

Supervisor menu for Sim375 application	56
Setpoint	57
Annunciators	57
Inputs	57
Print	58
Reset	58
Check	59
Outputs	59
Output-gross zero band	59
Under segment division	60
Over segment division	60
Reset	60
Battery	61
Enable	61
Timeout	61
Supervisor menu for Mid375 application	62
Setpoint	63
Tare	63
Tare Register 1-10	63
Printing	64
Reset	64
Check	64
Outputs	65
Output-gross zero band	65
Under segment division	65
Over segment division	66
Digits	66
Type	66
Auto Tare	67
Reset	67
Battery	67
Supervisor menu for Adv375 application	68
Setpoint	69
Tare	69
Check	69
Outputs	69
Outputs-gross zero band	70
Under segment division	70
Over segment division	70
Print total	71
Total format	71
Clear total	71
Digits	72
Stats	72
Packrun	72
Type	73
Auto Tare	73
Reset	73
PLU	74
Edit	74
Print	75
Import	76
Export	76
Reset	76
Battery	77
Supervisor menu for Per375 application	78
Setpoint	79

Tare	79
Check	79
PLU	79
Battery	79
Supervisor menu for the Grad375 application	80
Setpoint	80
Tare	80
Grading	81
Battery	81

1 General information and warnings

1.1 About this manual

This manual is divided into chapters by the chapter number and the large text at the top of a page. Subsections are labeled using the 1.1 and 1.1.1 convention. The names of the chapter and the next subsection level appear at the top of alternating pages of the manual to remind you of where you are in the manual. The manual name and page numbers appear at the bottom of the pages.

1.1.1 Text conventions

Key names are shown in **bold** and reflect the case of the key being described. If a key has dual functions, the function is shown first followed by the key name in parentheses and in bold, such as in these examples: **F1**, **SELECT**, **PRINT**, etc.

Displayed messages appear in ***bold italic*** type and reflect the case of the displayed message.

1.1.2 Special messages

Examples of special messages you will see in this manual are defined below. The heading words have specific meanings to alert you to additional information or the relative level of hazard.



CAUTION!

This is a Caution symbol.

Cautions give information about procedures that, if not observed, could result in damage to equipment or corruption to and loss of data.



NOTE: *This is a Note symbol. Notes give additional and important information, hints and tips that help you to use your product.*

1.2 Installation



NO USER SERVICEABLE PARTS. REFER TO QUALIFIED SERVICE PERSONNEL FOR SERVICE.

1.2.1 Safe handling of equipment with batteries



CAUTION: *Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.*

ATTENTION: *Il y a danger d'explosion s'il y a remplacement incorrect de la batterie, remplacer uniquement avec une batterie du même type ou d'un type équivalent recommandé par le constructeur. Mettre au rebut les batteries usagées conformément aux instructions du fabricant.*

1.2.2 Wet conditions

Under wet conditions, the plug must be connected to the final branch circuit via an appropriate socket / receptacle designed for washdown use.

Installations within the USA should use a cover that meets NEMA 3R specifications as required by the National Electrical Code under section 410-57. This allows the unit to be plugged in with a rain tight cover fitted over the plug.

Installations within Europe must use a socket which provides a minimum of IP56 protection to the plug / cable assembly. Care must be taken to make sure that the degree of protection provided by the socket is suitable for the environment.

1.3 Routine maintenance



IMPORTANT: *This equipment must be routinely checked for proper operation and calibration. Application and usage will determine the frequency of calibration required for safe operation.*

Always turn off the machine and isolate from the power supply before starting any routine maintenance to avoid the possibility of electric shock.

Before use in any NSF / ANSI 3-A food application this scale must be regularly inspected to guarantee cleanliness at all times.


Scale needs to be regularly inspected to guarantee there are no loose or missing nuts and that all bolt and knob threads are completely covered.

Check that the indicator and any battery or external OPTO22 relay box are secured correctly in place with the correct locking knob.

Check that the scale is set on a clean, flat, stable surface and levelled using the scale feet and bubble level found between the column and the base.

Feet can be adjusted by loosening the locking sleeve and rotating the foot in or out until the base becomes level.

Once level, the locking sleeve needs to be retightened with a spanner onto the base, guaranteeing there are no threads visible once locked in place. See the illustration below:



1.4 Cleaning the machine

1.4.1 ZQ375 cleaning process

The ZQ375 checkweigher has been designed for use within NSF / ANSI 3-A food applications.

It has minimum food trap areas to aid fast and efficient cleaning. All versions of the ZQ375 scale, indicator, remote battery pack and external opto22 relay box can be subjected to external high pressure cleaning to IP69K standards.

Bases marked with Model number **BSF** are suitable for high pressure cleaning externally and under the scale platter in line with IP69K standards.

Bases marked with model number **BSG** are only suitable for high pressure cleaning externally. Extra care has to be taken cleaning under the scale platter in line with IP65 / Nema4X standards.

1.4.2 Indicator



CAUTION: *It is essential that the power plug is kept in a safe dry area while cleaning is in progress.*

If external USB or Ethernet glands are installed in the indicator, it is essential these be sealed with water tight caps prior to cleaning or when the connectors are not in use.




1.4.3 Cleaning the Rear of the Column

For rigorous cleaning it is recommended that the external battery pack or external relay box, if installed, are removed to allow better access to the rear of the column while cleaning. Before high pressure washing the battery, protect the battery connector with the water tight cap supplied.



1.4.4 Base Cleaning

While cleaning, it is essential that the weighing platform and the breakaway plate should be removed to allow full easy access into the base to aid the cleaning process and help to sanitize all areas of the base.



1.5 Training

Do not attempt to operate or complete any procedure on a machine unless you have received the appropriate training or read the instruction books.

To avoid the risk of RSI (Repetitive Strain Injury), place the machine on a surface which is ergonomically satisfactory to the user. Take frequent breaks during prolonged usage.

1.6 Sharp objects

Do not use sharp objects such as knives, screwdrivers or long fingernails to operate the keys.

1.7 FCC and EMC declarations of compliance

United States

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Canada

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la Classe A prescrites dans le Règlement sur le brouillage radioélectrique édicté par le ministère des Communications du Canada.

European Countries

WARNING: This is a Class A product. In a domestic environment, this product may cause radio interference in which the user may be required to take adequate measures.

1.8 Declaration of Conformity

Avery Weigh-Tronix

Foundry Lane, Smethwick, West Midlands B66 2LP, England

	Declaration of Conformity Verklaring van Overeenstemming Déclaration de Conformité	Konformitätserklärung Dichiarazione di conformità Declaración de Conformidad

<table border="1"> <tr> <td style="text-align: center;">Manufacturer Type</td> <td>Avery Weigh-Tronix Limited ZQ375 Checkweigher</td> </tr> <tr> <td style="text-align: center;">No. of EC type approval certificate</td> <td>UK/2924</td> </tr> </table>	Manufacturer Type	Avery Weigh-Tronix Limited ZQ375 Checkweigher	No. of EC type approval certificate	UK/2924	<table border="1"> <tr> <td style="text-align: center;">Fabrikant Type</td> <td>Avery Weigh-Tronix Limited ZQ375 Checkweigher</td> </tr> <tr> <td style="text-align: center;">Nummer van de Verklaring van EG-typegoedkeuring</td> <td>UK/2924</td> </tr> </table>	Fabrikant Type	Avery Weigh-Tronix Limited ZQ375 Checkweigher	Nummer van de Verklaring van EG-typegoedkeuring	UK/2924	<table border="1"> <tr> <td style="text-align: center;">Fabricant Type</td> <td>Avery Weigh-Tronix Limited ZQ375 Checkweigher</td> </tr> <tr> <td style="text-align: center;">No. de certificat d'approbation de type CE</td> <td>UK/2924</td> </tr> </table>	Fabricant Type	Avery Weigh-Tronix Limited ZQ375 Checkweigher	No. de certificat d'approbation de type CE	UK/2924
Manufacturer Type	Avery Weigh-Tronix Limited ZQ375 Checkweigher													
No. of EC type approval certificate	UK/2924													
Fabrikant Type	Avery Weigh-Tronix Limited ZQ375 Checkweigher													
Nummer van de Verklaring van EG-typegoedkeuring	UK/2924													
Fabricant Type	Avery Weigh-Tronix Limited ZQ375 Checkweigher													
No. de certificat d'approbation de type CE	UK/2924													
corresponds to the requirements of the following EC directives:														
EMC Directive	2004/108/EC	EMC Richtlijn	2004/108/EG	Directive CEM	2004/108/CE									
Low Voltage Directive	2006/95/EC	Laagspanningsrichtlijn	2006/95/EG	Directive Basse Tension	2006/95/CE									
Non-Automatic Weighing Instruments Directive	2009/23/EC ¹	Richtlijn niet-automatische weegwerktuigen	2009/23/EG ¹	Directive pour les instruments de pesage à fonctionnement non automatique	2009/23/CE ¹									
The applicable harmonised standards are:			Toegepaste geharmoniseerde normen:											
EN 45501 : 1994 EN 60950-1 : 2006 +A12:2011	EN 61000-6-3 : 2007 +A1:2011	EN 45501 : 1994 EN 60950-1 : 2006 +A12:2011	EN 61000-6-3 : 2007 +A1:2011	EN 45501 : 1994 EN 60950-1 : 2006 +A12:2011	EN 61000-6-3 : 2007 +A1:2011									
<p>Note 1: This declaration is only valid if the non-automatic weighing instrument was verified by the manufacturer or with a certificate of conformity issued by a notified body.</p> <p>Avery Weigh-Tronix Limited Reg. Office: Foundry Lane, Smethwick, West Midlands B66 2LP, England. Registered in England No: 595129</p>			<p>Noot 1: Deze verklaring is alleen geldig indien het weegwerktuig door de fabrikant is geverifieerd, of met een Verklaring van overeenstemming, afgegeven door een bevoegde instantie.</p> <p>Avery Weigh-Tronix Limited Reg. Office: Foundry Lane, Smethwick, West Midlands B66 2LP, England. Registered in England No: 595129</p>			<p>Nota 1: Cette déclaration est valide seulement si l'instrument de pesage à fonctionnement non automatique a été vérifié par le fabricant ou avec une attestation de conformité délivrée par un organisme notifié.</p> <p>Avery Weigh-Tronix Limited Reg. Office: Foundry Lane, Smethwick, West Midlands B66 2LP, England. Registered in England No: 595129</p>								

<table border="1"> <tr> <td style="text-align: center;">Hersteller Typ</td> <td>Avery Weigh-Tronix Limited ZQ375 Checkweigher</td> </tr> <tr> <td style="text-align: center;">Nr. der EG-Bauartzulassung</td> <td>UK/2924</td> </tr> </table>	Hersteller Typ	Avery Weigh-Tronix Limited ZQ375 Checkweigher	Nr. der EG-Bauartzulassung	UK/2924	<table border="1"> <tr> <td style="text-align: center;">Produttore Modello</td> <td>Avery Weigh-Tronix Limited ZQ375 Checkweigher</td> </tr> <tr> <td style="text-align: center;">N. di certificato di approvazione di tipo CE</td> <td>UK/2924</td> </tr> </table>	Produttore Modello	Avery Weigh-Tronix Limited ZQ375 Checkweigher	N. di certificato di approvazione di tipo CE	UK/2924	<table border="1"> <tr> <td style="text-align: center;">Fabricante Tipo</td> <td>Avery Weigh-Tronix Limited ZQ375 Checkweigher</td> </tr> <tr> <td style="text-align: center;">Número del certificado de aprobación de tipo CE</td> <td>UK/2924</td> </tr> </table>	Fabricante Tipo	Avery Weigh-Tronix Limited ZQ375 Checkweigher	Número del certificado de aprobación de tipo CE	UK/2924
Hersteller Typ	Avery Weigh-Tronix Limited ZQ375 Checkweigher													
Nr. der EG-Bauartzulassung	UK/2924													
Produttore Modello	Avery Weigh-Tronix Limited ZQ375 Checkweigher													
N. di certificato di approvazione di tipo CE	UK/2924													
Fabricante Tipo	Avery Weigh-Tronix Limited ZQ375 Checkweigher													
Número del certificado de aprobación de tipo CE	UK/2924													
entspricht den Anforderungen folgender EG-Richtlinien:														
EMV-Richtlinie	2004/108/EG	Normativa EMC	2004/108/CE	Directiva CME	2004/108/CE									
Niederspannungs Richtlinie	2006/95/EG	Normativa per la bassa tensione	2006/95/CE	Directiva de baja tensión	2006/95/CE									
Waagenrichtlinie für nichtselbsttätige Waagen	2009/23/EG ¹	Normativa per strumenti di pesatura non automatici	2009/23/CE ¹	Directiva para equipos de pesaje no automáticos	2009/23/CE ¹									
Die angewendeten harmonisierten Normen sind:			Le norme standard armonizzate e nazionali applicate sono:											
EN 45501 : 1994 EN 60950-1 : 2006 +A12:2011	EN 61000-6-3 : 2007 +A1:2011	EN 45501 : 1994 EN 60950-1 : 2006 +A12:2011	EN 61000-6-3 : 2007 +A1:2011	EN 45501 : 1994 EN 60950-1 : 2006 +A12:2011	EN 61000-6-3 : 2007 +A1:2011									
<p>Anmerkung 1: Diese Erklärung gilt nur, wenn die nichtselbsttätige Waage vom Hersteller geeicht wurde oder in Verbindung mit einer Konformitätsbescheinigung einer benannten Stelle.</p> <p>Avery Weigh-Tronix Limited Reg. Office: Foundry Lane, Smethwick, West Midlands B66 2LP, England. Registered in England No: 595129</p>			<p>Nota 1: Questa dichiarazione è valida solamente se lo strumento di pesatura non automatico è stato verificato dal produttore o provvisto di un certificato di conformità rilasciato da un ente riconosciuto.</p> <p>Avery Weigh-Tronix Limited Reg. Office: Foundry Lane, Smethwick, West Midlands B66 2LP, England. Registered in England No: 595129</p>			<p>Nota 1: Esta declaración es válida solamente si el equipo de pesaje no automático ha sido verificado por el fabricante o con certificado de conformidad emitido por un organismo notificado.</p> <p>Avery Weigh-Tronix Limited Reg. Office: Foundry Lane, Smethwick, West Midlands B66 2LP, England. Registered in England No: 595129</p>								

<p>Signature/Name Handtekening/Naam Signature/Nom Unterschrift/Name Firma/Nombre Firma/Nombre</p>	 S. Hine Head of R&D (UK)	<p>Authorised signatory for Avery Weigh-Tronix Limited Namens van Avery Weigh-Tronix Limited Signataire autorisé d'Avery Weigh-Tronix Limited Unterschriftsberechtigter für Avery Weigh-Tronix Limited Firmatario autorizzato per Avery Weigh-Tronix Limited Firmante autorizado para Avery Weigh-Tronix Limited</p> <p style="text-align: right;">Date Datum Date Datum Data Fecha</p> <p style="text-align: right;">12 April 2012</p>
---	---	--

2 Introduction

This manual covers operation of the ZQ375 Checkweigher from Avery Weigh-Tronix. The checkweigher consists of a bench scale, an attached column and the ZQ375 Checkweigher head or indicator.

The ZQ375 Checkweigher is a reliable, easy to operate, high speed weighing scale, designed to allow entry of a target weight, along with selected over and under weight limits for the rapid processing of items that must be checked for conformity to a precise weight range. It offers a range of standard statistical packages to allow precise monitoring of any pack run. The data received enables the operation to be fine-tuned to maximise performance and profitability.

It may be used in stand-alone or interfaced applications. The ZQ375 incorporates serial multi-scale communications capabilities. The scale is housed in a watertight enclosure to permit use in wet environments and can be washed down as necessary to meet sanitary requirements.

This scale has been calibrated and inspected for mechanical and electronic integrity prior to shipment. It should be free of defects and in perfect operating condition upon receipt. To confirm this, the scale should be inspected immediately for any physical damage incurred in transit. If the scale is damaged, contact your local Avery Weigh-Tronix supplier.

2.1 Initial setup

Unpack the unit and place it on a stable, non-vibrating, level surface. Feet can be adjusted to level the scale by loosening the locking sleeve and rotating the foot in or out until the base becomes level. Use the bubble level located between the scale and the column.

Once level, tighten the locking sleeve up against the base to completely cover the feet's threads and to keep the feet from turning. See Figure 2.1.




Figure 2.1 Locking sleeve shown in unlocked and locked position

Plug the unit into an easily accessible, grounded power receptacle. See *General information and warnings on page 7* for a complete list of precautions concerning the electrical safety of this product and for cleaning procedures.

2.2 Front panel

The front panel, shown in Figure 2.2, consists of the keys and the display.




Figure 2.2 ZQ375 front panel



Never press a key with anything but your finger. Damage to the overlay may result if sharp or rough objects are used.

The function of the keys on the front panel are listed below.

	<p>Weigh / Checkweigh mode - In weigh mode the TARE key will work as configured via the Admin menu. (See the Service manual). In checkweigh mode, the TARE key does not function and the display will show cAnt.</p> <p>Menu navigation - Acts as an up arrow key.</p> <p>Numeric / Tolerance Entry - Increments a value.</p>
	<p>Weigh / Checkweigh mode - Press this key to change from weighing mode to checkweighing mode and vice versa.</p> <p>Menu navigation - Acts as a Down Arrow key.</p> <p>Numeric / Tolerance Entry - Decrements a value.</p>
	<p>Weigh / Checkweigh mode - Press to perform a print function.</p> <p>Menu navigation - Functions as the Left Arrow key.</p> <p>Numeric / Tolerance Entry - Functions as a backspace.</p>
	<p>Weigh / Checkweigh mode - Press to zero the weight display.</p> <p>Menu navigation - Functions as an Enter key to accept displayed choices.</p> <p>Numeric / Tolerance Entry - Functions as an Enter key.</p>
	<p>Weigh / Checkweigh mode - Press UNITS to cycle the displayed unit of measure through all the available units of measure.</p> <p>Menu navigation - Functions as the Right Arrow key.</p> <p>Numeric / Tolerance Entry - Moves the cursor position to the right in the Numeric Entry Procedure.</p>

	<p>Weigh / Checkweigh mode - Press UNDER to briefly display the active under value. Press and hold UNDER to add or modify an existing under value tolerance.</p> <p>Menu navigation - N/A</p> <p>Numeric / Tolerance Entry - N/A</p>
	<p>Weigh / Checkweigh mode - TARGET key acquires a target value, when applicable. Its function changes in different applications. See the appropriate application section.</p> <p>Menu navigation - N/A</p> <p>Numeric / Tolerance Entry - N/A</p>
	<p>Weigh / Checkweigh mode - Press OVER to briefly display the active over value. Press and hold OVER to add or modify an existing over value tolerance.</p> <p>Menu navigation - N/A</p> <p>Numeric / Tolerance Entry - N/A</p>
	<p>Weigh / Checkweigh mode - Press the ID key briefly to view the active ID number. Press and hold the ID key to view a prompt for ID number entry. Use the Numeric Entry Procedure on page 18 to scroll in a new ID.</p> <p>Menu navigation - N/A</p> <p>Numeric / Tolerance Entry - N/A</p>
	<p>Weigh / Checkweigh mode - Press to access PLU database, if enabled. Press and hold to access the menu password display.</p> <p>Menu navigation - Press to escape a screen without doing anything and move up in the menu.</p> <p>Numeric / Tolerance Entry - Press to escape a screen without doing anything and move up in the menu.</p>

2.2.1 Annunciators

The annunciators on the display are shown and labeled in Figure 2.3.




Figure 2.3 Annunciators

These annunciators will light during operation to inform the user of the weighing mode, active unit of measure, etc.

Table 2.1 Circle Annunciator assignments

Annunciator	Indicates
Circle 1 (left most)	Network activity
Circle 2	Custom unit
Circle 5	Transaction counter
Gross + Circle 5	Gross total
Net + Circle 5	Net total
Tare + Circle 5	Transaction total

2.3 Tolerance entry procedure



If you are in a target or tolerance value entry screen and no key is pressed within five seconds, the scale will act as if the **F1/Escape** key was pressed and return to the previous screen without saving any information.

When you are in a tolerance entry screen the yellow **OVER** segments flash as a reminder. Figure 2.4 shows the key functions when in this




Figure 2.4 Key functions in tolerance entry

In tolerance entry screens, the segments shown in Figure 2.4 flash. Use the keys, as described in Figure 2.4, to enter a value on the display. Following is an example:

Example: To increase a value of 0.002 to 0.125:

Press and hold **TARE(▲)** key until the number approaches **0.125**. Number will increase by **0.010s** for a short time and then by **0.100s**.

Press and release **TARE(▲)** to increment the right most digit by 1.

If you overshoot, press and release **SELECT(▼)** to decrement the right most digit by 1.

Press and hold **SELECT(▼)** to decrease the value by **0.010s** and then by **0.100s**, the longer you hold it.

When the display show 0.125, or the value you desire, press the **ZERO** key to enter or accept the value. The screen returns to the previous mode.

2.4 Numeric entry procedure

The keys in Figure 2.5 have alternate functions in numeric entry screens.




Figure 2.5 Key function during numeric entry

In numeric entry screens, the segments shown in Figure 2.5 flash. Use the keys, as described in Figure 2.5, to enter a value on the display. Following is an example:

Example: To key in the number 507:

Repeatedly press the **TARE(▲)** or **SELECT(▼)** key until **5** appears on the display.

Press the **UNITS(→)** key once to move cursor one space to the right.

Repeatedly press the **TARE(▲)** or **SELECT(▼)** key until **0** appears on the display.

Press the **UNITS(→)** key once to move cursor one space to the right.

Repeatedly press the **TARE(▲)** or **SELECT(▼)** key until **7** appears on the display.

Press the **ZERO** key to enter or accept the value.

Press the **PRINT(◀)** key to move the entry function one digit to the left. This effectively deletes the current value in that position and allows you to enter a new value in that position.

2.5 ID Entry Procedure

1. To enter an ID number press and hold the **ID** key ...

The current ID number is displayed with the digit or digits flashing.

2. Within five seconds begin to use the *Numeric entry procedure* [on page 19](#) to scroll in a new ID and press **ZERO** to accept.
3. The new ID number is now active.



If the entry screen times out and disappears, repeat step 1 and try again. You must start the number entry procedure within five seconds.

2.6 Powering up the ZQ375

Power is always on as long as the power cable is plugged into the appropriate electrical outlet.

2.7 Battery option

The ZQ375 can be operated on battery power by the ZQ-BAT battery option. See Figure 2.6.



Figure 2.6 ZQ-BAT battery option installed in the column

2.7.1 Installation

The battery pack is easy to install. The projections on the side of the pack slide into the slots in the column. The tab on the top of the pack goes over the threaded stud on the column and the pack is secured in place with the star knob. See Figure 2.7.




Figure 2.7 ZQ-BAT installation

Attach the battery cable from the indicator to the connector on the top of the battery.

2.7.2 Battery charging and operation

The battery has five annunciator lights to tell you when the unit is charging, when the battery level is low or high, when there is a fault in the battery and when the battery is on or off. Below these lights is the **ON/OFF** button. See Figure 2.8.




Figure 2.8 Top of ZQ-BAT battery pack

To charge the battery, disconnect the checkweigher from the case and connect the charging unit. The battery should be charged for 8 hours before first use and also when recharging.

Battery life is rated at 16 hours continuous duty.

If so configured, the checkweigher will automatically switch off the battery after a set amount of time if no scale motion or keypad activity occurs.

Checkweigher Operation on Battery Power

1. To operate the checkweigher using the battery pack, be sure the pack is fully charged and connected to the checkweigher. Press the **ON/OFF** key on the battery pack ...

The Battery ON LED will light.

2. The ZQ375 should power up as soon as the battery is turned on.
3. To power down the battery and the ZQ375, press the **ON/OFF** key ...

The Battery ON LED light will go out and the ZQ375 will power down.

2.8 Light stack option

The ZQ375 has an optional light stack for a bright, visual sign that an object on the scale is over, under or at the acceptable target weight. The unit, shown installed in Figure 2.9, attaches to the column in exactly the same way as the battery pack and connection is also made with a simple screw-in connector.



Figure 2.9 Light stack option

2.8.1 Light stack operation

The lights function the same way as the bargraph, showing red for under, orange for over and green for accept conditions.

3 Checkweighing applications

The ZQ375 has five applications for different levels of checkweighing and specialty checkweighing.

- Sim375** Simple, quick checkweighing application. Fast and simple to set up. Displays a \pm deviation reading from the target weight set within the scale.
- Mid375** Mid-level checkweighing. This application uses weigh mode versus deviation mode. It is fast and simple to set up and displays target weight in gross or net weight. Target weight setup by either the **TARGET** key or entered through the indicator keypad.
- Adv375** Advanced checkweighing. This is like Mid375 but adds a Product Look Up (PLU) database. This allows you to quickly activate target weights and high and low tolerances for up to 500 products from the PLU database. Statistical packages like X-bar/R and Standard Deviation are also included in this application.
- Per375** Percent checkweighing allows the operator to accurately increase the weight of a product by a set percentage of the starting weight.
- Grad375** This application categorizes weight within up to 10 bands or weight windows.

Applications are enabled in a password protected menu. See the Service manual (PN AWT35-500813 for the English version).

Each application is fully explained below.

3.1 Checkweighing terminology

There are some terms you should understand when checkweighing.

Target	The exact weight desired
Target-Hi	Target weight plus the Tolerance-Hi
Target-Low	Target weight minus the Tolerance-Low
Tolerance-Low	Weight allowed under the target weight but still considered acceptable
Tolerance-Hi	Weight allowed over the target weight but still considered acceptable

3.2 Normal weighing procedures

The Sim375, Mid375 and Adv375 applications allow normal weighing using gross and net weighing. Below are the steps for the normal weighing practices.

3.2.1 Gross weighing



*If enabled, press **UNITS** to change the unit of measure.*

To perform gross weighing, power up the unit and follow these steps:

1. Press the **SELECT** key if the *GROSS* annunciator is not lit ...
The *GROSS* annunciator lights and the scale is in gross weighing mode.
2. Empty the scale and press **ZERO** to zero the display ...
0 is displayed and the *center-of-zero* annunciator lights.
3. Place item to be weighed on the scale ...
Weight is displayed.
4. Repeat steps 1 through 3.

3.2.2 Tare/Net weighing



In the Sim375 application, the tare functionality is not available

There are two kinds of tare entry. These are enabled when the indicator is configured.

- Pushbutton tare
- Preset tare



If Preset Tare is enabled, Pushbutton Tare is automatically disabled.

There is also a function called auto tare clear. If this is enabled, after a weighment, when the weight falls into the gross zero band and is steady, any tare is removed from the indicator. No tare remains active between weighments.

The two types of tare are explained below.

Using Pushbutton Tare (if enabled)

To perform a net weighment using pushbutton tare, power up the unit and follow these steps:

1. Empty the scale and press **ZERO** ...
0 is displayed and the *center-of-zero* annunciator lights.
2. Place item to be tared on the scale ...
Weight is displayed.
3. Press **TARE** ...
0 is displayed and the *NET* annunciator lights.



To clear a tare weight, remove all weight from the scale and press **TARE**.

4. Place material to be weighed on the scale ...
Net weight of material is displayed.
5. Repeatedly press **SELECT** to view the gross, tare, and net values.
6. Remove all weight from the scale.
7. To repeat weighing the net weight, place a container of the same weight on the scale and then the material to be weighed ...
Net weight of material is displayed.
8. To remove the tare, remove all weight from the scale. With **0** displayed, press **TARE**.
The tare is cleared and the scale is in gross weigh mode.

Using Preset Tare (if enabled)

Preset tares are entered in a password protected menu. There can be up to 10 tares numbered 1-10. To perform a net weighment using one of the preset tares, power up the unit, go to normal gross weighing mode and follow these steps:

1. Empty the scale and press **ZERO** ...
0 is displayed and the *center-of-zero* annunciator lights.
2. Press **TARE** ...
Tare number entry screen appears.
3. Use the *Numeric entry procedure on page 19* and key in the preset tare number and press **ZERO** ...
-X is displayed and the *NET* annunciator lights. **X** is the tare value.
4. Place object to tared and material to be weighed on the scale ...
Net weight of material is displayed.

5. Repeatedly press **SELECT** to view the gross, tare, and net values.
6. Remove all weight from the scale ...
 -X is displayed.
7. Repeat steps 4 - 6 until you are finished using that tare weight.

3.3 Sim375 application

This section applies if the Sim375 application is enabled. See the Service manual for information on enabling the applications.

The SIM375 application is a fast and efficient checkweighing application that displays the \pm deviation from a target point set by the operator.

3.3.1 Checkweighing

Switching Between Checkweighing and Normal Weighing Mode

To switch between checkweighing and normal weighing mode, press **SELECT**. When the *GROSS* annunciator is displayed, the unit is in normal weighing mode. Press **SELECT** again and the *GROSS* annunciator disappears. The unit is now in checkweighing mode. The display may show a negative weight and the *Under* segments of the bargraph may be lit if there is an active target value.

Setting a New Target Weight and Simple Checkweighing

1. With the unit in Checkweighing mode, press **ZERO** to zero the scale and place an item of the correct weight on the scale and press **TARGET** ...

The scale will read **0** weight and the center *Accept* segment will light showing the target weight has been set successfully.



*If motion is present for greater than 2-3 seconds after the **TARGET** key press, the target operation will be aborted and the word **cant** will be displayed briefly.*

2. Clear the scale and place the next item on the scale ...

The bargraph will show the item is under the target weight, over the target weight or on target.



By default the Target segment lights if the weight is within \pm the high and low tolerance of the target weight. The over and under segments each represent 1 division.

3. Repeat step 2 for all the other items to be weighed.

View the High and Low Tolerances

1. To view the high tolerance, press and hold **OVER** ...

toL-hi (high tolerance) is briefly displayed, then the value is briefly displayed before the normal checkweighing mode returns.

2. To view the low tolerance, press and hold **UNDER** ...

toL-Lo (low tolerance) is briefly displayed, then the value is briefly displayed before the normal checkweighing mode returns.

Set New High and Low Tolerances



You can escape from an entry screen or choice level. Press **F1** and the action is aborted and the display returns to its previous state.

To set custom tolerances follow these steps:

1. Press **UNDER** to set the low tolerance ...

x.xxx is displayed. This is the current low tolerance. The *Under* segments also flash.
2. Refer to the *Tolerance entry procedure on page 18* and key in a new tolerance and press **ZERO** to accept ...

Display returns to checkweighing mode with the new low tolerance active.
3. Press **OVER** to set the high tolerance ...

x.xxx is displayed. This is the current high tolerance. The *Over* segments also flash.
4. Refer to the *Tolerance entry procedure on page 18* and key in a new tolerance and press **ZERO** to accept ...

Display returns to checkweighing mode with the new high tolerance active.



The tolerances can be set from 1 division to the capacity of the scale.

Clearing a Target Weight

If there is an active target value, you can clear the value.

1. Remove all weight from the scale and press **TARGET** ...

The active target weight is cleared and the scale goes into gross weighing mode with *GROSS* annunciator lit.

3.4 Mid375 application

This section applies if the Mid375 application is enabled. See the Service manual for information on enabling the applications.

In the Mid375 application the checkweigher mode is always active and the target weight is always displayed in either gross or net weight. Unlike the Sim375 that only displays the deviation from target, the Mid375 offers more flexibility when extra print or statical data is required.

3.4.1 SELECT key operation

In the Mid375 application, press **SELECT** to cycle through the active display values: GROSS, NET, TARE and TRANSACTION COUNT. The appropriate annunciator will light for each display value. (The transaction count annunciator is the green circle under the right digit on the display.)

3.4.2 Checkweighing

For the Mid375 application the checkweigher is always active. Weight is displayed instead of deviation.

Setting a New Target Weight and Checkweighing

Setting a target weight can be done in two ways:

- **Quick check target weight:** from a live target weight
- **Preset target weight:** entered through keypad.



*When at gross 0, press **TARGET** and you can adjust the target weight using the Tolerance entry procedure on page 18.*

Quick Check Method

1. Place an item of the correct weight on the scale and press **TARGET** ...

The scale will read **0** weight and the center *Accept* segment will light showing the target weight has been set successfully.



*If motion is present for greater than 2-3 seconds after the **TARGET** key press, the target operation will be aborted and the word **cant** will be displayed briefly.*

2. Clear the scale and place the next item on the scale ...

The bargraph will show the item is under the target weight, over the target weight or on target.

3. Repeat step 2 for all the other items to be weighed.

Preset Target Weight

1. Press **ZERO** to zero the scale and press **TARGET** ...
The current value for target is displayed.
2. Use the *Numeric entry procedure on page 19* to key in a value for target and press **ZERO** to accept ...
The target weight becomes active.
3. Place an item on the scale ...
The weight will be displayed and *OVER*, *UNDER* or *ACCEPT* segments will light depending on the weight.
4. Clear the scale.
5. Repeat steps 3 and 4.

View the Target Weight and Upper and Lower Tolerances

1. To view the target weight, press and hold **TARGET** ...
tArGEt is briefly displayed, then the value is briefly displayed before the normal checkweighing mode returns.
2. To view the upper tolerance, press and hold **OVER** ...
toL-hi (high tolerance) is briefly displayed, then the value is briefly displayed before the normal checkweighing mode returns.
3. To view the lower tolerance, press and hold **UNDER** ...
toL-Lo (low tolerance) is briefly displayed, then the value is briefly displayed before the normal checkweighing mode returns.

Set New Upper and Lower Tolerances



*You can escape from an entry screen or choice level. Press **F1** and the action is aborted and the display returns to its previous state.*

To set custom tolerances follow these steps:

1. Press **UNDER** to set the lower or under tolerance ...
x.xxx is displayed. This is the under tolerance value. The *Under* segments also flash.
2. Refer to the *Tolerance entry procedure on page 18* and key in a new tolerance. Press **ZERO** to accept ...
Display returns to checkweighing mode with the new lower tolerance active.
3. Press **OVER** to set the upper tolerance ...
x.xxx is displayed. This is the over tolerance value. The *Over* segments also flash.

4. Refer to the *Tolerance entry procedure on page 18* and key in a new tolerance. Press **ZERO** to accept ...

Display returns to checkweighing mode with the new upper tolerance active.



The tolerances can be set from 1 division to the capacity of the scale.

3.4.3 Transaction counter

You can view the number of transactions since the last clearing by pressing the **SELECT** key until the transaction count display is shown. The counter is incremented every time **PRINT** is pressed. See example in Figure 3.1.



Figure 3.1 Transaction count display

If enabled in a password protected menu, press and hold **PRINT** to clear the transaction count.

3.5 Adv375 application

This section applies if the Adv375 application is enabled. See the Service manual for information on enabling the applications.

3.5.1 SELECT key operation

In the Adv375 application, press **SELECT** to cycle through the active display values: GROSS, NET, TARE and TRANSACTION COUNT. The appropriate annunciator will light for each display value. (The transaction count annunciator is the green circle under the right digit on the display.)

3.5.2 Checkweighing

The Adv375 application is identical in function to the Mid375 application with the addition of Product Look Ups (PLUs). PLUs consist of a PLU# (1-500), the lower tolerance, the target weight and the upper tolerance. These are created and edited in a password protected menu. See your supervisor for more information.



*A short key press of the **OVER**, **UNDER**, and **TARGET** keys will do nothing if the PLU# is from 1 to 500. If the PLU# = 0, these keys will work like in the Mid375 application. See Set New Upper and Lower Tolerances on page 31.*

*If you press and hold the **OVER**, **UNDER**, and **TARGET** keys and the PLU# = 1 to 500, you will see hi tolerance, target and low tolerance, respectively. If the PLU# = 0, then the over, under, target values will be shown, but are only temporary ones since the PLU#=0.*

Setting a New Target Weight and Checkweighing



You can escape from an entry screen or choice level. Press **F1** and the action is aborted and the display returns to its previous state.



When at gross **0**, press **TARGET** and you can adjust the target weight using the Tolerance entry procedure on page 18.

These steps apply only if the active PLU# is 0.

1. In gross weighing mode, press **ZERO** to zero the scale. Place an item of the correct weight on the scale and press **TARGET** ...

The scale will read show the weight of the item, the center *Accept* segment will light showing the target weight has been set successfully and the *Gross* or *Net* annunciator will be lit.



If motion is present for greater than 2-3 seconds after the **TARGET** key press, the target operation will be aborted and the word **cant** will be displayed briefly.

2. Clear the scale and place the next item on the scale ...

The bargraph will show the item is under the target weight, over the target weight or on target.

3. Repeat step 2 for all the other items to be weighed.

Choosing a PLU and Checkweighing

Use these steps when you want to recall a PLU and checkweigh.

1. Press **ZERO** to zero the scale, then press **F1** ...

A flashing **0** is displayed prompting you for the PLU # you wish to recall.

2. Use the *Numeric entry procedure on page 19* to enter the PLU number and press **ZERO** to accept ...

The PLU values are recalled. The target, upper and lower tolerances become active. If that PLU number has no values assigned, the display will show **cAnt**.

3. Place an item on the scale ...

The scale will show the weight and the bargraph segments will light in accordance with the target and tolerances that are active.

4. Clear the scale and place the next item on the scale ...

The bargraph will show the item is under the target weight, over the target weight or on target.

5. Repeat step 2 through 4 for all the other items to be weighed.

View the Upper and Lower Tolerances

1. To view the upper tolerance, press and hold **OVER** ...
toL-hi (high tolerance) is briefly displayed, then the value is briefly displayed before the normal checkweighing mode returns.
2. To view the lower tolerance, press and hold **UNDER** ...
toL-Lo (low tolerance) is briefly displayed, then the value is briefly displayed before the normal checkweighing mode returns.

Set New Upper and Lower Tolerances



*You can escape from an entry screen or choice level. Press **F1** and the action is aborted and the display returns to its previous state.*

If the active PLU# is 0, you can set custom tolerances. Follow these steps:

1. Press **UNDER** to set the lower or under tolerance ...
x.xxx is displayed. This is the under tolerance value. The *Under* segments also flash.
2. Refer to the *Tolerance entry procedure on page 18* and key in a new tolerance. Press **ZERO** to accept ...
 Display returns to checkweighing mode with the new lower tolerance active.
3. Press **OVER** to set the upper tolerance ...
x.xxx is displayed. This is the over tolerance value. The *Over* segments also flash.
4. Refer to the *Tolerance entry procedure on page 18* and key in a new tolerance. Press **ZERO** to accept ...
 Display returns to checkweighing mode with the new upper tolerance active.



The tolerances can be set from 1 division to the capacity of the scale.

3.5.3 Transaction counter

You can view the number of transactions since the last clearing by pressing the **SELECT** key until the transaction count display is shown. The counter is incremented every time **PRINT** is pressed.

If enabled in a password protected menu, press and hold **PRINT** to clear the transaction count for the active PLU.



Transaction counts and accumulators are stored with each PLU.

3.5.4 Statistical Package and Packrun

If the statistical package, Standard Deviation, is enabled, after a configurable number of transactions have occurred (packrun quantity), the ZQ375 will totalize the number of transactions and compute the standard deviation of the transactions.

If autoprint is enabled or the **PRINT** key is pressed a valid transaction occurs. Valid transactions are counted as one entry in a packrun.

To end a packrun before the configured quantity is met, press and hold **PRINT** and the valid transactions are totaled and standard deviation is performed.

If enabled, the standard deviation report is printed automatically upon completion of the packrun.

3.5.5 X-Bar/R Program

The X-bar/R program is designed to weigh process samples, establish the average weight, calculate the range between high and low weights, and the trend of deviation. If the X-bar/R feature is enabled, the ZQ375 will keep a queue of the average weights of the last eight sample sets. This queue of averages is used to print trend information on the statistical reports.

Trend Message	Meaning
1 of 1	The last average in the queue has an error greater than 3x the limit
2 of 3	Two of the last three averages in the queue have an error greater than the limit.
4 of 5	Four of the last five averages have an error greater than the limit.
8 of 8	Eight of eight averages are on the same side of the target weight.

3.6 Per375 application

This section applies if the Per375 application is enabled. See the Service manual for information on enabling the applications.

3.6.1 Checkweighing

The Per375 application is identical in function to the Adv375 application with the exception that weights are now expressed in percentages. PLUs consist of a PLU#, the lower tolerance, the target percentage and the upper tolerance. These are created and edited in a password protected menu. See your supervisor for more information.



A short key press of the **OVER**, **UNDER**, and **TARGET** keys will do nothing if the PLU# is from 1 to 500. If the PLU# = 0, these keys will work like in the Mid375 application. See Set New Upper and Lower Tolerances on page 31.

If you press and hold the **OVER**, **UNDER**, and **TARGET** keys and the PLU# = 1 to 500, you will see hi tolerance, target and low tolerance, respectively. If the PLU# = 0, then the over, under, target values will be shown, but are only temporary ones since the PLU#=0.

Setting a New Target Percentage and Checkweighing



You can escape from an entry screen or choice level. Press **F1** and the action is aborted and the display returns to its previous state.

These steps apply only if the active PLU# is 0.

1. In gross weighing mode, press **ZERO** to zero the scale. Press **TARGET** ...

The display will show the last target value in percentage and the% annunciator will turn on. The *Target* segment will light.



If motion is present for greater than 2-3 seconds after the **TARGET** key press, the target operation will be aborted and the word **cant** will be displayed briefly.

2. Press **ZERO** to accept the displayed value or use the *Tolerance entry procedure on page 18* to key in a new target value and press **ZERO** to accept.
3. Place the item on the scale and press **TARGET** ...

Percent of item on the scale is now displayed. This should be **0.0%**.

4. Add additional weight (for example, by injection) until the target percentage has been reached ...

When the target percentage is reached, the center *Accept* segment will light.

5. Clear the scale and place the next item on the scale. Repeat steps 1 and 4.

Choosing a PLU and Checkweighing

Use these steps when you want to recall a PLU and checkweigh.

1. Press **ZERO** to zero the scale, then press **F1** ...
A flashing **0** is displayed prompting you for the PLU # you wish to recall.
2. Use the *Numeric entry procedure on page 19* to enter the PLU number and press **ZERO** to accept ...
The PLU values are recalled. The target, upper and lower tolerances become active. If that PLU number has no values assigned, the display will show **cAnt**.
3. Place an item on the scale and press **TARGET** ...
The display will show **0.0** and the *Under* segments will light in.
4. Add additional weight until the target percentage has been reached ...
The center *Accept* segment will light.
5. Clear the scale and repeat steps as needed.

View the Upper and Lower Tolerances

1. To view the upper tolerance, press and hold **OVER** ...
toL-hi (high tolerance in percent) is briefly displayed, then the value is briefly displayed before the normal checkweighing mode returns.
2. To view the lower tolerance, press and hold **UNDER** ...
toL-Lo (low tolerance in percent) is briefly displayed, then the value is briefly displayed before the normal checkweighing mode returns.

Set New Upper and Lower Tolerances



You can escape from an entry screen or choice level. Press **F1** and the action is aborted and the display returns to its previous state.

If the active PLU# is 0, you can set custom tolerances. Follow these steps:

1. Press **UNDER** to set the lower or under tolerance ...
x.x percent is displayed. This is the under tolerance value. The% annunciator is lit and the *Under* segments also flash.
2. Refer to the *Tolerance entry procedure on page 18* and key in a new tolerance. Press **ZERO** to accept ...
Display returns to checkweighing mode with the new lower tolerance active.
3. Press **OVER** to set the upper tolerance ...
x.x percent is displayed. This is the over tolerance value. The% annunciator is lit and the *Over* segments also flash.

4. Refer to the *Tolerance entry procedure on page 18* and key in a new tolerance. Press **ZERO** to accept ...

Display returns to checkweighing mode with the new upper tolerance active.

3.7 Grad375 application

This section applies if the Grad375 application is enabled. See the Service manual for information on enabling the applications.

3.7.1 Grade classifying

The Grad375 application does only one thing and that is to classify a weight as 1 of 10 weight grades. You set the weight values for each division between the grades. If the weight on the scale falls below or is equal to the weight value of a grade division, it is in the grade below the line. If it is greater than a weight value, it is in the grade above the line. Default value for Weight Points 2 is 10 is 0. See Figure 3.2 for an illustration.




Figure 3.2 Weight grade illustration

3.7.2 Setting weight grades

Follow these steps to set the weight points illustrated in Figure 3.2.

1. With the Grad375 application active, press and hold **TARGET** ...
grAding is displayed.
2. Press **SELECT** ...
grAd 1 is displayed. This is the first weight point that defines the lower limit of Grad 1.
3. Press **SELECT** ...
A numeric entry screen is displayed.
4. Key the first weight point and press **ZERO** to accept ...
grAd 1 is displayed.
5. Press **UNITS** to move to the next weight point ...
grAd 2 is displayed.
6. Repeat steps 3 through 5 until you've completed all 11 weight points ...
grAd 11 is displayed.
7. Press **TARE** twice ...
Indicator returns to the normal operating mode and the current weight is displayed.

3.7.3 Weighing using grades

1. With the weight points set, zero the scale and place the item to be weighed on the scale.

Any weight below weight point #1 or above weight point #11 will be displayed as weight.

Any other weight will be shown as one of the 10 Grades. The display will show **grAd X**, with **X** being the grade number for that weight.

2. Remove the item from the scale and weigh the next item.



You can reduce the number of grades by setting Grad Points to 0.

For example: To create 3 grades, set Grad Points 1, 2 and 3 normally. Set Grad Points 4 through 10 to 0 and set Grad Point 11 to the last value to create your third grade.

4 Menus

Password protected menus are available to customize the indicator and to view information.

4.1 Accessing the menus

Follow these steps to access the menus in the ZQ375.

1. With the indicator powered up and in normal operating mode, press and hold the **F1** key ...

Pass is displayed, prompting you to enter the password.

2. Key in the password for the menu you want and press the **ZERO** key ...

The first item in the top level of the menu you accessed is displayed.

3. Use the navigation keys, shown below, to navigate through the menu structure. The symbols in the chart appear on the bottom of the keys.

Menu Navigation Keys:

Press **SELECT**/ ▼ to move down in a menu

Press **TARE**/ ▲ to move up in a menu, except at the bottom item in a menu, then use **ZERO**/ ← or **F1**

Press **PRINT**/ ◀ to move left in a menu

Press **UNITS**/ ▶ to move right in a menu

Press **ZERO**/ ← to accept a value or choice and move up in the menu.

Press **F1** to escape and move up in the menu

4.2 Menu annunciators

The menu structure is made up of menu items, parameters, value entry screens and lists from which you choose one item. To help you know where you are in the menu, the bar graph at the top of the display is on while the indicator is in the menus and will change appearance according to the following rules:

All segments flashing	This means you are in the menu structure but not in any of the following screens.
Center flashing / others solid	This means you are in a parameter prompt screen. See Parameter Code section.
Center flashing / others off	This means you are in a numeric or octet entry screen. Enter a number and press ZERO to accept.
Right flashing / others off	This means you are in a list. Scroll through the choices with the PRINT and UNITS keys and press ZERO to accept.

Left most solid / others off

This means you are in a screen for string or hex data entry.

4.3 Exiting the menus

1. If you are at the bottom item in a menu use **ZERO** to accept a choice or value and move up a level, or use **F1** to escape and move up one level without accepting the choice or value. From that point, press the **TARE** key repeatedly until ...

SAVE no is displayed. This means “Do not save changes.”

2. Use the **PRINT** or **UNITS** key to scroll through the choices: **SAVE no**, **SAVEYES** and **CAnCEL**. Press **Enter** to accept the displayed choice.

If you choose **SAVE no** or **SAVEYES** the indicator exits the menu and returns to normal weighing mode.

OR

If you choose **CAnCEL**, the indicator remains in the menu.

4.4 USER level menus

The USER level menus are available to the user. The other menu levels are for supervisors and technicians only.

The USER level (password 111) contains the User, About, and Audit menus arranged as shown in Figure 4.1.




Figure 4.1 USER level (password 111) menus



Under some of the section headings you will see menu items with small arrows (↓ →). These are reminders of the menu structure and how you got to the menu item.

4.5 User menu

The User menu is shown in Figure 4.2.




Figure 4.2 User menu

Use this menu to set the time and date, to enter a site ID, and view the physical seal status. Each is explained below:

4.5.1 Time

User ↓ Time

1. Access the User menu (see *Power is always on as long as the power cable is plugged into the appropriate electrical outlet. on page 20*) and press **SELECT** ...
tiME is displayed. Use this to set the time and clock style.
2. Press **SELECT** ...
SEt is displayed.
3. Press **SELECT** ...
h- x is displayed, with the **x** flashing. This is a numeric entry screen for the hour value.
4. Key in the hour of the day using military (24 hr) time and press **ZERO** ...
The choice is made and **M- x** is displayed, with the **x** flashing. This is a numeric entry screen for the minute value.
5. Key in the minute value and press **ZERO** ...
The choice is made and **S- x** is displayed, with the **x** flashing. This is a numeric entry screen for the second value.

6. Key in the seconds value and press **ZERO** ...
The choice is made and **SEt** is displayed.
7. Press **UNITS** ...
StYLE is displayed. Use this to set the style of clock for printouts.
Choices are **12hr**, **12hr-AP** (AM/PM) and **24hr** (military time).
8. Press **SELECT** ...
12hr is displayed.
9. Press **PRINT** or **UNITS** to scroll through the choices. Press **ZERO** when your choice is displayed ...
The choice is made and **StYLE** is displayed.
10. Press **TARE** ...
tiME is displayed.

4.5.2 Date

User ↓ Time → Date

1. Press **UNITS** ...
dAtE is displayed.
2. Press **SELECT** ...
SEt is displayed.
3. Press **SELECT** ...
y- x is displayed, with the **x** flashing. This is a numeric entry screen for the year value.
4. Key in the year and press **ZERO** ...
The choice is made and **M- x** is displayed, with the **x** flashing. This is a numeric entry screen for the month.
5. Key in the month value and press **ZERO** ...
The choice is made and **d- x** is displayed, with the **x** flashing. This is a numeric entry screen for the day value.
6. Key in the day value and press **ZERO** ...
The choice is made and **SEt** is displayed.
7. Press **UNITS** ...
StYLE is displayed. Use this to set the style of date for printouts.
Choices are **MMDD2Y**, **MMDD4Y**, **DDMM2Y** and **DDMM4Y**.
8. Press **SELECT** ...
MMDD2Y is displayed.

9. Press **PRINT** or **UNITS** to scroll through the choices. Press **ZERO** when your choice is displayed ...
The choice is made and **StYLE** is displayed.
10. Press **TARE** ...
dAtE is displayed.

4.5.3 Site ID

User ↓ Time → Date → Site ID

1. Press **UNITS** ...
SitE id is displayed.
2. Press **SELECT** ...
A numeric entry screen is displayed.
3. Key in a site ID number on the numeric keypad and press **ZERO** to accept ...
SitE id is displayed.

4.5.4 Seal

User ↓ Time → Date → Site ID → Seal

1. Press **UNITS** ...
SEAL is displayed.
2. Press **SELECT** ...
unSEALE or **SEALed** is displayed. This is the status of the physical seal inside the indicator. If the unit is sealed, no changes can be made to the configuration of the indicator.
3. Press **F1** to return to the **SEAL** display.
4. To exit the menu, see *Exiting the menus on page 43*.

4.6 About menu

The About menu is shown in Figure 4.3.




Figure 4.3 About menu

Use this menu to display information about the various items shown in Figure 4.3. Each is explained below:

4.6.1 Boot

About ↓ Boot

1. Access the About menu and press **SELECT** ...
boot is displayed.
2. Press **SELECT** ...
PArtno is displayed
3. Press **SELECT** ...
The bootloader PN is displayed.
4. Press **ZERO** to return to the **PArtno** display.
5. Press **PRINT** or **UNITS** to move to the other item in this level ...
VERsion is displayed.
6. Press **SELECT** ...
The version number of the bootloader is displayed.

7. Press **ZERO** to return to the **VERsion** display.
8. Press **TARE** to return to the **boot** display.

4.6.2 Firm and App

About ↓ Boot → Firm and App

1. Press **UNITS** to move to the next item in this level ...
FirM is displayed. This stands for firmware.
2. Repeat the same pattern of key presses in steps 2 through 3 to view the part number and version for the **FirM**. and **APP** menu items.

4.6.3 Serial

About ↓ Boot → Firm → App → Serial

1. With **APP** displayed, press **UNITS** to move to the next item in this level ...
SEriAL is displayed.
2. Press **SELECT** ...
The indicator's serial number is displayed.
3. Press **TARE** to return to the **SEriAL** display.

4.6.4 Option

About ↓ Boot → Firm → App → Serial → Option

1. Press **UNITS** to move to the next item in this level ...
oPtion is displayed.
2. Press **SELECT** ...
VERsion is displayed. This stands for the software revision or version of the currently installed option card. This can be useful service information.
3. To view the version, press **SELECT** ...
The software revision number is shown.
4. Press **ZERO** ...
oPtion is displayed.
5. Press **UNITS** to move to the other item in this level ...
tYPE is displayed. This stands for the type of option card installed. The four option cards are: Analog, 802.11g wireless, USB-d, and RS-485.
6. Press **SELECT** ...
The currently installed option card name is displayed.

7. Press **ZERO** ...
tYPE is displayed.
8. Press **TARE** ...
oPtion is displayed.

4.6.5 Enet

About ↓ Boot → Firm → App → Serial → Option → Enet



If the indicator is connected to an ethernet network, the values displayed will be the current assigned addresses.

1. Press **UNITS** ...
EnEt is displayed. Use this item to view the values for the IP, Subnet, Gateway and MAC addresses.
2. Press **SELECT** ...
iP is displayed. Use this item to view the four part IP address.
3. Press **SELECT** ...
0 0 is displayed. This is first portion of the IP address
4. Press **ZERO** ...
1 0 is displayed. This is second portion of the IP address.
5. Press **ZERO** ...
2 0 is displayed. This is third portion of the IP address.
6. Press **ZERO** ...
3 1 is displayed. This is fourth portion of the IP address.
7. Press **ZERO** ...
iP is displayed.
8. Press **UNITS** ...
Subnet is displayed.
9. Repeat this sequence of key presses for the **Subnet**, **Gateway** and **MAC** addresses.
10. When you are finished, from the menu item, press **TARE** to return to the **Enet** menu item.

4.6.6 Dload

About ↓ Boot → Firm → App → Serial → Option → Enet → Dload

1. From **EnEt**, press **UNITS ...**
dLoAd is displayed. This stands for download. Under **SSEriAL** you can view the serial number of the software application that created the configuration file. Under **dSSEriAL** you can view the serial number of the software application that downloaded the configuration file. This is used for security and licensing purposes.
2. Press **SELECT ...**
SSEriAL is displayed.
3. Press **SELECT ...**
 The 1st half of the serial number of the creating application of the configuration file is displayed.
4. Press **ZERO** to show the 2nd half.
5. Press **F1 ...**
SSEriAL is displayed.
6. Press **UNITS ...**
dSSEriAL is displayed.
7. Press **SELECT ...**
 The 1st half of the serial number of the downloading application of the configuration file was downloaded to, is displayed.
8. Press **ZERO** to show the 2nd half.
9. Press **F1 ...**
dSSEriAL is displayed.
10. Press **TARE** until **About** is displayed.
11. To exit the menu, see *Exiting the menus on page 43*.

4.7 Audit menu

The Audit menu is shown in Figure 4.4.




Figure 4.4 Audit menu

Use this menu to display audit counters for configuration and calibration and to print the information. Each is explained below:

4.7.1 Counter

Audit ↓ Counter

1. Access the Audit menu and press **SELECT** ...
countEr is displayed. This has two counters that tell you how many times the indicator has been configured and calibrated.
2. Press **SELECT** ...
conFig is displayed.
3. Press **SELECT** again ...
 A number appears showing how many times the indicator has been configured.
4. Press **ZERO** ...
conFig is displayed.
5. Press **UNITS** to move to the next item in this level ...
cALib is displayed.
6. Press **SELECT** ...
 A number appears showing how many times the indicator has been calibrated.
7. Press **ZERO** ...
cALib is displayed.
8. Press **TARE** ...
countEr is displayed.

4.7.2 Print

Audit ↓ Counter → Print

1. Press **UNITS** ...
Print is displayed.
2. Press **SELECT** ...
Port1 is displayed. This is the first of three choices: **Port 1**, **Port 2** or **uSb**. Use these to select which port to print the audit report through.
3. Press **PRINT** or **UNITS** to scroll through the choices and press **ZERO** when your choice is displayed ...
 The audit log is printed through the chosen port and *Print* is displayed.
4. This completes the Audit menu. To exit the menu, see *Exiting the menus* on [page 43](#).

5 Error messages

The following errors may be displayed during use of the indicator.

Message	Display
Overload	
Can't fit on display	
Underload	
Can't	
Entry not in valid range	
Password entry failed	
General error. Report to repair tech.	
The indicator failed the attempted action	
Checkweigher did not reach a stable zero weight within time window set for automated weighing process.	  

6 Communications

The ZQ375 can communicate through these ports:

- Serial
- Ethernet
- USB
- Wireless 802.11g

6.1 Default print formats

Below are examples of the default formats that are available:

General Weighing (Format #1)

```

Gross  272.04 lb
Tare   95.88 lb
Net    176.16 lb
  
```

Under/Over/Accept (Format #24)

```

Accept:    176.16 lb
  
```

Accept/Reject (Format #25)

```

Reject:    142 lb
  
```

Net Weighment w/Band (Format #27)

```

3.601    lb    OVER
  
```

Standard Deviation (Format #28)

```

OVER     = 4.600 lb
UNDER    = 3.200 lb

OVER     = 4
UNDER    = 2
ACPT     = 9
AVG      = 4.0823 lb
HIGH     = 4.803 lb
LOW      = 3.003 lb
SD       = 0.6088
CV       = 14.91 PCT
SS       = 15
  
```

X-Bar/R (Format #29)

```
OVER    = 3.100 lb
UNDER   = 2.900 lb

AVG     = 3.5206 lb
RANGE   = 1.20 lb
```

Grading (Format #30)

```
Grad3   6.005 lb
```

The ZQ375 can be configured for many other outputs to match the application.

7 Supervisor menu

This menu allows a supervisor to change those functions of an application that are configurable. Access the supervisor menu using the password 1793. Refer to *Accessing the menus on page 42* for instructions.



Wherever there is an option to print information in the any of the supervisor's menus, be aware that the information will print out of Port 2 only.

The Supervisor menu changes based on the active application. Each is shown on the following pages.

- *Supervisor menu for Sim375 application on page 56*
- *Supervisor menu for Mid375 application on page 62*
- *Supervisor menu for Adv375 application on page 68*
- *Supervisor menu for Per375 application on page 78*
- *Supervisor menu for the Grad375 application on page 80*

Below is a chart showing how the keys are used in navigating through the menus. There is an abbreviated version in next to each menu as a reminder of the key functions.

Menu Navigation Keys:

Press SELECT / ▼ to move down in a menu
Press TARE / ▲ to move up in a menu, except at the bottom item in a menu, then use ZERO / ← or F1
Press PRINT / ◀ to move left in a menu
Press UNITS / ▶ to move right in a menu
Press ZERO / ← to accept a value or choice and move up in the menu.
Press F1 to escape and move up in the menu

7.1 Supervisor menu for Sim375 application

This section applies if the Sim375 application is active. The Sim375 Supervisor menu is shown in Figure 7.1.




Figure 7.1 Sim375 Supervisor menu

Follow these steps to use the Supervisor menu:

Access the Supervisor menu (password 1793). See *Accessing the menus* on page 42.

7.1.1 Setpoint

Super↓ Setpoint



The ↓ and → symbols stand for direction moved in the menu. So Super ↓ Setpoint illustrates that you move down from **Super** to **Setpoint**. This will help you keep track of where you are in the menu structure.



The Setpoint menu is the same for all the applications so will only be explained once here.

1. From **SuPEr**, press **SELECT** ...

SEtPnt is displayed. Use this to:

- set the function of the setpoint annunciators
- select inputs for up to three inputs
- print the setpoint settings
- reset all setpoint settings to factory defaults.

Annunciators

Setpoint ↓ Edit ↓ Annun

2. Press **SELECT** ...

Edit is displayed.

3. Press **SELECT** ...

Annun is displayed. This stands for annunciators, referring to the *SP1*, *SP2* and *SP3* setpoint annunciators. By default (**oFF**) these annunciators are lit and the associated outputs are on below Setpoint 1 and off above Setpoint 1. If you pick **on**, the associated outputs are on below Setpoint 1 and the annunciators are on above Setpoint 1.

4. Press **SELECT** ...

The current setting is displayed (**oFF** or **on**).

5. Press **PRINT** or **UNITS** to toggle between the choices and when your choice is displayed, press **ZERO** to accept ...

Annun is displayed.

Inputs

Setpoint ↓ Edit ↓ Annun → Inputs

6. Press **UNITS** ...

in1 is displayed. This stands for input 1. Use this to assign a function to input 1 when an external switch is tripped. Default choice is **nonE**. The choices are listed in Figure 7.1. Some may not apply in this application.

7. From **in1**, press **SELECT** ...
The current choice is displayed.
8. Press **PRINT** or **UNITS** to scroll through the choices and when your choice is displayed, press **ZERO** to accept ...
in1 is displayed.
9. Press **UNITS** ...
in2 is displayed.
10. Repeat steps 7 through 9 for **in2** and **in3**. Press **TARE** when finished ...
Edit is displayed.

Print

Setpoint ↓ Edit → Print

11. Press **UNITS** ...
Print is displayed. Use this to print the settings under **SEtPnt**.
12. Press **SELECT** ...
Port 1 is displayed.
13. Press **F1** to abort the print process or press **UNITS** to scroll to the desired port and press **ZERO** to print the information ...
Print is displayed after either action.

Reset

Setpoint ↓ Edit → Print → Reset

14. Press **UNITS** ...
rESEt is displayed. Use this to reset the settings under **Edit** to factory defaults.
15. Press **SELECT** ...
no is displayed.
16. Press **ZERO** to abort the reset or press **UNITS** ...
YES is displayed.
17. Press **ZERO** to reset the settings to factory defaults ...
rESEt is displayed.
18. Press **TARE** ...
SEtPnt is displayed.

7.1.2 Check

Super ↓ Setpoint → Check

1. From **tArE** press **UNITS** ...

chEck is displayed. This is the checkweighing configuration item. Under this you can:

- Set the outputs to be latched or unlatched
- Enable output-gross zero band (out-gZb)
- Set the under and over segment division size
- Reset all the checkweighing items to factory defaults.

Follow the steps below.

Outputs

Check ↓ Outputs

2. From **chEck**, press **SELECT** ...

outPutS is displayed. There are two choices for outputs, **LAtch** and **unLAtch** (default). If you choose **LAtch**, this means that weights will have to stabilize at or above the output value before the relay or annunciator changes. If you choose **unLAtch**, the relay and annunciator will change instantly as the weight swings above and below the output value.

3. From **outPutS**, press **SELECT** ...

The current choice is displayed.

4. Press **PRINT** or **UNITS** to toggle between the choices and when your choice is displayed, press **ZERO** to accept ...

outPutS is displayed.

Output-gross zero band

Check ↓ Outputs → Out-gzb

5. Press **UNITS** to go to the next menu item ...

out-gZb is displayed. This stands for output-gross zero band. You can set outputs to **on** (default) while the weight is in the gross zero band or set them to **oFF** while the weight is in the gross zero band.

6. Press **SELECT** ...

The current choice is displayed.

7. Press **PRINT** or **UNITS** to toggle between the choices and when your choice is displayed, press **ZERO** to accept ...

out-gZb is displayed.

Under segment division

Check ↓ Outputs → Out-gzb → USegDiv

8. Press **UNITS** to go to the next menu item ...

uSEgdiV is displayed. This stands for under-segment division size. Choose how many divisions are equal to one segment on the *UNDER* display bargraph. You can key in a value from 1 to 1000 divisions per segment.

9. Press **SELECT** ...

The current value is displayed.

10. Key in a new value and press **ZERO** to accept ...

uSEgdiV is displayed.

Over segment division

Check ↓ Outputs → Out-gzb → USegDiv → OSegDiv

11. Press **UNITS** to go to the next menu item ...

oSEgdiV is displayed. This stands for over-segment division size. Choose how many divisions are equal to one segment on the *OVER* display bargraph. You can key in a value from 1 to 1000 divisions per segment.

12. Press **SELECT** ...

The current value is displayed.

13. Key in a new value and press **ZERO** to accept ...

oSEgdiV is displayed.

Reset

Check ↓ Outputs → Out-gzb → USegDiv → OSegDiv → Reset

14. Press **UNITS** to go to the next menu item ...

rESet is displayed. Use this to reset the factory defaults for the checkweighing parameters.

15. Press **SELECT** ...

no is displayed. This is the default value.

16. Press **ZERO** to abort the reset or, to reset the defaults, press **UNITS** ...

YES is displayed. Accepting this will reset the defaults.

17. Press **ZERO** to accept ...

The defaults are reset and **rESet** is displayed.

18. Press **TARE** ...

chEcK is displayed.

7.1.3 Battery

Super ↓ Setpoint → Tare → Battery



The Battery menu is the same for all the applications so will only be explained once here.

1. Press **UNITS** to go to the next menu item ...

bAttErY is displayed. Use this to enable the battery and to set a timeout length (in minutes). If this time expires with no scale or keypad activity, the battery will be shut off.

Enable

Battery ↓ Enable

2. Press **SELECT** ...

EnAbLE is displayed. Choices are **OFF** (default) and **on**. Choose **OFF** to disable battery usage. Choose **on** to enable battery usage.

3. Press **PRINT** or **UNITS** to toggle between the choices and when your choice is displayed, press **ZERO** to accept ...

EnAbLE is displayed.



*Only enable the battery and set the **tMout** value if the ZQ-BAT option is being used. If battery use is enabled, setpoint output 3 cannot be used for setpoints in checkweighing or batching applications. It is used as a shutoff signal to the ZQ-BAT battery option.*

Timeout

Battery ↓ Enable → Timeout

4. Press **UNITS** to go to the next menu item ...

tMout is displayed. Use this to set the length of time before inactivity on the scale and keypad cause battery power to be shutoff. Values between 1 and 3600 minutes are valid. Default value is 60 minutes.

5. Press **SELECT** ...

A numeric entry screen appears.

6. Use the *Numeric entry procedure on page 19* to key in a value, in minutes and press **ZERO** to accept ...

tMout is displayed.

7. This completes the Supervisor menu for the Sim375 application. Repeatedly press **TARE** to return to normal operating mode.

7.2 Supervisor menu for Mid375 application

This section applies if the Mid375 application is active. The Mid375 Supervisor menu is shown in Figure 7.1.




Figure 7.2 Mid375 Supervisor menu

Follow these steps to use the Supervisor menu:

Access the Supervisor menu (password 1793). See *Accessing the menus* on page 42.

7.2.1 Setpoint

Super ↓ Setpoint

The Setpoint menu is the same in all the applications. See *Setpoint on page 57*.

7.2.2 Tare

Super ↓ Setpoint → Tare



The Tare menu is the same in any application that it appears so will only be explained once here. It appears only if Preset Tare is configured in a password protected menu.

1. From **SEtPnt** press **UNITS ...**

tArE is displayed.

Use this to:

- set values for up to 10 preset tares
- print the values of the preset tares
- reset all preset tares to factory defaults of 0

The following steps describe the procedures.

Tare Register 1-10

Tare ↓ Edit ↓ Tare 1-10

2. Press **SELECT ...**

Edit is displayed.

3. Press **SELECT ...**

tArE 1 is displayed. This is the first of the 10 preset tare values you can set.

4. Press **SELECT ...**

The current value is displayed with a flashing right digit.

5. Press **ZERO** to accept the displayed value or key in a new value and press **ZERO** to accept ...

tArE 1 is displayed.

6. Press **UNITS ...**

tArE 2 is displayed.

7. Repeat steps 4 through 6 for **tArE 2** through **tArE 10**. Press **TARE** when finished ...

Edit is displayed.

Printing

Tare ↓ Edit → Print

8. Press **UNITS** ...
Print is displayed. Use this to print the preset tare values.
9. Press **SELECT** ...
Port 1 is displayed.
10. Press **F1** to abort the print process or press **UNITS** to scroll to the desired port and press **ZERO** to print the information ...
Print is displayed after either action.

Reset

Tare ↓ Edit → Print → Reset

11. Press **UNITS** ...
rESet is displayed. Use this to reset all the preset tares to the factory default of 0.
12. Press **SELECT** ...
no is displayed. *no* is the default.
13. Press **ZERO** to abort the reset or press **UNITS** ...
YES is displayed.
14. Press **ZERO** to reset the settings to factory defaults ...
rESet is displayed.
15. Press **TARE** ...
tArE is displayed.

7.2.3 Check

Super ↓ Setpoint → Tare → Check

1. From *tArE* press **UNITS** ...
chEcK is displayed. This is the checkweighing configuration item. Under this you can:
 - Set the outputs to be latched or unlatched
 - Enable outputs on or off in gross zero band
 - Set the under and over segment division size
 - Turn weight digits on or off during checkweighing
 - Set the type of checkweighing: Limits or Sample
 - Reset all the checkweighing items to factory defaults.Follow the steps below.

Outputs

Check ↓ Outputs

- From **chEck**, press **SELECT ...**

outPutS is displayed. There are two choices for outputs, **LAtch** and **unLAtch** (default). If you choose **LAtch**, this means that weights will have to stabilize at or above the output value before the relay or annunciator changes. If you choose **unLAtch**, the relay and annunciator will change instantly as the weight swings above and below the output value.

- From **outPutS**, press **SELECT ...**

The current choice is displayed, **LAtch** or **unLAtch**.

- Press **PRINT** or **UNITS** to toggle between the choices and when your choice is displayed, press **ZERO** to accept ...

outPutS is displayed.

Output-gross zero band

Check ↓ Outputs → Out-gzb

- Press **UNITS** to go to the next menu item ...

out-gZb is displayed. This stands for output-gross zero band. You can set outputs to **on** (default) while the weight is in the gross zero band or set them to **oFF** while the weight is in the gross zero band.

- Press **SELECT ...**

The current choice is displayed.

- Press **PRINT** or **UNITS** to toggle between the choices and when your choice is displayed, press **ZERO** to accept ...

out-gZb is displayed.

Under segment division

Check ↓ Outputs → Out-gzb → USegDiv

- Press **UNITS** to go to the next menu item ...

uSEgdiV is displayed. This stands for under-segment division size. Choose how many divisions are equal to one segment on the **UNDER** display bargraph. You can key in a value from 1 to 1000 divisions per segment. 1 is the default value.

- Press **SELECT ...**

The current value is displayed.

- Key in a new value and press **ZERO** to accept ...

uSEgdiV is displayed.

Over segment division

Check ↓ Outputs → Out-gzb → USegDiv → OSegDiv

11. Press **UNITS** to go to the next menu item ...

oSEgdiV is displayed. This stands for over-segment division size. Choose how many divisions are equal to one segment on the *OVER* display bargraph. You can key in a value from 1 to 1000 divisions per segment. 1 is the default value.

12. Press **SELECT** ...

The current value is displayed.

13. Key in a new value and press **ZERO** to accept ...

oSEgdiV is displayed.

Digits

Check ↓ Outputs → Out-gzb → USegDiv → OSegDiv → Digits

14. Press **UNITS** to go to the next menu item ...

digitS is displayed. Use this to turn the weight display **oFF** or **on** (default) when in checkweighing mode. When set to **oFF** the bargraph is the only part of the display that is on.

15. Press **SELECT** ...

The current choice is displayed.

16. Press **PRINT** or **UNITS** to toggle between the choices and when your choice is displayed, press **ZERO** to accept ...

digitS is displayed.

Type

Check ↓ Outputs → Out-gzb → USegDiv → OSegDiv → Digits → Type

17. Press **UNITS** to go to the next menu item ...

TYPE is displayed. Use this to choose which type of checkweighing you want to do: **SAMPLE** or **LiMitS**.

Select **SAMPLE** mode (default) if you want to enter the Toler-Hi and Toler-Lo and target weight in the PLU editor.

Select **LiMitS** if you want to enter the targ-lo and targ-hi and target values.

18. Press **SELECT** ...

The current choice is displayed.

19. Press **PRINT** or **UNITS** to toggle between the choices and when your choice is displayed, press **ZERO** to accept ...

TYPE is displayed.

Auto Tare

Check ↓ Outputs → Out-gzb → USegDiv → OSegDiv → Digits → Type → A-tare

20. Press **UNITS** to go to the next menu item ...

A-tArE is displayed. Use this to disable or enable (**oFF** (default) or **on**) an auto tare when the target weight is reached. This allows you to add items to a box or pallet and auto-tare the weight of each item if it falls in the target range.

21. Press **SELECT** ...

The current choice is displayed.

22. Press **PRINT** or **UNITS** to toggle between the choices and when your choice is displayed, press **ZERO** to accept ...

A-tArE is displayed.

Reset

Check ↓ Outputs → Out-gzb → USegDiv → OSegDiv → Digits → Type → A-tare → Reset

23. Press **UNITS** to go to the next menu item ...

rESEt is displayed. Use this to reset the factory defaults for the checkweighing parameters.

24. Press **SELECT** ...

no is displayed. This is the default value.

25. Press **ZERO** to abort the reset or, to reset the defaults, press **UNITS** ...

YES is displayed. Accepting this will reset the defaults.

26. Press **ZERO** to accept ...

The defaults are reset and **rESEt** is displayed.

27. Press **TARE** ...

chEcK is displayed.

7.2.4 Battery

Super ↓ Setpoint → Tare → Check → Battery

The Battery menu is the same in all the applications. See *Battery on page 61*.

This completes the Supervisor menu for the Mid375 application. Repeatedly press **TARE** to return to normal operating mode.

7.3 Supervisor menu for Adv375 application

This section applies if the Adv375 application is active. The Supervisor menu is shown in Figure 7.3.




Figure 7.3 Supervisor menu for Adv375 applications

Follow these steps to use the Supervisor menu:

Access the Supervisor menu (password 1793). See *Accessing the menus on page 42*.

7.3.1 Setpoint

Super ↓ Setpoint

The Setpoint menu is the same in all the applications. See *Setpoint on page 57*.

7.3.2 Tare

Super ↓ Setpoint → Tare

The Tare menu is the same in all the applications. See *Tare on page 63*.

7.3.3 Check

Super ↓ Setpoint → Tare → Check

1. From **SEtPoint** press **UNITS** ...

chEcK is displayed. This is the checkweighing configuration item. Under this you can:

- Set the outputs to be latched or unlatched
- Enable outputs on or off in gross zero band
- Set the under and over segment division size
- Enable/disable printing of the total in a packrun
- Choose the total print format number
- Enable/disable clearing the total after a packrun
- Turn weight digits on or off during checkweighing
- Enable/disable Standard Deviation calculation on a packrun
- Choose the number of weighments in a packrun
- Set the type of checkweighing: Limits or Sample
- Enable/disable auto tare when target weight is reached
- Reset all the checkweighing items to factory defaults.

Follow the steps below.

Outputs

Check ↓ Outputs

2. From **chEcK**, press **SELECT** ...

outPutS is displayed. There are two choices for outputs, **LA**tch and **unLA**tch (default). If you choose **LA**tch, this means that weights will have to stabilize at or above the output value before the relay or annunciator changes. If you choose **unLA**tch, the relay and annunciator will change instantly as the weight swings above and below the output value.

3. From **outPutS**, press **SELECT** ...

The current choice is displayed, **LA**tch or **unLA**tch.

4. Press **PRINT** or **UNITS** to toggle between the choices and when your choice is displayed, press **ZERO** to accept ...

outPutS is displayed.

Outputs-gross zero band

Check ↓ Outputs → Out-gzb

5. Press **UNITS** to go to the next menu item ...

out-gZb is displayed. This stands for output-gross zero band. You can set outputs to **on** (default) while the weight is in the gross zero band or set them to **oFF** while the weight is in the gross zero band.
6. Press **SELECT** ...

The current choice is displayed.
7. Press **PRINT** or **UNITS** to toggle between the choices and when your choice is displayed, press **ZERO** to accept ...

out-gZb is displayed.

Under segment division

Check ↓ Outputs → Out-gzb → USegDiv

8. Press **UNITS** to go to the next menu item ...

uSEgdiV is displayed. This stands for under-segment division size. Choose how many divisions are equal to one segment on the **UNDER** display bargraph. You can key in a value from 1 to 1000 divisions per segment. 1 is the default value.
9. Press **SELECT** ...

The current value is displayed.
10. Key in a new value and press **ZERO** to accept ...

uSEgdiV is displayed.

Over segment division

Check ↓ Outputs → Out-gzb → USegDiv → OSegDiv

11. Press **UNITS** to go to the next menu item ...

oSEgdiV is displayed. This stands for over-segment division size. Choose how many divisions are equal to one segment on the **OVER** display bargraph. You can key in a value from 1 to 1000 divisions per segment. 1 is the default value.
12. Press **SELECT** ...

The current value is displayed.
13. Key in a new value and press **ZERO** to accept ...

oSEgdiV is displayed.

Print total

Check ↓ Outputs → Out-gzb → USegDiv → OSegDiv → Prt tot

14. Press
- UNITS**
- to go to the next menu item ...

Prt tot is displayed. Use this to enable/disable printing of the total packrun information. Choose **on** (default) to enable and **OFF** to disable this function.

15. Press
- SELECT**
- ...

The current choice is displayed.

16. Press
- PRINT**
- or
- UNITS**
- to toggle between the choices and when your choice is displayed, press
- ZERO**
- to accept ...

Prt tot is displayed.

Total format

Check ↓ Outputs → Out-gzb → USegDiv → OSegDiv → Prt tot → Tot Fmt

17. Press
- UNITS**
- to go to the next menu item ...

tot Fmt is displayed. Use this to choose a print format for the Total report of the packrun.

18. Press
- SELECT**
- ...

The current print format number is displayed.

19. Press
- ZERO**
- to accept this or use the
- Numeric entry procedure on page 19*
- to enter a new print format number and press
- ZERO**
- to accept ...

tot Fmt is displayed.

Clear total

Check ↓ Outputs → Out-gzb → USegDiv → OSegDiv → Prt tot → Tot Fmt → Clr Tot

20. Press
- UNITS**
- to go to the next menu item ...

cLr tot is displayed. Use this to enable or disable the clearing of the total packrun information. Choose **on** (default) to enable and **OFF** to disable the clearing of the information.

21. Press
- SELECT**
- ...

The current choice is displayed.

22. Press
- PRINT**
- or
- UNITS**
- to toggle between the choices and when your choice is displayed, press
- ZERO**
- to accept ...

cLr tot is displayed.

Digits

Check ↓ Outputs → Out-gzb → USegDiv → OSegDiv → Prt tot → Tot Fmt
→ Clr Tot → Digits

23. Press **UNITS** to go to the next menu item ...

digitS is displayed. Use this to turn the weight display **on** (default) or **oFF** when in checkweighing mode. When set to **oFF** the bargraph is the only part of the display that is on.

24. Press **SELECT** ...

The current choice is displayed.

25. Press **PRINT** or **UNITS** to toggle between the choices and when your choice is displayed, press **ZERO** to accept ...

digitS is displayed.

Stats

Check ↓ Outputs → Out-gzb → USegDiv → OSegDiv → Prt tot → Tot Fmt
→ Clr Tot → Digits → Stats

26. Press **UNITS** to go to the next menu item ...

StAtS is displayed. Use this to enable or disable the standard deviation statistical program, the X-Bar/R program or to turn **StAtS** off.

If you choose **Std dEV**, the standard deviation will be calculated after a packrun is complete.

If you choose **X bAr**, the trend of the last eight weighments will be reported in a printout. For more information see *X-Bar/R Program on page 36*

If you choose **oFF**, no statistical information will be calculated. This is the default choice.

27. Press **SELECT** ...

The current choice is displayed.

28. Press **PRINT** or **UNITS** to toggle between the choices and when your choice is displayed, press **ZERO** to accept ...

StAtS is displayed.

Packrun

Check ↓ Outputs → Out-gzb → USegDiv → OSegDiv → Prt tot → Tot Fmt
→ Clr Tot → Digits → Stats → Packrun

29. Press **UNITS** to go to the next menu item ...

PACkRun is displayed. Use this to set the number of items in the packrun.

30. Press **SELECT** ...

The current packrun number is displayed.

31. Press **ZERO** to accept this or use the *Numeric entry procedure on page 19* to enter a new packrun number and press **ZERO** to accept ...

PACkRun is displayed.

Type

Check ↓ Outputs → Out-gzb → USegDiv → OSegDiv → Prt tot → Tot Fmt
→ Clr Tot → Digits → Stats → Packrun → Type

32. Press **UNITS** to go to the next menu item ...

TYPE is displayed. Use this to choose which type of checkweighing you want to do: **SAMPLE** (default) or **LiMitS**.

Select **SAMPLE** mode (default) if you want to enter the Toler-Hi and Toler-Lo and target weight in the PLU editor.

Select **LiMitS** if you want to enter the targ-lo and targ-hi and target values.

33. Press **SELECT** ...

The current choice is displayed.

34. Press **PRINT** or **UNITS** to toggle between the choices and when your choice is displayed, press **ZERO** to accept ...

TYPE is displayed.

Auto Tare

Check ↓ Outputs → Out-gzb → USegDiv → OSegDiv → Prt tot → Tot Fmt
→ Clr Tot → Digits → Stats → Packrun → Type → A-tare

35. Press **UNITS** to go to the next menu item ...

A-tArE is displayed. Use this to disable or enable (**oFF** (default) or **on**) an auto tare when the target weight is reached. This allows you to add items to a box or pallet and auto-tare the weight of each item if it falls in the target range.

36. Press **SELECT** ...

The current choice is displayed.

37. Press **PRINT** or **UNITS** to toggle between the choices and when your choice is displayed, press **ZERO** to accept ...

A-tArE is displayed.

Reset

Check ↓ Outputs → Out-gzb → USegDiv → OSegDiv → Prt tot → Tot Fmt
→ Clr Tot → Digits → Stats → Packrun → Type → A-tare → Reset

38. Press **UNITS** to go to the next menu item ...

rESEt is displayed. Use this to reset the factory defaults for the checkweighing parameters.

39. Press **SELECT** ...
no is displayed. This is the default value.
40. Press **ZERO** to abort the reset or, to reset the defaults, press **UNITS** ...
YES is displayed. Accepting this will reset the defaults.
41. Press **ZERO** to accept ...
The defaults are reset and **rESEt** is displayed.
42. Press **TARE** ...
chEcK is displayed.

7.3.4 PLU

Super ↓ Setpoint → Tare → Check → Plu

1. Press **UNITS** to go to the next menu item ...
PLu is displayed. This stand for Product Look Up. Use this to edit the PLU list, print the list or reset the PLUs to factory defaults.

PLUs consist of a sequential number as an identifier, a target weight, a target-low weight and a target-high weight.

Edit

PLU ↓ Edit

2. Press **SELECT** ...
Edit is displayed. Use this item to setup the PLU list.
3. Press **SELECT** ...
A numeric entry screen appears with a flashing **0**.
4. Use the *Numeric entry procedure on page 19* to enter the PLU number you wish to create or edit and press **ZERO** to accept ...
tArGEt is displayed. Use this to set the target weight.
5. Press **SELECT** ...
A numeric entry screen appears with a flashing **0**.
6. Use the *Numeric entry procedure on page 19* to enter the target weight and press **ZERO** to accept ...
tArgEt is displayed.
7. Press **UNITS** to go to the next menu item ...
tArgLo is displayed. Use this to set the lowest weight that is still acceptable--the Target Low weight.
8. Press **SELECT** ...
A default value appears with a flashing rightmost digit.

9. Use the *Numeric entry procedure on page 19* to enter the target low weight and press **ZERO** to accept ...
tArgLo is displayed.
10. Press **UNITS** to go to the next menu item ...
tArgHi is displayed. Use this to set the highest weight that is still acceptable--the Target High weight.
11. Press **SELECT** ...
A default value appears with a flashing rightmost digit.
12. Use the *Numeric entry procedure on page 19* to enter the target high weight and press **ZERO** to accept ...
tArgHi is displayed.
13. Press **UNITS** to go to the next menu item ...
tArgHi is displayed. Use this to set the highest weight that is still acceptable--the Target High weight.
14. Press **TARE** ...
Edit is displayed.

Print

PLU ↓ Edit → Print

15. Press **UNITS** to go to the next menu item ...
Print is displayed. Use this to print the PLU information.
16. Press **SELECT** ...
Port 1 is displayed.
17. Press **F1** to abort the print process or press **UNITS** to scroll to the desired port and press **ZERO** to print the information ...
Print is displayed after either action.

Import

PLU ↓ Edit → Print → Import

18. Press **UNITS** ...

iMPort is displayed. Use this to import a .CSV (comma separated value) file of PLU values from a plugged in USB thumbdrive. This will overwrite any existing PLU values.



The USB drive **MUST** be plugged in before you enter the Supervisor menu for the **iMPort** and **EXPort** commands to work. The format of the file is shown below:
PLUNumber, PLUTargLo, PLUTargHi, PLUTolLo, PLUTolHi, PLUTarg, PLUTransCount, PLUGrossAccum, PLUNetAccum, PLUUnderAccum, PLUTargAccum, PLUOverAccum, PLUUnderCount, PLUTargCount, PLUOverCount, PLUPcwt, PLUunits.

19. With **iMPort** displayed, press **SELECT** to import the file ...

buSY and **donE** are briefly displayed as the .CSV file is imported and the old PLU values are overwritten. **iMPort** is displayed when finished.

Export

PLU ↓ Edit → Print → Import → Export

20. Press **UNITS** ...

EXPort is displayed. Use this to export the current PLU settings to a .CSV file in a connected USB thumbdrive.

21. With **EXPort** displayed, press **SELECT** to export the file ...

buSY and **donE** are briefly displayed as the .CSV file is exported to the USB drive. **EXPort** is displayed when finished.

Reset

PLU ↓ Edit → Print → Import → Export → Reset

22. Press **UNITS** ...

rESEt is displayed. Use this to reset the PLUs to factory defaults.

23. Press **SELECT** ...

no is displayed. This is the default choice.

24. With **no** displayed, press **ZERO** to abort the reset action or press **UNITS** to toggle to **YES** and press **ZERO** to reset the information ...

rESEt is displayed after either action.

25. Press **TARE** ...

PLu is displayed.

7.3.5 Battery

Super ↓ Setpoint → Tare → Check → Plu → Battery

The Battery menu is the same in all the applications. See *Battery on page 61*.

This completes the Supervisor menu for the Adv375 application. Repeatedly press **TARE** to return to normal operating mode.

7.4 Supervisor menu for Per375 application

This section applies if the Per375 application is active. The Supervisor menu is shown in Figure 7.4.




Figure 7.4 Supervisor menu for Per375 applications

Access the Supervisor menu (password 1793). See *Accessing the menus* on page 42.

7.4.1 Setpoint

Super ↓ Setpoint

The Setpoint menu is the same in all the applications. See *Setpoint on page 57*.

7.4.2 Tare

Super ↓ Setpoint → Tare

The Tare menu is the same in all the applications. See *Tare on page 63*.

7.4.3 Check

Super ↓ Setpoint → Tare → Check

The Check menu is the same as the Check menu in the Adv375 application with one exception: A-tare (auto tare) is not available in the Per375 application. See *Check on page 69*.

7.4.4 PLU

Super ↓ Setpoint → Tare → Check → Plu

The PLU menu is the same as the PLU menu in the Per375 application. See *PLU on page 74*.

7.4.5 Battery

Super ↓ Setpoint → Tare → Check → Plu → Battery

The Battery menu is the same in all the applications. See *Battery on page 61*.

7.5 Supervisor menu for the Grad375 application

This section applies if the Grad375 application is active. The Grad375 Supervisor menu is shown in Figure 7.5.




Figure 7.5 Supervisor menu for the Grad375 application

7.5.1 Setpoint

Super ↓ Setpoint

The Setpoint menu is the same in all the applications. See *Setpoint* on page 57.

7.5.2 Tare

Super ↓ Setpoint → Tare

The Tare menu is the same in all the applications. See *Tare* on page 63.

7.5.3 Grading

Super ↓ Setpoint → Tare → Grading

Use Grading to set the weight points that define up to 10 weight grades. Follow the process found in *Setting weight grades on page 40*.

7.5.4 Battery

Super ↓ Setpoint → Tare → Grading → Battery

The Battery menu is the same in all the applications. See *Battery on page 61*.

This completes the Supervisor menu for the Grad375 application. Repeatedly press **TARE** to return to normal operating mode.

Avery Weigh-Tronix



Avery Weigh-Tronix USA

1000 Armstrong Dr.

Fairmont MN 56031 USA

Tel:507-238-4461

Fax:507-238-4195

Email: usinfo@awtxglobal.com

www.wtxweb.com

Avery Weigh-Tronix UK

Foundry Lane,

Smethwick, West Midlands,

England B66 2LP

Tel:+44 (0) 8453 66 77 88

Fax: +44 (0)121 224 8183

Email: info@awtxglobal.com

www.averyweigh-tronix.com