GSE Scale Systems

450 Series Programmable Weigh Indicators (PWI)

Technical Reference Manual

Version 3.0

GSE scale systems

Excellence In Weighing Technology

SECTION B Important FCC Compliance Information

This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with this Reference Manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

CABLES: Shielded cables must be used and properly grounded with this equipment to ensure compliance with the Class A FCC limits

WARNING: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

B

List of Figures

Figure 1-1 Model 450 Indicator.....1-1
Figure 1-2 Model 455 Indicator.....1-1
Figure 1-3 Front Panel Display.....1-3
Figure 1-4 Model 450 Keyboard.....1-4
Figure 1-5 Model 455 Keyboard.....1-5
Figure 2-1 Standard Model 450 Rear Panel.....2-2
Figure 2-2 Standard Model 450 Mounting Holes/Dimensions.....2-2
Figure 2-3 Model 450 Panel Mount Version Side Dimensions.....2-4
Figure 2-4 Model 450 Panel Mount Version Front Dimensions.....2-4
Figure 2-5 Model 450 Panel Mount Version Cutout Dimensions.....2-5
Figure 2-6 Panel Mount Model 450 series Main Board.....2-6
Figure 2-7 Standard Model 455 Mounting Holes/Dimensions.....2-6
Figure 2-8 Load Cell Connections (PC777).....2-7
Figure 2-9 Load Cell Connections (PC792 and PC800).....2-8
Figure 2-10 Opening the Connector.....2-9
Figure 4-1 Model 450 Keypad Cursor Keys.....4-42
Figure 4-2 Character Listing.....4-42
Figure 4-3 Model 450 Keypad Cursor Keys.....4-42
Figure 5-1 Model 450 Keyboard.....5-1
Figure 5-2 Model 455 Keyboard.....5-3
Figure 5-3 Tare Key.....5-5
Figure 5-4 Select Key.....5-5
Figure 6-1 Model 450 Keypad Cursor Keys.....6-2
Figure 6-2 Character Listing.....6-3
Figure 6-3 Model 455 Keypad Cursor Keys.....6-3
Figure 7-1 Five Point Linearization Graph.....7-5
Figure 7-2 Five Point Linearization Graph (high end).....7-5
Figure 8-1 Model 450 Rear.....8-2
Figure 8-2 Connector.....8-4
Figure 8-3 RS232 Port (J6).....8-4
Figure 9-1 Method of Operation.....9-2
Figure 10-1 Remote Key Connection.....10-2
Figure 12-1 Select Key.....12-1
Figure 14-1 Setpoint Output Connections (J6).....14-4
Figure 14-2 Two-Speed Single Ingredient Fill vs Time.....14-9
Figure 14-3 Two Ingredient Batch vs Time (TARE).....14-18
Figure 14-4 Two Ingredient Batch vs Time (AUTO).....14-18
Figure 14-5 Two-Speed Emptying vs Time (TARE).....14-26
Figure 14-6 Filling and Emptying vs Time (REMOTE).....14-6
Figure 15-1 Relay Contact Protection Circuits.....15-6
Figure 15-2 Option Mounting Dimensions.....15-7
Figure 15-3 Relay Module.....15-8
Figure 16-1 Time/Date Option Installation (PC777C).....16-4
Figure 16-2 Time/Date Option Installation (PC800).....16-4
Figure 17-1 Main Board PC777C.....17-3
Figure 17-2 Main Board PC792B.....17-4
Figure 17-3 Main Board PC800B.....17-5
Figure 17-4 Main Board PC834.....17-6
Figure 18-1 Connector.....18-2
Figure 18-2 RS232 Port (J6).....18-2
Figure 19-1 Model 450 Scanner/Keyboard Adapter Cable.....19-2

Figure 19-2 Model 450 Scanner/Keyboard Cable Wiring Diagram.....19-2
Figure 19-3 Standard Line Printer Cable.....19-3
Figure 19-4 Standard Line Printer Cable Wiring Diagram.....19-3
Figure 19-5 Model 450 Eltron Printer Cable.....19-4
Figure 19-6 Model 450 Eltron Printer Cable Wiring Diagram.....19-4
Figure 19-7 Model 450 to PC/AT Cable.....19-5
Figure 19-8 Model 450 to PC/AT Cable Wiring Diagram.....19-5
Figure 19-9 M450 to PSC Laser Scanner Adapter Cable.....19-6
Figure 19-10 M450 to PSC Laser Scanner Cable Wiring Dia....19-6
Figure 21-1 Main Board PC777C Component Layout.....21-7
Figure 21-2 Main Board PC792B Component Layout.....21-8
Figure 21-3 Main Board PC800B Component Layout.....21-9
Figure 21-4 Main Board PC834 Component Layout.....21-10
Figure 22-1 IBM PC or Compatible Computer.....22-1
Figure 22-2 GSE 450 Simulator Computer Disk.....22-2
Figure 24-1 450 Keypad Cursor Keys.....24-1
Figure 24-2 Character Listing.....24-3
Figure 24-3 455 Keypad Cursor Keys.....24-4
Figure 25-1 450 Remote Display Mode at Power-up.....25-1
Figure 25-2 Parameter Mode to Select Remote Display.....25-1
Figure 25-3 Check Cable if “Check Cable” is Displayed.....25-2
Figure 25-4 Three Part Display Information.....25-2
Figure 25-5 Remote 450 setup to echo the master unit.....25-5
Figure 25-6 Remote 450 setup to continually display net weight..25-6
Figure 25-7 Remote 450 setup with Pass Through Capability.....25-7
Figure 25-8 Remote 450 setup with Addressing Capability.....25-8
Figure 26-1 Model 450i International Keypad.....26-5
Figure C-1 Model 450 Indicator Mounting Holes and Dimensions...C-3
Figure C-2 Model 455 Indicator Mounting Holes and Dimensions...C-4
Figure C-3 Model 450 Panel mount version cutout and dimensions.C-5
Figure E-1 Front/Rear enclosure views, 450 external power.....E-1
Figure E-2 Exploded View 1 M450 external power supply.....E-2
Figure E-3 Exploded View 2 M450 external power supply.....E-3
Figure E-4 Packaging Material M450 external power supply.....E-4
Figure E-5 Front/Rear enclosure views, 450 internal supply.....E-6
Figure E-6 Exploded View 1 M450 internal power supply.....E-7
Figure E-7 Exploded View 2 M450 internal power supply.....E-8
Figure E-8 Packaging Material M450 internal power supply.....E-9
Figure E-9 Front/Side enclosure views 450 panel mount int sup..E-11
Figure E-10 Mechanical/Electrical Interconnect Views M450.....E-12
Figure E-11 Front/Side Views M450 panel mount internal supply...E-14
Figure E-12 Mechanical/Electrical Interconnect Panel Mount.....E-15
Figure E-13 Front/Rear enclosure views of 455 internal supply...E-17
Figure E-14 Exploded View 1 M455 internal supply.....E-18
Figure E-15 Exploded View 2 M455 internal supply.....E-19
Figure E-16 Packaging Material M455 internal supply.....E-20
Figure F-1 Model 450 Main Board (PC777C).....F-1
Figure F-2 Model 450 Main Board (PC792B).....F-5
Figure F-3 Model 450 Main Board (PC800B).....F-9
Figure F-4 Model 455 Main Board (PC834).....F-15

INDEX

A

	page
A/D	21-2
A/D calibration data	21-5
A/D calibration procedure	21-5
A/D conversion rate	C-1
A/D Converter	21-1, 21-5
abort a transmission	4-12
absolute accuracy	7-6
access code (main)	3-1, 4-1, 4-2, 23-1
access code (quick cal)	4-1, 4-3, 7-1, 7-3
accumulation	4-10
accumulation (performing)	13-1, 13-2
accumulation (reset)	13-2
accumulation (setup)	13-1
accumulation count parameter	13-2
accumulation counter	13-2, 20-2
accumulation mode	1-5, 13-1
accumulation operation	10-2, 13-1
accumulation parameters	13-2, 20-2
accumulation registers	13-2
accuracy displayed	27-6
achieved accuracy	27-2, 27-3
activate	14-3, 15-1
additional memory	17-1
addressing capabilities	25-8
adjusting zero	7-2
advanced features	4-1
advanced setup parameters	4-1
aliphatic	2-2, 2-3
alpha character entry	8-5
alpha-numeric	8-7
alpha-numeric code	7-7
alpha-numeric display	3-1
alpha-numeric entry	4-3, 7-7, 8-16, 23-1
alpha-numeric input	3-1, 4-1
alpha-numeric keypad	24-5
alphabetic	4-3
amount of E2 memory	4-36
amount of EEPROM	20-1
Analog/Digital conversion	3-3
application files	22-1
aromatic hydrocarbons	2-2, 2-3
arrow keys	24-3, 24-5
ASCII	1-2, 8-7
ASCII characters	6-2, 8-6, 8-8, 23-1
ASCII codes	8-1, 8-5
ASCII control codes	8-8, D-1
ASCII file	5-2
ASCII Setup File	A-1
ASCII table	D-1
ASCII to hexadecimal	D-1
ASCII to hexadecimal conversion chart	D-1
ASCII transmission	20-7
audit trail	20-1, 20-3
audit trail number	4-36, 20-4
auto-enhance	27-1, 27-2, 27-6
auto tare	5-2, 5-3, 5-5, 11-1, 9-3
auto zero range	C-1
auto-increment	24-5
auto-incrementing registers	8-1, 24-1, 24-2, 24-3
auto-tare	5-2, 5-3, 5-5
auto-tare operation	4-10
automatic zero track	C-1
auxiliary display	5-2
available options	1-3
average piece weight	27-1

B

back EMF	15-2
bad A/D	25-5
basic operations	3-1, 3-2
basic setup	4-1
basic setup parameters	3-1, 3-2, 4-1, 4-2
batch (ingredients)	4-6, 14-1
batching operation	14-17
battery backed time-date option	16-1, 16-2
baud rate	8-1, 21-4, C-1
bi-directional	8-3
bi-directional connections	8-3
bits per second	8-1
board serial number	20-4
both fill and empty	14-1

INDEX

braided shield 2-7, 8-2
buffer 8-5
bytes 17-1

C

Cable Connection Information 8-2
cable connections 2-7, 8-2, 19-1
Cable Options 1-5, 19-1
Cal Reset 7-4
calculated factors 20-7
calculating a specific type of checksum 8-14
calibration 1-2, 4-2, 7-4, 20-5
calibration (establish new zero only) 7-2
calibration (quick cal.) 7-1
calibration (re-cal without est. new zero) 7-2, 7-3
calibration (standard) 7-1
calibration (weight already applied) 7-2
calibration check 7-2
calibration error messages 21-1, 21-3
calibration event counter 20-4
calibration factor 4-1, 7-2, 20-5, 20-6, 20-7
Calibration mode 1-5, 7-1, 7-2, 7-3, 7-4
calibration points 7-5
calibration procedure 7-4, 20-6
Calibration Re-zeroing 7-3
calibration reset 20-6
calibration routine 7-4
calibration selections 7-1
calibration units 4-8, 6-1, 7-3
calibration weight 3-1, 7-2, 7-3, 7-4, 7-5
calibration zero 7-2, 7-3, 7-4
capacity (full scale) 3-2, 3-4, 4-6, 7-2
CE labeling 26-1
center zero 3-1, 5-1, 5-2
center zero condition 1-3
character entry 4-4, 5-4, 6-2, 7-7, 8-16, 23-1, 24-4
character listing 6-2, 8-16
character type 8-15
character width 8-1
check weigh operation 14-1, 14-2, 4-21, 4-33
check weighing 4-21, 4-33, 14-1
check weighing-absolute 14-1
check-sums 8-13, 26-2, 26-3
checksum codes 8-14
checksum format 8-14
clock 4-1, 16-1
coarse gain 4-37, 20-5, 20-6
coarse zero 4-37, 20-5, 20-6, 20-6
coarse zero adjustments
color wiring code 2-8
comm port 4-11, 8-1, 8-3
COMM Port Connections 8-3
comm port handshake 8-3
command language 8-5
common weighing applications 1-2
communication cable connections 8-2, 8-3
communication port C-1
Communication Port Connections 8-3
Communication Protocol 8-1
communications 8-1, 8-2
communications error messages 21-4
Compatible Peripheral Options 1-5
compensation for the coarse gain 4-38
compensation for the coarse zero 4-37, 4-38
compensation of Reference Voltage 4-38
conductor color code 19-1
continuous print 8-14, 8-15
continuous transmits 3-3
control code table 8-9
control codes 8-7, 8-8, 8-9, D-1
control connections (relays) 15-3, 15-5
conversion factor 4-10, 6-1
converted units 6-1
copyright parameter 20-1
correct date 4-17
count-by 4-6, 4-14
counting mode 27-6
CRC's 8-14

current limit 15-1
cursor keys 4-42, 6-2, 6-3
custom configuration 20-4
Custom Transmit 4-3, 4-20, 8-5, 8-6, 8-14
Custom Transmit Setup 4-20, 8-6, 8-8, 8-10
Custom Transmit Table 8-6, 8-7
Custom Transmits 1-4
Custom Units 4-10, 5-1, 6-1

D

data bits 4-11, 8-1
data bits setup 8-1
data buffer 8-5
data field 24-1, 24-5
data registers 24-1, C-1
data stream 8-1
date and time parameters 24-1
date at power up 16-1
date code 4-36
date code software 20-1
date format 8-11
date option 4-3, 16-1, 16-2, 16-3
date parameters 4-3, 16-2
DC or AC power 1-2
de-asserted handshake 21-4
deactivate 14-10, 15-2
dead load 7-2, 21-1
debug 4-1, 20-8
debug mode 20-8
decrementing the transmitted number 8-13
decrementing values 8-13
default parameters 12-1, 20-8
default parameters listing 4-2, A-1
default sample size 27-6
default settings A-1
default unit (factory settings) 4-2, 20-8
delimiters 8-18
diagnostic information parameters 20-3
diagnostic parameters 20-3
dimensions 2-2, 2-4, 2-5, 2-6, C-3, C-4, C-5
disabling the input interpreter 8-17
disassembly 2-2
display 1-3
display update 3-1, 4-8
display update rate 4-8, C-1
displayed resolution C-1
division setup 3-1, 4-1
divisions 3-2
dot matrix 4-3
dot matrix display 1-3, 4-2
double accumulation prevention 13-2
double accumulations 13-2
download and upload 20-7
download setup 20-7
dual range 4-14, 7-8
dual range application 7-8
dual range feature 7-8

E

E2 17-1
E2 memory space 20-1
echo master unit 25-5
EEPROM 17-1, 17-2 20-1, 21-3, 21-4
EEPROM full 17-1
elastomeric C-1
electrical damage 2-5
EMI (electromagnetic interference) 2-3, 2-5, 2-9, 8-2, 8-16, 15-5
emptying operation 4-28, 4-30, 14-1, 14-22, 14-25, 14-29
enable transmissions 8-5
enclosure C-1
enclosure cutout 2-4
End character 4-12
Enter correct time 4-17
entering date 16-1
entering time 16-1
EOS 21-5
eploded views (model 450) E
EPROM 20-1
Epson 8-13
Epson standard 26-2
error count 20-8
error counter 20-8
error messages 20-8, 21-1,

INDEX

21-3, 21-4, 21-5
error occurred 20-8
ESD 2-3, 2-5, 2-9, 8-2, 8-16, 15-5
ESD discharge 21-5
European specific modifications 26-1
excessive loading 21-1
excitation leads 2-7
excitation voltage 2-6
excitation wiring 2-7
expanding a special code 8-7
exploded views E-1
extended codes 8-7, 8-8

F

faulty A/D 25-5
FCC Compliance B-1
FCC Rules B-1
features ` 1-2
FET 15-1
filling / emptying operation 4-30, 14-1
filling and emptying 4-30
filling operation 4-25, 4-30, 14-1, 14-12
filling the buffer 8-1
filter 27-4
filter selections 3-3, 1-1
filtering 3-3
fine calibration 4-37
fine gain 4-37
firmware release 20-1
firmware revision code 20-1
fixed text 8-7
fixed text portion of a transmission 8-7
foil shield 8-2
format codes (parameters) 8-10
front panel E
front panel keys 8-5
full scale 3-4
full scale capacity 3-4, 4-6, 7-1, C-1
full scale load 3-3
full scale mv/V 20-4
functions 5-1
fuse 15-6, C-1
fuse (relays) 15-6

G

gain (coarse) 4-37, 4-38, 20-5, 20-6
gain (fine) 4-37, 4-38, 20-5, 20-6
gain adjust 4-37, 20-6
gasket 2-4
general purpose registers 24-5, 24-6
gross weigh accumulation 4-20
gross weight entry 5-4
Ground 8-3

H

handshake 4-11, 8-1, 8-2, 8-3
handshake output has been de-asserted 8-6
hardware error messages 21-2
hardware problem 21-2
harmful interference B-1
hazardous voltage 2-4, 8-5
holding current 15-5

I

IBM compatible computer 22-1
identification parameters 20-1
inbound truck 9-3
incorrect access code 21-1
increment 21-3
incrementing registers 24-5
incrementing the transmitted number 8-13
incrementing values 8-13
indicator display 3-1
information mode 20-1
Information Mode parameters 7-6
information on memory 20-1
information parameters 20-1
input interpreter 4-3, 4-20,

8- 15, 8-19
instability 3-2
installation 2-1
Instrument gain 7-4
instrument setup 4-1
interface 8-2, 15-3
interference B-1
internal resolution C-1
international 2-3
international characters 4-15, 26-2
international date 16-2

K

key disabling 5-1, 5-5, 11-1
keyboard 1-3, 1-4
keyboard select operation 4-10
keyboard selectable modes 1-4
keyboard tare 5-3, 11-1
keyboard tare operation 4-10
keyed in tare 9-3
keypad 1-4, 1-5
keypad ribbon cable 2-5
keypad type 5-1

L

last sampled amount 27-7
leakage current 15-5
learn mode 14-29
LED 14-23, 15-4
lever connector 2-8
line type 8-15
linear hydrocarbons 2-2, 2-3
linearity 7-6
linearization 1-2, 3-3, 4-3
linearization (enable) 3-3, 4-37, 4-39
linearization data 20-7
linearization data parameters 7-7, 20-7
linearization factor 7-6
linearization process 7-6
load cell connections 2-5, 2-7
load cell current C-1
load cell excitation C-1
load cell leads 2-5
load cell shield 2-8
load cell simulation 22-4
loading in a setup file 22-5
logic output 15-2
logic output operations 15-1, 15-2
low capacitance rated cabling 10-1
low range 7-8
lower-case letters 4-3

M

main board (PCB) 17-3, 17-4, 17-5, 17-6, 21-6, 21-7, 21-8, 21-9
main board serial number 20-1
main boards F-1
master unit 25-1, 25-4
manual 1-1
manual tare entry 4-16
manufactured cables 19-1
manufacturer default code 3-2
maximum enhance amount 27-3
maximum excitation 2-6
maximum specifications C-1
maximum specifications (relays) 15-3
memory expansion 17-1
memory expansion option 1-5, 17-1
memory information parameters 20-1
memory installation 17-1
memory replacement 17-1
memory storage 17-1
memory storage space 17-1
minimum accuracy selections 27-1, 27-2, 27-4
minimum enhanceable piece weight 27-2
minimum width 8-10
mode selection parameters 5-3
model 450 indicator 1-1, 1-2
model type 20-1
model type indication 20-1
modifications 4-2
momentary switch closure 10-1, 10-2
monochrome monitor 22-1
motion 3-2, 4-7
motion (print) 3-2, 4-7
motion delay 3-2, 4-7, 4-12, 8-14

INDEX

mounting 2-2, 2-6
mounting nut 2-8
Multi-Point Linearization 4-8, 4-37, 4-39, 7-5, C-1
multi-point linearization information 20-5
multiple accumulations 13-1
multiple functions 1-4
multiplication factor (units) 6-2

N

namable weight parameters 26-2
name field 24-1
naming parameters 4-17
naming registers 24-1, 24-2
negative numbers 4-10
negative sampling 27-1, 27-2
negative tare 5-4, 21-1
NEMA 4X C-1
NEMA 4X (relays) 15-3
NEMA 4X rating 15-3
net weight accumulation 4-20
NIST 20-3
NIST approved 5-3
NIST H-44 3-2
NIST officials 20-4
NIST standards 20-4
no load 7-2
NO LOAD condition 7-2
nominal specifications C-1
non-battery backed 16-1
non-linear 7-6, C-1
non-numeric characters 4-3, 24-3
non-ratiometric offset 4-38
NOT H-44! 20-3, 20-4
not preset 4-16
NTEP 20-1, 20-2
NTEP compliance 4-16
NTEP conformance 20-4
NTEP parameter 4-3, 13-1
numeric entries 4-2, 5-4, 24-5
numeric field width 8-10
numeric keyboard 1-4, 1-5
Numeric parameter format selections 8-10
numeric parameters 8-10

O

OIML 26-1, 26-2
OIML keypad 26-1
OIML parameter 4-3, 26-1
OIML specifications 4-15
one ingredient emptying 4-28
one ingredient filling 4-23, 4-24, 14-8
one item check weighing 4-33, 14-4
Only Zero? 7-4
open collector type logic outputs 15-2
open drain outputs 15-1
operating mode 4-13, 5-2
operating mode parameters 4-1, 12-1
operating temperature C-1
optically isolated 15-4
optimum shielding 2-8
options 1-1, 18-1
output connections (relays) 15-2, 15-3
over-load 21-1, 26-1

P

packaging material (M450) E-4, E-9, E-20
panel mount 2-3, 2-5
parameter 8-7
parameter download 20-7
parameter listing (complete) 4-6
parameter number 3-1
parameter setup 3-1, 4-1
parameter table 8-8, 8-9
parameter types 4-6, 12-1, 24-2
parameter upload 20-7
parity 4-11, 8-1
parity setup 8-1
part number (tech manual) back cover
parts counting mode 27-1
parts listing E-5, E-10, E-13, E-16, E-21
parts listing (Electrical) F-1
parts listings (Mechanical) E-1
pass through capability 25-7
password 3-1, 4-1, 7-1, 23-1
performing accumulations 4-16, 13-1, 20-2

peripheral devices 8-3
peripheral equipment options 18-1
peripheral options 18-1
permanent mounting 2-1, 2-3
Personal Access 2 3-1
personal identification number (PIN) 4-2, 4-3, 4-15, 23-1
physical 2-5
piece weight 27-7
piece weight x 1000 27-7
piece weight accuracy 27-6
polar solvents 2-2
polycarbonate 2-1
polyethylene foam 2-2
PORON cellular urethane 2-3
post-cal zero mv/V 20-6
power input (AC) C-1
power input (DC) C-1
power module C-1
power-up units 4-9, 6-1, 7-2
pre-act 14-9
pre-named 24-2
pre-setable parameters 11-1, 26-2
preset 4-16, 26-1
preset parameter 4-3
print operation 4-20, 10-2
printers (GSE recommended) 18-1
printing 8-14
printing accumulation parameters 13-2
printing operations 8-14
program jumper 21-2
programmable parameters 4-3
programmed operation mode 1-4
programming code 4-1
programming security 3-1, 4-1
protocol C-1
PTB approved 8-13
punctuation symbols 4-3

Q

quantity 27-7
quantity displayed 27-3
quantity mode 27-1
quantity total 27-7
Quick Cal access code 4-15, 7-7
quick calibration 4-15, 7-6
Quick Calibration Personal Access Code 7-7

R

radio communications B-1
radio frequency B-1
RAM 20-1, 21-3
rated platform 3-2
re-cal (weight already applied) 7-2
re-cal (without establishing new zero) 7-2, 7-3
re-calibration 7-2, 7-4, 7-5
re-zeroing (re-establish zero only) 7-2
rear panel 2-3, E-1
receive buffer 21-4
receive communications 8-5
reference voltage 4-38, 20-6
register type parameters 24-3
registers, naming 24-1
relay contact protection circuits 15-7
relay module option 15-3
relay modules (relays) 15-3
relay output connections 15-3, 15-4,
relay power connections 15-5
relay protection circuits 15-6
remote display 25-1
remote display cascading 25-2
remote display connections 25-5, 25-6, 25-7, 25-8
remote display parameters 25-1
remote display setup 25-1
remote display (remote keys) 25-3
remote key connections 10-1
Remote Key Input 4-3
Remote Key operation 4-20, 10-1
remote keyboard 4-1
remote keypad keys 4-13
remote keys 4-1, 10-1, 25-3
renaming parameters 24-6
reset unit (factory default settings) 4-1, 20-2
resolution 3-2
response time 4-8
RFI 2-3, 2-5, 2-9, 8-2
ring terminal 2-8
round off tare values 4-10
rounding 24-5

INDEX

rounding parameters 24-6
RS-232 communications 8-3, 8-5
RS-232 input 8-3
RS-232 output C-1
RS232 receiver 8-1
rubber boot 2-7

S

sample size 27-1
sampling operation 27-1
schematic drawings 19-2, E-1
sealing design 20-3
sealing method (traditional) 20-3
seconds elapsed 8-13
security code 3-1, 4-2
security seal 20-3
selectable operating mode parameters 4-2, 4-3, 12-1
Selectable Operating modes 24-4
selectable parameters 4-2
selecting a parameter to be transmitted 8-7
selecting the format for the selected parameter 8-7
send setup 20-7
sense leads 2-7
serial number 20-1
service 21-1
setpoint error messages 21-5
setpoint inputs 15-2
setpoint operation 14-3, 15-1
setpoint output connections 15-4
setpoint output specifications 15-2
setpoint outputs 15-4
setpoint parameters 4-1, 15-1
setpoint power connections 15-5
setpoint protection circuits 15-6
setpoint status 14-2, 15-1, 22-6
setpoint target values 24-2
setpoint targets (front panel entry) 12-1, 14-1, 24-4
setpoint window 22-5
setpoints 15-1
Setup mode 1-5, 3-1, 4-2
setup parameter 3-1
setup, advanced 4-1
shield 2-8
shield lead 2-7, 2-8
shield termination 8-5
shielded cables B-1
signal connections 2-7
signal connections (relays) 15-3
signal leads 2-7
signal range C-1
silicon rubber 2-1
simulated input signal 22-4
simulator software (GSE 450 software) 22-1
single ingredient filling operation 4-23
single-speed filling 14-1
sink output 15-4
six lead cables 2-7
software copyright 20-1
software map 4-4
software revision 4-36
software revision code 20-1
Software Security Code 8-6
soldering iron 2-8
special characters 8-7
specifications (450) C-1
spreadsheet application 8-13
stability 3-3
stainless steel enclosure 2-3
Stainless Steel Washdown Enclosure 1-2
standard 450 programs 14-1
standard calibration 7-5, 7-6
standard keypad keys 5-1
Standard Programming Operations 1-2
standard programs 4-3, 14-1
Standard Selectable Programs 4-21
Start character 4-12
status bit 8-19
status parameter 8-13, 8-14, 12-1
stop bits 4-11, 8-1
storage memory 17-1
strain relief (back panel) 2-8
strain relief (relay module) 15-4
strain-gage 2-6
surge current 15-5
switch panel controls C-1
switch panel type C-1
swivel bracket 2-1
swivel stand 1-2
system gain 20-5

T

table top mounting 2-1
tank weighing 5-3, 14-31
tank weighing applications 7-3
tare (auto) 5-2, 5-3, 5-5
tare clear (automatic)
tare negative
tare operation 4-20, 10-3
tare rounding
tare save (power removed)
tare weight
target mode 14-1
target setting 12-1, 14-1
target variables 24-4
Temp Zero? 7-3
terminal block 15-4
terminal connections (comm port) 8-3
terminal connections (remote key) 10-1
terminating character 8-5, 8-15, 8-17, 8-18
test mode parameter 20-7
text (fixed character text) 8-7
Time and Date 1-2
time and date operations 16-1, 16-3
time and date parameter setup 16-2
time date option 4-3, 16-1
time date parameters 4-2, 16-1
time format 8-10, 8-11
time parameter 4-3, 16-1
time stamp 9-2, 9-3
time/date parameter 8-10
transducer excitation 2-6
transmission of current settings 20-7
transmission protocol 4-1
transmissions 8-1
transmit buffer 4-12, 8-1, 8-2, 21-4
transmit communications 8-6
transmit control codes 8-8
transmit fixed (custom) text 8-8
transmit once per weighment 8-1
transmit parameters 8-5
transmit the checksum 8-14, 26-4
transmitted data 8-10
troubleshooting 21-1
Truck I/O 1-6
Truck time register 9-1, 9-2
Truck Weighing 9-1
Truck Mode operation 9-2
TTL 15-2
TTL input 8-3
two ingredient batching 4-25, 14-1, 14-17
two ingredient filling 4-25, 14-4
Two ingredient, single speed 14-4
two speed filling 4-30, 14-1, 14-4
Two-speed, emptying operation 4-28

U

U.S.A. 2-3
umbilical cables 2-5
underload 21-1, 26-1
uni-directional connections 8-3
unit conversion table 6-1
unit resetting (factory defaults) 4-3, 20-8
units (custom) 6-1
units parameter 6-1
units setup 6-1
units, calibration 6-1
UNIX computer standard 16-1
unshielded 8-2
update rates 4-3
upload setup 5-1
upper-case 4-3
utility parameters 4-1, 20-1, 20-8

V

variable parameters 24-2
variables 24-1
voltage level logic circuits 15-1
voltage reference 20-6

W

washdown C-1
weigh platform 2-7, 2-8
weigh units C-1
weighing applications 1-2

INDEX