

Issued September 2001
Replaces 9/99**MODEL 8000 REPLACEMENT PARTS LIST**

<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>LIST PRICE</u>
SUB0206	<u>Main PCB Assembly, 115 VAC</u> Not for use on 8000MIS Intrinsically Safe Indicator - refer to 8000IS Parts List	\$ 440.00
SUB0207	<u>Main PCB Assembly, 230 VAC</u> Not for use on 8000MIS Intrinsically Safe Indicator - refer to 8000IS Parts List	\$ 470.00
DSW0022	<u>Program Memory IC</u> Used on Main PCB; 27C256	\$ 50.00
SUB0042R	<u>Touch Panel</u> Includes sheet of capacity labels; not for use on 8000MIS Intrinsically Safe Indicator - refer to 8000IS Parts List	\$ 85.00
SUB0004-1	<u>Foot Assembly Set</u> Rubber feet; S/S 10-24 x 1 screw, sold in sets of 6 only	\$ 25.00
HDW0042	<u>S/S Foot</u> Sold singly, for 18"x18" & larger bases, 1/2-20 NF Thread	\$ 25.00
SUB0063-1	<u>Power Cord</u> Shielded, 8 ft long, 18/3 SJEOW, with chosorb, connector assembly, and instruction sheet; connector unassembled	\$ 25.00
CNT0019	<u>Liquid-Tite Feed Thru</u> For load cell, power cord & option inputs	\$ 6.00
LBL0082	<u>Capacity Labels</u> Applied to label insert card	\$ 5.00
SWI0042-C	<u>Card, Label Insert</u> Inserted into touch panel pouch on back side	\$ 5.00
FUS0020	<u>Fuse, 1/2 Amp, Slo-Blo, 115 VAC</u> Used on Main PCB Assembly	\$ 3.00
FUS0019	<u>Fuse, 1/4 Amp, Slo-Blo, 230 VAC</u>	\$ 3.00

Issued September 2001
Replaces 9/99**MODEL 8000 REPLACEMENT PARTS LIST**

<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>LIST PRICE</u>
	Used in P/N SUB0207	
SUB0038-3	<u>Battery</u> 3.2 Ah, 6.3 Volt, lead acid, rechargeable, with terminals, wires, RTV	\$ 65.00
XFR0017	<u>Power Transformer, 115 VAC</u> For use on Main PCB	\$ 30.00
XFR0018	<u>Power Transformer, 230 VAC</u> For use on P/N SUB0207	\$ 30.00
SUB0235	<u>Calibration Port Cover Assembly</u> Includes cover, gasket & screws	\$ 15.00
SUB0085-2	<u>Gasket & Screw Set, Rear Panel</u> 24 standard & 4 cross-drilled 8-32 S/S screw with rubber and metal washers; rear panel rubber gasket w/ ESD foil	\$ 35.00
SUB0085	<u>Rubber Gasket, Rear Panel</u> 10" x 6" with ESD foil	\$ 8.00
SUB0211	<u>E Mounting Brackets- <i>*(OLD STYLE)*</i></u> Connects Base to Indicator Same as Option E. If the scale base does not have drilled and tapped holes on the side, this part MUST be used.	\$ 35.00
SUB0455	<u>E Mounting Brackets- <i>*(NEW STYLE)*</i></u> Connects Base to Indicator Same as Option E. If the scale base does have drilled and tapped holes on the side, this part MUST be used.	\$ 35.00
MAN0002	<u>Operator's Manual</u>	\$ 20.00
SUB0042	<u>Case Cover Assembly</u> Touch panel assembled	\$ 175.00
SUB0085-1	<u>Rear Panel Screw Set</u> 24 standard & 4 cross-drilled 8-32	\$ 30.00



Doran Scales, Inc.

www.doranscales.com

1315 Paramount Pkwy. • Batavia, IL 60510 • 630-879-1200 • 800-262-6844 • Fax: 630-879-0073



Issued September 2001
Replaces 9/99

MODEL 8000 REPLACEMENT PARTS LIST

<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>LIST PRICE</u>
	S/S screws with S/S & captive rubber washers.	
ENC0624	<u>"U" Bracket</u> Tilt Stand bracket for 8000M & 8000ISAC case	\$ 35.00
ENC0223	<u>Backplate</u> Rear cover with cord wrap bracket	\$ 65.00
SUB0210-1	<u>Knob, "U" Bracket Adjust</u> One Friction adjust knob with washers	\$ 7.00
LED0016	<u>4 Segment LED, Red</u> - HLCP-E100	\$ 10.00
LED0015	<u>Display LED Red</u> – Price per each	\$ 10.00
SUB0041	<u>Foot Switch</u> Non Washdown - Cable Included	\$ 65.00
MSC0085	<u>Scale Veils For 7000/8000</u>	\$ 12.00/ea.
	(5pcs. or more)	\$ 10.00/ea.