

CONFIDENTIAL DISTRIBUTOR REPLACEMENT PARTS & PRICE SCHEDULE

Floor Scales

ROUGHDECK™ HP, & HP-H


(See Diagram RoughDeck-A)



REF #	PART #	DESCRIPTION	SUGGESTED LIST PRICE
	23126	Junction box board, EL604STA 4-channel	\$140.00
	16960	Operating manual	10.00
1	43612	Junction box, 4-channel signal trim	220.00
2	26087	Flex connector, liquid-tight strain relief	4.00
3	15496	Cable, EL147HE 6-wire	1.80/ft
3	15611	Cable, EL147HE 6-wire, 20'	34.00
4	26320	Junction box tray	15.00
5	14876	Junction box screw	1.00
6	14908	Junction box enclosure screw, flat countersunk	1.00
6	43611	Junction box enclosure screw, panhead	1.00
7	15398	Rubber grommet, load cell cable	1.00
7	15377	Rubber grommet, deck-to-indicator cable	1.00
8	15658	Cable tie mount, 1" square	2.00
9	15631	Cable tie, 3"	1.00
10	15071	Load cell bolt (HP models only)	9.00
11	18756	Foot assembly (HP models only)	45.00
12	21491	Load cell, RL30000-1000 lb (2000 lb models)	295.00
12	21495	Load cell, RL30000-2500 lb (5000 lb models)	295.00
12	21498	Load cell, RL30000-4000 lb (10,000 lb models)	295.00
13	18777	Mounting plate, mild steel (optional) (HP models only)	24.00
13	18778	Mounting plate, stainless steel (optional) (HP models only)	30.00
14	15051	Overload protection screw (Canadian legal-for-trade version of HP model only)	1.00
15	15410	Bubble level (Canadian legal-for-trade version of HP model only)	5.00

Additional Parts for RoughDeck HP-H Heavy Capacity Floor Scales

10	40337	Load cell bolt	12.00
11	39021	Foot assembly, 20K capacity models	82.00
11	39022	Foot assembly, 30K capacity models	125.00
12	21503	Load cell, RL30000-10K	375.00
13	40387	Mounting plate, mild steel, 20K capacity models (optional)	40.00
13	40388	Mounting plate, mild steel, 30K capacity models (optional)	40.00



RoughDeck-A

Prices F.O.B. Rice Lake, Wisconsin • January 1, 2001

© Rice Lake Weighing Systems 2001 • Prices & specifications subject to change without notice


Floor Scales

ROUGHDECK™ SS

(See Diagram RoughDeck-B)



REF #	PART #	DESCRIPTION	SUGGESTED LIST PRICE
	23126	 Junction box board, EL604STA 4-channel	\$140.00
	16960	 Operating manual	10.00
1	21173	 Junction box, NEMA 4X, 4-channel, signal trim	295.00
2	25931	 Junction box faceplate	54.00
3	14877	 Junction box faceplate screw	2.00
4	23090	 Screw	1.00
5	15496	 Cable, EL147HE 6-wire	1.80/ft
5	15611	 Cable, EL147HE 6-wire, 20'	34.00
6	26087	 Flex connector, liquid-tight strain relief	4.00
	15630	 Flex connector nut	2.00
7	15669	 Cable grip	3.00
8	15658	 Cable tie mount, 1" square	2.00
9	15631	 Cable tie, 3"	1.00
10	15075	 Load cell screw	13.00
11	18756	 Foot assembly	45.00
12	30649	 Load cell, RL35023S-N5 1000 lb (2000 lb models)	365.00
12	30651	 Load cell, RL35023S-N5 2500 lb (5000 lb models)	365.00
12	30652	 Load cell, RL35023S-N5 4000 lb (10,000 lb models)	365.00
13	18777	 Mounting plate, mild steel (optional)	24.00
13	18778	 Mounting plate, stainless steel (optional)	30.00



RoughDeck-B

Floor Scales


ROUGHDECK™ HE

(See Diagram RoughDeck-C)



REF #	PART #	DESCRIPTION	SUGGESTED LIST PRICE
	23126	 Junction box board, EL604STA 4-channel	\$140.00
	16960	 Operating manual	10.00
1	21173	 Junction box, NEMA 4X, 4-channel signal trim	295.00
2	15496	 Cable, EL147HE 6-wire	1.80/ft
2	15611	 Cable, EL147HE 6-wire, 20'	34.00
3	15658	 Cable tie mount, 1" square	2.00
4	15631	 Cable tie, 3"	1.00
5	15075	 Load cell screw	13.00
6	18756	 Foot assembly	45.00
7	31283	 Load cell, RL35082-N5 1000 lb (2000 lb models)	425.00
7	31282	 Load cell, RL35082-N5 2500 lb (5000 lb models)	425.00
7	31281	 Load cell, RL35082-N5 4000 lb (10,000 lb models)	425.00
8	18777	 Mounting plate, mild steel (optional)	24.00
8	18778	 Mounting plate, stainless steel (optional)	30.00

Note: Older style non-NTEP certified HE Series decks are equipped with RL39523 series load cells and are not electronically compatible with the RL35082 series load cells listed above. Consult your current Load Cell Product Selection Guide for replacement RL39523 load cells.



RoughDeck-C

Floor Scales


Floor Scales

AUTOLIFT HE

(See Diagram AutoLift HE-A)



REF #	PART #	DESCRIPTION	SUGGESTED LIST PRICE
1	23127	 Junction box, NEMA 4X, 4-channel, signal trim	\$220.00
2	15611	 Cable, 6-wire, junction box to indicator	34.00
3	16141	 Cable ties, 8" (at back of assembly)	1.00
4	15075	 Load cell screw	13.00
5	18756	 Foot assembly	45.00
6	31283	 Load cell, (2000 lb capacity)	425.00
6	31282	 Load cell, (5000 lb capacity)	425.00
6	31281	 Load cell, (10,000 lb capacity)	425.00



AutoLift HE-A

Floor Scales


Floor Scales

AutoLift HE (Cont.)

Pneumatic Control Box

(See Diagram AutoLift HE-B)

REF #	PART #	DESCRIPTION	SUGGESTED LIST PRICE
5	42282	 Fitting, 1/8" female, straight to 5/16" tubing	\$13.00
6	42281	 Adjustable flow control valve	38.00
7	42268	 Brass nipple, 1/8" NPT 3/4", closed	2.00
8	42280	 Valve adaptor, push-button	14.00
9	42279	 Push button actuator, key operated, 30mm diameter	105.00
11	42277	 Control valve, 3-way spool	42.00
12	42276	 Brass nipple, 1/8" NPT x 2"	3.00
13	42275	 Fitting, 1/8" male, straight to 5/16" tubing	9.00
14	42274	 Check valve, poppet type	19.00
15	42273	 Fitting, 1/8" male elbow, 90° to 5/16" tubing	11.00
16	42272	 Adjustable flow control valve	38.00
17	42271	 Fitting, 1/8" NPT bulkhead	7.00
18	42270	 Muffler, 1/8" NPT porous metal	5.00
22	15631	 Cable tie, 3" nylon	1.00



AutoLift HE-B


Floor Scales

AutoLift HE (Cont.)

Pneumatic Lift Scale

(See Diagram AutoLift HE-C)

REF #	PART #	DESCRIPTION	SUGGESTED LIST PRICE
	42267	 Air filter/regulator and lubricator w/semi automatic drain	\$275.00
	44141	 Operating manual	25.00
1	41936	 Pit coping WLDT, 4' x 4'	995.00
1	41937	 Pit coping WLDT, 5' x 5'	1,195.00
3	42261	 Exhaust muffler/filter	9.00
5	42265	 Air cylinder, 5' x 5'	1,497.00
5	42266	 Air cylinder, 4' x 4'	1,350.00
7	42263	 Rod clevis, nut & cotter pins	118.00
8	42310	 Clevis pin	5.00
9	35356	 Cotter pin	2.50



AutoLift HE-C

Floor Scales

ROUGHDECK™ BPS



RoughDeck BPS-A1K



RoughDeck BPS-D1K


Mild Steel Construction

(See Diagram RoughDeck BPS-A)

REF #	PART #	DESCRIPTION	SUGGESTED LIST PRICE
	43612	Junction box, standard, 4-channel, signal trim	\$220.00
	18777	Mounting plates, set of two (optional)	24.00
	19352	Stand alone (floor mount) indicator stand, mild steel	195.00
	23126	Junction box board, EL604STA 4-channel	140.00
	28082	Operating manual	10.00
1	16024	Junction box enclosure	36.00
2	26320	Junction box tray	15.00
3	14876	Junction box tray screw	1.00
6	14908	Junction box enclosure screw, flat countersunk	1.00
6	43611	Junction box enclosure screw, panhead	1.00
5	15496	Cable, EL147HE 6-wire	1.80/ft
5	15611	Cable, EL147HE 6-wire, 20'	34.00
6	26087	Flex connector, liquid-tight strain relief	4.00
	15630	Flex connector nut	2.00
7	21491	Load cell, RL30000 (1000 lb model)	295.00
8	15071	Load cell screw	9.00
9	18756	Foot assembly	45.00

Additional Parts for Portable Mild Steel Model

10	28001	Column mount for indicator	237.00
11	16141	Cable tie	1.00
12	15019	Screw, cap	1.00
13	28096	Plunger clamp	71.00
14	44306	Adaptor	5.00
15	28095	Caster assembly	30.00
16	21938	Washer	1.00
17	15159	Lock washer	1.00
18	14743	Bolt	0.25



RoughDeck BPS-A

Note: Wheel assemblies, wheel mounts and indicator stand shown as reference for portable models; not offered as additional parts for standard models.

Floor Scales

RoughDeck™ BPS (Cont.)


Stainless Steel & HE Construction

(See Diagram RoughDeck BPS-B)

REF #	PART #	DESCRIPTION	SUGGESTED LIST PRICE
	23126	Junction box board, EL604STA 4-channel	\$140.00
	18778	Mounting plates, set of two (optional)	30.00
	28740	Stand alone (floor mount) indicator stand, stainless steel	295.00
	28082	Operating manual	10.00
1	21173	Junction box, NEMA 4X, 4-channel, signal trim	295.00
2	25931	Junction box faceplate	54.00
3	14877	Junction box faceplate screw	2.00
4	25930	Screw	1.00
5	15496	Cable, EL147HE 6-wire	1.80/ft
5	15611	Cable, EL147HE 6-wire, 20'	34.00
6	26087	Flex connector, liquid-tight strain relief	4.00
	15630	Flex connector nut	2.00
7	15669	Cable grip	3.00
8	17189	Load cell, RL39123SS (1000 lb SS models)	350.00
8	17252	Load cell, RL35083 (1000 lb HE models)	405.00
9	15075	Load cell screw	13.00
10	18756	Foot assembly	45.00

Additional Parts for Portable Stainless Steel & HE Models

11	28002	Column mount for indicator	294.00
12	16141	Cable tie	1.00
13 & 17	15020	Screw, cap (bolt for column mount & plunger)	1.00
14	36927	Plunger clamp	184.00
15	36926	Caster assembly	69.00
16	15160	Lock washer	4.00
18	44306	Spacer	5.00
19	15161	Washer, 3/8 SST	1.00




RoughDeck BPS-B

Floor Scales

ROUGHDECK™ QC QUICK CLEAN STAINLESS STEEL FLOOR SCALE (See Diagram RoughDeck QC-A)



REF #	PART #	DESCRIPTION	SUGGESTED LIST PRICE
	21173	 RoughDeck 4-channel j-box	295.00
7	47714	 Retaining ring, 5/16 shaft	2.00
17	47715	 Hinge pin, 5/16 diameter	4.00
18	47718	 Safety latch	24.00
19	14994	 Cap screw, 5/16-24NF x 1	1.00
20	47711	 Cap screw, 5/16-18NC x 1 3/4	1.00
21	47690	 Gas spring, 20" extended	200.00
22	15233	 Cotter pin, 1/8 x 3/4	1.00
23	47712	 Clevis pin, 5/16 x 11/2	2.00
24	14634	 Lock nut, 1/4-20NC hex	1.00
25	35088	 Cap screw, 1/4-20NC x 1 hex	1.00
26	40044	 Blank trigger spring	1.00
27	48682	 Corner lock subassembly	6.65
28	47691	 Corner lock knob, SST	15.00
29	52517	 Cotter pin, 1/16 x 1	2.00
30	47713	 Retaining ring, 1/2" shaft.....	2.00
32	31283	 Load cell, RL35082-1K (2K scales)	425.00
32	31282	 Load cell, RL35082-2.5K (5K scales)	425.00
32	31281	 Load cell, RL35082-4K (10K scales)	425.00



RoughDeck QC-A

Floor Scales


Floor Scales

ALTRALITETM

(See Diagram Altralite-A)



REF #	PART #	DESCRIPTION	SUGGESTED LIST PRICE
	22290	 Operating manual	5.00
1	21172	 Junction box, 4-channel, signal trim	\$220.00
2	15398	 Rubber grommet, load cell cable	1.00
3	15377	 Rubber grommet, deck-to-indicator cable	1.00
4	14876	 Junction box tray screw	1.00
5	26320	 Junction box tray	15.00
6	14908	 Junction box enclosure screw	1.00
7	15496	 Cable, EL147HE 6-wire	1.80/ft
7	15611	 Cable, EL147HE 6-wire, 20'	34.00
8	15658	 Cable tie mount, 1" square	2.00
9	15631	 Cable tie, 3"	1.00
10	15071	 Load cell screw	9.00
11	18756	 Foot assembly	45.00
12	21491	 Load cell, RL30000-1000 lb (2000 lb model)	295.00
12	21495	 Load cell, RL30000-2500 lb (5000 lb model)	295.00
13	17758	 Load cell shim	8.00
14	15671	 Cord grip, interface cable	3.00



Altralite-A

Floor Scales

CONFIDENTIAL DISTRIBUTOR REPLACEMENT PARTS & PRICE SCHEDULE

Floor Scales

DECKHAND™ PORTABLE SCALE




Mild Steel

(See Diagram DeckHand)

REF #	PART #	DESCRIPTION	SUGGESTED LIST PRICE
1	15494	Cable, 4-conductor, 3.5'	\$1.35
2	41011	Mount, indicator (for 310A, IQ plus 390-DC, 510, 710 & 800) ...	50.00
3	15398	Grommet, rubber 1/2 x 1/4	1.00
4	15145	Flat washer, 1/4	.50
5	14965	Cap screw, 1/4-20NC x 3/4	2.00
6	40986	Upper platter (DH-500, DH-1000)	300.00
6	42654	Upper platter (DH-2000)	350.00
7	14996	Cap screw, 5/16-18NC x 1	.50
8	41002	Load cell channels (DH-500, DH-1000)	65.00
8	42664	Load cell channels (DH-2000)	80.00
9	21939	Flat washer, 5/16	1.00
10	14646	Locknut, 5/16-18NC, hex	1.00
11	41003	Shim, load cell	13.00
12	41024	Load cell, RL1260-250 kg (500 lb)	310.00
12	41026	Load cell, RL1260-500 kg (1000 lb)	310.00
12	41027	Load cell, RL1260-35 kg (2000 lb)	310.00
13	40983	Base platform (DH-500, DH-1000)	375.00
13	42616	Base platform (DH-2000)	425.00
14	26667	Cap screws, 5/16-18NC x 1	.15
15	14989	Overload stop set screw, 5/16 x 18NC x 1/2	1.00
16	41004	Base shim, ramp end	9.00
17	41267	Scale base bumper, 3/4	4.00
18	14964	Cap screw, 1/4-20NC x 3/4	.25
19	15153	Lock washer, 5/16	1.00
22	15658	Cable tie mount	2.00
23	15631	Cable tie, 3"	1.00
25	40181	Locknut, 5/8-11NC	1.00
26	41268	Wheel, 10" diameter x 5/8 bore	35.00
27	41005	Axle, 5/8-11 x 6	28.00
28	14676	Jam nut, 5/8-11NC	.25
29	41266	Handle grip, 3/4 I.D.	6.00
30	40987	Mast, 57-13/16 x 15	460.00
31	15147	Lock washer, 1/4	1.00
32	14641	Hex nut, 1/4-20NC	1.00
35	43612	Junction box, 4-channel	220.00
36	21938	Flat washer, 3/8	1.00
37	15159	Lock washer, 3/8	1.00
38	14656	Hex nut, 3/8-16NC	.60
39	41108	Dampener strip, ramp stop	12.00
40	14908	Cap screw, 10-32NF x 3/4	1.00
41	41254	Cap screw, 3/8-16NC x 6	1.00
42	44130	Bubble level plate	13.00
43	15410	Bubble level	5.00
44	44127	Compression spring, 0.041	3.00
45	14941	Cap screw, 10-32NF x 1	1.00
46	44149	Bumper cushion, self-adhesive	25.00
50	15176	Nylon washer, 5/8	3.00
51	46259	Column back plate	100.00
52	14932	Cap screw, 10-32NF x 3/8	.25
53	47726	Base shim, all corners	13.00

Floor Scales



DeckHand

Floor Scales

DECKHAND™ PORTABLE SCALE




Stainless Steel

(See Diagram DeckHand)

REF #	PART #	DESCRIPTION	SUGGESTED LIST PRICE
1	15494	Cable, 4-conductor, 3.5'	\$1.35
2	41206	Mount, indicator (for 310A, IQ plus 390-DC, 510, 710 & 800) ...	35.00
3	15377	Grommet, rubber 1/2 x 1/4	1.00
4	15149	Flat washer, 1/4	1.00
5	41251	Cap screw, 1/4-20NC x 3/4	1.00
6	41181	Upper platter (DH-500, DH-1000)	410.00
6	42655	Upper platter (DH-2000)	585.00
7	41250	Cap screw, 5/16-18 NC x 1	1.00
8	41197	Load cell channels (DH-500)	153.00
8	42665	Load cell channels (DH-1000)	95.00
8	42653	Load cell channels (DH-2000)	338.00
9	44237	Flat washer, 5/16	1.00
10	35170	Locknut, 5/16-18NC, hex	.50
11	41198	Shim, load cell	14.00
12	41024	Load cell, RL1260-250 kg (500 lb)	310.00
12	41026	Load cell, RL1260-500 kg (1000 lb)	310.00
12	41027	Load cell, RL1260-35 kg (2000 lb)	310.00
13	41178	Base platform (DH-500, DH-1000)	745.00
13	42617	Base platform (DH-2000)	785.00
14	26670	Cap screws, 5/16-18NC x 1	1.00
15	21933	Overload stop set screw, 5/16 x 18NC x 1/2	2.00
16	41199	Base shim, ramp end	10.00
17	41267	Scale base bumper, 3/4	4.00
18	41251	Cap screw, 1/4-20NC x 3/4	1.00
19	15154	Lock washer, 5/16	1.00
22	15658	Cable tie mount	2.00
23	15631	Cable tie, 3"	1.00
25	41249	Locknut, 5/8-11NC	1.00
26	41268	Wheel, 10" diameter x 5/8 bore	35.00
27	41200	Axle, 5/8-11 x 6	38.00
28	14680	Jam nut, 5/8-11NC	1.00
29	41266	Handle grip, 3/4 I.D.	6.00
30	41182	Mast, 57-13/16 x 15	615.00
31	15148	Lock washer, 1/4	1.00
32	14642	Hex nut, 1/4-20NC	1.00
35	23127	Junction box, 4-channel	220.00
36	15161	Flat washer, 3/8	1.00
37	15160	Lock washer, 3/8	4.00
38	14655	Hex nut, 3/8-16NC	1.00
39	41108	Dampener strip, ramp stop	12.00
40	41253	Cap screw, 10-32NF x 3/4	1.00
41	41257	Cap screw, 3/8-16NC x 6	1.00
42	44129	Bubble level plate	19.00
43	15410	Bubble level	5.00
44	44128	Compression spring, 0.041	4.00
45	44126	Cap screw, 10-32NF x 1	1.00
46	44149	Bumper cushion, self-adhesive	25.00
50	15176	Nylon washer, 5/8	3.00
51	46260	Column back plate	150.00
52	46337	Cap screw, 10-32NF x 3/8	1.00
53	47727	Base shim, all corners	14.00

Floor Scales



DeckHand

CONFIDENTIAL DISTRIBUTOR REPLACEMENT PARTS & PRICE SCHEDULE

Floor Scales

ROUGHDECK™ FXB

(See Diagram RoughDeck FXB-A)




REF #	PART #	DESCRIPTION	CAPACITY	SUGGESTED LIST PRICE
1-3	33087	Flexure plate*, 3" x 4 3/4" x 1/32"		\$14.00
1-3	33303	Flexure plate*, 3" x 3 1/4" x 1/32"		12.50
1-3	33304	Flexure plate*, 3" x 3 1/4" x 1/64"		12.50
1-3	33302	Flexure plate*, 3" x 3 3/4" x 1/32"		12.50
1-3	33306	Flexure plate*, 2 1/2" x 3" x 1/64"		12.50
1-3	33305	Flexure plate*, 2 1/2" x 3" x 1/32"		12.50
1-3	33307	Flexure plate*, 4" x 7" x 1/16"		22.50
1-3	33086	Flexure plate*, 4" x 6" x 1/16"		48.00
4	17769	Load cell pull cable 500 lb through 1,500 lb (FXB-1824, FXB-1830, FXB-2424, FXB-3030)		30.00
4	33084	Load cell pull cable, 2,000 lb-20,000 lb (FXB-3030, FXB-3636, FXB-3846, FXB-4848, FXB-4860, FXB-4872, FXB-6060, FXB-6072, FXB-6084, FXB-7296, FXB-84108) NF x 3 5/8" long SST jam nuts included		36.00
	N/A	Load cell pull cable, 30,000 lb (FXB-96120)		Consult factory

Load Cells

5	21432	RL20000-150 (FXB-1824, FXB-2424, FXB-3030)	500 lb	275.00
5	21434	RL20000-250 (FXB-1824, FXB-1830, FXB-2424, FXB-3030)	1000 lb	275.00
5	21435	RL20000-300 (FXB-3030)	1500 lb	275.00
5	21436	RL20000-500 (FXB-3636, FXB-3846)	1000 lb	275.00
5	21436	RL20000-500 (FXB-3030, FXB-3636, FXB-4848)	2000 lb	275.00
5	21436	RL20000-500 (FXB-4848, FXB-4860, FXB-4872, FXB-6060)	5000 lb	275.00
5	21437	RL20000-750 (FXB-3636)	5000 lb	275.00
5	21438	RL20000-1000 (FXB-4848, FXB-4860, FXB-4872, FXB-6060, FXB-6072)	10,000 lb	275.00
5	21440	RL20000-2000 (FXB-6084, FXB-7296)	10,000 lb	275.00
5	21440	RL20000-2000 (FXB-4872)	20,000 lb	275.00
5	21441	RL20000-2500 (FXB-6060, FXB-7296, FXB-84108)	20,000 lb	275.00
5	21442	RL20000-3000 (FXB-4848, FXB-6084)	20,000 lb	315.00
5	21443	RL20000-5000 (FXB96120)	30,000 lb	440.00
6	33425	Spacer*, 3/4"		8.00
6	33426	Spacer*, 1"		8.00
	45377	Shim set, 3", 4 per set		30.00
	45378	Shim set, 4", 4 per set		31.00

* To determine the correct Flexure Plate(s) and Spacer needed, see next page



RoughDeck FXB-A

Prices F.O.B. Rice Lake, Wisconsin • January 1, 2001

© Rice Lake Weighing Systems 2001 • Prices & specifications subject to change without notice


Floor Scales

ROUGHDECK™ FXB (Cont.)

(See Diagram RoughDeck FXB-A)

To determine which Spacer and Flexure Plate(s) you need, find your scale configuration below:

BASE SIZE	CAPACITY (LB)	REF #1 LOAD FLEXURE	REF #2 FULCRUM FLEXURE	REF #3 CENTER FLEXURE	REF #6 SPACER
18" x 24"	500-1000	33304	33304	33306	N/A
18" x 30"	500-1500	33304	33304	33306	N/A
24" x 24"	500-1000	33304	33304	33306	N/A
30" x 30"	500-1500	33304	33304	33306	N/A
30" x 30"	2000	33087	33303	33305	33425
36" x 36"	1000-5000	33087	33303	33305	33425
38" x 46"	1000-10,000	33087	33303	33305	33425
48" x 48"	1000-5000	33087	33303	33305	33425
48" x 48"	7000	N/A	N/A	33305	33425
48" x 48"	10,000	33087	33302	N/A	33425
48" x 48"	20,000	33307	33086	33087	33426
48" x 60"	2000-5000	33087	33303	33305	33425
48" x 60"	10,000	33087	33302	33305	33425
48" x 60"	20,000	33307	33086	33087	33425
48" x 72"	2000-5000	33087	33302	33305	33425
48" x 60"	10,000	33087	33302	33305	33426
48" x 72"	20,000	33307	33086	33307	33425
60" x 60"	2000-5000	33087	33303	33087	33425
60" x 60"	10,000	33087	33302	33305	33425
60" x 60"	20,000	33307	33086	33087	33425
60" x 72"	5000-10,000	33307	33086	33305	33425
60" x 72"	20,000	33307	33086	33087	33425
60" x 84"	5000	33307	33086	33305	33425
60" x 84"	10,000-20,000	33307	33086	33087	33425
72" x 96"	5000-20,000	33307	33086	33087	33425
84" x 108"	5000	33307	33086	33087	33425
84" x 108"	10,000-20,000	N/A	33086	33087	33425
96" x 120"	10,000	33307	33086	33087	33425
96" x 120"	20,000-30,000	33307	33086	N/A	33425








RoughDeck FXB-A

CONFIDENTIAL DISTRIBUTOR REPLACEMENT PARTS & PRICE SCHEDULE

Floor Scales

THURMAN ELECTRONIC FLOOR SCALE INDIVIDUAL REPLACEMENT PARTS



PART #	DESCRIPTION	EQUIVALENT THURMAN #	SUGGESTED LIST PRICE
TH952SS ...	Bearing socket, .783" dia x 1/2"	10000170A	18.00
TH954SS ...	Bearing socket, 1.27" dia x 3/4"	10001630A	24.00
TH957SS ...	Bearing socket, 1.752" dia x 13/16"	10002410A	38.00
TH953SS ...	Load pin, 2 7/8" x 2" x 1" - 12 UNF	10001520A	60.00
TH958SS ...	Load pin, 4" x 2 1/2" x 1 1/2" - 12 UNF ...	10004350A	75.00
TH949SS ...	Load pin, 5 3/8" x 3" x 2" - 12 UNF	10004820A	85.00
TH960SS ...	Load receiver nut, 2" dia x 1" x 1"-12 UNF	10003020A	33.00
TH961SS ...	Load receiver nut, 2 1/2" dia x 1 1/2" x 1 1/2" - 12 UNF	10004340A	37.00
TH959SS ...	Load receiver nut, 3" dia x 2" x 2" - 12 UNF	10004810A	44.00
33654	Load cup, A: 3/4", B: 1 1/8", C: 1/2", D: 1/2" - 20	10000140A	22.00
33653	Load cup, A: 1 1/8", B: 1 1/2", C: 3/4", D: 3/4" - 16	10001640A	24.00
33652	Load cup, A: 1 3/4", B: 2", C: 13/16", D: 1" - 12	10028830A	68.00
33651	Load cup, A: 1 3/4", B: 2 13/16", C: 13/16", D: 1" - 12	10002400A	95.00
33650	Load cup, A: 1 3/4", B: 2 13/16", C: 13/16", D: 1" - 14	10002400A	95.00
33647	Load cup, A: 1 3/4", B: 2 3/4", C: 1/2", D: 1/2" - 20	N/A	26.00
18815	Hardened ball, 5/8" dia	10000190A	3.00
18816	Hardened ball, 7/8" dia	10001450A	5.00
10993	Hardened ball, 3/4" dia	N/A	4.00
10772	Hardened ball, 1" dia	N/A	6.00