

Symbol Scanner Setup Steps for Overdrive Type 42:

(Scan in order: top -> bottom, left -> right)



Set All Defaults

Delay between serial characters.



Intercharacter Delay



0



2

Setup Serial Format:



<DATA> <SUFFIX 1> <SUFFIX 2>

(03h)

Setup the data terminating characters.



Scan Suffix 1

(06h)

Suffix One is a carriage return.



1



0



1



3



Scan Suffix 2

(08h)

Suffix Two is a Line Feed.



1



0



1



0