

9. PARTS CATALOG

9.1 FACTORY RAM IDENTIFICATION

MOUNTING	FACTORY NUMBER	DESCRIPTION
DESK	3205 0001	STRAIGHT WEIGH
DESK	3205 0002	PARTS COUNTER
WALL	3205 0011	STRAIGHT WEIGH
WALL	3205 0012	PARTS COUNTER

9.2 MOUNTING HARDWARE DESK MOUNT

REF. NO.	PART NO.	DESCRIPTION	QTY.
1	A113973 00A	Label, FCC	1
2	108397 00A	Rubber Feet	4
3	111105 00A	Warning Tag	1
4	116154 00A	Decal, ON/OFF	1
5	116145 00A	Bar - Long	1
6	R02473 00A	Screw	2
7	A114700 00A	Mounting Angle	2
8	R01281 210	Screw	4
9	116146 00A	Bar - Short	1
10	033204 050	Spacer	2
11	R03030 00A	Screw	2

9.3 REAR PANEL DESK MOUNT

REF. NO.	PART NO.	DESCRIPTION	QTY.
1	114722 00A	Plate, Cover	1
2	R02502 00A	Screw	2
3	A116156 00A	Harness, AC to Indicator	1
4	R02473 00A	Screw	1
5	R01611 050	Nut	1
6	R00589 130	Lockwasher	1
7	098271 00A	Tie Wrap	1
8	116152 00A	Harness, Load Cell	1
9	114690 00A	Cover	1
10	117113 00A	Decal, Chassis Ground	1

9.4 PRINTED CIRCUIT BOARDS DESK MOUNT

REF. NO.	PART NO.	DESCRIPTION	QTY.
1	G111778 00A	PCB, Main	1
2	R02559 00A	Screw	4
3	114690 00A	Cover	1
4	114714 00A	Bezel and Keyboard Assy. - Straight Weigh	1
5	114715 050	Bezel and Keyboard Assy. - Parts Counter	1
6	113232 00A	Washer	2
7	R01817 050	Screw	8
8	000786 050	Washer	6
9	A117338 00A	Prom PCB - Parts Counter	1
10	117108 00A	Prom PCB - Straight Weigh	1

9.5 POWER SUPPLY ASSEMBLY DESK MOUNT

REF. NO.	PART NO.	DESCRIPTION	QTY.
1	116138 00A	Bracket	2
2	116153 00A	Ground Wire (N.S.)	1
3	R02559 00A	Screw	4
4	111443 00A	Switch	1
5	R02244 00A	Screw	4
6	115157 00A	PCB Standoff	4
7	R01611 050	Nut	2
8	R00589 130	Lockwasher	2
9	P00465 020	Clamp, Cable	1
10	094354 00A	Capacitor 9200 uF	1
11	A115136 00A	Transformer and Harness	1
12	116973 00A	Chassis and Power Supply	1
13	A116156 00A	Cable Assembly - Indicator, AC	1
14	R02502 00A	Screw	4
15	116149 00A	Harness, Printer	1
16	116150 00A	Harness, AC	1
17	116151 00A	Harness, Battery	1
18	116152 00A	Harness, Load Cell	1
N.S.	115146 00A	Plate, Locking	1
N.S.	R02065 210	Screw	2
N.S.	095920 00A	.25 Slo Blo Fuse	1
N.S.	095920 00A	Fuseholder	1

N.S. = Not Shown

9.6 WALL MOUNT ENCLOSURE

REF. NO.	PART NO.	DESCRIPTION	QTY.
1	117322 00A	Bezel and Keyboard Assy. - Straight Weigh	1
2	117323 00A	Bezel and keyboard Assy. - Parts Counter	1
3	R01817 050	Screw	8
4	000786 050	Washer	4
5	113232 00A	Retainer Washer	2
6	116154 00A	Decal, ON/OFF	1
7	105581 00A	Boot, Switch	1
8	100909 00A	Toggle Switch	1
9	117318 00A	Lens Cap (N.S.)	2
10	117317 00A	Power Cord Assembly (N.S.)	1
11	117113 00A	Decal, Ground (N.S.)	1
12	A113973 00A	Label, FCC "Not Tested" (N.S.)	1
13	117321 00A	Decorative Bezel	1
14	117305 00A	NEMA 4 Wall Mount Enclosure	1

9.7 BOTTOM PLATE ASSEMBLY WALL MOUNT

REF. NO.	PART NO.	DESCRIPTION	QTY.
1	117309 00A	PCB Shield	1
2	001265 050	Screw, Danish Sealing	4
3	111770 00A	Decal, Caution Static	1
4	104699 00A	Gasket	1
5	117327 00A	Cap	1
6	A108616 00A	Gasket	1
7	112143 00A	Cap	1
8	118792 00A	hazard Decal (N.S.)	1
9	109583 00A	Gasket	1
10	117328 00A	Cap	1
11	104554 00A	Gasket, Bottom Plt.	1
12	R02364 00A	Screw	6
13	R03089 00A	Nyl. Roll Collar	8
14	R00434 050	Nut	2
15	R02357 00A	Screw	2
16	R02333 00A	Lock Washer	1
17	R02956 00A	Acorn Nut	1

N.S. = Not Shown

9.8 PRINTED CIRCUIT BOARDS WALL MOUNT

REF. NO.	PART NO.	DESCRIPTION	QTY.
1	079231 050	Standoff	4
2	112855 00A	Wire Clamp (N.S.)	4
3	117330 00A	Keyboard Harness	1
4	G111778 00A	Main PCB	1
5	A117338 00A	Paddle PCB - Parts Counter	1
6	117108 00A	Paddle PCB- Straight Weight	1

N.S. Not Shown

9.9 POWER SUPPLY ASSEMBLY WALL MOUNT

REF. NO.	PART NO.	DESCRIPTION	QTY.
1	117313 00A	Line Filter	1
2	117301 00A	Transformer and Harness	1
3	100909 00A	Toggle Switch	1
4	105581 00A	Boot	1
5	117312 00A	AC Power harness	1
6	117311 00A	Printer harness	1
7	117310 00A	Load Cell Harness	1
8	117316 00A	Internal Battery Harness	1
9	116533 00A	Circuit Breaker	1
10	094354 00A	Capacitor, 9200 uF @ 15V	1
N.S.	095920 00A	.25A Slo Blo Fuse	1

3205 PRINTER CABLES

PRINTER	INDICATOR	LENGTH	PART NUMBER
301/307	DESK	6'	117137 00A
01/307	DESK	20'	117138 00A
/307	WALL	6'	117145 00A
/307	WALL	20'	117146 00A
8805	DESK	6'	117139 00A
8805	DESK	20'	117140 00A
8805	WALL	6'	117147 00A
8805	WALL	20'	117148 00A
8820/30	DESK	6'	117143 00A
8820/30	DESK	20'	117144 00A
8820//30	WALL	6'	117151 00A
8820/30	WALL	20'	117152 00A

8855	DESK	6'	117141 00A
8855	DESK	20'	117142 00A
8855	WALL	6'	117149 00A
8855	WALL	20	117150 00A

KOP'S FOR THE 3205

DESCRIPTION	PART NUMBER
Software Enhancement - KOP	117565 00A
Remote Wall Mount w/o Battery - KOP	116204 00A
Remote Wall Mount w/Battery - KOP	116205 00A
Conversion KOP Straight Weigh to Parts Counter	117129 00A
Conversion KOP Parts Counter to Straight Weigh	117130 00A
Installation KOP 3205 to 1985	117132 00A
Battery Power KOP - Rams 1 and 2	117170 00A
Battery Power KOP - Rams 11 and 12	118293 00A

OPTIONS

DESCRIPTION	PART NUMBER
Remote Battery Charger	116980 00A
Battery Pack	116176 00A
Keyboard Extender Harness	117330 00A