



9.3 TOP COVER




REF	PART NUMBER	DESCRIPTION	QTY
1	R02231 00A	Screw, #8 x 1/2	4
2	B099458 00A	Cover & Bezel Ass'y.	1
3		See Keyboard Section	1

9.4 KEYBOARD MOUNTING HARDWARE



REF	PART NUMBER	DESCRIPTION	QTY
1	R02113 020	Screw, (#6-32 x 1/4)	2
2	R01771 050	Washer, Lock (#6)	6
3	015192 020	Washer, Fibre	4
4	R00813 050	Nut, Hex (#6-32)	2
5	040841 020	Washer, Plain	2
6	099459 00A	Plate	2
7	099455 00A	Stud, Hex	2

9.5 PCB's



REF	PART NUMBER	DESCRIPTION	QTY
-----	----------------	-------------	-----

1	099465 00A	Bracket, Hold Down	2
2	000786 050	Washer, Plain in # 8 Screw	2
3	R00589 210	Washer, Lock (#8)	8
4	R01268 050	Screw , Self Tapping #8	2
5	G099324 00A	PCB Ass'y, Preamp 80	1
6	G099326 00A	PCB Ass'y,. A/D 80	1
7	A099328 00A	PCB Ass'y,. Logic 80 Rom*	1
8	H099332 00A	PCB Ass'y,. I/O 80	1
9	D099334 00A	PCB Ass'y ., Display	1
10	B099353 00A	Insulator, Display PCB	1
11	099343 00A	Harness, Keyboard Input	1
12	A103083 00A	Harness, Ground	1
13	126430 00A	Harness Display ** (New Harness)	1
14	099342 00A	Harness, Keyboard Output	1
15	R01532 210	Speednut, #8	1
16	099443 00A	Mounting Standoff, PCB	1
17	015192 020	Washer, Fibre	1
18	R01611 050	Nut, hex. (8-32)	1
19	A099442 00A	Bracket, PCB Display	1
20	99585 00A	2 digit LED	1
21	A099442 00A	3 digit LED	1

* As this PCB becomes unavailable, it will be replaced by Part Number 102089 00A, Prom Logic 80.

** For 10,000 X 1, 20,000 X 2 AND 50,000 X 5 lb. builds order 102082 00A Display Harness.