


VIII. PARTS CATALOG

9.1 VARIABLE SAMPLE KEYBOARD

(Part number A099350 00A)




REF	PART NUMBER	DESCRIPTION	QTY	REF	PART NUMBER	DESCRIPTION	QTY
1	099157 00A	Keytop "7"*	1	12	099435 00A	Pushbutton "Zero OK"	1
2	099158 00A	Keytop "8"*	1	13	099440 00A	Keytop "Avge Wght"*	1
3	099159 00A	Keytop "9"*	1	14	099163 00A	Keytop "Print"*	1
4	099156 00A	Keytop "6"*	1	15	099153 00A	Keytop "3"*	1
5	099438 00A	Keytop "Tare"*	1	16	099441 00A	Keytop "Clear"*	1
6	099439 00A	Keytop "Count"*	1	17	099152 00A	Keytop "2"*	1
7	095096 00A	Lamp	5	18	099150 00A	Keytop "0"*	1
8	099434 00A	Pushbutton "Wght Cnt"	1	19	099151 00A	Keytop "1"*	1
9	099433 00A	Pushbutton "Smpl Wght"	1	20	099154 00A	Keytop "4"*	1
10	099437 00A	Pushbutton "RCV"	1	21	099155 00A	Keytop "5"*	1
11	099436 00A	Pushbutton "Ship"	1		A094782 00A	Switch 8,9,10,11,12	
					B102788 00A	Keytronics Keyboard PCB Assy	

For "CRC" keyboards use number shown.
For "Keytronix" keyboards add "A" prefix to number.
Example: Item 21 - 099155 00A - "CRC" keyboard A099155 00A- "Keytronix" keyboard.

9.2 FIXED SAMPLE KEYBOARD

(Part Number A099349 00A)



REF	PART NUMBER	DESCRIPTION	QTY	REF	PART NUMBER	DESCRIPTION	QTY
1	0991577 00A	Keytop "7"*	1	13	099431 00A	Pushbutton "10"	1
2	099158 00A	Keytop "8"*	1	14	099430 00A	Pushbutton "5"	1
3	099159 00A	Keytop "9"*	1	15	099429 00A	Pushbutton "2"	1
4	099156 00A	Keytop "6"*	1	16	099428 00A	Pushbutton "1"	1
5	099438 00A	Keytop "Tare"	1	17	099163 00A	Keytop "Print"	1
6	095096 00A	Lamp	10	18/	099153 00A	Keytop "3"*	1
7	099434 00A	Pushbutton "Wght Cnt"	1	19	099441 00A	Keytop "Clear"*	1
8	099433 00A	Pushbutton "Smpl Wght"	1	20	099152 00A	Keytop "2"*	1
9	099437 00A	Pushbutton "RCV"	1	21	099150 00A	Keytop "0"*	1
10	099436 00A	Pushbutton "Ship"	1	22	099151 00A	Keytop "1"*	1
11	099435 00A	Pushbutton "Zero OK"	1	23	099154 00A	Keytop "4"*	1
12	099432 00A	Pushbutton "20"	1	24	099155 00A	Keytop "5"*	1
					094782 00A	Switch 10	

For "CRC": keyboards, use Part Number as shown. For "Keytronix" keyboards, add "A" prefix to number.

A099155 00A - "CRC" keyboard.

A099155 00A "Keytronix" keyboard.