



9.23 BEZEL ASSEMBLY



REF. NO.	PART NO.	DESCRIPTION	QTY.
1	113236 00A	Bezel-KeyBoard Assembly	1
2	033272 00A	1/2" Conduit Locknut	1
3	104699 00A	Gasket, "O" Ring	1
4	113180 00A	Cord Connector	1


9.24 PLATE & HARNESS



REF. NO.	PART NO.	DESCRIPTION	QTY.
1	A108616 00A	Printer Gasket	2
2	A113199 00A	Printer Harness	1
3	R00813 050	Nut, 6032	8
4	R01771 050	Lockwasher, 36	8
5	R02055 130	Screw, 6-32 x 1/2	8
6	114618 00A	Audio Alarm	1
7	114620 00A	Audio Alarm Gasket	1
8	R00844 130	Screw, 8-32 x 3/8	16
9	113194 00A	Connector Plate-Blank	2
10	113204 00A	Adaptor Plate Gasket	1
11	109853 00A	Connector Gasket	1
12	R02793 00A	Screwe, 1/4-20 x 1/2	2
13	R00434 050	Nut, 1/4-20	2
14	113973 00A	Label FCC, Not Tested (Ram	1
15	R00773 050	0001)	6
16	104554 00A	Screw, 1/4-20 Cap	1
17	113192 00A	Bottom Plate Gasket	1
18	A113198 00A	Plate-Wall Connector	1
		Auxiliary Harness	
19	R00859 210	Does not agree with 8182 P.C.	4
20	R01611 050	Lockwahser, #8	4


21	112143 00A	Nut, 8-32	2
22	113200 00A	Sealing Cap	1
		Scale-In Harness	

9.25 DISPLAY PCB




REF. NO.	PART NO.	DESCRIPTION	QTY.
1	113193 00A	Display Bracket	1
2	113247 00A	Assembly	1
3	R01611 050	Keyboard Logic Harness	4
4	108010 00A	Nut, 8-32	1
5	114621 00A	Display Power Harness	1
6	108032 00A	Beeper Harness	1
7	D114150 00A	Display PCB Insulator	1
8	E107980 00A	Display PCB - Dot	1
9	R00844 130	Matrix	4
10	111770 00A	Display PCB - 16	1
11	095915 00A	Segment	1
12	103889 00A	Screw, 8-32 x 3/8	1
		Static Caution Decal	
		Tie Wrap	
		Tie Wrap Mount	

9.26 ENCLOSURE




REF. NO.	PART NO.	DESCRIPTION	QTY.
1	B113182 00A	Enclosure, Nema 12	1
2	A108063 00A	Label, Program Switch	1
3	R101254 00A	Lockwasher, 3/8 ID	13
4	R02990 00A	Washer, 6-32	13
5	R01817 050	Screw, 6-32 x 1/4	13

9.27 PCB'S




REF	PART NO.		DESCRIPTION	QTY.
1	R00434	050	Nut, 1/4 -20	4
2	029919	050	Washer	4
3	R01611	050	Nut, 8-32	2
4	111161	00A	Term. Block Cover	1
5	H107974	00A	Logic PCB	1
6	f107974	00A	A/D PCB	1
7	1132200	00A	Scale-In Harness	1
8	113202	00A	Main Panel	1
9	113211	00A	Assembly	1
10	095100	00A	Component Clip	1
			Fuse, .6A 250V	

9.28 LINE CORD & FILTER




REF. NO.	PART NO.	DESCRIPTION	QTY.
1	111188 00A	Right Angle Power Cord	1
2	108090 00A	Fuse Decal	1
3	112127 00A	Linefilter Assembly	1
4	105408 00A	Fuse, 1.25A Slo Blo	1
5	R00589 210	Lockwasher, #8	2
6	R01145 130	Screw, 8-32 x 3/4"	2
7	R01611 050	Hex Nut, 8-32	4
8	097821 00A	3 Position Terminal	1
9	113187 00A	strip	1
10	R00849 130	Linefilter Bracket	4
11	113191 00A	Screw, 8-32 x 1/2"	1
12	P00561 020	Card Cage Support Plate	1
13	109859 00A	Cable Clamp	1
14	R02197 00A	Line Cord Assembly	4
		Speed Nut, 8-32	

9.29 VOLTAGE REGULATOR



REF. NO.	PART NO.	DESCRIPTION	QTY.
1	108009 00A	Battery Harness	1
2	R01611 050	Nut, 8-32	10
3	113177 00A	Mother PCB (Wall)	1
4	113197 00A	Insulator	1
5	113190 00A	PCB Shield	1
6	108750 00A	Spacer	2
7	114615 00A	Regulator	1

9.30 POWER SUPPLY



REF. NO.	PART NO.	DESCRIPTION	QTY.
1	097522 00A	Heatsink	1
2	108029 00A	PCB Insulator	1
3	E107984 00A	Power Supply PCB	1
4	107763 00 A	Capacitor, 11,000 uf @ 15V	1
5	E108008 00A	Power Supply Assembly	1
6	R01611 050	Nut, 8-32	12
7	A098462 00A	Label, Hazardous Area	1
8	110865 00A	Label, 4 Lang. Warning	1
9	108049 00A	Card cage	1
10	112385 00A	Card Guide, Snap In	8
11	093943 00A	Bridge Rectifier	1
12	R00849 130	Screw, 8-32 x 1/2"	3
13	095957 00A	Fuse, 3A Slo Blo	1

EXTERNAL SCALE K.O.P. (NON-VERIFIED)

PART NUMBER -- 108027 00A

PART NO.	DESCRIPTION	QTY.
108005 00A	Loadcell Harness	1
F107974 00A	A/D PCB	1
113204 00A	Gasket	1
113196 00A	Adaptor Plate	1

ACCESSORIES

PART NO.	DESCRIPTION	QTY.
082122 020	Diagnostic K.O.P.	1