


### User Acces to Viper PL/SL

**User Setup Mode**

After a timeout of about 3 minutes with no keystroke the setup will be left automatically



## KEY FUNCTIONS IN THE SETUP MODE


TARE cycles through the choices for the displayed program block.

**PRINT** accepts the displayed choice and continues to the next step.

\* To enter the program mode hold PRINT down for 3 seconds.

**CLEAR** takes you to the end of setup at any point in the program.

ZERO backs up one program block.



## Error Code List