


Báscula Portátil de Mesa *WILDCAT*® Instrucciones de Operación

Consignes D'utilisation de la Bascule *WILDCAT*®



ENCENDIDO/APAGADO


ON/OFF



Pulse y mantenga por 3 segundos — Appuyez sur on/off et maintenez pendant trois secondes —


CERO

ZÉRO




NETO

NET




BRUTO

BRUT



PANTALLA ILUMINADA


AFFICHAGE RÉTROÉCLAIRÉ



Si usted tiene una pantalla iluminada — Si vous avez un affichage rétroéclairé —

IMPRIMIR

IMPRESSION




METTLER TOLEDO



B15610100A

WILDCAT® Scale OPERATING INSTRUCTIONS




ON/OFF


Press and hold for 3 seconds




ZERO



NET




GROSS




BACKLIT DISPLAY

If you have a backlit display —



PRINT



METTLER TOLEDO



B15610100A