


STEEL YARD, BEAM ASSEMBLY



REF.	PART NUMBER	DESCRIPTION	QTY.
1	080284 00A	Hook, Nose Iron	1
2	080286 00A	Rod, Steelyard	1
3	R01406 050	Screw, 10-32 x 1/2	2
4	R01645 00A	Screw	2
5	A049977 00A	Beam Assy. LB-LB	*
6	A049978 00A	Beam Assy. KG-KG	*
7	A049980 00A	Beam Assy. LIBRA-LIBRA	*
8	A049981 00A	Beam Assy. LB-KG	*
9	A081475 00A	Beam Assy. LB-LIBRA	*
10	A049995 00A	Beam Assy. LIBRA-KG	*
11	A049983 00A	Beam Assy. KG-LB	*
12	A081476 00A	Beam Assy. LIBRA-LB	*
13	A081477 00A	Beam Assy. KG-LIBRA	*
14	007369 00A	Bearing	4
15	017874 050	Pin	4
16	003582 020	Pin, Cotter	8
17	049813 00A	Cap, Column	1

* Complete Beam Assembly. Description is front of beam and back of beam.