



BASE CASTING




REF. NO.	PART NUMBER	DESCRIPTION	QTY
1	111825 00A	Base Casting	1
2	R00591 050	Hex Nut, 1/4 - 28 JAM	1
3	105208 00A	Overload Screw, Long	1
4	R01388 210	Screw, 10-32 x 3/8" Hex Soc. Hd.	2
5	112731 00A	Hole Plug, 1 1/8" Black	2
6	R02798 00A	Screw, 10-32 x 3/4" Ph. Rd. Hd.	1
7	000956 130	Hex Nut, 10-32	1
8	104424 00A	Level Assembly	1
9	R01193 020	Screw, One-Way 10-32 x 3/8"	2
10	109454 00A	Cap, Level Foot, Black	4
11	039305 00D	Level Foot, Slotted	4
12	000741 00A	Locknut, Level Screw	4

BASE ASSEMBLY




REF. NO.	PART NUMBER	DESCRIPTION	QTY
1	109589 00A	Screw, 8-32 x 1/2 Hex Soc. Hd.	10
2	112354 00A	Clamp	10
3	A099473 00A	Flexure (.031)	5
4	A099477	Strut Assembly	1
5	112205 00A	Washer, Seal, Load Cell	1
6	R00569 050	Screw, 8-32 x 1 1/2" Rd. Hd.	2
7	R00589 210	Lockwasher, #8	2
8	R01611 050	Hex Nut, 8-32	2
9	073942 00A	Hex Head, Adjuster Nut	2
10	112229 00A	Load Cell Assembly, 50 # GP I	1
11	A099552 00A	Support Assembly	1
12	103755 00A	Adjuster Assembly	2
13	R01428 050	Screw, 1/4-28 x 1/2" Hex Soc. Hd.	2

POWER SUPPLY




REF. NO.	PART NUMBER	DESCRIPTION	QTY
1	111818 00A	Power Supply Assembly	1
2	111823 00A	Base Assembly, 50#	1
3	A105470 00A	Harness, Load Cell	1
4	R02180 050	Screw, 8-32 x 3/8" Ph. Rd. Hd. Taptite	5
5	R01677 050	Screw, 4-40 x 7/8" Ph. Rd. Hd.	2
6	R01678 050	Hex Nut, 4-40	2
7	R01679 050	Lockwasher, #4	2
8	P00604 020	Fuse Holder	1
9	095920 00A	Fuse, 1/4 SLO-BLO	1
10	113944 00A	Switch, ON-OFF	1
N.S.	P00570 020	Fuse, 3 Amp SLO-BLO (in line)	1

TOP COVER




REF. NO.	PART NUMBER	DESCRIPTION	QTY
1	B111783 00A	Cover, Scale	1
2	R02557 00A	Screw, 8-16 x 7/16" Hex Hd. Plastite	6
3	A112353 00A	Clip, Retainer	2
4	111819 00A	Harness, Display	1
5	103889 00A	Base, Band Clamp	1
6	095915 00A	Band Clamp	1

MAIN PCB




REF. NO.	PART NUMBER	DESCRIPTION	QTY
1	R03005 00A	Screw, 8-32 x 5/16" Ph. Rd. Hd. Taptite	4
2	R02559 00A	Screw, 8-32 x 5/16" Ph. Rd. Hd. Taptite	4
3	E113699 00A	PCB Assembly, Main Board	1
3	G111806 00A	PCB Assembly, Main Board	1
3	115220 00A	PCB Assembly, Main Board	1
*	117089 00A	Hole Cover, Panel Assembly	1

LINE CORD




REF. NO.	PART NUMBER	DESCRIPTION	QTY
1	103867 00A	Line Cord, Black	1
2	108250 00A	Line Cord Relief Plate	1
3	R02180 050	Screw, 8-32 x 3/8" Ph. Td. Hd. Taptite	2
4	111105 00A	Decal , Warning (4 Lang.)	1
5	R02385 00A	Set Screw, 10-32 x 3/4"	1
6	R02812 00A	Hex Nut, 10-32	1
7	R02459 00A	Rivet, Nylon	2

FRONT BEZEL




REF. NO.	PART NUMBER	DESCRIPTION	QTY
1	R02596 00A	Screw, 8-32 x 3/8" Ph. Head Drilled	1
2	109453 00A	Clip, Scale Seal	1
3	111770 00A	Decal, Static Awareness	1
4	R02560 00A	Screw, 8-32 x 1" Ph. Fh. Self-Tap	2
5	111787 00A	Bezel Front	1
6	111788 00A	Lens	1
7	1113768 00A	Keyboard, with Fractional Pricing	1
8	113772 00A	Keyboard, without Fractional Pricing	1
9	R00813 050	Nut, 6-32	4
10	R01771 050	Lockwasher, I.T. #6	4
11	113942 00A	Display Mask (Front)	1
12	113969 00A	Terminal, .25 Male	1

PLATTER SUPPORT PLATE



REF. NO.	PART NUMBER	DESCRIPTION	QTY
1	R03029 00A	Screw, 10-32 x 1 1/2" Hex. Soc. Fh	2
2	11815 00A	Sub Platter Assembly	1
3	R03030 00A	Screw, 8-32 x 1/2" Self Tapping	4
4	111816 00A	Bumper, Rubber	4

CUSTOMER DISPLAY & PLATTER



REF. NO.	PART NUMBER	DESCRIPTION	QTY
1	111781 00A	Platter	1
2	111788 00A	Lens	1
3	A111808 00A	PCB, Customer Display (N.S.)	1
4	111782 00A	Bezel, Rear Display	1
5	R02606 00A	Screw, #8 x 3/8"	4
6	108238 00A	Decal, ON/OFF	1
7	113943 00A	Display Mask (Rear)	1
		ACCESSORIES	
	113772 00A	Keyboard - w/O Fractional Pricing	1
	113940 00A	10" Scale Base Counter K.O.P.	1