

Indicators



WinBridge®

Unattended Driver Station



**The Quick and Easy Solution  
for Unattended Weighing Applications**

**METTLER TOLEDO**


# Processes Vehicle Scale Transactions without an Operator



The unattended driver station can be customized to meet your specific needs. Operation can be fully automatic or controlled by the driver. You determine how much information the driver must enter. An optional printer is available for supplying the driver with a ticket. All transaction information is automatically recorded in your WinBridge database.

- No Operator or Scale House Required
- Round-the-Clock Operation
- Identifies Vehicles by ID Card or Code
- Restricts Access to Authorized Persons
- Durable Stainless Steel Design for a Long Service Life
- Can be used in Harsh Climates
- Easily Integrated with Traffic Lights and Loops

**Options:** Printer, Proximity Card Reader, Magnetic Code Reader, Bar Code Reader, Loudspeaker, Traffic Lights, Wall-Mounting Bracket, Mounting Column, Swivel Arm



Power requirements: 230 VAC or 115 VAC, 50/60 Hz  
Power consumption: 85 watts (without heater)  
Heater power consumption: 60 watts  
Data transmission: 20 mA current loop  
Operating temperature: -30°C to +35°C (with built-in heater)  
Weight display: LCD with six digits, 25.4 mm high (optional)  
Information display: Alphanumeric LCD (2 lines each 20 characters)  
Printer: Printer paper width 84 mm  
Protection category: IP53 without printer, IP33 with printer  
Weight: 88 pounds (40 kg)

		TEL	FAX			TEL	FAX					
<b>METTLER TOLEDO</b>	Australia	(61-3) 9644 5700	(61-3) 9645 3935	Korea	(82-2) 518-2004	(82-2) 518-0813	<b>Internet</b> www.ml.com	Specifications subject to change without notice. © 2000 Mettler-Toledo, Inc. METTLER TOLEDO® and WinBridge® are trademarks of Mettler-Toledo, Inc.				
	Austria	(43-1) 604 1980	(43-1) 604 2880	Malaysia	(60-3) 703-2773	(60-3) 703 8773						
	Belgium	(32-2) 334 0211	(32-2) 378 1665	Mexico	(52-5) 547 5700	(52-5) 541 2228						
	Brazil	(55-11) 421 5737	(55-11) 7295-1692	Netherlands	(31-344) 638363	(31-344) 638390						
<b>USA and Canada</b> 1900 Polaris Parkway Columbus, Ohio 43240	China (Industrial)	(86-519) 6642040	(86-519) 6641991	Norway	(47-22) 30 44 90	(47-22) 32 70 02	Printed in USA.	2M0700 TRUCK SCALES 00-TRO339.0E				
	China (Systems)	(86-21) 6485-0435	(86-21) 6485-3351	Poland	(48-22) 651 9232	(48-22) 651-7172						
	Croatia	(385-1) 23 36 317	(385-1) 23 04 147*	Russia	(7-095) 921 9211	(7-095) 921 6353						
	Czech Republic	(420-2) 254962	(420-2) 24247583	Singapore	(65) 778 6779	(65) 778 6639						
TEL. (800) 786-0038 (614) 438-4511	Denmark	(45-43) 27 08 00	(45-43) 27 08 28	Slovak Republic	(421-7) 43 42 74 96	(421-7) 43 33 71 90						
FAX (614) 438-4900	France	(33-1) 30 97 17 17	(33-1) 30 97 16 16	Slovenia	(386-61) 162 1801	(386-61) 162 1789*						
<b>Headquarters</b> 8606 Greifensee Switzerland	Germany	(49-641) 50 70	(49-641) 52951	Spain	(34-93) 223 2222	(34-93) 223 0271						
	Hungary	(36-1) 257 9889	(36-1) 256 2175	Sweden	(46-8) 702 50 00	(46-8) 642 45 62						
	India	(91-22) 857-0808	(91-22) 857-5071	Switzerland	(41-1) 944 45 45	(41-1) 944 45 10						
	Italy	(39-2) 333321	(39-2) 356-2973	Taiwan	(886-2) 2579-5955	(886-2) 2579-5977						
TEL. (41-1) 944 22 11	Japan	(81-6) 6949-5901	(81-6) 6949-5944	Thailand	(66-2) 719 6480	(66-2) 719 6479	*Call for fax					
FAX (41-1) 944 30 60	Kazakhstan	(7-3272) 50 63 69	(7-3272) 60 88 35	United Kingdom	(44-116) 235 7070	(44-116) 236 6399						