


# Quick Installation Guide for the 8808 Heavy Duty Ticket Printer

Detailed information may be found in the 8808 User's Guide


## 1. Unpacking

The following items are packed with the 8808 printer.  
(Power supply not shown)




## 2. Installation

Remove the packing tape from the top and side of the printer cover. Open the cover by pulling on the tab on the left side. Remove the shipping damper from the printhead. Close the cover by pressing down on the top until it latches.



## 3. Attach interface Cable

Connect the interface cable to the 25-pin connector on the underside of the printer. The default settings are: 9600 baud, 7 data bits, even parity, x-on / x-off handshaking. Match these parameters to the source device.




## 4. Connect Power Supply


Make sure the power switch on the printer is turned off. Connect the power supply cable to the round connector on the underside of the printer. The flat side faces down. Plug the power supply's cord into a wall outlet.

## 5. Install the Ribbon Cartridge

Turn on the printer and open its cover by pulling up on the tab on the left side. Turn the knob on the cartridge in the direction of the arrow to take up any slack in the ribbon.





Insert the cartridge as shown below, making sure it snaps in place. The ribbon must be between the printhead and platen. Turn the knob to take up any slack. Close the printer cover.



## 6. Insert Paper

Insert the paper into the printer until it is stopped by the form stopper. **THE PRINTER IS NOW READY FOR USE.**



16348600A