


# PB-200

# Parts List



# Yamato

**YAMATO CORPORATION**  
 1775 S. Murray Blvd.  
 Colorado Springs, CO 80916 USA  
 Tel (719) 591-1500 Fax (719) 591-1045

**YAMATO TECH CORPORATION**  
 #112-19425 Langley By-Pass  
 Surrey, B.C. V3S 6K1 Canada  
 Tel (604) 533-2338 Fax (604) 533-0827

| ITEM | PART NUMBER     | DESCRIPTION                                 | QTY |
|------|-----------------|---------------------------------------------|-----|
| 1    | CHA-1585-200110 | Keypad                                      | 1   |
| 2    | CHA-1585-200100 | Front Mask                                  | 1   |
| 3    |                 | Screw, Tapping, Pan Head, M3 x 10           | 4   |
| 4    |                 | End, Indicator, Left                        | 1   |
| 5    |                 | Housing, Indicator                          | 1   |
| 6    | CHA-1585-200170 | Knobs, Adjustment                           | 2   |
| 7    |                 | Holder, Indicator                           | 1   |
| 8    |                 | Rod, Retaining                              | 2   |
| 9    |                 | Jack, AC Adaptor                            | 1   |
| 10   |                 | End, Indicator, Right                       | 1   |
| 11   |                 | Screw, Tapping, Pan Head, M2 x 5            | 2   |
| 12   |                 | Battery Pack, Rechargeable                  | 1   |
| 13   | CHA-1585-200120 | PCB, Display                                | 1   |
| 14   | CHA-1585-ODS310 | AC Adaptor (Not Shown)                      | 1   |
| 15   | CHA-1585-200150 | Cable, Connecting                           | 1   |
| 16   |                 | Platform, SS                                | 1   |
| 17   |                 | Screw, Hex Head, Flat, Countersunk, M6 x 20 | 4   |
| 18   |                 | Plate, Upper                                | 1   |
| 19   |                 | Standoff, A/D PCB                           | 4   |
| 20   |                 | Housing, A/D                                | 1   |
| 21   |                 | Screw, Pan Head, M4 x 5                     | 2   |
| 22   | CHA-1585-200140 | PCB, A/D                                    | 1   |
| 23   |                 | Jack, Foot Tare Switch                      | 1   |
| 24   |                 | Spacer, Load Cell                           | 2   |
| 25   | CHA-1585-200130 | Load Cell                                   | 1   |
| 26   |                 | Screw, Pan Head, M5 x 17                    | 4   |
| 27   |                 | Hex Nut, M5                                 | 4   |
| 28   |                 | Plate, Lower                                | 1   |
| 29   | CHA-1585-200160 | Foot, Adjustable, with Locknut              | 4   |
| 30   |                 | Screw, Pan Head, M4 x 6                     | 1   |
| 31   | CHA-1585-200180 | Switch, Foot Tare                           | 1   |