METTLER TOLEDO

Technical Bulletin

Number: I-07-06 Date: April 4, 2006

To: MT Sales US, MT Service US, MT Sales Canada, MT Service Canada, Distributor Sales, Distributor Service

Model: ADI310 Scoreboard

Intermittent Blanking of Display in Multi-continuous

When transmitting data to multiple ADI310 Scoreboards using Multi-Continuous data transmission, the weight display on the scoreboard for Scale 2 may blank off and on intermittently. This is caused by the selection of a lower baud rate. To correct this, increase the baud rate to at least 9600 baud.

Please add this information to your ADI310 Technical Manual.